

Ademco/Protection One 250P1-1 Programming Form

Local programming requires the use of a 2-line Alpha keypad connected to the keypad terminals on the control.

Field Function **Programmed Values** = Default Value

SYSTEM SETUP (*20-*30)

- *20 INSTALLER CODE 4112 Enter 4 digits, 0-9 [4112]
- *21 QUICK ARM ENABLE † 0 [0 = Disable]; 1 = Enable
- *22 RF SYSTEM 0 [0 = none]; 1 = 5800 (5881/5882); 4 = 5800 w/ RF Jamming
- *23 FORCED BYPASS † 0 0 = none; [1 = bypass open zones]
"0" for UL installations.
- *24 RF HOUSE ID CODE 00 [00] 00 = disable all wireless keypad usage; Enter 01 - 31 if using 5827 keypad.
- *25 WIRED ZONE EXPANSION † 0 [0 = none]; 1 = 4219; 2 = 4229; 3 = 4204
- *26 CHIME BY ZONE † 0 0 = no; [1 = yes]. Chime for zones in Zone List #3.
- *27 X-10 HOUSE CODE 00 [0 = A]; 1 = B; 2 = C; 3 = D; 4 = E; 5 = F; 6 = G; 7 = H; 8 = I; 9 = J;
#10 = K; #11 = L; #12 = M; #13 = N; #14 = O; #15 = P
- *28 PHONE MODULE ACCESS CODE (4285) 00 1st digit: enter 1-9; 2nd digit: 0; enter #+11 for "***";
or # + 12 for "#". Default = [00].
- *29 OUTPUT TO LONG RANGE RADIO 0 To enable enter Trouble code 1-9, A(#+10), B(#+11), C(#+12), D(#+13),
E (#+14), or F (#+15). The 2nd digit of Trouble Dialer Report is
automatically entered from field *60, [0 to disable]. "0" for UL installations.
- *30 HARDWIRE SHORT DETECTION 0 [0 = Disable]; 1 = Enable

ZONE SOUNDS AND TIMING (*31 - *39)

- *31 SINGLE ALARM SOUNDING/ZONE † 1 0 = no; [1 = yes]. "0" for UL installations.
- *32 FIRE SOUNDER TIMEOUT † 1 [0 = timeout]; 1 = no timeout.
- *33 ALARM BELL TIMEOUT † 2 0 = none; [1 = 4 min]; 2 = 8 min; 3 = 12 min; 4 = 16 min; "1" (4 min.) minimum for UL.
- *34 EXIT DELAY † 02 0=30 sec; 1=45 sec; [2=60 sec]; 3=90 sec; 4=120 sec; 5=180 sec; 6=240 sec;
- *35 ENTRY DELAY #1 (zone type 01) † 00 [0=30 sec]; 1=45 sec; 2=60 sec; 3=90 sec; 4=120 sec; 5=180 sec; 6=240 sec;
- *36 ENTRY DELAY #2 (zone type 02) † 02 0=30 sec; 1=45 sec; [2=60 sec]; 3=90 sec; 4=120 sec; 5=180 sec; 6=240 sec;
- *37 AUDIBLE EXIT WARNING † 1 0 = no; [1 = yes].
- *38 CONFIRMATION OF ARMING DING † 0 [0 = no]; 1 = yes,(wired keypads and RF); 2 = yes, RF only
- *39 POWER UP IN PREVIOUS STATE † 1 0 = no; [1 = yes]. "1". for UL installations.

DIALER PROGRAMMING (*40 - *55)

In fields *40, *41, *42, enter up to the number of digits shown. Do not fill unused spaces. Enter 0-9; #+11 for " * "; #+12 for "#"; #+13 for a pause.

- *40 PABX ACCESS CODE Enter 6 digits. If fewer than 6 digits are entered, exit by
pressing * (and press 41, if entering next field).
To clear entries from field, press *40*.
- *41 PRIMARY PHONE NUMBER Enter up to 20 digits.
Do not fill unused spaces. If fewer than 20 digits entered, exit by pressing *
(and press 42, if entering next field). To clear entries from field, press *41*.
- *42 SECONDARY PHONE NUMBER Enter up to 20 digits.
Do not fill unused spaces. If fewer than 20 digits entered, exit by pressing *
(and press 42, if entering next field). To clear entries from field, press *42*.
- *43 PRIMARY SUBSCRIBER ACCT # 0000 ***44** **SECONDARY SUBSCRIBER ACCT #** FFFFF
PRIMARY RECEIVER ACCT #
Enter 0-9; #+11 for B; #+12 for C; #+13 for D; #+14 for E; [#+15 for F].
Enter * as 4th digit, if 3+1 dialer reporting is to be used. If only 3 digits
used, exit by pressing * (and press next field).
To clear entries from field, press *43*, *44*.
Examples: For Acct No. **1234**, enter:

| | | | |
|------|---|---|---|
| 1 | 2 | 3 | 4 |
| #+11 | 2 | 3 | 4 |
| 1 | 2 | 3 | * |

For Acct No. **B234**, enter:
For Acct No. **123**, enter:

† Entry of a number other than one specified will give unpredictable results.

- *45 PHONE SYSTEM SELECT † 3 If Central Station *IS NOT* on a WATS line: 0 = Pulse Dial; 1 = Tone Dial
If Central Station *IS* on a WATS line: 2 = Pulse Dial; [3 = Tone Dial]
- *46 REPORT FORMAT PRIMARY/SECONDARY Primary 7 Secondary 7
5 = CONTACT ID REPORTING (10 digit) [7 = CONTACT ID REPORTING (4 digit)]
- *47 SPLIT/DUAL REPORTING 0 [0 = Disable (Backup report only)]
TO PRIMARY 1 = Alarms, Restore, Cancel
2 = All except Open/Close, Test
3 = Alarms, Restore, Cancel
4 = All except Open/Close, Test
5 = All
TO SECONDARY Others
Open/Close, Test
All
All
All
- *48 DIALER DELAY (BURG/FIRE) (in sec) † 0 0 [2]0 Select Dialer Delay; 0 = no; 1=15 sec; 2=30 sec; 3=45 sec; 4=60 sec; 5=120 sec.
- *49 PERIODIC TEST REPORT † 3 [0 = none]; 1 = 24 hours; 2 = weekly; 3 = 30 days.
(Enter Test Code in field *64.)
- *50 TEST REPORT OFFSET † 2 0 = 24 hour; 1 = 6 hours; [2 = 12 hours]; 3 = 18 hours.
(Time to 1st report from programming or downloading).
- *51 SESCOA/RADIONICS SELECT 0 [0 = Radionics (0-9, B-F reporting)]; 1 = SESCOA (0-9 only reporting)
Select 0 for all other formats.
- *52 CANCEL VERIFY 1 0 = Disable; [1 = Enable]
- *53 PAGER PHONE NUMBER Enter up to 20 digits.
Do not fill unused spaces. If fewer than 20 digits entered, exit by pressing *
- *54 PAGER REPORT OPTIONS 0 0 = No reports sent
1 = Open/close for all users
3 = O/C users 5-16+wireless key zones on zone list 6
4 = All alarms and troubles
5 = All alarms+troubles+O/C for all users
7 = All alarms+troubles, O/C users 5-16+wireless key zones on zone list 6
C = Alarms and troubles for zones entered on zone list 6
D = Alarms and troubles for zones entered on zone list 6, open/close for all users
F = Alarms+trbls for zns on zn list 6, O/C users 5-16, RF key zones on zone list 6

† Entry of a number other than one specified will give unpredictable results.

*56/58 ZONE ASSIGNMENT/ALARM REPORT CODES - This field is an interactive mode. Fill in the required data on the worksheet below (and on next page) and follow the programming procedure in the installation manual.

ZONES ON CONTROL:

See explanation of headings at top of next page →

| ZONE DESCRIPTION | ZONE NUMBER (Zn) | ZONE TYPE (ZT) | ALARM RPT CODE (Hex) (RC) | INPUT TYPE (In) | RESPONSE TIME (RT) |
|-----------------------------|--|---|--|-----------------|--------------------|
| Wired Zone 1* | <input type="checkbox"/> 0 <input type="checkbox"/> 1 | <input type="checkbox"/> 0 <input type="checkbox"/> 9 [9] | <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> - <input type="checkbox"/> - [01, --] | HW | 350 msec [1 = 350] |
| Wired Zone 2 | <input type="checkbox"/> 0 <input type="checkbox"/> 2 | <input type="checkbox"/> 0 <input type="checkbox"/> 1 [1] | <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> - <input type="checkbox"/> - [01, --] | HW | 350 msec [1 = 350] |
| Wired Zone 3 | <input type="checkbox"/> 0 <input type="checkbox"/> 3 | <input type="checkbox"/> 0 <input type="checkbox"/> 1 [1] | <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> - <input type="checkbox"/> - [01, --] | HW | 350 msec [1 = 350] |
| Wired Zone 4 | <input type="checkbox"/> 0 <input type="checkbox"/> 4 | <input type="checkbox"/> 0 <input type="checkbox"/> 3 [3] | <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> - <input type="checkbox"/> - [01, --] | HW | 350 msec [1 = 350] |
| Wired Zone 5 | <input type="checkbox"/> 0 <input type="checkbox"/> 5 | <input type="checkbox"/> 0 <input type="checkbox"/> 3 [3] | <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> - <input type="checkbox"/> - [01, --] | HW | 350 msec [1 = 350] |
| Wired Zone 6 | <input type="checkbox"/> 0 <input type="checkbox"/> 6 | <input type="checkbox"/> 0 <input type="checkbox"/> 4 [4] | <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> - <input type="checkbox"/> - [01, --] | HW | 350 msec [1 = 350] |
| Expansion Module | <input type="checkbox"/> 0 <input type="checkbox"/> 9 Tamper | <input type="checkbox"/> 0 <input type="checkbox"/> 5 [5] | <input type="checkbox"/> 0 <input type="checkbox"/> 0 <input type="checkbox"/> - <input type="checkbox"/> - [01, --] | -- | -- |
| Duress | <input type="checkbox"/> 9 <input type="checkbox"/> 2 Duress | -- NA | <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> - <input type="checkbox"/> - [01, --] | -- | -- |
| Console Panic (1 & *, or A) | <input type="checkbox"/> 9 <input type="checkbox"/> 5 1 *, A | <input type="checkbox"/> 0 <input type="checkbox"/> 9 [0] | <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> - <input type="checkbox"/> - [01, --] | -- | -- |
| Console Panic (3 & #, or C) | <input type="checkbox"/> 9 <input type="checkbox"/> 6 3 #, C | <input type="checkbox"/> 0 <input type="checkbox"/> 8 [0] | <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> - <input type="checkbox"/> - [01, --] | -- | -- |
| Console Panic (* & #, or B) | <input type="checkbox"/> 9 <input type="checkbox"/> 9 * #, B | <input type="checkbox"/> 0 <input type="checkbox"/> 7 [7] | <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> - <input type="checkbox"/> - [01, --] | -- | -- |

* Zone 1 can be used as a 2-wire Fire zone.

EXPLANATION OF ZONE ASSIGNMENT TABLE HEADINGS

Zn = ZONE NUMBER Zone Nos. are from 01 to 6, 9 to 35, 92, 95, 96, 99. Some are pre-assigned.
 With Field *25 set for auxiliary wired loops (4219 or 4229), use Zone Nos. 10-17 for loops A-H.
 With Field *22 set for RF (5800), use Zone Nos. 10-35.

ZT = ZONE TYPE

| | | |
|------------------------|------------------------------|------------------------|
| 00 = Not Used | 05 = Trouble Day/Alarm Night | 20 = Arm-Stay |
| 01 = Entry/Exit #1 | 06 = 24 Hr Silent | 21 = Arm-Away |
| 02 = Entry/Exit #2 | 07 = 24 Hr Audible | 22 = Disarm |
| 03 = Perimeter | 08 = 24 Hr Aux | 23 = No Alarm Response |
| 04 = Interior Follower | 09 = Fire Trouble | 24 = Silent Burglary |
| | 10 = Interior w/Delay | |
| | 12 = 24 Hour Monitor | |

| DEFAULT VALUES | | | |
|----------------|------|------|-----------|
| Zn: | 01 | 02 | 03 04 |
| ZT: | [09] | [01] | [01] [03] |
| Zn: | 05 | 06 | 99 |
| ZT: | [03] | [04] | [07] |

RC = ALARM REPORT CODE Two Hex Digits. For each Hex Digit, enter: 00-09 for 0-9
 10 for A, 11 for B, 12 for C, 13 for D, 14 for E, 15 for F.
 If "00" is entered in the first pair of boxes, there will be no report for that zone.
 For Contact ID reporting, this is an enabling code only. Enter any Hex digit (other than "00") in the first pair of boxes. The second pair of boxes will be ignored.

In = LOOP INPUT DEVICE

| | |
|-----------------------------|---------------------------------|
| HW: Hard Wire | Enter 2 for AW: Auxiliary Wired |
| AW: Aux Wire (4219 or 4229) | Enter 3 for RF: Supervised RF |
| | Enter 4 for UR: Unsupervised RF |
| | Enter 5 for BR: Button Type RF |

| |
|--|
| Hard wire zone input types are automatically assigned. |
|--|

RT = RESPONSE TIME 0 = 10 msec; 1 = 350 msec; 2 = 700 msec. Default Values for zones 01 - 06 = [1 (350 msec)]
L = LEARNED RF INPUT Used with 5800 RF Loop Input Devices. Record transmitter input number.

EXPANSION ZONES: Assign Zone Numbers (Zn) 10-17 to 4219/4229 Auxiliary Wired Loops A-H, if used.
 RF can use (Zn) 10-39.
 All expansion zone information defaults to [0].

ENTER FOR RF ONLY

| EXP'N DESCRIPTION | ZONE NUMBER (Zn) | ZONE TYPE (ZT) | ALARM RPT CODE (Hex) (RC) | INPUT TYPE (In) | LOOP NUMBER (L) | SERIAL NUMBER |
|----------------------------------|------------------|----------------|---------------------------|-----------------|-----------------|---------------|
| 4219/4229 Loop A, 1st Exp'n Zone | 1 0 | -- | 0 1 - - | -- | -- | -- |
| B, 2nd | 1 1 | -- | 0 1 - - | -- | -- | -- |
| C, 3rd | 1 2 | -- | 0 1 - - | -- | -- | -- |
| D, 4th | 1 3 | -- | 0 1 - - | -- | -- | -- |
| E, 5th | 1 4 | -- | 0 1 - - | -- | -- | -- |
| F, 6th | 1 5 | -- | 0 1 - - | -- | -- | -- |
| G, 7th | 1 6 | -- | 0 1 - - | -- | -- | -- |
| H, 8th | 1 7 | -- | 0 1 - - | -- | -- | -- |
| | 9th | -- | 0 1 - - | -- | -- | -- |
| | 10th | -- | 0 1 - - | -- | -- | -- |
| | 11th | -- | 0 1 - - | -- | -- | -- |
| | 12th | -- | 0 1 - - | -- | -- | -- |
| | 13th | -- | 0 1 - - | -- | -- | -- |
| | 14th | -- | 0 1 - - | -- | -- | -- |
| | 15th | -- | 0 1 - - | -- | -- | -- |
| | 16th | -- | 0 1 - - | -- | -- | -- |
| | 17th | -- | 0 1 - - | -- | -- | -- |
| | 18th | -- | 0 1 - - | -- | -- | -- |
| | 19th | -- | 0 1 - - | -- | -- | -- |
| | 20th | -- | 0 1 - - | -- | -- | -- |
| | 21st | -- | 0 1 - - | -- | -- | -- |
| | 22nd | -- | 0 1 - - | -- | -- | -- |
| | 23rd | -- | 0 1 - - | -- | -- | -- |
| | 24th | -- | 0 1 - - | -- | -- | -- |
| | 25th | -- | 0 1 - - | -- | -- | -- |
| | 26th | -- | 0 1 - - | -- | -- | -- |

***81 ZONE LISTS FOR OUTPUT DEVICES-** This is an interactive mode. Fill in the required data on the worksheet below and follow the procedure in the installation manual as you enter the data during the displays and prompts that appear in sequence.

Note: Record desired zone numbers below. More or fewer boxes than shown may be needed, since any list may include *any* or *all* of system's zone numbers.

Zone List 1: Started or stopped by zone numbers (enter 00 to end entries).

, , , , , , , , , , ...etc.

Zone List 2: Started or stopped by zone numbers (enter 00 to end entries).

, , , , , , , , , , ...etc.

Zone List 3: Started or stopped by zone numbers (enter 00 to end entries).

, , , , , , , , , ...etc.

Cross Zone List:

, , , , , , , , , ...etc.

Night Stay Zone List:

, , , , , , , , , ...etc.

Pager List:

, , , , , , , , , ...etc.

Special Function Pager List:

, , , , , , , , ...etc.

SPECIAL MESSAGES

OC = OPEN CIRCUIT (no communication between Console and Control).

EE or ENTRY ERROR = ERROR (invalid field number entered; re-enter valid field number).

After powering up, **AC**, **dl** (disabled) or **Busy Standby** and **NOT READY** will be displayed after approximately 4 seconds. This will revert to **READY** in appx. 1 minute, which allows PIRS, etc. to stabilize. To bypass this delay, press: **[#] + [0]**.

If **E4** or **E8** appears, more zones than the expansion unit's capacity have been programmed. Correct the programming and then completely de-power and re-power the control to clear this indication and remove the disable indication.

TO ENTER PROGRAMMING MODE:

1. POWER UP, then depress **[*]** and **[#]** both at once, within 50 seconds of powering up.
OR
2. Initially, key **Installer Code (4 + 1 + 1 + 2)** plus **8 + 0 + 0**.
OR
3. If different **Installer Code** is programmed, key: **New Installer Code + 8 + 0 + 0**.
(if *98 was used to exit previously, method 1 above must be used to enter the program mode again).

TO EXIT PROGRAMMING MODE:

- *98** Exits programming mode and *prevents* re-entry by: **Installer Code + 8 + 0 + 0**. If ***98** is used to exit programming mode, system must be powered down, and method 1 above used to enter the programming mode.
- *99** Exits programming mode and *allows* re-entry by: **Installer Code + 8 + 0 + 0**. or: **Power-up**, then **"*"** and **"#"** . within 50 seconds of power up.