


SL150

Security System

Programming Guide



**Local programming requires the use of a 2-line Alpha keypad
connected to the keypad terminals on the control.**

Field	Function	Programmed Values	[] = Default Value
SYSTEM SETUP (*20 - *30)			
*20	INSTALLER CODE	<input type="text" value=" "/> [4 1 1 2] Enter 4 digits, 0-9	
*22	RF SYSTEM	<input type="checkbox"/> [0] 0 = none; 1 = 5800 (5881/5882); 4 = 5800 with RF Jam detection Must be "4" for UL installations.	
*23	FORCED BYPASS	<input type="checkbox"/> [0] 0 = none; 1 = bypass open zones. "0" for UL installations.	
*24	RF HOUSE ID CODE	<input type="text" value=" "/> [0][0] 00 = disable all wireless keypad usage; 01-31 = using 5827 keypad	
*25	WIRED ZONE EXPANSION	<input type="checkbox"/> [0] 0 = none; 1 = 4219; 2 = 4229; 3 = 4204	
*26	CHIME BY ZONE	<input type="checkbox"/> [0] 0 = no; 1 = yes (program zones to chime on zone list 3)	
*27	X-10 HOUSE CODE	<input type="checkbox"/> [0] 0 = A; 1 = B, 2 = C, 3 = D, 4 = E, 5 = F, 6 = G, 7 = H, 8 = I, 9 = J, #10 = K, #11 = L, #12 = M, #13 = N, #14 = O, #15 = P	
*28	PHONE MODULE ACCESS CODE	<input type="text" value=" "/> [00] 1st digit: enter 1-9; 2nd digit: enter # + 11 for *, or # + 12 for #. Entering 0 for either digit disables code.	
*29	OUTPUT TO LONG RANGE RADIO	<input type="checkbox"/> [0] 0 = disable; enable = Trouble code 1-9, B (# + 11), C (# + 12), D (# + 13), E (# + 14), or F (# + 15). The 2nd digit of Trouble Dialer Report is automatically entered from field *60. "0" for UL installations.	
*30	KEYSWITCH ENABLE (ZONE 7)	<input type="checkbox"/> [0] 1 = Enable; 0 = Disable	
ZONE SOUNDS AND TIMING (*31 - *39)			
*31	SINGLE ALARM SOUNDING/ZONE	<input type="checkbox"/> [0] 1 = yes; 0 = no; "0" for UL installations.	
*32	FIRE SOUNDER TIMEOUT	<input type="checkbox"/> [0] 0 = timeout; 1 = no timeout	
*33	ALARM BELL TIMEOUT	<input type="checkbox"/> [1] 0 = none; 1 = 4 min; 2 = 8 min; 3 = 12 min; 4 = 16 min; "1" (4 min.) minimum for UL.	
*34	EXIT DELAY	<input type="text" value=" "/> [99] 00-99 = exit delay time (seconds) 60 seconds max. for UL installations	
*35	ENTRY DELAY 1 (zone type 01)	<input type="text" value=" "/> [60] 00-99 = entry delay 1 time; 20 seconds max. for UL installations	

NOTE: Entry of a number other than one specified will give unpredictable results.

Field	Function	Programmed Values	[] = Default Value
*36	ENTRY DELAY 2 (zone type 02)	<input type="text" value="1"/> [90] 00-99 = entry delay 2 time; 50 seconds max. for UL installations	
*37	AUDIBLE EXIT WARNING	<input type="checkbox"/> [1] 0 = no; 1 = yes	
*38	CONFIRMATION OF ARMING DING	<input type="checkbox"/> [0] 0 = no; 1 = yes (wired keypads and RF); 2 = yes, RF only	
*39	POWER UP IN PREVIOUS STATE	<input type="checkbox"/> [1] 0 = no; 1 = yes; "1" for UL installations	
DIALER PROGRAMMING (*40 - *44 and *47 - *53)			
In fields *40, *41, *42, enter up to the number of digits shown. Do not fill unused spaces. Enter 0-9; # +11 for *; # +12 for #; # +13 for a 2 second pause.			
*40	PABX ACCESS CODE	<input type="text" value=" "/> Enter 6 digits. If fewer than 6 digits are entered, exit by pressing * (and press 41, if entering next field). To clear entries from field, press *40*.	
*41	PRIMARY PHONE No.	<input type="text" value=" "/> Enter up to 20 digits; Do not fill unused spaces. If fewer than 20 digits entered, exit by pressing * (and press 42, if entering next field). To clear entries from field, press *41*.	
*42	SECONDARY PHONE No.	<input type="text" value=" "/> Enter up to 20 digits; Do not fill unused spaces. If fewer than 20 digits entered, exit by pressing * (and press 43, if entering next field). To clear entries from field, press *42*.	
*43	PRIMARY SUBS ACCT #	<input type="text" value=" "/>	For fields *43 and *44: Enter 0-9; # +11 for B; # +12 for C; # +13 for D; # +14 for E; [# +15 for F]. Enter * as 4th digit, if 3+1 dialer reporting is to be used. If only 3 digits used, exit by pressing * (and press next field). To clear entries from field, press *43* or *44*. Examples: For Acct. 1234, enter: <input type="text" value="1 2 3 4"/> For Acct. B234, enter: <input type="text" value="#+11 2 3 4"/> For Acct. 123, enter: <input type="text" value="1 2 3 *"/>
*44	SECONDARY SUBS ACCT #	<input type="text" value=" "/>	
*47	PHONE SYSTEM SELECT	<input type="checkbox"/> [3] If Cent. Sta. IS NOT on a WATS line: 0 = Pulse Dial; 1 = Tone Dial. If Cent. Sta. IS on a WATS line: 2 = Pulse Dial; 3 = Tone Dial.	
*48	REPORT FORMAT	<input type="checkbox"/> <input type="checkbox"/> [7] [7] Primary Secondary	
	0 = 3+1, 4+1 ADEMCO L/S STANDARD	6 or undefined = 4+2 ADEMCO EXPRESS	
	1 = 3+1, 4+1 RADIONICS STANDARD	7 = ADEMCO CONTACT ID REPORTING	
	2 = 4+2 ADEMCO L/S STANDARD	8 = 3+1, 4+1 ADEMCO L/S EXPANDED	
	3 = 4+2 RADIONICS STANDARD	9 = 3+1, 4+1 RADIONICS EXPANDED	

NOTE: Entry of a number other than one specified will give unpredictable results.

Field	Function	Programmed Values	[] = Default Value
*49	SPLIT/DUAL REPORTING	<input type="checkbox"/> [0] 0 = Disable (Backup report only)	
		TO PRIMARY PHONE No. 1 = Alarms, Restore, Cancel 2 = All except Open/Close, Test 3 = Alarms, Restore, Cancel 4 = All except Open/Close, Test 5 = All	TO SECONDARY PHONE No. Others Open/Close, Test All All All
*50	15 SEC DIALER DELAY (BURG)	<input type="checkbox"/> [1] 0 = no; 1 = yes; "0" for UL installations	
*51	PERIODIC TEST REPORT	<input type="checkbox"/> [0] 0 = none; 1 = 24 hours; 2 = weekly; 3 = 30 days (Enter Test Code in field *64.)	
*52	TEST REPORT OFFSET	<input type="checkbox"/> [2] 0 = 24 hour; 1 = 6 hours; 2 = 12 hours; 3 = 18 hours (Time to 1st report from programming or downloading).	
*53	SESCOA/RADIONICS SELECT	<input type="checkbox"/> [0] 0 = Radionics (0 - 9, B - F reporting); 1 = SESCOA (0 - 9 only reporting). Select 0 for all other formats.	
54	DYNAMIC SIGNALING DELAY	<input type="checkbox"/> [0] Delay selectable from 0 to 225 secs in 15-sec increments. (1 = 15 secs, 2 = 30 secs, etc. Enter 0 for UL installations.)	
55	DYNAMIC SIGNALING PRIORITY	<input type="checkbox"/> [0] 0 = Primary Dialer first; 1 = Long Range Radio first.	

* See "Data Field Descriptions" in Installation manual for details.

NOTE: Entry of a number other than one specified will give unpredictable results.

***56 ZONE ASSIGNMENT/ALARM REPORT CODES** — This field is an interactive mode. Fill in the required data on the worksheet below (and on next page) and follow the programming procedure in the installation manual.

See explanation of headings on next page ➡

ZONES ON CONTROL:

ZONE DESCRIPTION	ZONE No. (Zn)	ZONE TYPE (ZT)	ALARM RPT CODE (Hex) (RC)	INPUT TYPE (In)	RESPONSE TIME (RT)
Wired Zone 1*	0 1	[09]	[10]	HW	[1]
Wired Zone 2	0 2	[01]	[10]	HW	[1]
Wired Zone 3	0 3	[01]	[10]	HW	[1]
Wired Zone 4	0 4	[03]	[10]	HW	[1]
Wired Zone 5	0 5	[03]	[10]	HW	[1]
Wired Zone 6	0 6	[03]	[10]	HW	[1]
Wired Zone 7**	0 7	[04]	[10]	HW	[1]
Wired Zone 8***	0 8	[04]	[10]	HW	[1]
Expansion Module Suprvsn	0 9	0 5	[10]	—	—
Duress	9 2	— —	[10]	—	—
Keypad Panic (1 & *)	9 5		[10]	—	—
Keypad Panic (3 & #)	9 6		[10]	—	—
Keypad Panic (* & #)	9 9	[07]	[10]	—	—

* Zone 1 can be used as a 2-wire Fire zone.

** Zone 7 can be used for optional Keyswitch; shows as 77 for Zone Type (ZT)

*** Zone 8 can be used as a Glassbreak zone.

EXPANSION ZONES: Assign zone numbers (Zn) 10-17 to 4219/4229 Auxiliary Wired Loops A-H, if used.
RF zones can use zone numbers (Zn) 10-39

ZONE DESCRIPTION	ZONE No. (Zn)	ZONE TYPE (ZT)	ALARM RPT CODE (Hex) (RC)	ENTER FOR RF ONLY	
				INPUT TYPE (In)	LEARNED RF INPUT (L)
4219/4229 Loop A 1st Exp'n Zone or RF Zones	B	1 0	[10]		
	C	1 1	[10]		
	D	1 2	[10]		
	E	1 3	[10]		
	F	1 4	[10]		
	G	1 5	[10]		
	H	1 6	[10]		
		1 7	[10]		
RF Zones		1 8	[10]		
		1 9	[10]		
		2 0	[10]		
		2 1	[10]		
		2 2	[10]		
		2 3	[10]		
		2 4	[10]		
		2 5	[10]		
RF Zones		2 6	[10]		
		2 7	[10]		
		2 8	[10]		
		2 9	[10]		
		3 0	[10]		
		3 1	[10]		
		3 2	[10]		
		3 3	[10]		
		3 4	[10]		
		3 5	[10]		
		3 6	[10]		
		3 7	[10]		
		3 8	[10]		
	3 9	[10]			

EXPLANATION OF ZONE ASSIGNMENT TABLE HEADINGS

Zn = ZONE No. Zone Nos. are from 01 to 39, 92, 95, 96, 99. Some are pre-assigned.
With Field *25 set for auxiliary wired loops (4219, or 4229), use Zone Nos. 10-17 for loops A-H.
With Field *22 set for RF (5800), use Zone Nos. 10-39.

ZT = ZONE TYPE

00 = Not Used	07 = 24 Hr Audible	21 = Arm-Away*
01 = Entry/Exit #1	08 = 24 Hr Aux	22 = Disarm*
02 = Entry/Exit #2	09 = Fire	23 = No Alarm
03 = Perimeter	10 = Interior w/Delay	Response*
04 = Interior Follower	14 = Carbon Monoxide	24 = Silent Burglary
05 = Trouble Day/Alarm Night	15 = Medical	64 = One-button page
06 = 24 Hr Silent	20 = Arm-Stay*	

DEFAULT VALUES				
Zn:	01	02	03	04
ZT:	[09]	[01]	[01]	(03)
Zn:	05	06	07	08 99
ZT:	[03]	[03]	[04]	[04] [07]

*5800 Button-type transmitters only

RC = ALARM REPORT CODE Two Hex Digits. For each Hex Digit, enter: 00-09 for 0-9, 10 for A, 11 for B, 12 for C, 13 for D, 14 for E, 15 for F. If "00" is entered as the first digit, there will be no report for that zone. For contact ID reporting, this is enabling code only. Enter any hex digit (other than 00) in the first pair of boxes. The second pair of boxes is ignored.

In = LOOP INPUT HW: Hard Wire
AW: Aux Wire (4219 or 4229)
Enter 2 for AW: Auxiliary wired
Enter 3 for RF: Supervised RF
Enter 4 for UR: Unsupervised RF
Enter 5 for BR: Button Type RF

Hard wire zone input types are automatically assigned (HW).

RT = RESPONSE TIME 0 = 10msec; 1 = 350 msec; 2 = 700 msec. Default Values for zones 01-08 = 1 (350 msec)

L = LEARNED RF INPUT Used with 5800 RF Loop Input Devices. Record transmitter input number.

TO PROGRAM SYSTEM STATUS, & RESTORE REPORT CODES (*59 - *76, AND *89):

With a 3+1 or 4+1 Standard Format: Enter a code in the first box: 1-9, 0, B, C, D, E, or F. Enter "#+10" for 0, "#+11" for B, "#+12" for C, "#+13" for D, "#+14" for E, "#+15" for F. A "0" (not "#+10") in the first box will disable a report. A "0" (not "#+10") in the second box will result in automatic advance to the next field when programming.

With an Expanded or 4+2 Format: Enter codes in both boxes (1st and 2nd digits) for 1-9, 0, or B-F, as described above.

A "0" (not "#+10") in the second box will eliminate the expanded message for that report.

A "0" (not "#+10") in both boxes will disable the report.

With Ademco Contact ID Reporting: Enter any digit (other than "0") in the first box, to enable zone to report (entries in the second boxes will be ignored).

A "0" (not "#+10") in the first box will disable the report.

Examples: For Code 3 (single digit), enter: |

For Code 3 2 (two digits), enter: |

For Code B 2 (Hexadecimal), enter: |

SYSTEM STATUS REPORT CODES (*59 - *68)

*59 EXIT ERROR REPORT CODE |

*60 TROUBLE REPORT CODE |

*61 BYPASS REPORT CODE |

*62 AC LOSS REPORT CODE |

*63 LOW BAT REPORT CODE |

*64 TEST REPORT CODE |

*65 OPEN REPORT CODE | †

*66 ARM AWAY/STAY RPT CODE | | †

† 2nd digit is automatically sent as the 2nd AWAY HOME digit of the zone alarm report code programmed in *56, if expanded or 4+2 reporting is selected.

†† 2nd digit is automatically sent as the user number if expanded or 4+2 reporting is selected.

*67 RF XMTR LOW BAT RPT CODE |

*68 CANCEL REPORT CODE |

RESTORE REPORT CODES (*70 - *76)

*70 ALARM RESTORE RPT CODE |

2nd digit is automatically sent as the 2nd digit of the zone alarm report code programmed in *56, if expanded or 4+2 reporting is selected.

*71 TROUBLE RESTORE RPT CODE |

*72 BYPASS RESTORE RPT CODE |

*73 AC RESTORE RPT CODE |

*74 LOW BAT RESTORE RPT CODE |

*75 RF XMTR LO BAT RST RPT CODE |

*76 TEST RESTORE RPT CODE |

OUTPUT AND SYSTEM SETUP (*80-*82, *84-*93)

*80 OUTPUT RELAYS & POWER-LINE CARRIER DEVICES

Program *80 & *81 only if Relays and/or Powerline Carrier devices are to be used

*81 ZONE LISTS FOR OUTPUT DEVICES

*82 CUSTOM ALPHA EDITING: (Also entered from field *56): See procedure in instructions.

*84 PAGER REPORTS | | |

0 = No reports sent Pgr 1 Pgr 2

1 = Open/close for all users

3 = Open/close for users 5-16 and wireless key zones entered in zone list 6/7*

4 = All alarms and troubles

5 = All alarms, troubles, and open/close for all users

7 = All alarms, troubles, and open/close for users 5-16, and wireless key zones entered in zone list 6/7*

12 = Alarms and troubles for zones entered in zone list 6/7*

13 = Alarms and troubles for zones listed in zone list 6/7*, open/close for all users

15 = All alarms and troubles for zones entered in zone list 6/7*, open/close for users 5-16, and wireless key zones entered in zone list 6/7*

* Zone List 6 for Pager 1, Zone List 7 for Pager 2.

*85 PAGER 1 PHONE No.

| | | | | | | | |

| | | | | | |

Enter up to 20 digits; do NOT fill unused spaces. If fewer than 20 digits entered, exit this field by pressing * (then press 86, to enter next field). To clear entries from this field, press *86*.

*86 PAGER 1 CHARACTERS

| | | | | | | | | | |

| | | | |

Enter up to 16 characters to precede 7-digit system status code sent to pager 1. This may consist of any data, e.g., PIN #, Subscriber Acct #, or other information.

*87 PAGER 2 PHONE No.

| | | | | | | | |

| | | | | | |

Enter up to 20 digits; do NOT fill unused spaces. If fewer than 20 digits entered, exit this field by pressing * (then press 88, to enter next field). To clear entries from this field, press *87*.

*88 PAGER 2 CHARACTERS

| | | | | | | | | | |

| | | | |

Enter up to 16 characters to precede 7-digit system status code sent to pager 2. This may consist of any data, e.g., PIN #, Subscriber Acct #, or other information.

*89 EVENT LOG 80% FULL RPT CODE [00]

*90 EVENT LOGGING ENABLE [15]

- 0 = None;
- 1 = log Alarm/Alarm Restore;
- 2 = log Trouble/Trouble Restore;
- 4 = log Bypass/Bypass Restore;
- 8 = log Open/Close.

Example: To select "log Alarm/Alarm Restore", and "log Open/Close", enter 9 (1 + 8); To select all, enter 15.

Note: System messages are logged when any non-zero selection is made.

*91 OPTION SELECTION [8]

- 0 = None;
 - 2 = macros; 4 = AAV;
 - 8 = Enable Exit /Delay Restart;
 - 12 = both AAV and Exit Delay Restart enabled.
 - 14 = Enable all
- "0" for UL installations.

*92 PHONE LINE MONITOR ENABLE [0]

- 0 = Not used
- 1 = Keypad display when line is faulted
- 2 = Keypad display plus keypad trouble sound
- 3 = Same as "2", plus Device #2 STARTS. If armed, external sounder activates also.

Note:

Device #2 must either be programmed to be STOPPED in field *80 or STOPPED by Code + # + 8 + 2. Field *80 should be set to "0" for STOP.

For automatic restore, set the relay in field 80 for a STOP condition with System Operation choice 52 (kissoff).

*93 No. OF REPORTS IN ARMED PERIOD [0]

- 0 = 10 Alarm/Alarm Restore Reports;
 - 1 = Unlimited.
- "1" for UL installations.

DOWNLOAD INFORMATION (*94,*95)

*94 DOWNLOAD PHONE No.

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

Enter up to 20 digits, 0-9; #+11 for '*'; #+12 for '#'; # + 13 for a pause. Do not fill unused spaces. If fewer than 16 digits entered, exit field by pressing *

(and press 95, if entering next field).

To clear entries from field, press *94*.

*95 RING DET COUNT FOR DOWNLOADING [15]

- 0 = Disable Station Initiated Download;
- 1-14 = number of rings (1-9, # +10 =10, # +11 =11, # +12 =12, # +13 =13, # +14 =14);
- 15 = answering machine defeat (# +15 =15)

Note: Do not enter "0" if using 4285/4286 Phone Module.

*96 INITIALIZES DOWNLOAD ID, SUBSCRIBER ACCOUNT No. FOR INITIAL DOWNLOAD: No data entry required.

*97 SETS ALL PROGRAM FIELDS TO DEFAULT VALUES: No data entry required.

*98 EXITS PROGRAMMING MODE but prevents re-entry by: **Installer Code + 8 + 0 + 0**

Re-entry then possible only by powering down, then powering up again and pressing [*] and [#] at the same time within 50 seconds of power-up.

*99 Exits programming mode and allows re-entry by: **Installer Code + 8 + 0 + 0** or:

Power-up, then press [*] and [#] at the same time within 50 seconds of power up.

OUTPUT RELAYS/POWERLINE CARRIER DEVICES WORKSHEET FOR *80 and *81

Applicable only if Relays and/or Powerline Carrier Devices are to be used.

***80 OUTPUT DEVICES** – This is an interactive menu mode. Fill in the required data on the worksheet on below and follow the programming procedure in the installation manual as you enter the data during the displays and prompts that appear in sequence.

- Notes:**
1. For Relays, field *25 must be programmed for a 4229 (Relays 01 and 02), OR for a 4204 (Relays 01 to 04).
 2. For Powerline Carrier devices, field *27 must be programmed with a House Code.
 3. Tamperers of expansion units cannot be used to operate devices.

DEVICE NUMBER	ACTION (A)	S T A R T ⇐ either or both ⇐			S T O P ⇐ either or both ⇐		X-10 SELECT
		EVENT (EV)	ZONE LIST (ZL)	ZONE TYPE SYST OP'N (ZT)	RESTORE of ZONE LIST (ZL)	ZONE TYPE /SYST OP'N (ZT)	
OUTPUT RELAY OR P.L.C.D. 01	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>
OUTPUT RELAY OR P.L.C.D.* 02	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>
OUTPUT RELAY OR P.L.C.D.* 03	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>
OUTPUT RELAY OR P.L.C.D.* 04	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>
P.L.C.D.* 05	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>
P.L.C.D.* 06	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>
P.L.C.D.* 07	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>
P.L.C.D.* 08	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>

* P.L.C.D. = Powerline Carrier Device (X-10).

Where:

X-10 SELECT = Powerline Carrier Device Enter "1" if Powerline Carrier Device is being used, enter "0" if relay is being used.

A = DEVICE ACTION 0 = No Response; 1 = Close for 2 sec; 2 = Close and stay closed; 3 = Pulse on and off.

EV = EVENT 0 = Not used; 1 = Alarm; 2 = Fault; 3 = Trouble.

ZL = ZONE LIST 1, 2, or 3 (from Field *81) or 0 = Not Used.

"START" ZONE LIST: Upon alarm, fault, or trouble of ANY zone on this list, device action will START.

"STOP" RESTORE of ZONE LIST: Upon restore of ALL zones on this list, device action will STOP.

It need not be same list as used for START.

Note: Do not use input type "BR" transmitters in a zone list to STOP a relay action, since these transmitters do not send restores.

ZT = ZONE TYPE/SYSTEM OPERATION

Choices for Zone Types are:

- | | |
|------------------------------|-----------------------|
| 00 = Not Used | 07 = 24 Hr Audible |
| 01 = Entry/Exit#1 | 08 = 24 Hr Aux |
| 02 = Entry/Exit#2 | 09 = Fire |
| 03 = Perimeter | 10 = Interior w/Delay |
| 04 = Interior Follower | 14 = Carbon Monoxide |
| 05 = Trouble Day/Alarm Night | 15 = Medical |
| 06 = 24 Hr Silent | 24 = Silent Burglary |

Choices for System Operation are:

- | | | |
|-----------------------------|------------------------|----------------------------|
| 20 = Arming–Stay | 36 = At Bell Timeout** | 42 = System Battery Low |
| 21 = Arming–Away | 38 = Chime | 43 = Communication Failure |
| 22 = Disarming (Code + OFF) | 39 = Any Fire Alarm | 52 = Kissoff |
| 31 = End of Exit Time | 40 = Bypassing | 58 = Duress |
| 32 = Start of Entry Time | 41 = AC Power Failure | 65 = Any CO Alarm |
| 33 = Any Burglary Alarm | | |

Note: Any zone in "ZT" going into alarm, fault, or trouble will actuate relay.
Any zone of that type that restores will stop relay action.

** Or at Disarming, whichever occurs earlier.

Note: In normal operation mode:
Code + # + 7 + N Key Entry starts Device N.
Code + # + 8 + N Key Entry stops Device N.

***81 ZONE LISTS**

FOR OUTPUT DEVICES (01 - 03) and PAGER REPORTING (06, 07).

This is an interactive mode. Fill in the required data on the worksheet below and follow the procedure in the installation manual as you enter the data in response to the displays and prompts that appear in sequence.

Note: Record desired zone numbers below. More or fewer boxes than shown may be needed, since any list may include any or all of system's zone numbers.

Zone List 01: Started or stopped by zone numbers (enter 00 to end entries).

, , , , , , , , , , etc.

Zone List 02: Started or stopped by zone numbers (enter 00 to end entries).

, , , , , , , , , , etc.

Zone List 03: Started or stopped by zone numbers AND/OR assignment of Chime zones (enter 00 to end entries).

, , , , , , , , , , etc.

Zone List 06: Pager 1 Reporting list: All zones in this list will report to the pager independent of the report code enabled for these zones.

, , , , , , , , , , etc.

Zone List 07: Pager 2 Reporting list: All zones in this list will report to the pager independent of the report code enabled for these zones.

, , , , , , , , , , etc.

SPECIAL MESSAGES

OC = OPEN CIRCUIT (no communication between keypad and control).

EE or **ENTRY ERROR** = ERROR (invalid field number entered; re-enter valid field number).

After powering up, **AC**, **dI** (disabled) or **Busy Standby** and **NOT READY** will be displayed after approximately 4 seconds. This will revert to **READY** in appx. 1 minute, which allows PIRS, etc. to stabilize.

To bypass this delay, press: [#] + [0].

If **E4** or **E8** appears, more zones than the expansion units can handle have been programmed. Correct the programming and then completely de-power and re-power the control to clear this indication and remove the disable indication.

To Enter Programming Mode

1. POWER UP, then depress [*] and [#] both at once, within 50 seconds of powering up.
OR
2. Initially, key: **Installer Code (4 + 1 + 1 + 2)** plus **8 + 0 + 0**.
OR
3. If different **Installer Code** is programmed, key: **New Installer Code + 8 + 0 + 0**.
(if *98 was used to exit previously, method 1 above must be used to enter the program mode again)

To Exit Programming Mode:

- *98 Exits programming mode and *prevents* re-entry by: **Installer Code + 8 + 0 + 0**. If *98 is used to exit programming mode, system must be powered down, and method 1 above used to enter the programming mode.
- *99 Exits programming mode and *allows* re-entry by: **Installer Code + 8 + 0 + 0** or: Power-up, then press "*" and "#" within 50 seconds of power up.
















5800 Series Transmitter Input Loop Identification

- All of the transmitters illustrated below have one or more unique factory assigned input (loop) ID codes. Each of the input loops requires its own programming zone (e.g., a 5804's four inputs require four programming zones).
- Transmitter inputs entered as:

"RF" (Supervised RF) Type send periodic check-in signals, as well as fault, restore and low battery signals. The transmitter must remain within the receiver's range.

"UR" (Unsupervised RF) Type send all the signals that the "RF" Type does, but the control does not supervise the check-in signals. The transmitter may, therefore, be carried off-premises.

"BR" (Unsupervised Button RF) Type only send fault signals. They do not send restore or check-in signals. They will indicate a low battery condition when tested or activated normally. The transmitter may be carried off-premises.



Note: For information on any transmitter not shown above, refer to the instructions accompanying that transmitter for details regarding loop numbers, etc.

UL NOTE: The 5802MN, 5802MN2, 5804, 5804BD, 5814, 5816TEMP, 5819, 5819WHS & BRS, 5827BD, and 5850 transmitters are not intended for use in UL installations



*Two Mid America Plaza
Suite 200
Oakbrook Terrace, Illinois, 60181*



N7526-8PRV1 1/00 (See Instructions N7526-8)

Ref: V20AMTE