4150 Version 1 & 2 Commands

Test Burg System = $\frac{\#}{2}$ + $\frac{4}{2}$ (In this mode opening any protected zone will produce a brief sound from the external sounder. Exiting this mode occurs by hitting any key.

Alarm Memory = HOLD # KEY

Testing Communications of system if programmed for a test: + 5

4150 Version 3 Commands

Disarm = Master Code

Program Secondary

Codes:

While in this mode the Bypass LED will flash. A flashing zone LED indicates faulted zone while a steady LED indicates a bypassed zone. To exit depress

Test Burg System = $\begin{bmatrix} \frac{\pi}{2} \\ -\frac{\pi}{2} \end{bmatrix}$ + $\begin{bmatrix} 4 \\ -\frac{\pi}{2} \end{bmatrix}$ (In this mode opening any protected zone will produce a brief sound from the external sounder. Exiting this mode occurs by hitting any key.

Testing Communications of system if programmed for a test: + 5