

LYNXR/LYNXR24

Security Systems

Programming Form & Summary of Connections



TABLE OF CONTENTS

| | |
|--|----|
| DATA FIELDS | 3 |
| *56 ENHANCED ZONE PROGRAMMING | 8 |
| *80 DEVICE PROGRAMMING | 9 |
| *81 ZONE LISTS | 10 |
| *83 ENHANCED SEQUENTIAL MODE | 10 |
| *84 ASSIGN ZONE VOICE DESCRIPTORS..... | 11 |
| VOCABULARY INDEX (for *84 Assign Zone Voice Descriptors) | 11 |
| *85 RECORD CUSTOM VOICE DESCRIPTORS | 12 |
| *56 ENHANCED ZONE PROGRAMMING WORKSHEET | 12 |
| POWERLINE CARRIER DEVICE WORKSHEET FOR *80 and *81 | 14 |
| 5800 SERIES TRANSMITTER LOOP DESIGNATIONS DIAGRAM..... | 15 |
| SPECIAL MESSAGES | 15 |
| LYNXR/LYNXR24 SUMMARY OF CONNECTIONS DIAGRAM..... | 16 |

Refer to the Installation Instructions for detailed information on programming the LYNXR and LYNXR24 system, including full descriptions of all data fields.



LYNXR is not intended for UL985 Household Fire applications.

TO ENTER PROGRAMMING MODE:

1. Power up, then depress [*****] and [**#**] both at once, within 50 seconds of powering up.
OR
2. For factory defaulted system, enter: **Installer Code (4 + 1 + 1 + 2)** plus **8 + 0 + 0**. OR
If different **Installer Code** is programmed, enter: **New Installer Code + 8 + 0 + 0**.
(if *98 was used to exit previously, method 1 above must be used to enter the program mode again)
3. Upon entry into Program mode, data field *20 will be displayed (the first data filed in the system) and both keypad LEDs will flash.

TO PROGRAM THE DATA FIELDS:

1. Press [*****] followed by the desired field number (e.g., *21), then make the required entry.
2. The keypad beeps three times after entering data, then displays the next data field in sequence.
3. For phone number and account number fields, press [*****] to end the entry if less than number maximum number of digits is entered.
4. To delete an entry, simply press [*****] plus that field number and reenter the correct data. For phone number and account number fields *40-*44, *88 and *94, press [*****] + field number + [*****].

INTERACTIVE MENU MODES:

There are six interactive menu modes as listed below. To enter these modes, first enter Program mode. While in Program mode, press [*****] plus the mode number desired (e.g., *56).

- *56 Enhanced Zone ProgrammingFor programming zone characteristics, report codes, etc.
- *80 Device Programming.....For programming Powerline Carrier Devices
- *81 Zone List Programming.....For programming zone lists for use with Powerline Carrier Devices
- *83 Enhanced Sequential ModeFor entering transmitter serial numbers
- *84 Assign Zone Voice DescriptorsFor assigning voice descriptors to zones
- *85 Record Custom Voice DescriptorsFor recording custom voice descriptors

TO LOAD A DEFAULT SET:

While in Program mode, press *97, then enter a number 1-4 corresponding to the default table desired. See the Installation Instructions for the default tables. Enter 0 to exit *97 without loading a default table.

TO EXIT PROGRAMMING MODE:

- *98 Exits programming mode and *prevents* re-entry by: Installer Code + 8 + 0 + 0. If *98 is used to exit programming mode, system must be powered down, then press [*****] and [**#**] within 50 seconds of power up to re-enter programming mode.
- *99 Exits programming mode and *allows* re-entry by: Installer Code + 8 + 0 + 0 or: Power-up, then press [*****] and [**#**] within 50 seconds of power up.

LYNXR & LYNXR24

DATA FIELDS

| Field | Function | Programmed Values | [] = Table 1 Default Values |
|--|---|---|------------------------------|
| SYSTEM SETUP (★ 20– ★ 30) | | | |
| ★20 | INSTALLER CODE | <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> [4112] Enter 4 digits, 0–9 | |
| ★21 | QUICK ARM ENABLE | <input type="text"/> † [1] 0 = no; 1 = yes | |
| ★22 | KEYPAD BACKLIGHT TIMEOUT | <input type="text"/> [0] 0 = none (backlighting always on); 1 = backlight off after 10secs | |
| ★23 | FORCED BYPASS | <input type="text"/> † [0] 0 = none; 1 = bypass open zones UL installations = 0 | |
| ★24 | RF HOUSE ID CODE | <input type="text"/> <input type="text"/> [00] 00 = disable all wireless keypad usage; 01–31 = 5827/5827BD/5804BD/5804BDV house ID | |
| ★25 | POWERLINE CARRIER DEVICE HOUSE CODE | <input type="text"/> [0] 0 = A; 1 = B, 2 = C, 3 = D, 4 = E, 5 = F, 6 = G, 7 = H, 8 = I, 9 = J, #10 = K, #11 = L, #12 = M, #13 = N, #14 = O, #15 = P | |
| ★26 | CHIME BY ZONE | <input type="text"/> † [1] 0 = no; 1 = yes (program zones to chime on zone list 3) | |
| ★27 | REAL TIME CLOCK DISPLAY | <input type="text"/> † [1] 0 = no; 1 = yes, display time on keypad | |
| ★29 | DAYLIGHT SAVING TIME START/END MONTH | <input type="text"/> <input type="text"/> [4, 10] Start End 1-9, #+10,#+11,#+12. Enter 0,0 if no daylight savings time used. | |
| ★30 | DAYLIGHT SAVING TIME START/END WEEKEND | <input type="text"/> <input type="text"/> [1,5] Start End 0 = disable; 1=first; 2=second; 3=third; 4=fourth; 5=last; 6=next to last; 7=third from last | |
| ZONE SOUNDS AND TIMING (★ 31– ★ 39) | | | |
| ★31 | SINGLE ALARM SOUNDING/ZONE | <input type="text"/> † [0] 1 = yes, limit once per arming period (also applies to long range radio output if "0" is selected in *91 field); 0 = no limit; UL installations = 0 | |
| ★32 | FIRE SOUNDER TIMEOUT | <input type="text"/> † [0] 0 = timeout; 1 = no timeout | |
| ★33 | ALARM BELL TIMEOUT | <input type="text"/> † [1] 0 = none; 1=4 min; 2=8 min; 3=12 min; 4 = 16 min; UL installations = 1 (4 min) minimum | |

† Entry of a number other than one specified will give unpredictable results.

- ★43 PRIMARY SUBS ACCT # See note on previous page
- ★44 SECONDARY SUBS ACCT # See note on previous page
- ★47 PHONE SYSTEM SELECT † [1]
 If Cent. Sta. *IS NOT* on a WATS line: 0 = Pulse Dial; 1 = Tone
 Dial; if Cent. Sta. *IS* on a WATS line: 2 = Pulse Dial ; 3 = Tone
- ★48 REPORT FORMAT for PRIM./SEC. [7, 0]
 Primary Secondary
 0 = 3+1, 4+1 ADEMCO L/S STANDARD **6 or undefined** = 4+2 ADEMCO EXPRESS
 1 = 3+1, 4+1 RADIONICS STANDARD 7 = ADEMCO CONTACT ID REPORTING
 2 = 4+2 ADEMCO L/S STANDARD 8 = 3+1, 4+1 ADEMCO L/S EXPANDED
 3 = 4+2 RADIONICS STANDARD 9 = 3+1, 4+1 RADIONICS EXPANDED

- ★49 SPLIT/DUAL REPORTING [0]
 0 = Disable (Backup report only)

| | |
|--|---|
| <p>TO PRIMARY PHONE No.</p> <p>1 = Alarms, Restore, Cancel 2 = All except Open/Close, Test 3 = Alarms, Restore, Cancel 4 = All except Open/Close, Test 5 = All TO PRIMARY PHONE No. 6 = All except Open/Close 7 = All reports 8 = All reports 9 = All except Open/Close</p> | <p>TO SECONDARY PHONE No.</p> <p>Others Open/Close, Test All All All</p> <p>TO PAGING** No. (Secondary)</p> <p>Alarms, Open/Close[†], Troubles Alarms, Troubles Alarms, Open/Close[†], Troubles Open/Close[†]</p> |
|--|---|

** Pager Message
 A 7-digit code (plus optional 16-digit prefix) is sent to the pager consisting of a 3-digit event code, followed by 00 and a 2-digit user or zone number. See Installation Instructions for an explanation of the pager code, which takes the following form:
 AAAAAAAAAAAAAAAAAA-EEE-00NN
 Where: AAA...= optional 16 digits (see field *88)
 EEE = 3-digit event code: 911 (alarm), 101 (open), 102 (close), 811 (trouble)
 00 = always displayed
 NN = 2-digit user number or zone number depending on type of event (EEE) that occurred

[†] Will report users 0, 5-8 or wireless arm/disarm button zones 26-33; all other zones and users do not report

- ★50 15 SEC DIALER DELAY (BURG) † [0]
 0 = no; 1 = yes; UL installations = 0
- ★51 PERIODIC TEST REPORT † [0]
 0 = none; 1 = 24 hours; 2 = weekly; 3 = 30 days (enter Test Code in field *64)
- ★52 FIRST TEST REPORT OFFSET † [2]
 0 = 24 hour; 1 = 6 hours; 2 = 12 hours; 3 = 18 hours (Time to 1st report from power up/programming or downloading).
- ★53 SESCOA/RADIONICS SELECT [0]
 0 = Radionics (0–9, B–F reporting); 1 = SESCOA (0–9 only reporting). Select 0 for all other formats.
- ★ 56 ENHANCED ZONE PROGRAMMING See procedure later in this form and refer to the Installation Guide.

† Entry of a number other than one specified will give unpredictable results.

- ★ 58 RF JAM DETECT [0]
 0 = no RF Jam Detection; 1 = RF Jam Detect on, no CS report;
 2 = RF Jam Detect on with CS report (if trouble/restore report is enabled in fields *60, *71)
 Note: This feature can not be used in conjunction with the 5827 wireless keypad.

TO PROGRAM SYSTEM STATUS, & RESTORE REPORT CODES (*59-*76, & *89):

With a 3+1 or 4+1 Standard Format: Enter a code in the *first* box: 1-9, 0, B, C, D, E, or F. Enter "#+10" for 0, "#+11" for B, "#+12" for C, "#+13" for D, "#+14" for E, "#+15" for F.

A "0" (not "#+10") in the *first* box will disable a report.

A "0" (not "#+10") in the *second* box will result in automatic advance to the next field when programming.

With an Expanded or 4+2 Format: Enter codes in *both* boxes (1st and 2nd digits) for 1-9, 0, or B-F, as described above.

A "0" (not "#+10") in the *second* box will eliminate the expanded message for that report.

A "0" (not "#+10") in *both* boxes will disable the report.

With Ademco Contact ID Reporting: Enter any digit (other than "0") in the *first* box, to enable zone to report (entries in the *second* boxes will be ignored).

A "0" (not "#+10") in the *first* box will disable the report.

Examples: For Code **3** (single digit), enter: |

For Code **3 2** (two digits), enter: |

For Code **B 2** (Hexadecimal), enter: |

SYSTEM STATUS REPORT CODES (*59-*68)

Field Function **Programmed Values** [] = Table 1 Default Value

| | | | |
|------------|-----------------------------|---|---|
| *59 | EXIT ERROR REPORT CODE | <input type="text"/> [1] | 2nd digit is automatically sent as 2nd digit of the zone alarm report code programmed in *56, if expanded or 4+2 reporting is selected. |
| *60 | TROUBLE REPORT CODE | <input type="text"/> <input type="text"/> [1,0] | |
| *61 | BYPASS REPORT CODE | <input type="text"/> <input type="text"/> [0,0] | |
| *62 | AC LOSS REPORT CODE | <input type="text"/> <input type="text"/> [0,0] | |
| *63 | LOW BAT REPORT CODE | <input type="text"/> <input type="text"/> [1,0] | |
| *64 | TEST REPORT CODE | <input type="text"/> <input type="text"/> [1,0] | |
| *65 | OPEN REPORT CODE | <input type="text"/> †† [0] | (†† 2nd digit is automatically sent as the user number if expanded or 4+2 reporting is selected.) |
| *66 | ARM AWAY/STAY RPT CODE | <input type="text"/> <input type="text"/> †† [0,0] AWAY STAY | |
| *67 | RF XMTR LOW BAT REPORT CODE | <input type="text"/> <input type="text"/> [1,0] | |
| *68 | CANCEL REPORT CODE | <input type="text"/> <input type="text"/> [1,0] | |

RESTORE REPORT CODES (*70-*76)

| | | | |
|------------|-----------------------------|---|---|
| *70 | ALARM RESTORE RPT CODE | <input type="text"/> [1] | 2nd digit is automatically sent as 2nd digit of the zone alarm report code programmed in *56, if expanded or 4+2 reporting is selected. |
| *71 | TROUBLE RESTORE RPT CODE | <input type="text"/> <input type="text"/> [1,0] | |
| *72 | BYPASS RESTORE RPT CODE | <input type="text"/> <input type="text"/> [0,0] | |
| *73 | AC RESTORE RPT CODE | <input type="text"/> <input type="text"/> [0,0] | |
| *74 | LOW BAT RESTORE RPT CODE | <input type="text"/> <input type="text"/> [1,0] | |
| *75 | RF XMTR LO BAT RST RPT CODE | <input type="text"/> <input type="text"/> [1,0] | |
| *76 | TEST RESTORE RPT CODE | <input type="text"/> <input type="text"/> [0,0] | |

OUTPUT AND SYSTEM SETUP (*80-*92)

| | | |
|------------|---------------------------------|--|
| *80 | DEVICE PROGRAMMING MENU MODE | Program *80 and *81 only if Powerline Carrier Devices or chime by zone are to be used. See procedure later in this manual. |
| *81 | ZONE LISTS MENU MODE | |
| *83 | ENHANCED SEQUENTIAL MODE | See procedure later in this manual. |
| *84 | ASSIGN ZONE VOICE DESCRIPTORS | See procedure later in this manual. |
| *85 | RECORD CUSTOM VOICE DESCRIPTORS | See procedure later in this manual. |

| Field | Function | Programmed Values[] = Table 1 Default Value |
|---|---|--|
| *87 | AUX FUNCTION/ 1-BUTTON PAGING | <input type="checkbox"/> [0] 0 = Aux key performs defined function (macro); 1 = Aux key sends message (999-9999) to pager; If 1, you must also select an option 6-9 in field *49. |
| * 88 | PAGER CHARACTERS | <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> Up to 16 digits can be entered that will appear in front of the 7-digit pager message sent by the control (either upon system event or upon pressing AUX key [if programmed for paging]; see field *87 and *49 for other options regarding the paging feature). See the Installation Instructions (fields *87, *88 and *49) for full descriptions of the paging feature. You do not need to fill all 16 digits (press [*] to advance to next field). To clear entries, enter *88*. To enter "*" = [#] + [11]; To enter "#" = [#] + [12] To enter 2-second pause = [#] + [13] (some pagers require an additional delay [pause] in order to receive the entire message) |
| *89 | EVENT LOG 80% FULL RPT CODE | <input type="checkbox"/> <input type="checkbox"/> [0,0] |
| *90 | EVENT LOGGING | <input type="checkbox"/> [3] 0 = None; 1 = Alarm/Alarm Restore; 2 = Trouble/Trouble Restore; 4 = Bypass/Bypass Restore; 8 = Open/Close. <i>Example:</i> To select "Alarm/Alarm Restore", and "Open/Close", enter 9 (1 + 8); To select all, enter #15. Note: System messages are logged when any non-zero selection is made. |
| *91 | LONG RANGE RADIO/ALARM AUDIO VERIFICATION TRIGGER | <input type="checkbox"/> [0] 0 = Long Range Radio Trigger; 4 = Alarm Audio Verification. Notes: If long range radio is selected, trigger output will generate a steady signal for burglar alarm (3 to 4-second single pulse for all types of silent alarms) or a temporal signal for fire alarm. (Refer to Long Range Radio Installation Instructions for appropriate wiring. Burglary zone input reporting delay should be set to 2-seconds.) Audio Alarm Verification cannot be used for UL installations. Audio Alarm Verification will only function when Contact ID is selected. |
| *92 | No. OF REPORTS IN ARMED PERIOD | <input type="checkbox"/> [0] 0 = 10 Alarm/Alarm Restore Reports; 1 = Unlimited. UL installations = 1 |
| DOWNLOAD INFORMATION (*93,*94,*95) | | |
| *93 | FLEXIBLE CALLBACK | <input type="checkbox"/> [0] 0 = No flexible callback; 1 = Last digit flexible; 2 = Last 2 digits flexible; 3 = Last 3 digits flexible |
| *94 | DOWNLOAD PHONE No. | <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> Enter up to 20 digits, 0-9; #+11 for '*'; #+12 for '#'; #+13 for a pause. Do not fill unused spaces. If fewer than 20 digits entered, pressing * advances to the next field. To clear entries from field, press *94*. Note: In UL installations, downloading may only be performed if a technician is at the site. |
| *95 | RING DETECT COUNT FOR DOWNLOADING | <input type="checkbox"/> [0] 0 = Disable Station Initiated Download; 1-14 = number of rings (1-9, [#] +10 =10, [#] +11 =11, [#] +12 =12, [#] +13 =13, [#] +14 =14); 15 = answering machine defeat ([#] +15 =15) |
| *96 | INITIALIZES DOWNLOAD ID, SUBSCRIBER ACCOUNT No. FOR INITIAL DOWNLOAD: No entry required. | |
| *97 | SELECT 1 OF 4 DEFAULT OPTION SETUPS. Enter 1-4 to select from default tables 1-4. Enter 0 to abort. | |

- ★98 EXITS PROGRAMMING MODE AND PREVENTS RE-ENTRY by: Installer Code + 8 + 0 + 0.
If ★98 is used to exit programming mode, you must press "★" and "#" within 50 seconds of power up or from exiting Programming mode to re-enter Programming mode.
- ★99 EXITS PROGRAMMING MODE AND ALLOWS RE-ENTRY by: Installer Code + 8 + 0 + 0 or: Power-up, then press "★" and "#" within 50 seconds of power up or from exiting Programming mode.

After exiting Program mode, the system takes up to 1 minute to reset. To bypass the reset delay, press [#] + [0].

*56 ENHANCED ZONE PROGRAMMING PROCEDURE

Use this mode to program zone information. Press *56 while in programming mode.

NOTE: Entry of a number other than one specified will give unpredictable results.

A 01

ZONE NUMBER

Enter the 2-digit zone number to be programmed:

[*] = Continue

00 = exit zone programming mode;

upon exiting, the prompt "56" blinks; press

[*] + any field number to go to that field.

• Zone 1 = hard wire zone

• Zones 2-25 = RF transmitter zones

• Zone 26-41 = RF button zones

• Zone 92 = Duress

• Zone 95, 96, 99 = Panic zones

b zt

ZONE TYPE

Enter the 2-digit zone type (zt) for this zone (see table of zone types on worksheet page 13).

[*] = Continue [if 00 is entered the system will skip to DELETE ZONE PARAMETERS prompt (F)].

[#] = Return to previous prompt

C rc

REPORT CODE

Enter the report code (rc) for this zone.

Report consists of 2 hexadecimal digits, each of which consist of 2 numerical digits (A = 10, B = 11, C = 12, D = 13, E = 14, F = 15; see Report Code description on page 6 for explanation of codes).

[*] = Continue; If this is zone 1, 95, 96 or 99, the system skips to the VOICE DESCRIPTOR prompt (1C)

[#] = Return to previous prompt

d i

INPUT TYPE

Enter the input type (i) for the transmitter assigned to this zone as follows:

3 = Supervised RF (RF)

[*] = Continue

4 = Unsupervised RF (UR)

[#] = Return to previous prompt

5 = Button type (BR)

E lL

LOOP NUMBER

RF Learning - Two (2) transmissions will be required for BR type devices (device type 5). Two beeps will sound after the second transmission, confirming that the loop number and serial number have been learned.

For all other device types, four (4) transmissions are required (fault, restore and fault, restore). A single beep will sound after the second transmission confirming that the loop and serial number have been captured. Two beeps will sound after the fourth transmission confirming that the loop and serial numbers have been learned.

Note: BR type devices cannot be enrolled by using UR or RF type. Likewise, UR or RF type devices cannot be enrolled by using a BR type device. There is a 52-second time-out for RF enrolling. At the end of the time-out, the system returns to the INPUT TYPE prompt (d). If enrolled, loop number and "L" are displayed.

Manual Entry - Enter the desired loop number and press[*] to continue (see the transmitter's Installation Instructions for specific loop designations). If "L" is displayed the zone's serial number has already been enrolled.

Note: The loop number can be changed even if the zone has already been entered. Care should be taken when using this feature as it has the capability to make zones inoperable by creating a mismatch of a working serial number/loop number combination. This should be re-confirmed if the loop number is changed.

0 + [*] = to Delete Serial Number prompt (F)

[*] = Continue to the ENROLL MODE prompt (1A) if not enrolled, or VOICE DESCRIPTOR prompt (1C) if already enrolled.

[#] = Return to previous prompt

1-4 = Loop number for the zone of the transmitter being entered or learned

F

DELETE ZONE PARAMETERS

0 = Discard the delete request.

1 = Confirm the requested delete.

If 00 is entered in the zone type, confirmation of the delete request will delete all information associated with zone currently being programmed.

If 0 is entered in the loop number, confirmation of the delete request will delete the serial number associated with zone currently being programmed.

Note: 00 was entered as a zone type in prompt (b), 00 will be retained and system will advance to prompt (1C).

1A LC

ENROLL MODE

0 = Skip to the VOICE DESCRIPTOR prompt (1C). If zone type is "00," then skips to DELETE SERIAL NUMBER prompt instead.

1 = Enroll now and proceed to SERIAL NUMBER prompt (1b) (If "L" is not displayed).

2 = Copy the last serial number from the local memory buffer (If "L" is not displayed).

3 = View existing serial number. (Only if "L" is displayed).

9 = Delete existing serial number. (Only if "L" is displayed).

[*] = Advance to the VOICE DESCRIPTOR prompt (1C). This will save all zone parameters.

[#] = Return to the loop number prompt (E).

Note: "L" will be displayed only if transmitter was already learned. "C" will be displayed only after confirmation.

1b

SERIAL NUMBER

Manually enter the transmitter's 7-digit serial number (printed on the transmitter). If an incorrect digit is entered, press the [#] key to return to prompt (1A).

Note: In order for all parameters to be accepted, you must advance to prompt (1C).

When all 7 digits are entered, press the [*] key. The serial number will be copied into EEROM and the local memory buffer and "L" will be displayed.

If 30 seconds pass and no entry has been made, the system returns to prompt (1A).

1C

VOICE DESCRIPTOR

0 = Skip to next zone (A)

1 = Enter descriptor mode (existing zone descriptor will be announced, then descriptor 1 will be repeated)

1d vv

DESCRIPTOR 1

Enter [#] + 2-digit vocabulary index† number (vv) of first descriptor word for this zone.

To change the entered index number, press [#] + desired index number.

6 = accept word and advance to descriptor 2 (descriptor 2 will be announced)

8 = accept word and advance to next zone (prompt A) – zone descriptor will be announced

Press any other key to repeat the selected word

1E vv

DESCRIPTOR 2

Enter [#] + 2-digit vocabulary index† number (vv) of second descriptor word for this zone.

To change the entered index number, press [#] + desired index number.

6 = accept word and advance to descriptor 3 (descriptor 3 will be announced)

8 = accept word and advance to next zone (prompt A) – zone descriptor will be announced

Press any other key to repeat the selected word

1F vv

DESCRIPTOR 3

Enter [#] + 2-digit vocabulary index† number (vv) of third descriptor word for this zone.

To change the entered index number, press [#] + desired index number.

6 or 8 = accept word and advance to next zone (prompt A) – zone descriptor will be announced

Press any other key to repeat the selected word

† See *84 ASSIGN ZONE VOICE DESCRIPTORS section for Vocabulary Index.

***80 DEVICE PROGRAMMING**

Use this mode to program Powerline Carrier Devices or zone lists for Chime by Zone feature. Press *80 while in programming mode. **NOTE:** Entry of a number other than one specified will give unpredictable results.

80

Device Programming

0 = Exit mode, upon which this prompt blinks. Press [*] + any field number to go to that field.

1 = Enter mode

A 01

DEVICE NUMBER

Enter the 2-digit device number (01-08) to be programmed

[*] = Continue

00 = Exit Device Programming mode (displays blinking 80; enter * + desired data field or menu mode number)

b aa

DEVICE ACTION

Enter the 1-digit action, 0-3, for the device being programmed (current action is displayed).

0 = No response

3 = Pulse on and off

1 = Close for 2 seconds

[*] = Continue

2 = Close and stay closed

[#] = Return to previous prompt

C et

START EVENT TYPE (if applicable)

Enter the 1-digit start event type, 0-3, for the device being programmed.

0 = Not used

3 = Trouble

1 = Alarm

[*] = Continue

2 = Fault

[#] = Return to previous prompt

d zl

START ZONE LIST (if applicable)

Enter the 1-digit zone list number, 1-3, or 0 if not used, for the device being programmed.

[*] = Continue

[#] = Return to previous prompt

E *zt*

START ZONE TYPE (if applicable)

Enter the 2-digit start zone type for the device being programmed (see Powerline Carrier Device Worksheet for zone type/system operation codes later in this manual).

[*] = Continue

[#] = Return to previous prompt

F *zl*

STOP ZONE LIST (if applicable)

Enter the 1-digit zone list number, 1-3, or 0 if not used, for the device being programmed.

[*] = Continue

[#] = Return to previous prompt

IR *zt*

STOP ZONE TYPE (if applicable)

Enter the 2-digit stop zone type for the device being programmed (see Powerline Carrier Device Worksheet for zone type/system operation codes later in this manual).

[*] = Return to Device Number prompt (A)

[#] = Return to previous prompt

*81 ZONE LISTS

Use this mode to define zone lists for Powerline Carrier Devices and/or for the chime by zone feature. Press *81 while in programming mode. **NOTE:** Entry of a number other than one specified will give unpredictable results.

81

ZONE LIST PROGRAMMING

0 = Exit mode, upon which this prompt blinks. Press [*] + any field number to go to that field.

1 = Enter mode

A *01*

ZONE LIST NUMBER

Enter the 2-digit zone list number (01-03) to be programmed (use zone list 03 for chime by zone feature).

[*] = Continue

00 = Exit mode (displays blinking 81; enter * + desired data field or menu mode number)

b *zz*

ZONE ENTRY TO LIST

Enter the 2-digit zone number (zz) to be added to this zone list.

[*] = Accept zone number and enter the next zone number

00 = Accept zone number and continue to next prompt

C

DELETE ENTIRE ZONE LIST?

0 = Don't delete; continue to next prompt

1 = Delete the current zone list

d

DELETE SPECIFIC ZONES FROM LIST?

0 = Don't delete; continue to next zone list number (prompt A 01)

1 = Continue to delete zones prompt

E

DELETE ZONES

Enter the 2-digit zone number to be deleted from the current zone list

[*] = Delete zone and enter next zone to be deleted

00 = Return to next zone list number (prompt A 01)

*83 ENHANCED SEQUENTIAL MODE

Use this mode to enter transmitter serial numbers. Press *83 while in programming mode. **NOTE:** Entry of a number other than one specified will give unpredictable results.

A *01*

ZONE NUMBER

Enter the 2-digit zone number of the first transmitter to have its serial number entered.

[*] = Continue; system searches for zones not yet entered, (for zones 2 to 25 a zone type must be entered) then advances to ENROLL SERIAL NUMBER prompt (1b).

00 = Exit Sequential mode, upon which the prompt "83" blinks. Press [*] + any field number to go to that field.

1A zz

ENROLL MODE

0 = Advance to next unlearned zone.

1 = Enter now and proceed to SERIAL NUMBER prompt (1b). For 4-button keys (zones 26, 30, 34 and 38) the serial number will be learned to all four buttons.

2 = Copy the last serial number entered. If this is the first zone, no serial number will be in the buffer and the panel will emit a long tone.

3 = View existing serial number. (Only if "L" is displayed. If "L" is not displayed, panel will emit a long beep. Each digit will be displayed and the keypad will beep once for digits 1-6 and three times for last digit.

4 = Copy the 4-button key template set for zones 26 - 29 (includes all zone parameters except serial numbers). Only valid on 4-button key zones 30, 34 and 38 that do not have serial numbers learned.

(Template acceptance is indicated by two beeps after copying. A single long beep emitted when copying templates indicates the template is not valid.)

9 = Delete existing serial number. Go to the (1A) prompt. (For 4-button key zones 26, 30, 34 and 38, deletes all four at once.)

[*] = Advance to the next unlearned zone.

[#] = Return to previous prompt (1A).

1A LC

SERIAL NUMBER

This prompt can be used to enroll the transmitter serial number via RF transmission or manually.

RF Learning - Two (2) transmissions will be required for BR type or four (4) transmissions (fault, restore and fault, restore) for UR or RF type. BR type devices can be enrolled only by transmission from BR devices. Likewise, UR and RF devices can only be enrolled by transmission from a UR or RF device.

If the loop number captured by RF transmission and that entered in *56 mode match, the system will return to Prompt (1A) and "LC" will be displayed. No additional transmissions are needed for confirmation.

Manual Entry - Enter the 7-digit serial number printed on the transmitter. If you enter an incorrect digit, press the [#] key to backup to prompt (1A) and start over. When all 7 digits are entered, press the [*] key. If the serial and loop number combination is already present in the system, or if less than 7 digits are entered, the keypad will emit a single long beep and return to the (1A) prompt with displaying the "L".

If more than 7 digits have been entered, the first 6 digits will be saved along with the last digit that was entered (entering 123456789 yields the serial number 1234569).

Note: If 52 seconds passes and no entry has been made, the system returns to prompt (1A).

1b zz

1b

F

DELETE ZONE PARAMETERS CONFIRMATION

0 = Discard the delete request.

1 = Confirm requested delete.

*84 ASSIGN ZONE VOICE DESCRIPTORS

Use this mode to assign voice descriptors for each zone. These are the descriptors that are announced when the system announces any event involving a zone number. Press *84 while in programming mode. **NOTE:** Entry of a number other than one specified will give unpredictable results.

84

ASSIGN ZONE VOICE DESCRIPTORS

0 = Exit mode, upon which this prompt blinks. Press [*] + any field number to go to that field.

1 = Enter mode

A zz

ZONE NUMBER

Enter the 2-digit zone number (zz) for which this descriptor is being assigned.

[*] = Continue to next prompt (existing descriptors will be announced, then descriptor 1 will be repeated.)

00 = Exit Zone Voice Descriptor mode (displays blinking 84; enter * + desired data field or menu mode number)

b vv

DESCRIPTOR 1

Enter [#] + 2-digit vocabulary index number of first descriptor word for this zone.

To change the entered index number, press [#] + desired index number.

6 = accept word and advance to descriptor 2 (descriptor 2 will be announced)

8 = accept word and advance to next zone (prompt A....zz) – zone descriptor will be announced

Press any other key to repeat the selected word

c vv

DESCRIPTOR 2

Enter [#] + 2-digit vocabulary index number of second descriptor word for this zone.

To change the entered index number, press [#] + desired index number.

6 = accept word and advance to descriptor 3 (descriptor 3 will be announced)

8 = accept word and advance to next zone (prompt A....zz) – zone descriptor will be announced

Press any other key to repeat the selected word

d vv

DESCRIPTOR 3

Enter [#] + 2-digit vocabulary index number of third descriptor word for this zone.

To change the entered index number, press [#] + desired index number.

6 or 8 = accept word and advance to next zone (prompt A....zz) – zone descriptor will be announced

Press any other key to repeat the selected word

VOCABULARY INDEX

| | | | |
|----------------|------------|------------|---------------------------------------|
| 00 ½ sec pause | F | M | U |
| 01 ALARM | 14 FIRE | 25 MAIN | 40 UPSTAIRS |
| 02 ATTIC | 15 FLOOR | 26 MASTER | 41 UTILITY |
| | 16 FRONT | 27 MESSAGE | W |
| | G | 28 MOTION | 42 WINDOW |
| 03 BABY | 17 GARAGE | O | Y |
| 04 BACK | 18 GUN | 29 OFFICE | 43 YARD |
| 05 BASEMENT | H | P | Z |
| 06 BATHROOM | 19 HALL | 30 PATIO | 44 ZONES |
| 07 BEDROOM | I | 31 POOL | 45 1 ST |
| | 20 INSIDE | R | 46 2 ND |
| 08 CHECK | K | 32 ROOM | 47 3 RD |
| | 21 KITCHEN | S | 70 Custom Word #1 |
| 09 DEN | L | 33 SHED | 71 Custom Word #2 |
| 10 DETECTOR | 22 LAUNDRY | 34 SHOP | 72 Custom Word #3 |
| 11 DINING | 23 LIBRARY | 35 SIDE | 73 Custom Word #4 |
| 12 DOOR | 24 LIVING | 36 SLIDING | 74 Custom Word #5 |
| | | 37 SMOKE | 99 Blank |
| 13 EMERGENCY | | 38 STORAGE | (to erase previously programmed word) |
| | | 39 SYSTEM | |

| |
|---|
| <p>SYSTEM WORDS (Announced by system – not programmable)</p> <p>AC LOSS ARMED AWAY BYPASSED CHIME DISARMED DISARM SYSTEM NOW EXIT NOW FAULT INSTANT LOW BATTERY NOT READY TO ARM STAY</p> |
|---|

*85 RECORD CUSTOM VOICE DESCRIPTORS

Use this mode to record up to 5 custom voice descriptors for use with zone announcements. Press *85 while in programming mode. **NOTE:** Entry of a number other than one specified will give unpredictable results.

85

RECORD CUSTOM VOICE DESCRIPTORS

0 = Exit mode, upon which this prompt blinks. Press [*] + any field number to go to that field.
 1 = Enter mode

A 7d

CUSTOM DESCRIPTOR NUMBER

Enter 7 + d + [*], where d = 0-4, each representing custom word 70, 71, 72, 73 or 74 respectively. Existing descriptor will be announced.

Press [#] to start recorder. Start speaking immediately after the third beep.

Speak the desired word clearly near the keypad microphone. Recording stops after 1.5 seconds.

6 = Accept word and ready to record next descriptor (prompt A...7d)

[#] = Re-record descriptor

00 = Exit Record mode after pressing 6 (displays blinking 85; enter * + desired data field or menu mode number)

Press any other key to repeat the recorded word.

*56 ENHANCED ZONE PROGRAMMING WORKSHEET

Fill in the required data on this worksheet, then follow the programming procedure in the Installation Instructions.

ZONES ON CONTROL: See explanation of headings on next page (defaults shown are for Table 1)

| Zone Description | Zone No. (a 01) | Zone Type (zt) | Alarm rpt code (hex) (rc) | Vocabulary Index |
|----------------------|---|--|---|---|
| Wired Zone 1 | <input type="text" value="0"/> <input type="text" value="1"/> | <input type="text" value=""/> <input type="text" value=""/> [00] | <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> [00 00] | <input type="text" value=""/> <input type="text" value=""/> |
| Duress | <input type="text" value="9"/> <input type="text" value="2"/> | -- -- | <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> [01 00] | <input type="text" value=""/> <input type="text" value=""/> |
| Keypad Panic (1 & *) | <input type="text" value="9"/> <input type="text" value="5"/> | <input type="text" value=""/> <input type="text" value=""/> [00] | <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> [00 00] | <input type="text" value=""/> <input type="text" value=""/> |
| Keypad Panic (3 & #) | <input type="text" value="9"/> <input type="text" value="6"/> | <input type="text" value=""/> <input type="text" value=""/> [00] | <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> [00 00] | <input type="text" value=""/> <input type="text" value=""/> |
| Keypad Panic (* & #) | <input type="text" value="9"/> <input type="text" value="9"/> | <input type="text" value=""/> <input type="text" value=""/> [06] | <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> [01 00] | <input type="text" value=""/> <input type="text" value=""/> |

Note: Zone 1 cannot be used as a fire zone.

| Zone No. (A 01) | Zone Type (zt) | Alarm Report Code in hex (rc) | Input Type (I) | Loop No. (I) | Transmitter Serial Number | Vocabulary Index |
|---------------------------------|--|---|-----------------------------------|-----------------------------------|-------------------------------|--|
| <input type="text" value="02"/> | <input type="text" value=""/> <input type="text" value=""/> [01] | <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> [01 00] | <input type="text" value=""/> [3] | <input type="text" value=""/> [2] | <input type="text" value=""/> | <input type="text" value=""/> <input type="text" value=""/> [16-12-99] |
| <input type="text" value="03"/> | <input type="text" value=""/> <input type="text" value=""/> [01] | <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> [01 00] | <input type="text" value=""/> [3] | <input type="text" value=""/> [2] | <input type="text" value=""/> | <input type="text" value=""/> <input type="text" value=""/> [04-12-99] |
| <input type="text" value="04"/> | <input type="text" value=""/> <input type="text" value=""/> [03] | <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> [01 00] | <input type="text" value=""/> [3] | <input type="text" value=""/> [2] | <input type="text" value=""/> | <input type="text" value=""/> <input type="text" value=""/> [42-99-99] |
| <input type="text" value="05"/> | <input type="text" value=""/> <input type="text" value=""/> [10] | <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> [01 00] | <input type="text" value=""/> [3] | <input type="text" value=""/> [1] | <input type="text" value=""/> | <input type="text" value=""/> <input type="text" value=""/> [28-10-99] |
| <input type="text" value="06"/> | <input type="text" value=""/> <input type="text" value=""/> | <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> | <input type="text" value=""/> | <input type="text" value=""/> | <input type="text" value=""/> | <input type="text" value=""/> <input type="text" value=""/> |
| <input type="text" value="07"/> | <input type="text" value=""/> <input type="text" value=""/> | <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> | <input type="text" value=""/> | <input type="text" value=""/> | <input type="text" value=""/> | <input type="text" value=""/> <input type="text" value=""/> |
| <input type="text" value="08"/> | <input type="text" value=""/> <input type="text" value=""/> | <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> | <input type="text" value=""/> | <input type="text" value=""/> | <input type="text" value=""/> | <input type="text" value=""/> <input type="text" value=""/> |

| Zone No. (A 01) | Zone Type (zt) | Alarm Report Code in hex (rc) | Input Type (I) | Loop No. (l) | Transmitter Serial Number | Vocabulary Index |
|---------------------|-------------------|----------------------------------|-------------------|-----------------|------------------------------|---------------------|
| 09 | | | | | | |
| 10 | | | | | | |
| 11 | | | | | | |
| 12 | | | | | | |
| 13 | | | | | | |
| 14 | | | | | | |
| 15 | | | | | | |
| 16 | | | | | | |
| 17 | | | | | | |
| 18 | | | | | | |
| 19 | | | | | | |
| 20 | | | | | | |
| 21 | | | | | | |
| 22 | | | | | | |
| 23 | | | | | | |
| 24 | | | | | | |
| 25 | | | | | | |
| Button Zones | | | | | | |
| 26 | [21] | [01 00] | [5] | [3] | | |
| 27 | [22] | [01 00] | [5] | [2] | | |
| 28 | [20] | [01 00] | [5] | [4] | | |
| 29 | [23] | [00 00] | [5] | [1] | | |
| 30 | [21] | [01 00] | [5] | [3] | | |
| 31 | [22] | [01 00] | [5] | [2] | | |
| 32 | [20] | [01 00] | [5] | [4] | | |
| 33 | [23] | [00 00] | [5] | [1] | | |
| 34 | | | | | | |
| 35 | | | | | | |
| 36 | | | | | | |
| 37 | | | | | | |
| 38 | | | | | | |
| 39 | | | | | | |
| 40 | | | | | | |
| 41 | | | | | | |

EXPLANATION OF ZONE ASSIGNMENT TABLE HEADINGS

- A 01 = ZONE No.** Zone Numbers are 01 (wired), 2-25 (RF), 26-41 (Button), 92 (duress), 95, 96, 99 (panic)
- zt = ZONE TYPE**
- | | | | |
|--------------------|------------------------------|-----------------------|---------------------------|
| 00 = Not Used | 04 = Interior Follower | 08 = 24 Hr Aux | 21 = Arm-Away |
| 01 = Entry/Exit #1 | 05 = Trouble Day/Alarm Night | 09 = Fire | 22 = Disarm |
| 02 = Entry/Exit #2 | 06 = 24 Hr Silent | 10 = Interior w/Delay | 23 = No Alarm Response 24 |
| 03 = Perimeter | 07 = 24 Hr Audible | 20 = Arm-Stay | = Silent Burglary |
- rc = ALARM REPORT CODE** Two Hex Digits. For each Hex Digit, enter: 00-09 for 0-9, 10 for A, 11 for B, 12 for C, 13 for D, 14 for E, 15 for F. If "00" is entered as the first digit, there will be no report for that zone.
For Contact ID reporting, this is enabling code only. Enter any hex digit (other than 00) in the first pair of boxes. The second pair of boxes is ignored.
- i = INPUT TYPE** Enter 3 for RF: Supervised RF
Enter 4 for UR: Unsupervised RF
Enter 5 for BR: Button Type RF
- I = LOOP NUMBER** Used with 5800 RF Loop Input Devices. Record transmitter loop number. Entries are 1-4, depending on device being used. Refer to the transmitter's instructions for appropriate loop numbers.

POWERLINE CARRIER DEVICES WORKSHEET FOR *80, and *81.

Applicable only if Powerline Carrier Devices are to be used, or chime-by-zone feature is used.

UL Powerline Carrier Devices are not UL Listed for fire or burglary functions and are intended for home automation.

*80 OUTPUT DEVICES

Fill in the required data on the worksheet on below and follow the programming procedure in the Installation Instructions as you enter the data during the displays and prompts that appear in sequence.

Note: Field *25 must be programmed with a House Code.

| DEVICE NUMBER | ACTION (aa) | S T A R T either or both | | | S T O P either or both | |
|--------------------|-------------|-----------------------------|----------------|------------------------------|---------------------------|-------------------------------|
| | | EVENT TYPE (et) | ZONE LIST (zl) | ZONE TYPE SYS OPERATION (zt) | RESTORE ZONE LIST (zl) | ZONE TYPE/ SYS OPERATION (zt) |
| P.L.C.D.*† 01 | | | | | | |
| P.L.C.D.*† 02 | | | | | | |
| P.L.C.D.*† 03 | | | | | | |
| P.L.C.D.* 04 | | | | | | |
| P.L.C.D.* †05 | | | | | | |
| P.L.C.D.*† 06 | | | | | | |
| SYS. P.L.C.D.*† 07 | | | | | | |
| SYS. P.L.C.D.*† 08 | [2] | | | [33] | | [36] |

* P.L.C.D. = Powerline Carrier Device (X-10).

Note: If using an X-10 Powerhouse Security SH10A Siren as device 8, you must change the action default to "3" if using default table 4.

Where: **A = DEVICE ACTION** 0 = No Response; 1 = Close for 2 sec; 2 = Close and stay closed; 3 = Pulse on and off.

ET = EVENT TYPE 0 = Not used; 1 = Alarm; 2 = Fault; 3 = Trouble.

ZL = ZONE LIST 1, 2, or 3 (from Field *81) or 0 = Not Used.

"START" ZONE LIST: Upon alarm, fault, or trouble of ANY zone on this list, device action will START.

"STOP" RESTORE of ZONE LIST: Upon restore of ALL zones on this list, device action will STOP.

It need not be same list as used for START.

NOTE: Do not assign zones with types 20, 21, or 22 to a zone list.

ZT = ZONE TYPE/SYSTEM OPERATION Choices for Zone Types are:

- | | | |
|-------------------|------------------------------|-----------------------|
| 00 = Not Used | 04 = Interior Follower | 08 = 24 Hr Aux |
| 01 = Entry/Exit#1 | 05 = Trouble Day/Alarm Night | 09 = Fire Zone |
| 02 = Entry/Exit#2 | 06 = 24 Hr Silent | 10 = Interior w/Delay |
| 03 = Perimeter | 07 = 24 Hr Audible | 24 = Silent Burglary |

Note: Any zone in "ZT" going into alarm, fault, or trouble will activate device. Any zone that restores will stop device action.

Choices for System Operation are:

- | | | | |
|-----------------------------|-------------------------------|----------------------------|--|
| 20 = Arming-Stay | 32 = Start of Entry Time | 39 = Any Fire Alarm | 52 = Kissoff |
| 21 = Arming-Away | 33 = Any Alarm (except ZT=08) | 40 = Bypassing | 58 = Duress |
| 22 = Disarming (Code + OFF) | 36 = *At Bell Timeout | 42 = System Battery Low | * Or at Disarming, whichever occurs earlier. |
| 31 = End of Exit Time | 38 = Chime | 43 = Communication Failure | |

Note: In normal operation mode:
 For Devices 1-6: Function + Lights On + N For Devices 7 and 8: Code + Function + 4 + N N = device (unit) number (Entry **starts** Device N)
 Function + Lights Off + N Code + Function + 7 + N (Entry **stops** Device N)




K5482 7/00

165 Eileen Way, Syosset, New York 11791
 Copyright © 2000 PITTSWAY CORPORATION



LYNXRL YNXR24 SUMMARY OF CONNECTIONS



THIS EQUIPMENT SHOULD BE INSTALLED IN ACCORDANCE WITH THE NATIONAL FIRE PROTECTION ASSOCIATION'S STANDARD 72, CHAPTER 2 (NATIONAL FIRE PROTECTION ASSOC., BATTERYMARCH PARK, QUINICY, MA 02269). PRINTED INFORMATION DESCRIBING PROPER INSTALLATION, EVACUATION PLANNING AND REPAIR SERVICE IS TO BE PROVIDED WITH THIS EQUIPMENT.

THIS DEVICE COMPLIES WITH PART 15 OF FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIREDD OPERATION.

LYNXR IS EQUIPPED WITH AN INTEGRAL RECHARGABLE BATTERY PACK P/N LYNXRCHKIT-SC. REPLACE EVERY FOUR YEARS.

LYNXR24 IS EQUIPPED WITH AN INTEGRAL RECHARGABLE BATTERY PACK P/N LYNXRCHKIT-HC. REPLACE EVERY FOUR YEARS.