

Name:

Business:

Vista15PSIA-6 PROGRAMMING FORM

Local programming requires the use of a 2-line Alpha keypad connected to partition 1 keypad terminals on the control.

NOTE: For UL installations, the system may be configured as a single partition only.

Field Function Programmed Values [] = Default Value

SYSTEM SETUP (*20-*29)

*20	INSTALLER CODE	<input type="text" value="4"/> <input type="text" value="1"/> <input type="text" value="1"/> <input type="text" value="2"/>	[4112] 4 digits, 0-9
*21	QUICK ARM ENABLE	<input type="text" value="0"/>	[0] 0 = No; 1 = Yes
*22	RF JAM OPTION	<input type="text" value="0"/>	[0] 0 = No RF Jam; 1 = Rf Jam Enabled
*23	FORCED BYPASS	<input type="text" value="0"/>	[0] 0 = None; 1 = Bypass Open Zones (0 for UL installations)
*24	RF HOUSE ID CODE	<input type="text" value="00"/>	[00] 00 = Disable all wireless touchpad usage 01-31 = using 5827 or 5827BD touchpad
*26	CHIME BY ZONE	<input type="text" value="0"/>	[0] 0 = No; 1 = Yes (program zones to chime on zone list 3)
*27	X-10 HOUSE CODE	<input type="text" value="0"/>	[0] 0 = A; 1 = B; 2 = C; 3 = D; 4 = E; 5 = F; 6 = G; 7 = H; 8 = I; 9 = J; #10 = K; #11 = L; #12 = M; #13 = N; #14 = O; #15 = P
*28	PHONE MODULE ACCESS CODE	<input type="text" value="0"/> <input type="text" value="0"/>	[0,0] 1st digit: enter 1-9; 2nd digit: enter #+11 for "**", or #+12 for "#". 0 = Disable code
*29	OUTPUT TO LONG RANGE RADIO	<input type="text" value="0"/>	[0] 0 = Disable; 1 = Enable (0 for UL installations).

ZONES SOUNDS AND TIMING (*31-*38)

*31	SINGLE ALARM SOUNDING/ZONE	<input type="text" value="0"/>	[0] 0 = No; 1 = Yes; 0 for UL installations
*32	FIRE ALARM SOUNDER TIMEOUT	<input type="text" value="0"/>	[0] 0 = Timeout; 1 = No Timeout;
*33	ALARM BELL TIMEOUT	<input type="text" value="1"/>	[1] 0 = None; 1 = 4 min; 2 = 8 min; 3 = 12 min; 4 = 16 min; 1 (4 min) minimum for UL.
*34	EXIT DELAY	<input type="text" value="60"/>	[60,60] 45-96 = 45-96 sec; 97 = 120 sec; SIA Installations: minimum exit delay = 45 sec. Common zones use same delay as partition 1.
*35	ZONE TYPE 01 ENTRY DELAY	<input type="text" value="30"/>	[30,30] 30-96 = 30-96 sec; 97 = 120 sec; 98 = 180 sec; 99 = 240 sec SIA Installations: minimum entry delay = 30 sec. Common zones use same delay as partition 1. For UL Residential Burglary Alarm installations, must be set for a max of 30 sec; entry delay plus dial delay should not exceed 1 min. For UL Commercial Burglar Alarm, total entry delay may not exceed 45 sec.
*36	ZONE TYPE 02 ENTRY DELAY	<input type="text" value="30"/>	See *35 Entry Delay 1 above for entries.
*38	CONFIRMATION OF ARMING DING	<input type="text" value="0"/>	[0] 0 = No; 1 = Yes; (wired Keypads and RF) 2 = yes, RF only

Entry of a number other than one specified will give unpredictable results.

DIALER PROGRAMMING (*40-*42)

In fields *40, *41, *42 enter up to the number of digits shown. Do not fill unused spaces.
Enter 0-9; #+11 for "**"; #+12 for "#"; #+13 for a 2-second pause (represented as a comma).

*40	PABX ACCESS CODE	<input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/>	[] Enter 6 digits. If fewer than 6 digits, then exit by pressing *. To clear entries from field, press Q40Q. If call waiting is used, enter call waiting disable digit enter *(#+11)+7+0+(#+13 for pause) and set call waiting disable option in *91.
*41	PRIMARY PHONE NUMBER	<input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/>	[] Enter up to 20 digits; Do not fill unused spaces. If fewer than 20 digits are entered, exit by pressing * and next desired field number. To clear entries from field, press *41*.
*42	SECONDARY PHONE NUMBER	<input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/>	[] Enter up to 20 digits; Do not fill unused spaces. If fewer than 20 digits are entered, exit by pressing * and next desired field number. To clear entries from field, press *42*.

Name:

Business:

For fields *43-*44:
 Enter 0-9; #+11 for B; #+12 for C; #+13 for D; #+14 for E; #+15 for F. Enter * as the 4th digit. If only 3 digits used, exit by pressing "" (and press next field).
 To clear entries from field, press *43* or *44*. Examples:
 For Acct. **1234**, enter:

1	2	3	4
---	---	---	---

 For Acct. **B234**, enter:

#+11	2	3	4
------	---	---	---

 For Acct. **123**, enter:

1	2	3	*
---	---	---	---

Field	Function	Programmed Values	[] = Default Value										
*43	PRIMARY SUBSCRIBER ACCOUNT NUMBER	<table border="1" style="display: inline-table;"><tr><td>9</td><td>9</td><td>9</td><td>9</td><td></td><td></td><td></td><td></td><td></td><td></td></tr></table> [FFFFFFFF] See box above	9	9	9	9							
9	9	9	9										
*44	SECONDARY SUBSCRIBER ACCOUNT NUMBER	<table border="1" style="display: inline-table;"><tr><td>F</td><td>F</td><td>F</td><td>F</td><td>F</td><td>F</td><td>F</td><td>F</td><td>F</td><td>F</td></tr></table> [FFFFFFFF] See box above	F	F	F	F	F	F	F	F	F	F	
F	F	F	F	F	F	F	F	F	F				
*47	PHONE SYSTEM SELECT	<table border="1" style="display: inline-table;"><tr><td>1</td></tr></table>	1	[1] If Central Station <i>IS NOT</i> on a WATS line: 0 = Pulse Dial; 1 = Tone Dial; If Central Station <i>IS</i> on a WATS line: 2 = Pulse Dial; 3 = Tone Dial;									
1													
*48	REPORT FORMAT PRIMARY/SECONDARY	Primary <table border="1" style="display: inline-table;"><tr><td>7</td></tr></table> Secondary <table border="1" style="display: inline-table;"><tr><td>7</td></tr></table> [7/7]	7	7	0 = 3+1, 4+1 ADEMCO LOW SPEED STANDARD 1 = 3+1, 4+1 RADIONICS STANDARD 2 = 4+2 ADEMCO LOW SPEED STANDARD 3 = 4+2 RADIONICS STANDARD 5 = 10-Digit CONTACT ID REPORT 6 = 4+2 ADEMCO EXPRESS 7 = 4-Digit CONTACT ID REPORT 8 = 3+1, 4+1 ADEMCO LOW SPEED EXPANDED 9 = 3+1, 4+1 RADIONICS EXPANDED								
7													
7													
*49	SPLIT/DUAL REPORTING	<table border="1" style="display: inline-table;"><tr><td>0</td></tr></table>	0	[0] 0 = Disable (Backup report only) TO PRIMARY PHONE No. 1 = Alarms, Restore, Cancel 2 = All except Open/Close, Test 3 = Alarms, Restore, Cancel 4 = All except Open/Close, Test 5 = All SECONDARY PHONE No. Others Open/Close, Test All All All									
0													
*50	BURGLARY DIAL DELAY	Digit 1 <table border="1" style="display: inline-table;"><tr><td>2</td></tr></table> Digit 2 <table border="1" style="display: inline-table;"><tr><td>0</td></tr></table>	2	0	[2,0] Digit 1 :Burglary Dial Delay 1 = 15 sec [2 = 30 sec] 3 = 45 sec SIA Installation: delay must be min. of 30 sec. Digit 2 :Dialer Delay Override for zone list 6 Zones 0=No delay disable; 1=Dial delay disable for zones listed in zone list 6 use zone list 6 to enter zones that require dial delay to be ignored UL: Dial delay plus entry delay must not exceed one minute;								
2													
0													
*53	SESCOA/RADIONICS SELECT	<table border="1" style="display: inline-table;"><tr><td>0</td></tr></table>	0	[0] 0 = Radionics (0-9, B-F reporting); 1 = SESCOA (0-9 only reporting)									
0													
54	DYNAMIC SIGNALING DELAY	<table border="1" style="display: inline-table;"><tr><td>0</td></tr></table>	0	[0] Delay selectable from 0 to 225 sec in 15-sec increments. 1 = 15 sec; 2 = 30 sec; etc. Enter 0 for UL installations.									
0													
55	DYNAMIC SIGNALING PRIORITY	<table border="1" style="display: inline-table;"><tr><td>0</td></tr></table>	0	[0] 0 = Primary Dialer first; 1 = Long Range Radio first. * See "Data Field Descriptions" in Installation manual for details.									
0													

Entry of a number other than one specified will give unpredictable results.

Note: 1.The following only applies if Option *29 = 1 (IP/GSM enabled). Also, AAV will only occur if enabled.
 2.If an AVS is installed, and the Dynamic signaling priority = 1, then a voice capable device must be used on that channel.

*54	*55	CS transmissions path(s)	Path to establish AAV session with AVS
0	0	Both(Phone and IP/GSM)	Phone
0	1	Both(Phone and IP/GSM)	GSMV
1-15	0	Phone Primary, with IP/GSM backup reporting	Phone
1-15	1	IP/GSM Primary, with Phone backup reporting	GSMV

Name: **OUTPUT RELAYS/POWERLINE CARRIER DEVICES WORKSHEET FOR *79, *80, and *81.**
Business:
Applicable on if Relays and/or Powerline Carrier Devices are to be used.

***79 RELAYS & POWERLINE CARRIER DEVICE MAPPING**

Output #	X-10/Relay	Device Addr	Unit Code	Position Number	Output #	X-10/Relay	Device Addr	Unit Code	Position Number
1	Relay	N/A	N/A	N/A	5	Relay	N/A	N/A	N/A
2	Relay	N/A	N/A	N/A	6	Relay	N/A	N/A	N/A
3	Relay	N/A	N/A	N/A	7	Relay	N/A	N/A	N/A
4	Relay	N/A	N/A	N/A	8	Relay	N/A	N/A	N/A

ON-BOARD TRIGGER 1

High

ON-BOARD TRIGGER 2

High

***80 OUTPUT DEFINITIONS**

Fill in the required data on the worksheet below and follow the programming procedure in the installation manual as you enter the data during the displays and prompts that appear in sequence.

- Notes:**
1. For Relays, 4229 and 4204 devices are programmed in *79, *80, and *81 modes.
 2. For powerline Carrier devices, field *27 must be programmed with a House Code.
 3. Tamperers of expansion units cannot be used to operate devices.

Output Function Number	Activated By	Zone Number	Zone List	Zone Type	Partition Number	Zone List Event	Zone Number Event	Device Action	Device Number	Device Type
1	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
2	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
3	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
4	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
5	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
6	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
7	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
8	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
9	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
10	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
11	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
12	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
13	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
14	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
15	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
16	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
17	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
18	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
19	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
20	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
21	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
22	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
23	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--
24	0 - Not Used	N/A	N/A	N/A	N/A	N/A	N/A	--	--	--

Name:

Business:

TRIG = TRIGGER TYPE: 0=Not Used; 1=Zone List; 2=Zone Type; 3=Zone Number;
ZL = ZONE LIST: 1-8 (zone lists 9-12 are reserved for paging zones)
ZT = ZONE TYPE: See Zone Type/System Operation table below
ZN = ZONE NUMBER: 1-64
A = DEVICE ACTION: 0=Off; 1=Close for 2 sec.; 2=Stay Closed; 3=1 sec On/Off;

P = PARTITION NUMBER: 1
E(ZONE LIST) = EVENT TRIGGER FOR ZONE LIST: 0=Restore; 1=Alarm; 2=Fault; 3=Trouble.
E(ZONE NUMBER) = EVENT TRIGGER FOR ZONE NUMBER: 0=Restore; 1=Alarm/Fault/Trouble.

ZONE TYPE/SYSTEM OPERATION - Choices for Zone Types are:

- 00 = Not Used, 01 = Entry/Exit#1, 02 = Entry/Exit#2, 03 = Perimeter, 04 = Interior Follower, 05 = Trouble Day/Alarm Night, 06 = 24 Hr Silent, 07 = 24 Hr Audible, 08 = 24 Hr Aux, 09 = Fire, 10 = Interior w/Delay, 12 = 24 Hr Monitor, 14 = CO ALARM, 16 = Fire w/Verification, 23 = No Alarm Response, 24 = Silent Burglary, 77 = Keypad, 81 = AAV Monitor Zone, 90-91 = Configurable

Note: Any zone in "ZT" going into alarm, fault, or trouble will activate device.

Any zone of that type that restores will stop relay action.

Choices for System Operation are:

- 20 = Arming-Stay, 21 = Arming-Away, 22 = Disarming(Code + OFF), 31 = End of Exit Time, 32 = Start of Entry Time, 33 = Any Burglary Alarm, 36 = ***At Bell Timeout***, 38 = Chime, 39 = Any Fire Alarm, 40 = Bypassing, 41 = **AC Power Failure, 42 = **System Battery Low, 43 = Communication Failure, 52 = KISSOFF, 54 = Fire Zone Reset, 58 = Duress, 60 = Audio Alarm Verification†, 61 = AVS over GSM, 62 = AVS Off, 66 = Function Key, 67 = Bell Failure, 68 = TELCO Line Fault, 78 = Keypad Red LED, 79 = Keypad Green LED

Note: In normal operation mode: Code + # + 7 + N Key Entry starts Device, Code + # + 8 + N Key Entry stops Device

**Use 3 (common) for Partition Number (P) entry
***Or at Disarming, whichever occurs earlier.
† Use *57 Menu mode to assign the function key.

*81 ZONE LISTS FOR OUTPUT DEVICES

Fill in the required data on the worksheet below and follow the procedure in the installation manual as you enter the data during the displays and prompts that appear in sequence.

Note: Record desired zone numbers below. More or fewer boxes than shown may be needed, since any list may include any or all of system's zone numbers.

Zone List 1: Started or stopped by zone numbers (enter 00 to end entries).

Grid of boxes for Zone List 1 entries

Zone List 2: Started or stopped by zone numbers (enter 00 to end entries).

Grid of boxes for Zone List 2 entries

Zone List 3: Started or stopped by zone numbers AND/OR assignment of Chime zones (enter 00 to end entries).

Grid of boxes for Zone List 3 entries

Zone List 4: Started or stopped by zone numbers AND/OR assignment of Cross zones (enter 00 to end entries).

Grid of boxes for Zone List 4 entries

Zone List 5: Started or stopped by zone numbers AND/OR assignment of Night/Stay zones (enter 00 to end entries).

Grid of boxes for Zone List 5 entries

Zone List 6: Started or stopped by zone numbers (enter 00 to end entries).Dialer Delay Override for zone list 6 Zones (see *50 for dial delay disable option.)Use zone list 6 to enter those zones that require Dialer Delay to be ignored.

Grid of boxes for Zone List 6 entries

Zone List 7: Started or stopped by zone numbers(enter 00 to end entries).Unlimited Report.(see *93 for unlimited reports option.) Use zone list 7 to enter those zones that require unlimited reporting; these zones ignore the setting in entry 1.

Grid of boxes for Zone List 7 entries

Zone List 8: Started or stopped by zone numbers (enter 00 to end entries).

Grid of boxes for Zone List 8 entries

Zone List 9: Pager 1 reporting list. All zones in this list will report to the pager independent of the report code enabled for that zone (enter 00 to end entries). Can't be used for relays.

Grid of boxes for Zone List 9 entries

Zone List 10: Pager 2 reporting list. All zones in this list will report to the pager independent of the report code enabled for that zone (enter 00 to end entries). Can't be used for relays.

Grid of boxes for Zone List 10 entries

Name:

Business:

SCHEDULING

Schedule Number	Event	Start Hour	Start Min	Start							Sa	Stop Hour	Stop Min	PM	Stop							Sa	Randomize	Partition	Repeat Option	Relay/ Access Group Number
				S	M	T	W	Th	F	S					M	T	W	Th	F							
1	0 - Clear Event	12	00								12	00									N/A	N/A	No Repeat	0		
2	0 - Clear Event	12	00								12	00									N/A	N/A	No Repeat	0		
3	0 - Clear Event	12	00								12	00									N/A	N/A	No Repeat	0		
4	0 - Clear Event	12	00								12	00									N/A	N/A	No Repeat	0		
5	0 - Clear Event	12	00								12	00									N/A	N/A	No Repeat	0		
6	0 - Clear Event	12	00								12	00									N/A	N/A	No Repeat	0		
7	0 - Clear Event	12	00								12	00									N/A	N/A	No Repeat	0		
8	0 - Clear Event	12	00								12	00									N/A	N/A	No Repeat	0		

Name:

Business:

***56 ZONE ASSIGNMENT/ALARM REPORT CODES** - This field is an interactive mode. Fill in the required data on the worksheet below (and on next page) and follow the programming procedure in the installation manual.

ZONES ON CONTROL:

See explanation of headings at top of next page →

ZONE ALPHA	ZONE NUMBER (Zn)	ZONE TYPE (ZT)	PARTITION NUMBER (P)	ALARM RPT CODE (Hex) (RC)	INPUT TYPE (IN)	RESPONSE TIME (RT)
	0 1	0 9	1	0 1 - -	0 - EOLR	350 msec
	0 2	0 1	1	0 1 - -	0 - EOLR	350 msec
	0 3	0 3	1	0 1 - -	0 - EOLR	350 msec
	0 4	0 3	1	0 1 - -	0 - EOLR	350 msec
	0 5	0 3	1	0 1 - -	0 - EOLR	350 msec
	0 6	0 3	1	0 1 - -	0 - EOLR	350 msec
	9 1	0 5	N/A	0 1 - -	-	-
	9 2	- -	N/A	0 1 - -	-	-
	9 5	0 0	N/A	0 1 - -	-	-
	9 6	0 0	N/A	0 1 - -	-	-
	9 9	0 6	N/A	0 1 - -	-	-

* Zone 1 can be used as a 2-wire Fire zone. Also, if zone 1 is used for "clean me," response time must be set to 03.

** Zone 6 can be used as a Glassbreak zone.

EXPANSION ZONES:

EXPANSION ALPHA	ZONE NUMBER (Zn)	ZONE TYPE (ZT)	ALARM RPT CODE (Hex) (RC)	PARTITION (P)	INPUT TYPE (IN)	ENTER FOR RF ONLY	
						LOOP NUMBER	SERIAL NUMBER
	0 9	--	0 1 - -	-	--	--	--
	1 0	--	0 1 - -	-	--	--	--
	1 1	--	0 1 - -	-	--	--	--
	1 2	--	0 1 - -	-	--	--	--
	1 3	--	0 1 - -	-	--	--	--
	1 4	--	0 1 - -	-	--	--	--
	1 5	--	0 1 - -	-	--	--	--
	1 6	--	0 1 - -	-	--	--	--

Name:

Business:

EXPLANATION OF ZONE ASSIGNMENT TABLE HEADINGS

Zn = ZONE No. Zone Nos. are from 01 to 6, 9 to 34, 49 to 56, 91,92,95,96,99. Some are pre-assigned.

ZT = ZONE TYPE

00 = Not Used
 01 = Entry/Exit #1
 02 = Entry/Exit #2
 03 = Perimeter
 04 = Interior Follower
 05 = Trouble Day/Alarm Night

06 = 24 Hr Silent
 07 = 24 Hr Audible
 08 = 24 Hr Aux
 09 = Fire
 10 = Interior w/Delay
 12 = 24 Hr Monitor
 14 = CO ALARM
 16 = Fire w/Verification
 20 = Arm-Stay*

21 = Arm-Away*
 22 = Disarm*
 23 = No Alarm Response
 *20,21,22, & 23 used for 5800 RF systems only
 24 = Silent Burglary
 77 = Keypress Enable
 81 = AAV Monitor Zone
 90-91 = Configurable (do not use BR input type)

DEFAULT VALUES				
Zn:	01	02	03	04
ZT:	[09]	[01]	[03]	[03]
Zn:	05	06		
ZT:	[03]	[03]		
Zn:	95	96	99	
ZT:	[00]	[00]	[06]	

P = PARTITION No.

1 Default Values for zones 01-06 = [1].

RC = ALARM REPORT CODE

To enable Contact ID reporting, enter any hex digit (other than 00) in the first pair of boxes. The second pair of boxes is ignored.

In = LOOP INPUT TYPE

HW: Hard Wire
 AW: Aux Wire (4219 or 4229)

Enter 2 for AW: Auxiliary wired
 Enter 3 for RF: Supervised RF
 Enter 4 for UR: Unsupervised RF
 Enter 5 for BR: Button Type RF

Hard wire zone input types are automatically assigned.

RT = RESPONSE TIME

0 = 10 msec; 1 = 350 msec; 2 = 700 msec; 3 = 1.2 sec; Default values for zones 01-06 = [1] (350 msec)

L = LEARNED RF INPUT

Used with 5800 RF Loop Input Devices. Record Transmitter input number.

EXPANSION ALPHA	ZONE NUMBER (Zn)	ZONE TYPE (ZT)	PARTITION NUMBER (P)	ALARM RPT CODE (Hex) (RC)	INPUT TYPE (IN)	LOOP NUMBER (L)	SERIAL NUMBER
	17	--	--	01 --	--	--	--
	18	--	--	01 --	--	--	--
	19	--	--	01 --	--	--	--
	20	--	--	01 --	--	--	--
	21	--	--	01 --	--	--	--
	22	--	--	01 --	--	--	--
	23	--	--	01 --	--	--	--
	24	--	--	01 --	--	--	--
	25	--	--	01 --	--	--	--
	26	--	--	01 --	--	--	--
	27	--	--	01 --	--	--	--
	28	--	--	01 --	--	--	--
	29	--	--	01 --	--	--	--
	30	--	--	01 --	--	--	--
	31	--	--	01 --	--	--	--
	32	--	--	01 --	--	--	--
	33	--	--	01 --	--	--	--
	34	--	--	01 --	--	--	--
	49	--	--	01 --	--	--	--
	50	--	--	01 --	--	--	--
	51	--	--	01 --	--	--	--
	52	--	--	01 --	--	--	--
	53	--	--	01 --	--	--	--
	54	--	--	01 --	--	--	--
	55	--	--	01 --	--	--	--
	56	--	--	01 --	--	--	--

Name:

Business:

PARTITIONS

Key Function Choices:

The values for index 00 defers for Key Functions A,B,C,D as shown below

Key A Zone95	Key B Zone99	Key C Zone96	Key D Single Button Paging
-----------------	-----------------	-----------------	-------------------------------

- | | |
|-------------------------|--------------------------------------|
| 01 - Single Button Page | 02 - Display Time |
| 03 - Arm Away | 04 - Arm Stay |
| 05 - Arm Night Stay | 06 - Step Arming |
| 07 - Toggle | 08 - Single Button Communicator Test |
| 09 - Macro Key 1 | 10 - Macro Key 2 |

Partition	Description	Primary Subscriber Id	Secondary Subscriber Id	Entry Delay 1	Entry Delay 2	Exit Delay	Key A Function	Key B Function	Key C Function	Key D Function	Confirmation of Arming Ding	Forced Bypass	RF House ID	Quick Arm Enable
1		9999	FFFFFFFF	30 sec	30 sec	60 sec	0	0	0	0	No			<small>00 - Disable all wireless keypads</small>

MACROS

Macro #	Macro Key
1	
2	

Name:

Business:

USERS

User Number	Access Code	User Name	Group	Authority Level	RF Zone Number	Enable Open/Close Reports	AUI Descriptor
2	1234		0	Master Authority		X	
3			0	Standard User		X	
4			0	Standard User		X	
5			0	Standard User		X	
6			0	Standard User		X	
7			0	Standard User		X	
8			0	Standard User		X	
9			0	Standard User		X	
10			0	Standard User		X	
11			0	Standard User		X	
12			0	Standard User		X	
13			0	Standard User		X	
14			0	Standard User		X	
15			0	Standard User		X	
16			0	Standard User		X	
17			0	Standard User		X	
18			0	Standard User		X	
19			0	Standard User		X	
20			0	Standard User		X	
21			0	Standard User		X	
22			0	Standard User		X	
23			0	Standard User		X	
24			0	Standard User		X	
25			0	Standard User		X	
26			0	Standard User		X	
27			0	Standard User		X	
28			0	Standard User		X	
29			0	Standard User		X	
30			0	Standard User		X	
31			0	Standard User		X	
32			0	Standard User		X	
33			0	Standard User		X	