

PROGRAMMING GUIDE



XT SERIES™ PANELS

MODEL XT30/XT50 PROGRAMMING GUIDE

When using the XT30/XT50 Series control for any listing organization's approved methods, refer to this manual and the XT30/XT50 Installation Guide. These documents outline the installation and programming requirements of all applications for which the XT30/XT50 is approved.

FCC Notice

This equipment generates and uses radio frequency energy and, if not installed and used properly in strict accordance with the manufacturer's instructions, may cause interference with radio and television reception. It has been type tested and found to comply with the limits for a Class B computing device in accordance with the specification in Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the installer is encouraged to try to correct the interference by one or more of the following measures:

- Reorient the receiving antenna
- Relocate the computer with respect to the receiver
- Move the computer away from the receiver
- Plug the computer into a different outlet so that computer and receiver are on different branch circuits

If necessary, the installer should consult the dealer or an experienced radio/television technician for additional suggestions. The installer may find the following booklet, prepared by the Federal Communications Commission, helpful:

"How to identify and Resolve Radio-TV Interference Problems."

This booklet is available from the U.S. Government Printing Office, Washington D.C. 20402

Stock No. 004-000-00345-4

© 2008 Digital Monitoring Products, Inc.

Information furnished by DMP is believed to be accurate and reliable.

This information is subject to change without notice.

TABLE OF CONTENTS

Introduction.....	1
1.1	Before You Begin1
	Programming Information Sheet1
1.2	Getting Started1
	Initializing the Panel.....1
	Program from any Keypad Address.....1
	Accessing the Programmer1
1.3	Programming Menu.....2
1.4	Programmer Lockout Codes.....2
	Installing a lockout code.....2
1.5	Reset Timeout2
1.6	Keypads3
1.7	Special Keys3
	COMMAND (CMD) Key.....3
	Back Arrow (<←) Key3
	Select Keys/Areas3
1.8	Entering Alpha Characters4
1.9	Entering Non-Alpha Characters4
1.10	Keypad Displays Current Programming5
Initialization.....	6
2.1	Initialization6
2.2	Clear All Codes6
2.3	Clear All Schedules6
2.4	Clear Events6
2.5	Clear Zone Programming6
2.6	Clear Communication6
2.7	Set to Factory Defaults.....6
Communication.....	7
3.1	Communication7
3.2	Account Number7
3.3	Transmission Delay7
3.4	Communication Type.....7
3.5	Backup Dialer7
3.6	Backup Cellular.....7
3.7	Test Time.....8
3.8	Test Days8
3.9	Check-in Minutes8
3.10	Failed Minutes8
3.11	Send Communication Trouble8
3.12	First GPRS APN.....8
3.13	Second GPRS APN8
3.14	Alarm Reports8
3.15	Supervisory/Trouble Reports.....8
3.16	Opening/Closing and User Reports.....9
3.17	First Telephone Number9
3.18	Second Telephone Number9
3.19	First IP Address9
3.20	First IP Port.....9
3.21	Second IP Address.....9
3.22	Second IP Port9
Network Options.....	10
4.1	DHCP Mode Enabled10
4.2	Local IP Address10
4.3	Gateway Address10
4.4	Subnet Mask10
4.5	DNS Server10
4.6	Programming Port.....10

TABLE OF CONTENTS

Messaging Setup	11
5.1 Messaging Setup	11
5.2 Enable Messaging	11
5.3 System Name	11
5.4 Destination 1	11
5.5 Destination 2.....	11
5.6 Destination 3.....	11
5.7 Email Communication Type.....	11
5.8 Email O/C	11
5.9 SMS O/C	11
5.10 SMTP Server	12
5.11 SMTP Server Port.....	12
5.12 SMTP Username	12
5.13 SMTP Password	12
5.14 From Email Address	12
Remote Options	13
6.1 Remote Options.....	13
6.2 Remote Key.....	13
6.3 Manufacturer Authorization	13
6.4 Armed Rings	13
6.5 Disarmed Rings	13
6.6 Alarm Receiver Authorization	13
6.7 Service Receiver Authorization	14
6.8 Remote Disarm.....	14
System Reports	15
7.1 System Reports	15
7.2 Opening/Closing Reports	15
7.3 Abort Reports	15
7.4 Zone Restoral Reports	15
7.5 Bypass Reports	15
7.6 Code Change Reports	15
7.7 Ambush	15
System Options	16
8.1 System Options	16
8.2 System	16
8.3 Closing Code	16
8.4 Closing Check.....	16
8.5 Entry Delay 1	16
8.6 Exit Delay.....	17
8.7 Cross Zone Time.....	17
8.8 Power Fail Delay	17
8.9 Reset Swinger Bypass	17
8.10 Telephone Access	17
8.11 Zone Activity Hours.....	18
8.12 Arm Activity Days	18
8.13 Time Zone Changes	18
8.14 Time Display	19
8.15 House Code.....	19
8.15.1 Detect Wireless Jamming	19
8.15.2 Wireless Audible Annunciation	19
8.16 Enable Keypad Panic Keys	19
8.17 Occupied Premise	19
Bell Options	20
9.1 Bell Options.....	20
9.2 Bell Cutoff Time.....	20
9.3 Automatic Bell Test	20

TABLE OF CONTENTS

9.4	Bell Output.....	20
9.5	Bell Action.....	20
9.5.1	Fire.....	20
9.5.2	Burglary.....	20
9.5.3	Supervisory.....	20
9.5.4	Panic.....	20
9.5.5	Emergency.....	20
9.5.6	Auxiliary 1.....	20
9.5.7	Auxiliary 2.....	20
Output Options.....		21
10.1	Output Options.....	21
10.2.1	Cutoff Outputs.....	21
10.2.2	Output Cutoff Time.....	21
10.3	Communication Failure Output.....	21
10.4	Fire Alarm Output.....	21
10.5	Fire Trouble Output.....	21
10.6	Ambush Output.....	21
10.6	Entry Output.....	22
10.7	Exit Output.....	22
10.8	Ready Output.....	22
10.9	Armed Output.....	22
10.10	Burglary Output.....	22
10.11	Late To Close Output.....	22
10.12	Arm-Alarm Output.....	22
Output Information.....		23
11.1	Output Information.....	23
11.2	Output Number.....	23
11.3	Output Name.....	23
11.4	Serial Number.....	23
11.5	Supervision Time.....	23
Area Information.....		24
12.1	Area Information.....	24
12.2	Area Number.....	24
12.3	Area Name.....	24
12.4	Automatic Arming.....	24
12.4.1	Bad Zones.....	24
12.5	Automatic Disarming.....	24
Zone Information.....		25
13.1	Zone Information.....	25
13.2	Zone Number.....	25
13.3	Key Fob.....	25
13.4	Zone Name.....	25
13.5	Zone Type.....	25
13.6	Area Assignment.....	26
13.7	Arming Zone Assignment.....	26
13.7.1	Style.....	26
13.8	Next Zone.....	27
13.9	Wireless.....	27
13.9.1	Serial Number Entry.....	27
13.9.2	Contact.....	28
13.9.3	Supervision Time.....	28
13.9.4	LED Operation.....	28
13.9.5	Next Zone.....	28
13.10	Series Key Fobs.....	29
13.10.1	Key Fob User Number.....	29
13.10.2	Key Fob Serial Number.....	29

TABLE OF CONTENTS

13.10.3	Key Fob Supervision Time	29
13.10.4	Number of Key Fob Buttons	29
13.10.5	Key Fob Button Selection (Four Buttons).....	29
13.10.6	Key Fob Button Selection (Two Buttons)	29
13.10.7	Button Action	30
13.10.8	Button Press Time	30
13.10.9	Arm/Disarm Area Selection	30
13.10.10	Output Number	30
13.10.11	Output Action	31
13.11	Alarm Action.....	31
13.12	Disarmed Open	31
13.12.1	Message To Transmit.....	32
13.12.2	Output Number	32
13.12.3	Output Action	32
13.13	Swinger Bypass	32
13.14	Prewarn Address	33
13.15	Entry Delay	33
13.16	Cross Zone	33
13.17	Priority.....	33
13.18	Zone Number	33
Stop.....	34	
14.1	Stop	34
Set Lockout Code	34	
15.1	Set Lockout Code.....	34
Appendix	35	
16.1	Status List.....	35
16.2	False Alarm Reduction.....	35
	System Recently Armed report.....	35
16.3	Diagnostics Function	35
	Cellular Status	35
	Cellular Signal	35
	Email Status.....	35
	Panel Settings	36
	MAC Address.....	36
	Serial Number	36
	Panel Number.....	36
	Firmware Version.....	36
16.4	Manual Telephone Line Seizure	36
	NBR.....	36
	PICKUP	36
16.5	Using the Walk Test	37
	Walk Test	37
	Trip Counter for Walk Test (STD)	37
	Test End Warning	37
	Failed Zones Display.....	37
16.6	Keypad Speaker Operation	38
16.7	Cross Zoning	38
16.8	Zone Type Descriptions	38
16.9	Zone Type Defaults	39
16.10	Common Keypad Messages	40
	Listings and Approvals.....	41

This page intentionally left blank.

Introduction

1.1 Before You Begin

Before starting to program, we recommend you read through the contents of this manual. The information in this document allows you to quickly learn the programming options and operational capabilities of the XT30/XT50 panel.

After this Introduction, the remaining sections describe the functions of each programming menu items along with their available options. The XT30/XT50 contains all of its programming information in an on-board processor and does not require an external programmer.

In addition to this manual, you should also be familiar with the following XT30/XT50 documents:

- XT30/XT50 Installation Guide
- XT30/XT50 User's Guide
- XT30/XT50 Programming Sheet

Programming Information Sheet

Included with each XT30/XT50 panel is the Programming Sheet. This sheet lists the various options available for programming the panel. Before starting, completely fill out the sheet with the programming options you intend to enter into the panel.

Having completed programming sheets available while entering data helps to prevent errors and can shorten the length of time you spend programming. Completed sheets also provide you with an accurate account of the panel's program you can keep on file for future system service or expansion.

The remainder of the Introduction explains starting and ending a programming session.

1.2 Getting Started



Ground Yourself Before Handling the Panel! Touch any grounded metal, such as the enclosure, before touching the panel to discharge static.

Remove All Power From the Panel! Remove all AC and Battery power from the panel before installing or connecting any modules, cards, or wires to the panel.

The XT30/XT50 panel should be completely installed before you begin programming. Make sure the panel is properly grounded, and the AC and battery wires are correctly installed.

Initializing the Panel

When programming an XT30/XT50 panel for the first time or rewriting the entire program of an existing XT30/XT50, use the **Initialization** function described in section 2. Initializing clears the panel's memory of any old data and sets the highest numbered user number to user code 99.

Program from any Keypad Address

You can program the XT30/XT50 panel from any 32-character keypad connected to the keypad data bus. See the XT30/XT50 Installation Guide for keypad addressing and installation information.

Note: Programming can not be accessed using an Icon Series keypad. Use a 32-character keypad to complete the panel programming.

Accessing the Programmer

To access the programmer function of the XT30/XT50:

1. Install the reset jumper across the two J16 reset pins for two seconds.
2. Remove the reset jumper and place it over just one pin for future use.
3. Enter the code 6653 (PROG) into a 32-character alphanumeric keypad.
4. The keypad displays: **PROGRAMMER**.

1.3 Programming Menu

You are now ready to start programming the XT30/XT50 panel. Pressing the COMMAND key scrolls you through the programming menu items listed below.

Menu Item	Section in This Manual	Menu Item	Section in This Manual
Initialization	2	Bell Options	9
Communication	3	Output Options	10
Network Options	4	Output Information	11
Messaging Setup	5	Area Information	12
Remote Options	6	Zone Information	13
System Reports	7	Stop	14
System Options	8	Set Lockout Code	15

To select a section for programming, press any Select key when the name of that section displays on the keypad. The detailed instructions for each programming step are found in sections 2 to 15 of this manual.

1.4 Programmer Lockout Codes

Although the XT30/XT50 panels allow you to access Programmer mode without a lockout code, it is recommended you program one to restrict programming access to authorized individuals only. You can do this by using SET LOCKOUT CODE at the end of the programming menu.

Installing a lockout code

1. After entering the Programmer menu, the keypad displays PROGRAMMER. Press the COMMAND key until SET LOCKOUT CODE is displayed (after STOP).
2. Press any Select key. At the ENTER CODE: - display, enter a 1- to 5-digit programmer lockout code. Press COMMAND.
3. The displays shows ENTER AGAIN. Enter the same lockout code again and press COMMAND. The display shows CODE CHANGED. The new code number must now be entered before the Programmer menu can be accessed.

The lockout code should be written down and kept in a secure place with access limited to authorized persons only.

Lost Lockout Code requires factory reset: If you lose or forget the lockout code, the panel must be sent back to the factory to be reset. There is no field option for gaining access to the panel without a valid lockout code.

1.5 Reset Timeout

The XT30/XT50 has a feature that requires you to enter the Programmer within 30 minutes of resetting the panel. After 30 minutes, if you attempt to program by entering the 6653 (PROG) code, the keypad displays: RESET PANEL. You must reset the panel and enter the program code within the next 30 minutes.

If you are already in the Programmer and do not press any keys on the programming keypad for 30 minutes, the panel terminates programming. All data entered up to that point is saved in the panel's memory.

Using the STOP function disarms all areas: To exit the panel's Programmer you must use the Stop function. The STOP option is the second to the last option in programming. The Stop function disarms all areas and clears the panel's Status List.

The programming session is then terminated and the keypad returns to the Status List.

1.6 Keypads

DMP offers multiple keypads in a variety of styles. All DMP 32-character keypads provide the same programming capabilities. Each keypad and its operation are shown and described in the following sections.

Note: Programming can not be accessed using an Icon Series keypad. Use a 32-character keypad to complete the panel programming.




Figure 1: Security Command Keypad




Figure 2: Thinline/Aqualite Keypad




Figure 3: Clear Touch Keypad




Figure 4: Icon Keypad

1.7 Special Keys

The following special keys/areas are common to all DMP keypads.

COMMAND (CMD) Key

Pressing the COMMAND key allows you to go forward through the programming menu and through each step of a programming section. As you go through the programming, the keypad display shows any current programming already stored in the panel memory. If no change is required for a prompt, press the COMMAND key to advance to the next step.

The COMMAND key is also used to enter information into the panel's memory such as phone numbers or zone names. Press the COMMAND key after entering information.

Back Arrow (←) Key

Use the Back Arrow key to back up one step while programming. The Back Arrow key is also used when an error is made while entering information. Press the Back Arrow key once to erase the last character entered.

Select Keys/Areas

The top row of keys are called the Select keys on Security Command, Thinline, and Aqualite keypads or Select Areas on Clear Touch keypads. Each time you need to press a Select key, the keypad displays the function or options above one of the keys or in the Select Area. Displaying choices above individual Select keys or in Select Areas allows them to be used for many different applications. For example, you can enter AM or PM when programming the automatic test time or answer YES or NO for a system option.

During programming, the Select keys/areas also allow you to change information currently in panel memory by pressing the appropriate Select key under or on the display. You then enter the new information using the keypad data entry digit keys.

INTRODUCTION

When there are more than four response options available, press the COMMAND key to display the next one to four options. Pressing the Back Arrow key allows you to review the previous four choices.

The Select keys/areas are also used for choosing a section from the programming menu. Press any Select key or touch the Select Area when the programming section name you want displays.

Note: On Security Command, Thinline and Aqualite keypads, when instructed to press the first Select key, press the far left Select key; the second Select key is the second from the left; third Select key is second from the right; and the fourth Select key is the far right key. See Figures 4 and 5.

On Clear Touch Keypads, when instructed to press the first Select key, touch Select Area 1; the second Select key touch Select Area 2; third Select key touch Select Area 3; and the fourth Select key touch Select Area 4. See Figure 6.

1.8 Entering Alpha Characters

Some options during programming require you to enter alpha characters. To enter an alpha character, press or touch the key that has that letter written below it. The keypad displays the number digit of the key. Next, press the Select key/area that corresponds to the location of the letter under the key. Pressing a different Select key/area changes the letter. When another digit key is pressed, the last letter displayed is retained and the process starts over.




Figure 5: Security Command Select Keys




Figure 6: Thinline/Aqualite Select Keys




Figure 7: Clear Touch Select Areas

1.9 Entering Non-Alpha Characters

To enter a space in an alpha entry, press the 9 digit key followed by the third Select key/area. The three characters on the 9 digit key are Y, Z, and space. You can also enter the following characters: - (dash), . (period), * (asterisk), and # (pound sign) using the 0 (zero) key and the four Select keys/areas from left to right. For example, to enter a - (dash), press the 0 (zero) key and then the left Select key/area. A dash now appears in the keypad display. The table below shows the character locations for DMP keypads.

Key Number	Select Key 1	Select Key 2	Select Key 3	Select Key 4
1	A	B	C	(
2	D	E	F)
3	G	H	I	!
4	J	K	L	?
5	M	N	O	/
6	P	Q	R	&
7	S	T	U	@
8	V	W	X	,
9	Y	Z	space	_
0	-	.	*	#

1.10 Keypad Displays Current Programming

Each programming prompt displayed at the keypad shows the currently selected option in the panel memory. These options are either shown as a number, a blank, or a **NO** or **YES**. To change a number or blank to a new number, press any top row Select key or touch any Select Area. The current option is replaced with a dash. Press the number(s) on the keypad you want to enter as the new number for that prompt. It is not necessary to enter numbers with leading zeros. The panel automatically right justifies the number when you press the **COMMAND** key.

To change a programming prompt that requires a **NO** or **YES** response, press the Select key or touch the Select Area for the response not selected. See Figure 10.

For example, if the current prompt is selected as **YES** and you want to change it to **NO**, on Security Command, Thinline, or Aqualite keypads press the third top row Select key. On Clear Touch keypads touch Select Area 3. The display changes to **NO**. Press the **COMMAND** key to display the next prompt.




Figure 8: Changing the Current Programming Option


Initialization

2.1 | | |----------------| | INITIALIZATION | |----------------| Initialization

This function allows you to set the panel's programmed memory back to the factory defaults in preparation for system programming.

After you select YES to clear a section of memory, the panel asks if you are sure you want to clear the memory. This is a safeguard against accidentally erasing part of your programming. No memory is cleared from the programming until you answer YES to the SURE? YES NO prompt.

For each section of the panel program you can initialize, a NO or YES option is provided.



2.2 | | | | |--------|-----|-----| | CODES? | NO | YES | | SURE? | YES | NO | Clear All Codes

NO leaves existing codes intact.

YES clears the user code memory and assigns the user code number 99 to user 30 on the XT30, and 99 on the XT50.

2.3 | | | | |------------|-----|-----| | SCHEDULES? | NO | YES | | SURE? | YES | NO | Clear All Schedules

NO - Leaves existing schedules intact.

YES - Clears all schedules from the XT30 or XT50 programming.

2.4 | | | | |---------|-----|-----| | EVENTS? | NO | YES | | SURE? | YES | NO | Clear Events

NO leaves existing event memory intact.

YES clears all event memory currently held in the panel's Display Events buffer.

2.5 | | | | |--------|-----|-----| | ZONES? | NO | YES | | SURE? | YES | NO | Clear Zone Programming

NO leaves existing zone information intact.

YES sets all zones in the system to * UNUSED *

2.6 | | | | |-------|-----|-----| | COMM? | NO | YES | | SURE? | YES | NO | Clear Communication

NO - Leaves existing communication, network, and email programming intact.

YES - Clears communication, network and email programming to factory defaults.

2.7 | | | | |-----------|-----|-----| | DEFAULTS? | NO | YES | | SURE? | YES | NO | Set to Factory Defaults

NO leaves the remainder of the existing panel programming intact.

YES sets the panel's programming back to factory default selections. Selecting DEFAULTS does not clear the panel's event memory, zone or user code information, or schedules.

Communication

- 3.1** **Communication**
 The **Communication** section allows you to configure the communication settings for the XT30/XT50 panel. After choosing the Communication Type, continue through the list of options.
- 3.2** **Account Number**
 Enter the account number sent to the receiver.

DD, NET, CELL - The range of account numbers for Digital Dialer, Network, and Cell is 1 to 65535. For account numbers of four digits or less, you do not have to enter leading zeros. The panel automatically right justifies the account number.

CID - The account number range for this format is 1 - 9999.
- 3.3** **Transmission Delay**
 Enter the number of seconds (15 to 45 seconds) the panel waits before sending burglary alarm reports to the receiver. The bell and relay outputs are not delayed during this period. Program Burglary Outputs for steady, and set Abort Reports to **YES** if Opening and Closing reports are not being sent. Enter 0 (zero) to disable this function. The default is 30.

 If the area where the alarm occurred is disarmed during the Transmit Delay time, only an Abort Report (S45) message is sent to the receiver. If the area where the alarm occurred is disarmed after the alarm message is sent to the receiver but before the Bell Cutoff time expires, even if the alarm was silenced, an Alarm Cancelled (S49) message is sent. The Alarm Cancelled report cannot be disabled.
- 3.4** **Communication Type**
 This specifies the communication method the panel uses to contact the receiver. Press any Select key to display the following communication options:

 DD - Digital Dialer communication to DMP SCS-1R Receivers.
 CID - Contact ID dialer communication to non-DMP receivers. This format sends the report codes of the Ademco Contact ID communication format.
NET - Network communication to DMP Model SCS-1R Receivers.

CELL - Cellular communication to DMP Model SCS-1R Receivers.

NONE - For local systems. Selecting this ends communication programming.

NOTE: The Backup Dialer, Backup Cellular, Check-in Minutes, and Failed Minutes options revert to their default values when the communication type is changed. All other communication programming items remain at their programmed values.
- 3.5** **Backup Dialer**
 Backup Dialer option is available if COMM TYPE is set for NET or CELL. The Backup Dialer tries to send the message after the main communication fails for 60 seconds on NET and 4 send attempts with CELL. If the backup dialer fails then the message is discarded.
- 3.6** **Backup Cellular**
 Backup Cellular option is available if COMM TYPE is set for NET or DD/CID. The Backup Cellular tries to send the message after the main communication fails for 60 seconds on NET and 10 dial attempts with DD/CID. If the backup dialer fails then the message is discarded.

COMMUNICATION

- 3.7** **Test Time**
Press COMMAND to enter the Test Time. Enter the time of day the panel sends the test report to the SCS-1R Receiver. Use entries between 12:00 to 11:59 and then choose AM or PM.
- 3.8** **Test Days**
Enter how often the panel test report is sent to the receiver for each communication type programmed. Enter from 1 to 60 days. Enter zero to disable the test report. Default is 1 (one) day. These options only display if a test time is entered and that particular communication method is being used.
- 3.9** **Check-in Minutes**
Enter the number of minutes (15 to 240) between check-in reports. Check-in reports are a method of supervising the panel for communication with the receiver for Net or Cell communication. Enter 0 (zero) to disable this feature. The default CHECK-IN TIME is 200 minutes for NET and 0 (zero) for CELL.
- 3.10** **Failed Minutes**
Failed Minutes allows the receiver to miss a defined number of check-ins before logging that the panel is missing. For example, if CHECKIN is 20 and FAIL MINS is 30, the receiver only indicates a Panel Not Responding after 30 minutes. The FAIL MINS must be equal to or greater than the CHECKIN minutes: If the CHECKIN is 20 minutes, the FAIL MINS must be 20 or more. The maximum FAIL MINS is 240 minutes. The default FAIL MINS is 240 minutes for Net and 0 minutes for Cell.
- 3.11** **Send Communication Trouble**
Enable communication fail notification by selecting YES at COMM TRBL. Select NO to disable. Default is YES.

When COMM TRBL is YES and the panel detects a failure of communication, the panel sends an S72 (Comm Trouble) message through a backup communication method with notification of the failure. If both primary and secondary methods of communication fail, then two S72 messages will be sent via the third communication method, if programmed. The keypad sounds a continuous tone, which may be silenced by pressing any key, and displays "COMM -TRBL".

When communication is restored, the panel sends an S73 (Comm Restored) message through the primary communication. The "COMM -TRBL" message is removed from the keypad display and the keypad sounder is turned off, if no other trouble messages are pending.
- 3.12** **First GPRS APN**
Enter the first APN (Access Point Name). This allows an access point for cellular communication and is used to connect to a DNS network. The APN may contain two lines of 16 characters to equal 32 characters. Default is set to SECURECOM200.

Note: If using the Level 400 SIM Card to support messaging via cellular, the APN should be changed to SECURECOM400.
- 3.13** **Second GPRS APN**
Enter the second APN (Access Point Name). This works as a backup in case the first APN fails. The APN may contain two lines of 16 characters to equal 32 character. Default is set to SECURECOM200.
- 3.14** **Alarm Reports**
YES enables Abort, Alarm, Alarm Restoral, Alarm Bell Silenced, Ambush, Exit Error, and System Recently Armed reports to be sent to the receiver. Default is YES.
- 3.15** **Supervisory/Trouble Reports**
YES enables Supervisory, Trouble, Trouble Restoral, Force Armed, Late to Close, and Fault reports to be sent to the receiver. Default is YES.

3.16 O/C USER NO YES **Opening/Closing and User Reports**
 YES enables Opening/Closing, Door Access, Schedule and Code Changes, Bypass, and Sensor Reset reports by user to be sent to the receiver. Default is YES.

3.17

First Telephone Number
 Enter the first number the panel dials to send reports to a receiver. A phone number may contain two lines of 16 characters to equal 32 characters. You can program a three-second pause in the dialing sequence by entering P. Program a dial tone detect by entering D. These characters are counted as part of the 32 characters.
Call Waiting: You can place the “* 7 0 P” (Star, Seven, Zero, Pause) in the telephone number first position to cancel Call Waiting. For example, program NET with second line DD and phone number *70P555-1212, and you have NET with Call Waiting cancelled on the second line.



Caution: A call waiting cancel programmed on a non-call waiting telephone line would prevent communication to the central station.

3.18

Second Telephone Number
 The panel dials the second number after two successive attempts failed using the first number. If the panel cannot reach the receiver after two attempts using the second number, it returns to the first number and makes two additional attempts. A total of ten dialing attempts are made using the first and second phone numbers. If a second phone number is not entered, the first phone number is used for all dialing attempts. Each number can be up two lines of 16 characters to equal 32 characters in length, including any P, D, or *70P characters entered for pause, dial tone detect, or call waiting cancel option.

3.19

First IP Address
 Enter the first (primary) IP address where the panel sends network or cell messages. The IP address must be unique and cannot be duplicated on the network. Enter all 12 digits and leave out the periods. For example, enter IP address 192.168.0.250 as 192168000250. The periods display automatically.
 For NET: The first and second IP addresses are alternately used for 8-second intervals until successful communication or 1 minute elapses. If communication fails on the first IP address and succeeds on the second IP, future network communication attempts begin using the second IP address.
 For Cell: The message is sent using First GPRS APN and the First IP Address. If no acknowledgment is received, First GPRS APN and the Second IP address are used, followed, if needed, by Second GPRS APN and first and second IP addresses, respectively. Future cellular communication attempts start with the APN/IP combination of the last successful communication.

3.20

First IP Port
 Enter the first IP port number to be used in conjunction with the First IP Address. The IP port identifies the port used to communicate messages to and from the panel. The default IP Port setting is 2001.

3.21

Second IP Address
 Enter the second IP address where the panel sends network messages. The IP Address must be unique and cannot be duplicated on the network. Enter all 12 digits and leave out the periods. For example, enter IP address 192.168.0.250 as 192168000250. The periods display automatically.

3.22

Second IP Port
 Enter the second IP port number to be used in conjunction with the Second IP Address. The IP port identifies the port used to communicate messages to and from the panel. The default IP Port setting is 2001.

Network Options

Network Options are provided to define the network configuration for the panel. This information will be used during communication of messages via network or email.

Note: IP addresses and port numbers may need to be assigned by the network administrator. When entering an IP, Gateway, or Subnet Mask address be sure to enter all 12 digits and leave out the periods. For example, IP address 192.168.000.250 is entered as 192168000250.

- 4.1** DHCP NO YES **DHCP Mode Enabled**
If the panel uses a dynamic IP address Select YES. When set to YES the panel will operate in DHCP and will not use the Local IP Address number. When the DHCP option is set to NO, the panel will use the IP address entered in Local IP Address. The default value for DHCP mode is YES.
- 4.2** **Local IP Address**
 Enter the local IP address for the panel. The Local IP Address must be unique and cannot be duplicated on the network. The default local IP address is 192.168.0.250.
- 4.3** **Gateway Address**
 Enter the local gateway address. The Gateway IP Address is needed to exit the local network. The default gateway address is 192.168.0.1.
- 4.4** **Subnet Mask**
 Enter the local subnet mask assigned to the panel. The default subnet mask address is 255.255.255.000.
- 4.5** **DNS Server**
 Enter the IP address of the DNS (Domain Name System) used by the panel to resolve domain names into IP addresses. The default address is 0.0.0.0.
- 4.6** **Programming Port**
 Enter the programming port number. The programming port identifies the port used to communicate messages to and from the panel. The default Programming Port setting is 2001.

Messaging Setup

5.1

MESSAGING SETUP

Messaging Setup

This section allows you to enter the information needed to receive messages directly from the panel via email and cellular communication. All of the name and address options below allow up to 32 lowercase characters to be entered. System Name will display with initial caps.

The transmitted messages are:

- Zone Alarms by Zone Name
- Zone Troubles by Zone Name
- Zone Bypass by User
- Arming (Closings) by User
- Disarming (Openings) by User
- Late to Close
- AC Power Trouble and Restoral
- System Low Battery
- Ambush
- Abort, Cancel and Alarm Verified by User
- Check-in by user

Note: If messages will be sent via cellular communication, the SIM card of the XT30/XT50 panel or 263G Digital Cellular Communicator must be upgraded to the Level 400 SIM card. Order model number 380-400 to obtain the Level 400 SIM Card.

5.2

ENABLE MESSAGING

Enable Messaging

NO YES

Select YES to allow the panel to send messages to three programmed destinations. Default is NO.

5.3

SYSTEM NAME

System Name

-

Enter a unique name for the panel. The panel name will be used as the sender of the message. The text entered will be displayed with initial caps. If this field is left blank, the panel account number will be sent.

5.4

DESTINATION 1

Destination 1

-

Enter the first email address or cell phone number that messages will be sent to. The message can be sent to any device (computer, cell phone, PDA) as long as a valid email address or cell phone number is entered. When entering email addresses, press the 7 digit key followed by the fourth Select Key to add the @ symbol and the 9 digit key followed by the fourth Select Key to add the _ symbol. See the Entering Non-Alpha Characters section for additional symbols.

Note: Mail servers that require Transport Layer Security (TLS) encryption are not supported by the XT30/XT50.

5.5

DESTINATION 2

Destination 2

-

Enter the second email address or cell phone number that messages will be sent to.

5.6

DESTINATION 3

Destination 3

-

Enter the third email address or cell phone number that messages will be sent to.

5.7

EMAIL COMM TYPE

Email Communication Type

NET CELL

Choosing NET will ensure that email messages are sent over the network. Choosing CELL will ensure that email messages are sent via cellular communication. Default is NET. This prompt appears only if any destination above is an e-mail and the panel is a network panel (has an Ethernet connector).

Note: If messages will be sent via cellular communication, the SIM card of the XT30/XT50 panel or 263G Digital Cellular Communicator must be upgraded to the Level 400 SIM card. Order model number 380-400 to obtain the Level 400 SIM Card.

MESSAGING SETUP

- 5.8** EMAIL O/C NO YES **Email O/C**
Select YES to allow the panel to send Opening and Closing reports via email. Default is NO. This prompt appears only if any destination above is an email address.
- 5.9** SMS O/C NO YES **SMS O/C**
Select YES to allow the panel to send Opening and Closing messages to a cell phone via SMS protocol. Default is NO. This prompt appears only if any destination above is a cell phone number.

The remaining options will only appear if email messaging has been selected to be sent via network. The options allow the email server to be selected by the installing dealer. Typically this will be the email service provided by the installing dealer. This allows opportunity for additional services to be provided to the end user.

- 5.10** **SMTP Server**
 Enter the SMTP (Simple Mail Transfer Protocol) Server name. The SMTP email server is responsible for sending the email to its destination. An example SMTP email server name is: mail.somedomain.com. The domain should be the email server that will provide email support for your alarm customers.
- 5.11** **SMTP Server Port**
The SMTP server port number is the port that the panel uses to initiate a TCP connection with the email server. The default port is 25.
- 5.12** **SMTP Username**
 Most SMTP servers require a username to send email. This will be sent to the SMTP server in conjunction with the SMTP Password to provide email authentication to the server.
- 5.13** **SMTP Password**
 Most SMTP servers require a password to send email. This will be sent to the SMTP server in conjunction with the SMTP Username to provide email authentication to the server.
- 5.14** **From Email Address**
 Enter the email address on file with the email service. This will show up in the email messages as the sender's address.

Remote Options

- 6.1** REMOTE OPTIONS **Remote Options**
 This section allows you to enter the information needed for Remote Command/ Remote Programming operation via a dial up or network link. A description of the Remote Options follows:
- 6.2** RMT KEY: **Remote Key**
 This option allows you to enter a code of up to eight digits for use in verifying the authority of an alarm or service receiver to perform a remote command/ programming session. The receiver must give the correct key to the panel before being allowed access. All panels are shipped from the factory with the Remote Key preset as blank.
 To enter a new Remote Key, press any Select key and enter any combination of up to 8 digits. The numbers you enter appear as asterisks. Press COMMAND.
- 6.3** MFG AUTH NO YES **Manufacturer Authorization**
 Enter YES to allow DMP service technicians to access the panel when required during system service or troubleshooting. This authorization automatically expires within one hour.
DMP remote service is provided on a read only basis: DMP technicians can look at the system programming and make suggestions only.
- 6.4** ARMED RINGS: 8 **Armed Rings**
 Enter the number of rings the panel counts within a two-minute period before answering the phone line when all areas of the system are armed. Any number from 1 to 15 can be entered. If zero is entered, the panel does not answer the phone when all areas of the system are armed. Default is 8.
Answering machine bypass procedure: Entering a number greater than zero into either Armed Rings or Disarmed Rings, allows a central station operator to connect remotely with the panel.
How it works: The operator calls the panel, rings the phone once, and then hangs up. The panel stores this attempt to communicate. The operator then calls back within 30 seconds causing the panel to seize the phone line and allow remote programming.
 This feature does not interfere with the normal operation of the Armed Rings/ Disarmed Rings function.
- 6.5** DISARM RINGS: 8 **Disarmed Rings**
 Enter the number of rings the panel counts before answering the phone line while any areas of the system are disarmed. Any number from 1 to 15 can be entered. If zero (0) is entered, the panel does not answer the phone when any area of the system is disarmed. Default is 8.
- 6.6** ALR RCVR NO YES **Alarm Receiver Authorization**
 Enter YES to enable remote commands and programming to be accepted from the alarm SCS-1R Receiver. The Remote Key option can also be required.
 When YES is selected, the panel requests the **alarm receiver key** during its first alarm communication with the first SCS-1R receiver. The panel retains this **alarm receiver key** in memory and allows remote commands to be accepted from the alarm receiver. If an alarm occurs during a remote connect, the alarm report is immediately sent to this receiver only.
 When NO is selected, remote commands and programming are not accepted from the alarm SCS-1R receiver.

REMOTE OPTIONS

- 6.7** SVC RCVR NO YES **Service Receiver Authorization**
YES enables remote commands and programming to be accepted from a secondary service receiver other than the alarm SCS-1R Receiver. The Remote Key option can also be required.
With YES selected, the panel requests the **service receiver key** the first time it is contacted by the service receiver. The panel retains this **service receiver key** in memory and accepts remote commands from the service receiver.
If an alarm occurs during a remote connect, the panel disconnects from the service receiver and calls the alarm receiver. Alarm reports are only sent to the alarm receiver. It is important that the **alarm receiver key** and the **service receiver key** programmed at the central station are NOT the same so the panel can determine the difference between receivers.
When NO is selected, remote commands and programming are not accepted from a secondary service receiver.
- 6.8** DISARM NO YES **Remote Disarm**
Enter YES to enable the panel to be disarmed remotely. Selecting NO disables remote disarming.

System Reports

- 7.1**

SYSTEM REPORTS

System Reports
 This function allows you to select the reports the XT30/XT50 will send to the receiver.
- 7.2**

OPEN/CLOSE	NO
NO	YES

Opening/Closing Reports
NO - Will not send Opening/Closing Reports.
YES - Will cause the panel to send Opening/Closing Reports for each programmed area.
- 7.3**

ABORT	NO	YES
-------	-----------	-----

Abort Reports
YES allows the panel to send an Alarm Abort Report to the receiver any time an area is disarmed during Transmit Delay before an alarm report is sent and the Bell Cutoff Time has not expired. See the Bell Cutoff section. The area must be disarmed and no alarmed zones can still be armed.
YES also allows a Bell Silenced Report to be sent if the alarm bell is silenced with a valid user code during an alarm, if the communication type is not CID. Default is **NO**.
Note: Alarm Cancel or Verify Reports are sent if the alarm is canceled or verified after being sent to the alarm receiver, if the Bell Cutoff timer has not expired. The Abort Reports option does not affect Cancel or Verify reports.
 The panel will not send Abort reports for Fire zones, Fire Verify, or Supervisory-type zones.
- 7.4**

RESTORAL	YES	
NO	YES	DISARM

Zone Restoral Reports
 This option allows you to specify whether the panel sends zone restoral reports and also when they will be sent.
NO - Restoral reports are not sent by the panel.
YES - The panel always sends zone restoral reports at the time the zone restores from an alarm or trouble condition.
DISARM - The panel sends zone restoral reports when a zone that has restored from an alarm or trouble is disarmed. Twenty-four hour zones send restorals immediately.
- 7.5**

BYPASS	NO	YES
--------	----	------------

Bypass Reports
YES allows the panel to send all zone bypass, reset, and force arm reports to the receiver. The bypass report includes the zone number, zone name, and the user number of the individual bypassing the zone.
- 7.6**

CODE CHG	NO	YES
----------	-----------	-----

Code Change Reports
YES allows the panel to send all code additions, changes, and deletions to the receiver. The code change report includes the user number added or deleted and the user number of the individual making the change.
- 7.7**

AMBUSH	NO	YES
--------	-----------	-----

Ambush
YES allows an ambush report to be sent any time user code number one is entered at a keypad. Selecting **NO** disables the ambush report and allows user code number one to operate the same as all other codes.

System Options

- 8.1**

SYSTEM OPTIONS

System Options
This section allows you to select system wide parameters used in the operation of the XT30/XT50 system. A description of each System Option follows:
- 8.2**

SYSTEM: ALL/PERIM
AREA A/P H/A

System
This configures the panel as either a four Area system, an All/Perimeter system (Perimeter/Interior), or a Home/Away system (Perimeter, Interior, and Bedrooms). Zones must be assigned to Bedrooms for the area to be active.

When using wireless zones for an Area or All/Perimeter system, the keypad trouble buzzer resounds every four hours when wireless zone trouble or wireless low battery is displayed.
- 8.3**

CLS CODE	NO	YES
----------	----	-----

Closing Code
When YES is selected, a code number is required for system arming. If NO is selected, a code number is not required for system arming. Default is NO.
- 8.4**

CLS CHK	NO	YES
---------	----	-----

Closing Check
Select YES to enable the panel to verify that all areas have been armed after a schedule expires. If the Closing Check finds any areas disarmed past the scheduled time, all keypads emit a steady beep and display **CLOSING TIME!**. The user must extend the schedule or arm the system within 10 minutes or a Late to Close message will be sent to the central station. Default is NO.
- 8.5**

ENTRY DLY 1:	30
ENTRY DLY 2:	60

Entry Delay 1
Enter the entry delay time for all exit type zones programmed to use Entry Delay 1. When an armed Exit type zone is faulted, the keypad prewarn tone begins sounding. **ENTER CODE:-** and the name of the zone causing the Entry Delay displays on all keypads.

When the first digit of a code is entered, the prewarn tone stops at the keypad. If, within five seconds, a valid user code is not entered or an invalid user code is entered, the prewarn tone begins sounding again. Fifteen seconds must elapse before entering a digit silences the prewarn tone again.

The area must be disarmed before the entry delay expires or an will be detected. All Burglary type zones in all areas are delayed along with the Exit zone.

Entry delay times can be from 30 to 250 seconds. Repeat the above for Entry Delay 2 if it is being used. Default is 30 seconds for Entry Delay 1.

Note: Specific Exit Error operation is based on the Entry Delay used (1 or 2) with an EX type zone. See Exit Delay.

- 8.6** EXIT DELAY: 60 **Exit Delay**
 Enter the Exit Delay time for all Exit type zones. When the exit delay time starts, all activity on exit and burglary zones is ignored until the exit delay expires. The keypad displays the Exit Delay time countdown and annunciates the Exit Delay tone at 8 second intervals until the last 10 seconds when annunciation is at 3 second intervals. The exit delay can be from 45 to 250 seconds. Default is 60 seconds.
 During Exit Delay, if an exit zone trips, then restores, and trips again, the Exit Delay timer restarts. This restart can occur only once.
Exit Error Operation: At arming, when an entry/exit zone (EX) is **faulted** at the end of the exit delay then one of two sequences occur:
 For Entry Delay 1 EX type zones:
 - the bell sounds for the length of time set in Bell Cutoff programming
 - the Entry Delay operation starts, requiring code entry to disarm
 - if not disarmed, a zone alarm and an Exit Error are sent to the receiver.
 For Entry Delay 2 EX type zones:
 - the zone is force armed and a zone force arm message is sent to the receiver
 - an Exit Error is sent to the receiver
 - the bell sounds for the length of time set in Bell Cutoff programming
- 8.7** CRS ZONE TM: 0 **Cross Zone Time**
 Enter the time allowed between zone faults. When a zone programmed for cross zoning faults, the panel begins counting down the Cross-Zone Time entered here. If the same zone or another cross-zoned zone faults within this time, an alarm report is sent to the receiver.
 If the Cross-Zone Time expires without the second zone fault, only a zone fault report from the first zone is sent to the receiver. The Cross-Zone Time can be from 4 to 250 seconds in one second increments. Enter 0 (zero) to disable the Cross-Zone Time feature. See the Appendix.
- 8.8** PWR FAIL HRS: 1 **Power Fail Delay**
 This option tracks the duration of an AC power failure. The delay time can be from 1 to 9 hours. When the AC power is off for the length of the programmed delay time, an AC power failure report is sent to the receiver. For example, if the power failure delay is set for two hours, then the AC power failure report will be sent between 2-3 hours. Entering a 0 (zero) sends the AC power failure report within 15 seconds.
- 8.9** RST SBYP NO YES **Reset Swinger Bypass**
 When YES is selected, an automatically bypassed zone is reset if it remains in a normal condition for one complete hour after being bypassed. A report of the automatic reset is sent to the receiver if Bypass Reports has been selected as YES. Default is NO. See the **BYPASS REPORTS** section.
- 8.10** PHONE ACC NO YES **Telephone Access**
 YES allows the use of standard DTMF telephones to arm and disarm and check the armed status of the XT30/XT50 panel. Refer to the XT30 or XT50 User's Guide for complete information.

SYSTEM OPTIONS

8.11 Zone Activity Hours

This option provides supervision of a person living alone for non-activity. Enter the number of hours, 0 to 9, allowed to elapse without a disarmed zone being tripped before a message is sent to the receiver. Default is 0 (zero).

When the system is disarmed, the timer begins to countdown the number of hours programmed. Each time activity occurs, the timer restarts the countdown.

Before the countdown time expires, the keypad sounds a tone and PRESS ANY KEY displays to allow the user to restart the activity timer. The duration of the tone is the number of seconds programmed for Entry Delay 2.

Select the SUPV/TRBL receiver option in communication programming to send S93 ALARM: User Activity Not Detected, S94 Alert: Activity Check Enabled, and S95 Alert: Activity Check Disabled messages.

When an open/close schedule is programmed, the timer only counts down during the scheduled open period. Also, when a schedule is programmed, if the timer is counting down and the scheduled open time occurs, the timer resets and begins the countdown again.

8.12 Arm Activity Days

This allows selection of the number of days a countdown timer is set for area arming and disarming activity. The range for the countdown timer is 00 to 99.

When the timer counts down to zero because of no arming or disarming activity, the panel sends a "No Arming/Disarming" message to the receiver at 10:00 AM. Each time an area is armed or disarmed, the timer is restarted. When the countdown timer expires because of no arming or disarming activity, and a message is sent, the timer does not restart until a panel reset occurs or an area is armed or disarmed.

The SUPV/TRBL receiver option *must* be selected in communication programming for the message to be sent.

8.13 Time Zone Changes

This option allows the panel to request automatic time changes from the DMP SCS-1R Receiver. For the receiver to send time changes, it must be programmed to send time changes and must be receiving time change updates from the host automation computer at least every 24 hours. Default is YES.

When time zone is programmed YES, enter the number (0-23) that indicates the Greenwich Time zone (GMT) where the panel is located. The default is 6. See table below for GMT values.

GMT	City/Time Zone
0	London, Monrovia, Lisbon, Dublin, Casablanca, Edinburgh
1	Cape Verde Island, Azores
2	Mid-Atlantic, Fernando de Noronha
3	Buenos Aires, Georgetown, Brasilia, Rio de Janeiro
4	Atlantic Time (Canada), Caracas, La Paz, Santiago
5	Eastern Time (US, Canada) Bogota, Lima, Arequipa
6	Central Time (US, Canada), Mexico City, Saskatchewan
7	Mountain Time (US, Canada), Edmonton
8	Pacific Time (US, Canada), Tijuana
9	Alaska
10	Hawaii
11	Midway Island, Samoa
12	Fiji, Marshall Island, Wellington, Auckland, Kwajalein, Kamchatka

GMT	City/Time Zone
13	New Cadelonia
14	Guam, Sydney
15	Tokyo, Seoul
16	Hong Kong, Singapore
17	Bangkok, Hanoi
18	Dhaka, Almaty
19	Islamabad, Karachi
20	Abu Dhabi, Kazan
21	Moscow, Bagdad
22	Eastern Europe
23	Rome, Paris, Berlin

8.14 TIME DSP NO YES **Time Display**
 YES allows the keypad to display the time and day in the Status List. When NO is selected, time and day of the week are not displayed.

8.15 HOUSE CODE: 0 **House Code**
 When using a DMP wireless system, enter a house code between 1 and 50 for the wireless system to use. The DMP wireless receiver automatically programs the house code into the wireless transmitters when the unique transmitter serial number is programmed into the panel. See Wireless programming in Zone Information. Default is 0 (zero) indicating the DMP wireless system is not being used.
 The house code identifies the panel, receiver, and transmitters to each other. When operating, the receiver listens for transmissions that have the programmed house code and transmitter serial number.
Note: The flexibility of DMP two-way wireless operation allows an existing house code to be changed in the panel at any time. The transmitter may take up to two minutes to learn the new house code and continue operation.
Note: When any wireless zone programming is changed in the panel, wireless receiver zone programming is updated by the panel. At that point, all wireless zones display as normal for up to 1 minute, regardless of the actual state of the zone.

8.15.1 DET JAMNG NO YES **Detect Wireless Jamming**
 This option displays when the House Code entered is for a DMP 1100D Series Wireless system. When enabled and the receiver detects jamming, a trouble or alarm message is sent to the receiver and displays in the Status List. Select YES to enable jamming messages to display in the Status List. Select NO to disable jamming messages. Default is NO.

8.15.2 WLS AUDIBLE: DAY **Wireless Audible Annunciation**
 This option displays when the House Code entered is for a DMP 1100D Series Wireless system (1-50). Press any top row key to select the keypad buzzer annunciation method for wireless low battery and missing messages.
ANY DAY MIN

- Select ANY to enable annunciation anytime.
- Select DAY to enable annunciation except during sleeping hours (9 PM to 9 AM).
- Select MIN (minimum) to annunciate only Fire and Fire Verify zones during daytime hours (9 AM to 9 PM). Default is DAY.

8.16 KPD PANCS NO YES **Enable Keypad Panic Keys**
 This option allows the two-button panic key operation selected at a keypad to send the Panic, Emergency, or Fire message to the central station receiver. Select YES to enable the two-button panic operation. To disable the two-button panic operation, select NO. Default is YES.

8.17 OCCUPIED PREMISE NO YES **Occupied Premise**
 Select YES to allow the panel to automatically disarm the interior area(s) when arming all areas and a perimeter exit zone is not tripped during the exit delay.
 This False Alarm Reduction feature will keep a user from arming the entire system when they do not exit and remain in the premise. Select NO to not automatically disarm interior area(s). Default is YES.

Bell Options

- 9.1** **Bell Options**
This section allows you to program the panel bell output functions.
- 9.2** **Bell Cutoff Time**
Enter the maximum time from 1 to 15 minutes the Bell Output remains on. If the Bell Output is manually silenced or the system is disarmed, the cutoff time is reset. Enter zero to provide continuous bell output. Default is 5.
Note: To support the Cancel/Verify operation on an All/Perimeter or Home/Sleep/Away system, set the Bell Cutoff Time to greater than 0.
- 9.3** **Automatic Bell Test**
When YES is selected, the Bell Output is turned on for two seconds when all areas in the system are armed. The Bell Test only occurs when the areas are armed from a keypad. Arming performed from an Arming zone or remotely from Remote Link™ does not activate the Bell Test. In addition, the Closing Wait feature is activated if Opening/Closing Reports is YES. See OPENING/CLOSING AND USER REPORTS.
Closing Wait operation
Closing Wait provides a delay time before a monitored system arms until the panel receives an acknowledgment of the closing report from the central station receiver. During the delay, the keypad displays ONE MOMENT . . . Once the closing is acknowledged, the keypad buzzes for one second and then displays the ALL SYSTEM ON message. If the primary communication fails, but the backup communication is successful, then the message BACKUP ALR ONLY will appear. If both primary and backup communication fail, the message LOCAL ALARM ONLY will appear.
- 9.4** **Bell Output**
Enter the output number when needed to follow the panel Bell terminal 5 operation for all action and off conditions. Enter 0 (zero) to disable.
Note: When BELL ACTION below is set to T for Temporal Code 3, this Bell Output action is pulse for wired outputs 1-4 and wireless outputs 31-34 and 41-44.
- 9.5** **Bell Action**
This defines the type of Bell Action from zone alarms that will occur on the panel's bell terminal number 5. Trouble conditions do not activate Bell Action. There are seven zone types you can program individually for Bell Output. To provide a steady Bell Output, enter S. For a pulsed output, enter P. For a Temporal Code 3 output, enter T and for no Bell Output, enter N.
- 9.5.1** **Fire**
Defines Bell Action for Fire Type Zones. The default is set at P.
- 9.5.2** **Burglary**
Defines Bell Action for Burglary Type Zones. The default is set at S.
- 9.5.3** **Supervisory**
Defines Bell Action for Supervisory Type Zones. The default is set at N.
- 9.5.4** **Panic**
Defines Bell Action for Panic Type Zones. The default is set at N.
- 9.5.5** **Emergency**
Defines Bell Action for Emergency Type Zones. The default is set at N.
- 9.5.6** **Auxiliary 1**
Defines Bell Action for Auxiliary 1 Type Zones. The default is set at N.
- 9.5.7** **Auxiliary 2**
Defines Bell Action for Auxiliary 2 Type Zones. The default is set at N.

Output Options

10.1 OUTPUT OPTIONS **Output Options**

This section allows you to program panel output options. Switched Ground (open collector) outputs are available using the 4-wire output harness on the XT30/XT50 board. Wireless outputs are available when using the built-in 1100 Series Receiver of the XT50 or an 1100D Wireless Receiver with the XT30. Refer to the XT30/XT50 Installation Guide (LT-0624) for complete information.

Select from the following output numbers:

- 1 to 4
- 31 to 34 – Slow response time* wireless outputs (activate within 15 seconds)
- 41 to 44 – Fast response time* wireless outputs (activate within 1 second)

* The response time of a wireless output is the time it takes for a wireless output to activate once the panel event occurs. You determine whether a wireless output is a slow or fast response based on the output number assigned. A slow response output number extends battery life, but response time may be up to 15 seconds. A fast response output number responds within 1 second, but reduces battery life. Refer to the specific wireless output installation guide to determine battery life.

10.2.1 CO OUTS: - - - - **Cutoff Outputs**

This option allows you to define the operation of the four on-board annunciator outputs. For each programming option, enter the number of the output you wish to activate or 0 (zero) for no output. Any or all of the available outputs can be programmed here to turn off after the time specified in **Output Cutoff Time**. See the Output Cutoff Time section for additional information. To disable this option, press any Select key to clear the display of output numbers and then press COMMAND.

Note: Whenever an output is assigned in Output Options, that output cannot be turned on from the User Menu.

10.2.2 CUTOFF TIME: 0 **Output Cutoff Time**

If a Cutoff Output is assigned, you can enter a Cutoff Time for the output to remain on up to 15 minutes. If the output is turned off manually, the cutoff time is reset. The Cutoff Time can be 1 - 15 minutes. Enter 0 (zero) to provide continuous output.

The Cutoff Timer is shared by all outputs. If a second output trips, the timer is not reset. Both outputs turn off when the original time expires.

10.3 COM FAIL OUT: 0 **Communication Failure Output**

This output turns on when the panel fails to communicate with the receiver after three successive dial attempts. Enter 0 (zero) to disable this output.

Note: To turn off the Communication Failure Output, disarm the panel or turn the output off using the User Menu Outputs On/Off function.

10.4 FIRE ALR OUT: 0 **Fire Alarm Output**

This output turns on any time a fire type zone is placed in alarm. The output turns off using the Sensor Reset option when no additional fire type zones are in alarm. Enter 0 (zero) to disable this output.

10.5 FIRE TRB OUT: 0 **Fire Trouble Output**

This output turns on any time a fire type zone is placed in trouble or when a supervisory type zone is placed in alarm or trouble. The output turns off when all fire and supervisory type zones restore to normal. Enter 0 (zero) to disable.

10.6 AMBUSH OUT: 0 **Ambush Output**

This output turns on any time an Ambush code is entered at a keypad. The output turns off using the Sensor Reset option. Enter 0 (zero) to disable this output.

OUTPUT OPTIONS

- 10.6** **Entry Output**
This output turns on at the start of the entry delay time. The output turns off when the area disarms or the entry delay time expires. Enter 0 (zero) to disable.
- 10.7** **Exit Output**
This output turns on any time an exit delay time starts. The output turns off when the system arms or when the arming has been stopped. Enter 0 (zero) to disable.
- 10.8** **Ready Output**
This output turns on whenever all disarmed zones are in a normal state. The output turns off when any disarmed zone is in a bad state. Enter 0 (zero) to disable.
- 10.9** **Armed Output**
This output turns on any time an area of the system arms. The output turns off when the system completely disarms. Enter 0 (zero) to disable this output.
- 10.10** **Burglary Output**
This output turns on any time a burglary zone goes into alarm. The output turns off when the area in which the alarm occurred disarms and no other burglary zones are in alarm. Enter 0 (zero) to disable this output.
- 10.11** **Late To Close Output**
Enter the output number to turn on at the expiration of a closing schedule when all areas are not armed. The output activates simultaneously with the **CLOSING TIME!** keypad display. The output is turned off when all areas are armed, the closing is extended, or the schedule is changed.
- 10.12** **Arm-Alarm Output**
Enter the output number to turn on steady when any area of the system is armed. If an alarm occurs causing the keypads to turn Red, this output pulses and continues to pulse for approximately five (5) minutes after the panel is disarmed. Enter 0 (zero) to disable.

Wireless Outputs

- The Arm-Alarm Output is compatible with the Model 1117 Wireless LED Annunciator and the Model 1116 Wireless Relay Output connected to a Model 572 Indicator LED.
- When the Model 1117 is battery operated, the LED is off when the system is armed to conserve battery life. If an alarm occurs, the output flashes quickly.
- When using the Model 1116 connected to a Model 572, the LED is on when the system is armed. If an alarm occurs, the output pulses.
- To operate the Arm-Alarm output within one second, program a fast response number from 41 to 44. Fast response operation reduces overall wireless output battery life.
- To operate the Arm-Alarm output within 15 seconds, program a slow response number from 31 to 34. Slow response operation increases overall wireless output battery life.

Output Information

- 11.1** OUTPUT INFO **Output Information**
 This section allows you to program and name wireless outputs into the panel when using an 1100D/1100DH/1100DI Wireless Receiver with an XT30 panel or the built-in receiver of the XT50. Wireless outputs are also available on the XT50 when using an onboard receiver. Output Information only displays when a House Code (1-50) is entered in System Options programming.
- 11.2** OUTPUT NO: - **Output Number**
 Enter an output number. Entry range is 31 to 34, 41 to 44.
Note: Addresses 31 to 34 and 41 to 44 are available for wireless outputs, keypad bus zones, wireless zones or wireless key fob zones and can only be assigned to one device.
- 11.3** * UNUSED * **Output Name**
 This section allows you to define a 16 character alphanumeric name for any wireless output.
 An output that is not part of the system must be marked *UNUSED*. To mark an output unused, delete the old name by pressing any Select key, then press the COMMAND key. The programmer automatically programs the name as * UNUSED *.
- 11.4** SERIAL#: - **Serial Number**
 Enter the eight-digit serial number found on the wireless device.
- ALREADY USED: ZXX This message displays when the serial number is already programmed for another output or zone. The programmed output or zone number displays.
- 11.5** SUPRVSN TIME: 240 **Supervision Time**
 Press any top row key to select the supervision time required for the wireless output. Press COMMAND to accept the default time. Default is 240 minutes.
- 0 3 60 240 Select the required number of minutes. The transmitter must check in at least once during this time or a missing condition is indicated for that zone. 1100 Series transmitters automatically check in based on the supervision time selected for the wireless zone, no additional programming is needed. Zero (0) indicates an unsupervised transmitter.
- Note:** When the panel is reset, a receiver is installed or powered down and powered up, or programming is complete, the supervision timer restarts for all wireless outputs.

Area Information

- 12.1** **Area Information**
This section allows you to assign functions to individual areas for XT30 and XT50 panels. All non-24-hour zones must be assigned to an active area. See the section on Zone Information.
Activate an area by assigning it a name. A name is given to each active area in place of a number to assist the user during arming and disarming.
- 12.2** **Area Number**

 Enter the number of the area to program. In an area system, select from areas 1 to 4. In an All/Perimeter system, select **INT**erior or **PERIM**eter. In a Home/Away system, select **INT**erior, **BDRM**, or **PERIM**eter.
- 12.3** **Area Name**
In an area system, enter up to 16 characters for the area name. Only those areas given names can have zones assigned to them. All others are marked ***UNUSED***. Refer to the Entering Alpha Characters section.
To add an area name to the system, press any Select key and then enter up to 16 characters for the new name. Press **COMMAND** to continue.
To mark an active area as unused, delete the old name by pressing any Select key then press the **COMMAND** key. The panel automatically sets the name as ***UNUSED***. If you have already Initialized the panel, all areas will be marked as ***UNUSED***. See section 2.3.
- 12.4** **Automatic Arming**
Select **YES** to allow this area to arm automatically according to the opening and closing schedule.
If Closing Check is selected as **YES**, the automatic arming does not take place until the expiration of a 10-minute Closing Check delay. If the area has been disarmed outside a schedule, the Closing Check delay occurs one hour after the area is disarmed.
At arming, faulted zones are handled according to the option selected in Bad Zones. If a Closing report is sent, the user number is indicated as SCH on the SCS-1R Receiver. Select **NO** to disable automatic arming for this area. Default is **NO**.
Note: For ANSI/SIA CP-01 installations, Automatic Arming cannot be used for arming.
- 12.4.1** **Bad Zones**
 At the time of automatic arming, some zones in the area may not be in a normal condition. This option allows you to program the panel's response to these bad zones. This option is not displayed if **AUTO ARM** is **NO**.
BYP - All bad zones are bypassed. A report of the bypass is sent to the receiver if Bypass Reports has been selected as **YES**. See the Bypass Reports section. The report indicates SCH as the user number.
FORC - All bad zones are force armed. Zones force armed in a bad condition are capable of restoring into the system and reporting alarms if tripped. A report of the force arm is sent if Bypass Reports is **YES**. See the Bypass Reports section. The report indicates the user number as SCH.
REF - The automatic arming is refused and no arming takes place. A No Closing report is sent to the receiver regardless of the Closing Check selection. See the XT30 and XT50 Programming Sheets.
Note: For NRTL listed installations, set Bad Zones to REF.
- 12.5** **Automatic Disarming**
NO disables automatic disarming by schedule for this area. Select **YES** to allow this area to automatically disarm according to a schedule. If an Opening report is sent to the receiver, the user number is indicated as SCH.
Note: For ANSI/SIA CP-01 installations, Automatic Disarming cannot be used.

Zone Information

13.1 ZONE INFORMATION **Zone Information**
 This allows you to define the operation of each protection zone used in the system.

13.2 ZONE NO: - **Zone Number**
 Enter the number of the zone you intend to program. Press COMMAND to enter a zone name. Refer to the **Enter Alpha Characters** section.

Keypad Address	Zone Numbers
1	11-14
2	21-24
3	31-34
4	41-44
5	51-54
<p>Note: Use zone numbers 31 to 34 or 41 to 44 with 1100 Series Key Fobs or DMP wireless output modules.</p>	

The XT50 has 20 onboard wireless zones numbered 80-99 or can be programmed to use zones 11-54 as wireless. Since the XT50 contains a built-in 1100 Series Receiver any keypad bus zone can be programmed as wireless while the next consecutive zone number can be hardwire from a keypad or zone expander.

When using the XT30 panel any wireless input zone for a particular device address is programmed (Ex: 11-14 = Addr 1), the 1100D/1100DH/1100DI responds to the panel for this address. Other devices, such as keypads or hardwired zone expanders, cannot use this address. Zones connected directly to the panel cannot be wireless.

13.3 KEYFOB NO YES **Key Fob**
 Select **YES** to program an 1100 Series Key Fob for zones 31-34 or 41-44. When **YES** is selected, programming continues at the 1100 Series Key Fobs Section. Default is **NO**.

13.4 * UNUSED * **Zone Name**
 Press any Select key and enter up to 16 characters for the zone name. A name must be given to each zone in the system. This name can be displayed at the keypads when the zone is bad or viewed in Display Events. The zone name is also sent to the receiver as part of a zone event report.

A zone that is not part of the system must be marked ***UNUSED***. To mark a zone unused, delete the old name by pressing any Select key, then press the COMMAND key. The programmer automatically programs the name as ***UNUSED***. If you selected **ZONES? NO YES** to clear the panel's memory during Initialization, the zones will already be marked ***UNUSED***. See the Initialization section.

13.5 ZONE TYPE: - **Zone Type**
 The Zone Type defines the panel's response to the zone being opened or shorted. See the Zone Types Specifications chart.

When you assign a Zone Type to a zone, responses are made automatically for the zone. There are 11 Zone Types to choose from including Blank. The functional details of each response are described in Zone Types Specification.

To select a new Zone Type, press any Select key. The display lists the four Zone Types shown below. When the Zone Type you want to select displays, press the Select key below the name.

--	NT	DY	EX
FI	PN	EM	SV
A1	A2	FV	AR

Blank, Night, Day, or Exit. Press COMMAND to display additional zone types.

Fire, Panic, Emergency, or Supervisory. Press COMMAND to display additional zone types.

Auxiliary 1, Auxiliary 2, Fire Verify, or Arming. Press the Back Arrow key to display the previous zone types.

ZONE INFORMATION

If you select Blank, Night, Day, Exit, Auxiliary 1, or Auxiliary 2 as the Zone Type, the zone must be assigned to an area. If you select Fire, Panic, Emergency, or Supervisory as the Zone Type, these are 24-hour zones that are always armed and no area assignment is needed. Press COMMAND to continue.

CAUTION: When a sensor reset is performed at the keypad, power will drop to devices connected to zone 10 causing the panel to sense an open condition on all zone types other than Fire (FI), Fire Verify (FV), and Supervisory (SV). Whenever non-Fire and non-Supervisory zone types are used on zone 10, make the appropriate adjustments to the zone Armed Action to prevent false alarms from occurring.

Refer to the Appendix for zone type specifications and descriptions.

Note: For NRTL listed installations using wireless zones, do not use the FV zone type.

13.6 **Area Assignment**

For Area systems, enter the area number from 1 to 4 where this zone is being assigned.

For All/Perimeter systems, choose INTERIOR or PERIMETER.

For Home/Away systems, choose INTERIOR, PERIMETER, or BEDROOMS.

- INT (Interior) - Assigns the zone to area 2, Interior.
- BDRM (Bedroom)- Assigns the zone to area 3, Bedrooms. This option is only displayed in Home/Away systems.
- PERIM (Perimeter) - Assigns the zone to area 1, Perimeter.

13.7 **Arming Zone Assignment**

For Area systems, this option specifies the areas to be armed by the Arming Type zone. Press the appropriate number keys on the keypad to assign areas 1 to 4. When disarmed, all programmed areas are disarmed.

For All/Perimeter systems, choose PERIM or ALL. For Home/Away systems, choose HOME, SLEEP, or AWAY.

Perimeter/All - Specify whether the arming zone arms just the Perimeter (PERIM) or the Perimeter and Interior areas (ALL) for All/Perimeter systems. When disarming, all areas are disarmed.

HOME/SLEEP/AWAY - Specify whether the arming zone arms the Perimeter (HOME), the Perimeter and Interior (SLEEP), or all three areas (AWAY). When disarming, all areas are disarmed.

Arming zone operation

If a bad (faulted) Priority zone is in the area being armed by an Arming zone, the arming is stopped. If there are no Priority zones, or they are all in a normal condition, the following applies:

When a non-Priority zone is bad when an area is armed with a keyswitch on an Arming zone, the arming is delayed for five seconds. If, during the five-second delay, the keyswitch is turned to disarm, the arming stops. If the keyswitch is held in the arming position for the full five seconds, the bad zone is force armed and the area is armed.

The ability to stop the arming does not apply if a wireless arming device is being used. Refer to the **Appendix**.

Note: Arming from a zone, voice module, touch tone telephone, or Remote Link is not affected by this operation.

13.7.1 **Style**

This option specifies the style for the arming/disarming operation. The default for **STYLE:** is TGL (toggle). Pressing any Select key displays the **STYLE** options. To view more style options press the command key. The following is a description of the action for each option condition.

TGL (Toggle) - When the zone changes from normal to shorted, the programmed

areas toggle between the armed or disarmed condition. When restored to normal, no action occurs. When the zone is opened from a normal (disarmed) state, a trouble is reported. When opened from a shorted (armed) state, an alarm is reported and the zone is disabled until you disarm the area(s) from either a keypad or Remote Link™ computer.

ARM - When the zone is shorted, the programmed areas are armed. When restored to normal, no action occurs. When the zone is opened from a normal (disarmed) state, a trouble is reported. When opened from a shorted (armed) state, an alarm is reported.

DIS (Disarm) - When programmed as an Area system, a short will disarm the programmed areas. When programmed as a **ALL/PERIM** or **HOME/AWAY** system, a short will disarm **ALL** areas. When restored to normal, no action occurs. When the zone is opened from a normal (disarmed) state, a trouble is reported.

STEP - When programmed as an area system, a short will arm the areas and beep the keypads once. When programmed as **ALL/PERIM** or **HOME/AWAY**, on the first short **HOME** will arm and beep the keypad once. On the second short, **SLEEP** will arm and beep the keypads twice. On the third short, **AWAY** will arm and beep the keypad three times. A normal condition will cause no action. An open condition will disarm the programmed areas and beep the keypads for one second.

Note: This arming style is designed for wireless arming pendants. When using a arming/disarming keyswitch, locate the keyswitch within the protected area.

MNT (Maintain) - When the zone is shorted, the programmed areas are armed. When restored to normal, the programmed areas are disarmed and any alarm bells are silenced. When the zone is opened from a normal (disarmed) state, a trouble is reported. If opened from a shorted (armed) state, an alarm is reported and the zone is disabled until you disarm the area(s) from either a keypad or Remote Link™ computer.

13.8

Next Zone

When **YES** is selected, the programming for the zone terminates and the display returns to **ZONE NO:** - allowing you to enter a new zone number. Select **NO** to program wireless devices or to make changes to the Alarm Action for a zone. The Alarm Action is defined after 1100 Series Wireless Key Fob programming.

DMP Wireless

For **1100 series wireless operation**, set the House Code from 1 to 50. See House Code programming in System Options.

For an **1100 Series Key Fob** see the 1100 Series Wireless Key Fob programming section.

NOTE: All wireless programming is stored in the XT30 or XT50 panel. The Wireless Receiver obtains the necessary programming information from the panel each time the receiver powers up, when the programmer **STOP** routine is selected or the panel is reset. The receiver memory refresh takes up to 45 seconds to complete depending on the number of wireless zones programmed and the Red LED remains on during this time. Normal receiver operation is inhibited during the memory refresh period.

13.9

Wireless

Select **YES** to program this zone as a DMP wireless zone. You must program the wireless House Code prior to adding wireless zones to the system. See House code programming in System Options. Default is **NO**.

Note: For wireless zones 80-99 on the XT50, this prompt does not display. If a DMP wireless House Code is not programmed, then **NO HOUSE CODE** displays.

13.9.1

Serial Number Entry

Enter the eight digit serial number, including leading zeros, found on the wireless device.

Displays when the serial number is already programmed for another zone. The programmed zone number displays.

ZONE INFORMATION

13.9.2 CONTACT: INTERNAL Contact

This option displays if the serial number entered is for an 1101 or 1103 Universal Transmitter or 1114 Wireless Four-Zone Expander. Press any top row key to select the contact.

INT EXT

This option displays when programming an 1101 or 1103 Transmitter. Select INT to use the internal reed switch contacts. Select EXT to connect an external device to the 1101 or 1103 terminal block. Default is INTERNAL.

By allowing both of the Model 1101 or 1103 transmitter contacts (INT and EXT) to be used at the same time, two zones may be programmed from one transmitter. When using both contacts, you must use consecutive zone numbers.

For example, program transmitter serial number 01345678 as Zone 11 with an INT contact type and Zone 12 with an EXT contact type. The same serial number is used for both zones.

CONTACT: x

This option displays when programming an 1114 zone expander which provides four input contacts. Press any top row key to select the contact. Default is Contact 1.

1 2 3 4

Select the contact number to program. The same transmitter serial number is used for all four contacts. When using the contacts, you must use consecutive zone numbers.

For example, use serial number 08345678 to program Contact 1 for Zone 21, Contact 2 for Zone 22, Contact 3 for zone 23, and Contact 4 for zone 24.

A tamper on the 1114 is transmitted as the zone number assigned to Contact 1.

ALREADY USED Zxx

This message displays when the Contact is already programmed for another zone. The programmed zone number displays.

NORM OPEN NO YES

The Normally Open option only displays when EXT is selected as the Contact type. For external devices connected to the 1101 terminal block, select NO to use normally closed (N/C) contacts. Select YES to use normally open (N/O) contacts. Default is NO.

13.9.3 SUPRVSN TIME: XX Supervision Time

Press any top row key to select the supervision time required for the wireless zone. Press COMMAND to accept the default time. Default is 240 minutes.

0 3 60 240

Select the required number of minutes. The transmitter must check in at least once during this time or a missing condition is indicated for that zone. 1100 Series transmitters automatically checkin based on the supervision time selected for the wireless zone, no additional programming is needed. If two zones share the same transmitter, the last programmed supervision time is stored as the supervision time for both zones. Zero (0) indicates an unsupervised transmitter.

Note: When the panel is reset or a receiver is installed or powered down and powered up, the supervision timer restarts for all wireless zones.

13.9.4 LED OPER NO YES LED Operation

This only displays when programming a panic or pendant transmitter. Select YES to turn a panic or pendant LED on during normal operation. Select NO to turn the LED off during normal operation. The LED always operates on all transmitters when the transmitter case is open and the tamper is faulted. Default is YES.

13.9.5 NEXT ZN NO YES Next Zone

Select YES to return to the ZONE NO: - prompt to program a new zone. Select NO to display the Alarm Action option.

13.10 Series Key Fobs

For an 1100 Series Key Fob set the House Code from 1 to 50. See House Code programming in System Options. Only zones 31-34 or 41-44 can be programmed as 1100 Series Key Fob zones. Refer to the 1100 Series Key Fob Programming Sheet (LT-0706) supplied with the 1100D Wireless Receiver and the 1100 Series Key Fob Install Guide (LT-0703) as needed.

To operate arming and disarming properly, the Key Fob should be assigned to a User Number with appropriate area assignments, however, the User Number does not have to exist at the time the Key Fob is programmed. The User Number can be added at the User Menu later by the User.

The following programming continues from when Key Fob YES is selected.

13.10.1 KF USER NO: Key Fob User Number

Enter the User Number used to identify the key fob user and their arming and disarming authority. Default is blank.

- User number 1 to 30 on XT30 panels
- User number 1 to 99 on XT50 panels

NOT IN USE Displays when the User Number entered does not exist in User Code programming. The key fob can be added, but the user must eventually be added to cause the key fob to operate.

13.10.2 SERIAL #: - Key Fob Serial Number

Enter the eight-digit serial number found on the wireless device.

ALREADY USED Zxx Displays when the serial number is already programmed. The programmed zone number displays.

13.10.3 SUPRVSN TIME: 0 Key Fob Supervision Time

Press any top row key to select the supervision time required for the key fob zone. Press COMMAND to accept the default time. Default is 0.

0 3 60 240 Press the Select key under the required number of minutes. The key fob must check in at least once during this time or a missing condition is indicated for that zone. 1100 Series key fobs automatically checkin based on the supervision time selected for the wireless zone, no additional programming is needed. Zero (0) indicates an unsupervised transmitter.

Note: When the panel is reset or a receiver is installed or powered down and powered up, the supervision timer restarts for all wireless zones.

13.10.4 BUTTONS: 4 Number of Key Fob Buttons

Enter the number of buttons (1, 2, or 4) on the key fob being programmed. Default is four buttons.

Note: If the key fob is a one-button model, programming continues at the Button Action section. Default button assignment for one-button key fobs is a Panic Alarm (PN) with no output assigned.

13.10.5 TOP BTM LFT RGT Key Fob Button Selection (Four Buttons)

This prompt only displays if the key fob being programmed is a four-button model. Press the Select key under the key fob button to program. The following list identifies the default button assignments:

- TOP Arming with areas 1, 2, and 3 assigned
- BTM Disarming with areas 1, 2, and 3 assigned
- LFT Panic Alarm (PN) with no output assigned
- RGT Arming with Area 1 assigned

13.10.6 TOP BTM Key Fob Button Selection (Two Buttons)

This prompt only displays if the key fob being programmed is a two-button model. Press the Select key under the key fob button to program. The following list identifies the default button assignments:

- TOP Arming with areas 1, 2, and 3 assigned
- BTM Disarming with areas 1, 2, and 3 assigned

ZONE INFORMATION

13.10.7 ACTION: XXXXXX **Button Action**

This option specifies the Button Action for an individual key fob button. The default action for the button selected is displayed. Press any Select key to display the Button Action options. To view more options press the COMMAND key.

ARM DIS TGL STA

ARM (Arm) - Arms selected areas and force arms bad zones.

DIS (Disarm) - Disarms selected areas.

TGL (Toggle Arm) - Toggles arm/disarm for selected areas and force arms bad zones when arming.

STA (Status) - Causes the key fob LED to indicate the arm/disarm status of the system.

PN PN2 EM EM2

PN (Panic) - Triggers a Panic zone type alarm with no restoral.

PN2 (Panic 2) - Triggers a Panic zone type alarm with no restoral when pressed simultaneously with any other Panic 2 button. No action occurs when pressed alone.

EM (Emerg) - Triggers an Emergency zone type alarm with no restoral.

EM2 (Emerg 2) - Triggers an Emergency zone type alarm with no restoral when pressed simultaneously with any other Emergency 2 button. No action occurs when pressed alone.

OUT RST UN

OUT (Output) - Causes an output to turn on steady, pulse, momentary, toggle or off.

RST (Sensor Reset) - Causes the panel to perform a standard Sensor Reset.

UN (Unused) - The button is not used and performs no action.

13.10.8 PRESS TIME: XXXXX **Button Press Time**

This option specifies the amount of time (SHORT or LONG) the user must press the button before the key fob sends a message to the wireless receiver. The default press time displays. Press any Select key to set the Button Press Time for Arm, Disarm, Toggle, Status, Output, and Sensor Reset.

Note: The Button Press Time is not programmable on Panic (PN or PN2), Emergency (EM or EM2) or Unused (UN) zones. For those zones the button press time is always two (2) seconds.

SHORT LONG

SHORT - Press the button for one-half (1/2) second to send the message to the wireless receiver.

LONG - Press the button for two (2) seconds to send the message to the wireless receiver.

13.10.9 AREA: 1 2 3 4 **Arm/Disarm Area Selection**

For Area systems, enter the areas, 1 to 4, to be armed/disarmed by the Key Fob button being programmed.

ARM AREAS: PERIM

This specifies the area to be armed by the Key Fob button being programmed.

For All/Perimeter systems, choose PERIM or ALL.

For Home/Sleep/Away or Home/Away systems, choose HOME, SLEEP, or AWAY.

After selecting the areas, for one-button key fobs the Zone No.: prompt displays.

For two-button or four-button key fobs, the Key Fob Button Selection option displays to program additional buttons.

13.10.10 OUTPUT NO: 0 **Output Number**

You can specify a relay output to operate when OUT (Output), PN (Panic), PN2 (Panic 2), EM (Emergency), or EM2 (Emergency 2) is selected for a key fob Button Action and the button is pressed. Valid range is 1 to 4. For an output turned on by a PN, PN2, EM, or EM2 button action, the output turns off when any area is disarmed.

To enter an output number, press a top row Select key followed by the output number. Press the COMMAND key.

13.10.11 ACTION:

Output Action

This option allows you to define the output action (STD, PLS, MOM, TGL, OFF) for the selected output number. The default is Steady.

STD PLS MOM TGL

STD (Steady) - The output is turned on and remains on.

PLS (Pulse) - The output alternates one second on and one second off.

MOM (Momentary) - The output is turned on only once for one second.

TGL (Toggle) - The output alternates between the on state and off state. Each button press toggles the output state.

OFF

OFF (Off) - The output is turned off. If programmed, the output was turned on by some other means such as another button press, a zone action, or a schedule.

Note: When the output is assigned to PN/PN2 or EM/EM2 button action and is turned on, the output turns off when any area is disarmed.

When the output action is steady, pulse or toggle and the output is turned on, the output remains on until:

- the output cutoff time expires
- the output is reset from the keypad menu
- toggled off

NOTE: All wireless programming is stored in the XT30 or XT50 panel. When using the XT30, the 1100D, 1100DI, or 1100DH Wireless Receiver obtains the necessary programming information from the panel each time the receiver powers up, when the programmer STOP routine is selected or the panel is reset. The receiver memory refresh takes up to 45 seconds to complete depending on the number of wireless zones programmed and the Red LED remains on during this time. Normal receiver operation is inhibited during the memory refresh period.

13.11 ALARM ACTION . . .

Alarm Action

The Alarm Action section allows you to change or confirm the default alarm characteristics of a zone type.

If you selected the non-24-hour zone type Blank, Night, Day, Exit, Auxiliary 1, or Auxiliary 2, the Alarm Action programming begins with Disarmed Open.

If you selected the 24-hour zone type Fire, Panic, Emergency, or Supervisory, the Alarm Action programming begins with Armed Open.

The Fire Verify zone type functions the same as Fire Type, with the following exceptions: When a Fire Verify zone is placed into shorted condition, the panel performs a Sensor Reset and does not send a report. If any Fire Verify or Fire zone initiates an alarm within 120 seconds after the reset, an alarm is indicated. If an alarm is initiated after 120 seconds, the cycle is repeated. If no other Fire Verify or Fire zone is alarmed within 120 seconds, a zone fault report is sent to the receiver.

13.12 DISARMED OPEN

Disarmed Open

Defines the action taken by the panel when the zone is opened while the area is disarmed. There are three actions to define:

- Message to Transmit
- Output Number
- Output Action

You must also make these selections for the Disarmed Short, Armed Open, and Armed Short zone conditions. Press the COMMAND key to continue.

ZONE INFORMATION

13.12.1 **Message To Transmit**

You can send two report types to the receiver: Alarm and Trouble. These are represented by the characters A and T. Press any Select key to display the zone report options.

ALARM - Selecting **A** allows an alarm report to be sent to the receiver and the bell output to activate according to zone type. See the Bell Action section. The zone name appears in the panel's alarmed zones status lists.

TROUBLE - Selecting **T** allows a trouble report to be sent to the receiver and the zone name to appear in the panel's alarmed zones status lists.

LOCAL - When you select **L**, an alarm report is NOT sent to the receiver. The bell output still activates according to zone type and the zone name appears in the panel's alarmed zones status lists.

- (dash) - When you select -, reports are NOT sent to the receiver. The bell output does not activate and there is no display in the panel's alarmed zones status list. Only the programmed Output Number activates.

13.12.2 **Output Number**

You can specify any of the outputs on the XT30/XT50 to be activated by a zone condition. The output can be activated regardless of the report to transmit or whether or not the zone is programmed as local. An output activated by a non-24-hour armed zone is turned off when the zone's area is disarmed by a user.

To enter an Output Number, press any Select key followed by the output number 1 to 4, 31-34, or 41-44. Press the COMMAND key.

13.12.3 **Output Action**

Entering an Output Number displays this prompt that allows you to assign an output action to the relay. A description of the available output actions is given below:

STEADY - The output is turned on and remains on until the area is disarmed, an output cutoff time expires, or the output is reset from the keypad User Menu.

PULSE - The output alternates one second on and one second off until the area is disarmed, an output cutoff time expires, or the output is reset from the keypad User Menu.

MOMENTARY - The output is turned on only once for one second.

FOLLOW - The output is turned on and remains on while the zone is in an off normal, or bad condition. When the zone restores, the output is turned off.

After you have selected the Message To Transmit, the display prompts you for the same three selections for Disarmed Short, Armed Open, and Armed Short conditions. If the zone is a 24-hour type, only the Armed Open and Armed Short conditions are displayed. When you have programmed all of the zone conditions, the Swinger Bypass selection is then displayed.

13.13 **Swinger Bypass**

YES allows the zone to be bypassed by the panel after one alarm, trouble, or local trip within one hour. Selecting **NO** disables swinger bypassing for this zone. Default is YES.

How Swinger Bypass works

If within one hour, a zone trips two times, the panel bypasses it until one of the following conditions occur; the area in which the zone is assigned is disarmed, the zone is manually reset through the Bypass Zones? keypad User Menu function, or the zone remains normal for one hour and the Reset Swinger Bypass is YES.

After the first trip, if the zone does not trip one more time before the remaining time expires, the bypass trip counter returns to 0 (zero) and the zone must trip a full two times within the next hour to be automatically bypassed.

A report of a swinger bypass is sent to the receiver if Bypass Reports has been enabled. See the **Bypass Reports** section.

Bypassed zones are automatically reset when the area they are assigned to is disarmed. All bypassed 24-hour zones are reset when the system is disarmed.

13.14 PREWARN: 12345

Prewarn Address

Option is only shown for an Exit zone.

At the start of the entry delay, all keypad addresses display **ENTER CODE:-**. If you want the prewarn to sound at all five addresses, leave the default as shown.

To delete an address, press the matching number on the keypad. To disable prewarning at all keypads, press a top row key to clear the addresses shown. Press the **COMMAND** key when the address selection is complete.

Note: On XT30 and XT50 systems, the prewarn tone stops at the keypad when the first digit of a user code is entered. If, within five seconds, a valid user code is not entered or an invalid user code is entered, the prewarn tone begins sounding again. Fifteen seconds must elapse before entering a digit silences the prewarn tone again.

13.15 ENTRY DELAY: 1

Entry Delay

Option is only shown for an Exit zone. Select the entry delay timer for this zone. Entry delay timers 1 and 2 are programmed in Entry Delay in the System Options menu.

13.16 CRS ZONE NO YES

Cross Zone

Select **YES** to enable cross-zoning for this zone. Cross-zoning requires this zone to trip twice, or this zone and another cross-zoned zone to trip, within a programmed time before an alarm report is sent to the receiver.

Note: To operate correctly, all cross-zone zones need to be programmed as the same zone type.

When a cross-zoned zone trips, the Output action assigned to the zone activates. See the Bell Action section. The cross-zone time specified in System Options begins to count down. See the Cross-Zone Time section. If another cross-zoned zone in the system faults, or if the first zone restores and faults again before the cross-zone time expires, the bell turns on and the panel sends an alarm report.

If no other cross-zoned zone in the system trips before the cross-zone time expires, the panel sends only a fault report from the first zone to the receiver.

Note: If CRS ZONE is YES, a valid CRS ZN TIME must be programmed for this feature to be enabled.

Cross-zoning is not compatible with Fire Verify zone types: You cannot enable cross-zoning for Fire Verify zones.

13.17 PRIORITY NO YES

Priority

Selecting **YES** allows you to provide additional protection for a zone by requiring it to be in a normal condition before its assigned area can be armed. A priority zone cannot be bypassed.

A Priority zone not in a normal condition cannot be armed. If a user attempts to arm the area, the keypad displays the bad zone name followed by **PRIORITY ZONE** and the arming is stopped.

13.18 ZONE NO: -

Zone Number

Enter the zone number you want to program next. Return to section 11.1 and follow the descriptions of each programming prompt. If all zones are programmed, press the **ARROW** key at the **ZONE NO: -** display to continue.

Stop

14.1

STOP

Stop

At the **STOP** prompt, pressing any Select key allows you to exit the programmer function of the XT30/XT50 panel. When selected, the panel performs an internal reset and exits the programmer. The Stop function causes the following conditions to occur:

- The system is DISARMED
- All 1100 Series DMP Wireless transmitters are reset to NORMAL
- The panel's Status List is CLEARED

During the Stop function, all keypad displays are momentarily disabled for two seconds. Afterwards, the programming function is terminated and the keypads return to the Status List display.

SET LOCKOUT CODE

Set Lockout Code

15.1

SET LOCKOUT CODE

Set Lockout Code

Pressing **COMMAND** at the Stop prompt displays **SET LOCKOUT CODE**. This feature allows you to program a special code that will then be required to gain access to the panel's internal Programmer through the keypad.

Changing the Lockout Code

You can change this code at any time to any combination of numbers from 1 to 5 digits long (1 to 65535). *Do not use leading zeros for the lockout code.*

1. Press any Select key. The display changes to **ENTER CODE: -**.
2. Enter a 1- to 5-digit code (do not enter a number higher than 65535). Press **COMMAND**.
3. Enter the new Lockout Code again. Press **COMMAND**. The keypad display changes to **CODE CHANGED**.

Once you have changed the code, it is important that you write it down and store it in a safe place. Lost lockout codes require the panel to be sent back into DMP for repair. You may cancel a Lockout Code by entering 00000 at the Set Lockout Code command prompt.

Lockout Code restriction

Do not set a Lockout Code higher than 65535.

Appendix

This section of the XT30/XT50 Programming Guide provides additional zone and system information.

16.1 Status List

The Status List is the current status of the system or records of recent system events that display on alphanumeric keypads. For example, in Home/Away systems you may see the display **SYSTEM READY**.

If an event were to occur on the system, such as an AC failure, the keypad would also display the **AC POWER -TRBL** message. This is a system event that is placed into the Status List to alert the user to a problem with the system.

Some Status List items remain in the display until manually cleared and some are cleared automatically when the condition returns to normal. Below is a list of status and event displays the keypad can show in the Status List:

Description	Must be manually cleared?
Fire and Supervisory zone alarms	Yes - by Sensor Reset
Fire and Supervisory zone troubles	No - clears when zone restores
Burglary zone alarms	No - clears at disarming.
All other zone alarms	No - clears when zone restores
Zone monitor displays	No - clears after approximately 8 minutes
Day zone alerts	No - clears after approximately 8 minutes
System monitor troubles (AC and battery trouble)	No - clears when condition restores
Armed status display (System On)	No
Disarmed status displays (System Ready, System Not Ready)	No
Remote keypad messages (Sent to the keypad by your office or central station)	No

Each item in the list is displayed for four seconds. When there are multiple items in the list, you can use the **COMMAND** or **Back Arrow** keys to scroll forward or back through the items.

16.2 False Alarm Reduction System Recently Armed report

The System Recently Armed report (S78) is sent when a burglary zone goes into alarm within two minutes of the system being armed.

16.3 Diagnostics Function

The XT Series panels contains a Diagnostics function that allows you to test the integrity of the cellular communication, cellular signal, and email communication. The Diagnostics function also displays the panel settings. To use Diagnostics, reset the panel, enter the Diagnostics code 2313 (DIAG), and press **COMMAND**.

Cellular Status

This option tests the individual components of cellular communication. Entry into the Cellular Status (CELL STATUS) menu will cause each component of the panel's cellular communication to be tested. The test will proceed until the first component failure or until all components have been tested with positive results. The test screen will display after each component and will be displayed for two seconds or until the **CMD** key has been pressed.

Cellular Signal

This option tests the cellular signal strength (CELL SIGNAL). The signal strength will be displayed with 1-7 boxes, with 7 boxes being the best signal available.

Email Status

The Email Status menu tests each component of the panel's e-mail communication. The test will proceed until the first component failure or until all components have been tested with positive results. The test screen will display after each component and will be displayed for two seconds or until the **CMD** key has been pressed.

Panel Settings

Hitting a top row key will allow access to the MAC Address, Serial Number, Panel Model, and Firmware Version.

MAC Address

Short for Media Access Control address. This hardware address uniquely identifies each network node. Not to be confused with an IP address, which is assignable. The MAC address is the panel on-board network hardware address. Press any top row Select key to display the panel MAC address. Press the COMMAND key to view the next prompt.

Serial Number

This number is the network communicator serial number. Reference this number for communicator date-of-manufacture, hardware version, etc. Press any top row Select key to display the Serial Number. Press the COMMAND key to view the next prompt.

Panel Number

This menu option displays the model number of the panel. The display will show XT30 or XT50 followed by 1-3 letters to indicate the communication type: C=Cellular, D=Dialer, N=Network.

Firmware Version

This menu option displays the Firmware Version number of the panel and date it was released.

16.4 Manual Telephone Line Seizure for Remote Programming

This feature allows you to connect to a service receiver, primarily used to bring a new account on-line as it allows you to upload panel programming completed in Remote Link™. There are two options to allow manual phone line seizure: Number and Pickup. Using the Number method, the phone number of the service receiver connected to Remote Link is entered. The panel will then call the receiver. Using the Pickup method, the panel seizes the phone line while the receiver is ringing the line.

The two methods to seize a phone line are described below.

NBR

After completing panel programming in Remote Link, set a trap to seize the panel when it calls. Traps are set by selecting Panel > Trap. Refer to the Remote Link User's Guide, LT-0565, or Remote Link's Help File for complete information about setting traps.

Then, from the panel, enter 984 and the COMMAND key, while the panel is in the Status List. The keypad display changes to **NBR PICKUP**. Select **NBR**. Enter the phone number for the service receiver connected to the Remote Link computer. Press each number key slowly and deliberately. The panel dials each number as it is pressed. If you make a mistake, press the Back Arrow key. The panel will stop dialing and return to the Status List.

You can enter up to 15 characters for the phone number. To enter a # (pound sign) press the fourth (far right) Select key, and to enter an * (asterisk) press the third Select key. Program a pause by entering the letter P. Program a dial tone detect by entering the letter D. Cancel call waiting by entering *70P as the first characters. These characters are counted as part of the allowable 15 characters. Press COMMAND after you enter the phone number.

After the phone number is entered the panel calls the receiver connected to Remote Link to download the new programming. Remote Link then traps the panel and uploads the programming into the panel.

Note: The panel makes ten attempts to reach the receiver. If while attempting to contact the receiver, the panel needs to send an alarm report, the dialing attempts are stopped and the panel can use the phone line to send its report.

PICKUP

After completing panel programming in Remote Link, connect to the panel by selecting Panel > Connect. Refer to the Remote Link User's Guide, LT-0565, or Remote Link's Help File for complete information about connecting to panels.

When the telephone line at the panel rings, enter 984 and the COMMAND key, while the panel is in the Status List. The keypad display changes to **NBR PICKUP**. Select **PICKUP** to allow the panel to seize the line. The panel immediately seizes the phone line and sends a carrier tone to the receiver.

After the panel has seized the line, send the file from Remote Link by selecting Panel > Send. Remote Link then uploads the new programming into the panel.

16.5 Using the Walk Test

The XT30/XT50 panel provides a walk test feature that allows a single technician to test all the protection devices connected to zones on the system. Conduct the Walk Test within 30 minutes of resetting the panel. The Walk Test automatically ends if no zones are tripped for 20 minutes. **TEST IN PROGRESS** displays at all keypads. When five minutes remain, **TEST END WARNING** displays. If any areas are armed the Walk Test does not start and **SYSTEM ARMED** displays.

WALK TEST

Walk Test

STD WLS

To conduct the Walk Test, reset the control panel by momentarily placing a jumper on J16 then wait one minute. From the keypad, enter the code 8144. The keypad displays **WALK TEST**. If the system is monitored and the communication type is DD or NET, the system sends a System Test Begin report to the central station. All programmed zones are included in the test.

STD (Standard Walk Test) - Select STD to Walk test zones. All programmed zones are included in the test.

WLS (Wireless Check-in Test) - Select **WLS** to automatically test 1100 Series wireless transmitter communications. Includes all wireless devices except key fobs and transmitters programmed for a supervision time of 0 (zero).

Note: For the XT30, Wireless Check-in Test operation only displays when connected to 1100D Wireless Receiver Version 105 or higher.

WALK TEST

Trip Counter for Walk Test (STD)

TRIPS: XXX END

Displays the number of zone trips during the Walk Test.

- Each time a selected zone trips, the keypad buzzes and the bell rings for two seconds.
- Each time a FI, FV, or SV zone trips, a Sensor Reset occurs.

END - Press the Select key directly below END to stop the Walk Test. When the Walk Test ends or a 20 minute time-out expires, a final Sensor Reset occurs. The System Test End message is sent to the receiver along with Verify and Fail messages for each zone under test. Faulted zones then display on the keypad.

WIRELESS TEST

Trip Counter For DMP Wireless Check-in Test (WLS)

CHKIN: XX/ZZ END

Displays the number of wireless zones that automatically communicate a supervisory check-in message.

- The number of zones that check in. (XX in the example).
- The total number of wireless zones programmed for supervision that should check in. (ZZ in the example).

END - Select END to stop the Wireless Check-in Test. When the test ends or a 20-minute time-out expires, normal wireless zone processing returns. If all transmitters check-in, both numbers will match within three (3) minutes. If a transmitter has multiple zones (1101, 1114, etc.), all zones will be included in the counts. Failed wireless zones will then display on the keypad.

TEST END WARNING

Test End Warning

When no zones have been tripped and five minutes remain on the 20 minute Walk Test timer, the keypad displays **TEST END WARNING** and the keypad tones. If no additional test zone trips occur, the test ends and a final Sensor Reset automatically occurs. The System Test End message is sent to the receiver along with Verify and Fail messages for each zone under WALK test. Faulted zones then display on the keypad.

SOUTH LOBBY

Failed Zones Display

ZONE: 10 -FAIL

Each zone that did not trip at least once during the Walk Test displays on the keypad that initiated the test. Any Fire (FI) Panic (PN) or Supervisory (SV) 24-hour zone that is faulted at the end of the Walk Test displays a trouble condition for that zone regardless of the message programmed for the open or short condition of the zone and a zone trouble is sent to the receiver. Press the COMMAND key to display the next failed zone.

For the Wireless Check-in Test, failed wireless zones display only on the keypad. Zone Verify/Fail reports are not sent to the central station receiver for the wireless checkin test.

16.6 Keypad Speaker Operation

When using LCD Keypads, the panel provides distinct speaker tones from the keypad for Fire, Burglary, Zone Monitor, and Prewarn events. The list below details the conditions under which the speaker is turned on and off for each event.

Fire	On - Fire zone alarm and Bell Output are ON. Off - Alarm Silence or briefly when a key is pressed.
Burglary	On - Burglary zone alarm and Bell Output and is ON. Off - Alarm Silence or briefly when a key is pressed.
Zone Monitor	On - One time only when a monitored zone is tripped. Off - After one tone.
Prewarn	On - During Entry Delay. Off - When Entry Delay expires, when a Valid Code is entered, or briefly when a key is pressed.

16.7 Cross Zoning

Caution must be taken when cross zoning devices to ensure that the Cross Zone Time is long enough to allow an intruder to trip both devices before it expires. A Cross Zone Time that is too short may allow an intruder to trip the devices and allow only a zone fault report be sent to the central station.

When a Cross Zoned zone trips, a FAULT report is sent to the SCS-1R Receiver. When two Cross Zoned zones trip within the Cross Zone Time, both zones send ALARM signals to the receiver. For example, if zones 1 and 2 are Cross Zoned zones, and only zone 1 trips, a FAULT report is sent to the receiver for zone 1. If zone 1 trips and zone 2 trips within the Cross Zone Time, an ALARM report is sent to the receiver for zone 1 and zone 2.

Note: To operate correctly, all cross-zone zones need to be programmed as the same zone type.

16.8 Zone Type Descriptions

This section describes applications for the default zone types in Zone Information programming.

NT (Night Zone) - Controlled instant zone used for perimeter doors and windows and interior devices such as PIRs and glassbreak detectors.

DY (Day zone) - Used for emergency doors or fire doors to sound the keypad buzzer and display the zone name when the zone is faulted. Day zones also will send alarm reports to the receiver during the system's armed periods.

EX (Exit zone) - Initiates the entry delay timer when its assigned area is fully armed. Also, can initiate an exit delay timer to allow a user to exit an area after the arming process has started.

PN (Panic zone) - Used for connecting to mechanical devices that allow a user to signal an emergency alarm. Panic zones can provide either a silent or audible alarm with or without reporting to a central station receiver.

EM (Emergency zone) - These are used for reporting medical or other non-panic emergencies to the central station.

SV (Supervisory zone) - Used to provide 24-hour zone supervision. Typical applications are high water, and low and high temperature gauges.

FI (Fire zone) - Used for any type of powered or mechanical fire detection device. Typical applications are for smoke detectors, sprinkler flow switches, manual pull stations, and beam detectors.

FV (Fire Verify zone) - Used primarily for smoke detector circuits to verify the existence of an actual fire condition. When a Fire Verify zone initiates an alarm, the panel performs a Fire Reset. If any Fire zone initiates an alarm within 120 seconds after the reset, an alarm is indicated. If an alarm is initiated after 120 seconds, the cycle is repeated.

A1 and A2 (Auxiliary 1 and Auxiliary 2) - These zones are similar to a Night zone and are typically used to protect restricted areas within a protected premises. Auxiliary 2 zones do not appear in the Status List.

AR (Arming zone) - This zone allows you to connect a keyswitch to a zone and use it to arm and disarm the system.

Zone Information Assign Area and Disarmed condition for NT, DY, EX, A1, and A2 only. Assign Prewarn and Entry Delay for EX only. Assign Style for AR only. Assign 31 to 34 or 41 to 44 to Key Fobs or wireless output modules.	Key Fob N or Y	Type -- NT DY EX FI PN EM SV A1 A2 FV AR	Area INT BDRM PERIM or 1 to 4	Wireless				DMP Wireless				Disarmed Open		Disarmed Short		Armed Open		Armed Short		Swinger	Prewarn	Entry Delay	Cross Zone	Priority	TGL ARM DIS STEP MNT
				1101 Contact	1101 External Contact N/O?	1114 Contact	Supervision Time	1142 LED Operation	Output *	Action	Message	Output *	Action	Message	Output *	Action	Message	Output *	Action						
				INT or EXT	N or Y	1 2 3 4	0 3 60 240	N or Y	- 0 S	S P M F	- A T L -	- 0 S	S P M F	- A T L -	- 0 S	S P M F	- A T L -	- 0 S	S P M F						
NIGHT	N	NT		N	INT	N	1	240	Y	-	0	S	A	0	S	A	0	S	Y				N		
DAY	N	DY		N	INT	N	1	240	Y	T	0	S	A	0	S	A	0	S	Y				N		
EXIT	N	EX		N	INT	N	1	240	Y	-	0	S	A	0	S	A	0	S	Y			1-2	N		
FIRE	N	FI		N	INT	N	1	240	Y														N		
PANIC	N	PN		N	INT	N	1	240	Y														N		
EMERGENCY	N	EM		N	INT	N	1	240	Y														N		
SUPERVISORY	N	SV		N	INT	N	1	240	Y														N		
AUXILIARY 1	N	A1		N	INT	N	1	240	Y	T	0	S	A	0	S	A	0	S	N				N		
AUXILIARY 2	N	A2		N	INT	N	1	240	Y	T	0	S	A	0	S	A	0	S	N				N		
FIRE VERIFY	N	FV		N	INT	N	1	240	Y														N		
ARMING	N	AR		N	INT	N	1	240	Y														N		

* Outputs = 1 to 4, 31 to 34, or 41 to 44. = This function not available for this zone type.

16.9

Zone Type Defaults

The XT30/XT50 panel contains 11 default zone types for use in configuring the system. These zone types provide the most commonly selected functions for their applications. All zone types can be customized by changing the variable options listed below.

Below is a description of the various zone options shown on the table above.

Zone Type Defaults - These are complete spellings of the abbreviations used for the zone types.

Key Fob - Indicates whether a DMP key fob is programmed.

Type - These are the abbreviations you will see on the keypad for the zone types.

Area - For a ALL/PERIM or HOME/SLEEP/AWAY system, this is either Interior, Bedroom, or Perimeter. For an AREA system use 1 to 4.

Wireless - These options are for use with the DMP Wireless Receiver.

1101 Contact - Indicates if the DMP 1101 Universal Transmitter is programmed to use the internal or external contact.

1101 External Contact N/O? - Identifies whether externally installed contacts are programmed as a normally open (N/O) or normally closed (N/C) circuit. Y = N/O Contacts. N = N/C Contacts.

1114 Contact - Indicates if the 1114 Zone Expander is programmed for contact(s) 1, 2, 3, or 4.

Supervision Time - Selects the number of minutes for DMP wireless supervision.

1142 LED Operation - Identifies DMP 1142 Wireless Two-Button transmitter LED operation.

Message - A = alarm report, T = trouble report, L = local with no report, - (dash) = no report.

Output - The 1 to 4 on-board switched ground (open collector) outputs, 31 to 34 and 41 to 44 wireless outputs, wireless key fob zones, or keypad bus zones.

Action - This selects the type of relay output: S = steady, P = pulse, M = momentary, and F = follow

Swinger Bypass - Allows the zone to be automatically shunted after three trips.

Prewarn - This selects the keypad address that sounds the entry prewarn for this zone.

Entry Delay - Selects the entry delay timer used for this zone.

Cross Zone - Provides cross zoning for this zone.

Priority - Requires this zone to be in a normal condition before the area can be armed.

Style - The abbreviations that display on the keypad for arming zone style. TGL = Toggle,

ARM = Arm only, DIS = Disarm only,

STEP = Wireless arming, MNT = Maintain

16.10 Common Keypad Messages

Message	Meaning	Possible Solutions
INVALID CODE	The user code you have entered is not recognized by the system.	Check the user code and try again.
CLOSING TIME	The schedule has expired but the system has not been armed.	Users still on the premise should arm the system or extend the schedule to a later time.
AC TROUBLE	The system is not getting proper power.	Check that the AC connections are good.
BATTERY TROUBLE	The battery is either low or missing.	Check that the battery connections are good and the battery is still good.
SYSTEM TROUBLE or SERVICE REQUIRED	There is a problem with one or more components in the system.	Make sure the J16 jumper is removed from the panel. Make sure there is not a short or open condition on the green data wire to the keypad. You may also need to check that all of the keypads and expansion modules on the bus are good.
SYSTEM BUSY	The system is performing another task with a higher priority.	Wait a few moments for the system to complete the task. Make sure the J16 jumper is not on the panel. If the message displays for a long period of time, the processor could be locked up.
TRANSMIT FAIL	The panel has attempted to communicate with the central station 10 times and has not succeeded.	Verify your communication type, account number, and phone number. Make sure the telephone line is connected and working properly.
ENTER CODE (When entering Programming)	A lockout code has been programmed for the panel.	Enter the lockout code.
WIRELESS TROUBLE	The panel is unable to communicate with the wireless receiver.	Verify the receiver is properly connected to the panel. Verify the correct House Code is programmed in System Options.
	The wireless receiver is missing.	

Listings and Approvals

California State Fire Marshal (CSFM)
ETL: ANSI/SIA CP-01 False Alarm Reduction
ANSI/UL 1023 Household Burglar
ANSI/UL 985 Household Fire Warning
ANSI/UL 1635 Digital Burglar
FCC Part 15 ID: CCKPC0096
FCC Part 68 Registration ID CCKAL00BXT50
Industry Canada ID: 5251A-PC0096



800-641-4282

www.dmp.com

Made in the USA

INTRUSION • FIRE • ACCESS • NETWORKS

2500 North Partnership Boulevard

Springfield, Missouri 65803-8877

LT-0981 1.01 © 2008 Digital Monitoring Products, Inc.

8274

