

DSC



T-Link TL250/300 Network Communicator

Application Guide



Copyright DSC June 2007

Related Documents

- Surgard System III Installation Manual PN 29034500
- Surgard System III Console Software Help File PN 29034574
- SG-DRL3 IP Line Card Installation Manual PN 29034630
- T-Link TL-250/TL300 Installation Manual PN 29034631
- PC5108 Zone Expander Installation Instruction PN 29001758

Compatible Control Panels & Hardware

- Power864 - PC4020 v3.3 or higher (Rev04B hardware)
- MAXSYS -PC5020 v3.x or higher (Rev03 hardware)
- Any Control Panel with Bell Follower output
- Any Control Panel with Telephone (Tip/Ring) output (TL300 only)
- PC5108 Zone Expander
- See Appendix B - T-Link Compatibility Chart

Compatible Software

- T-Link Console Software
- DLS 2000 with T-Link Driver Pack
- DLS SA with T-Link Driver Pack

Agency Listings

- UL AA (High Line Security) Residential and Commercial Fire & Burg
- ULC Level 4, Residential and Commercial Fire & Burg
- DSC has received ULC Level-5 for Internet monitoring using the T-Link TL250/TL300 and Sur-Gard System III communication solution – the first in the industry to achieve this. ULC has contested all test reports from competitors stating that they do not comply with the Canadian requirements of ULC-S304 for Level 3. DSC has worked closely with ULC in developing a high standard for security and reliability to ensure that Internet communication is a valid and reliable medium. The T-Link TL250/TL300 and Sur-Gard System III Internet monitoring solution also have UL-AA listing for high line security of Fire and Burg applications.

DSC has also received UL and ULC approval of the DPU-414 serial / parallel printer for Commercial Fire and Burg applications. This printer can now be used in any central station application or as a panel event printer where required for UL/ULC.

- FCC Part 15
- IC
- CE, CISPR22 Class B, EN50120-4:1995, EMI

Technical Support

1-800-387-3630 (Canada & US)

905-760-3036

Web Site: www.dsc.com

Revision Record

Retain these records in front of manual. On receipt of revision, insert revised pages in manual and enter revision number, date inserted and initial.

Revision Number	Revision Date	Date Filled	By

Revision Number	Revision Date	Date Filled	By

List of Effective Pages

Subject	Page	Date
Title Page	T-1	Oct. 11/2005
A page	A	Oct. 11/2005
B page	B	Oct. 11/2005
C page	C (Blank)	Oct. 11/2005
TOC	i	Oct. 11/2005
	ii	Oct. 11/2005
Section 1 Introduction	1	Oct. 11/2005
	2	Oct. 11/2005
	3	Oct. 11/2005
	4 (Blank)	Oct. 11/2005
Section 2 System Overview	5	Oct. 11/2005
	6	Oct. 11/2005
	7 (Foldout)	Oct. 11/2005
	8 (Blank)	Oct. 11/2005
	9	Oct. 11/2005
	10	Oct. 11/2005
	11	Oct. 11/2005
	12	Oct. 11/2005
	13	Oct. 11/2005
Section 3 Installation	14	Oct. 11/2005
	15	Oct. 11/2005
	16	Oct. 11/2005
	17	Oct. 11/2005
	18	Oct. 11/2005
	19	Oct. 11/2005
	20	Oct. 11/2005
	21	Oct. 11/2005
	22	Oct. 11/2005
	23	Oct. 11/2005
	24	Oct. 11/2005
	25	Oct. 11/2005
	26	Oct. 11/2005
	27	Oct. 11/2005
Section 4 Programming	28	Oct. 11/2005
	29	Oct. 11/2005
	30	Oct. 11/2005
	31	Oct. 11/2005
	32	Oct. 11/2005
	33	Oct. 11/2005

Section 5 T-Link Programming Options	33 34 35 36 37 38	Oct. 11/2005 Oct. 11/2005 Oct. 11/2005 Oct. 11/2005 Oct. 11/2005 Oct. 11/2005
Section 6 Testing and Troubleshooting	39 40 41	Oct. 11/2005 Oct. 11/2005 Oct. 11/2005
Glossary	42 43 44 45 46 47 48	Oct. 11/2005 Oct. 11/2005 Oct. 11/2005 Oct. 11/2005 Oct. 11/2005 Oct. 11/2005 Oct. 11/2005
Appendix A		
Appendix B		
Appendix C		
Appendix D		
Appendix E		

This page intentionally left blank

Table of Contents

Section	Description	Page
Section 1: Introduction		1
1.1	T-Link Version Differences	1
1.2	Panel Connection (Mode 4)	2
1.3	Secure IP Environment	2
1.4	Call Directions	2
1.5	Supervision	2
1.6	Programming	2
1.7	Remote functions	2
1.8	Specifications/Requirements	3
Section 2: System Overview		5
2.1	Introduction	5
2.2	Network-Loading / Bandwidth Impact	6
2.3	T-Link Operating Modes	9
2.3.1	Mode 1: Bell Follower (TL250 Only)	9
2.3.2	Mode 2: 4-zone Stand-alone (TL250 and TL300)	9
2.3.3	Mode 3: 12-zone Stand-alone (TL250 and TL300)	9
2.3.4	Mode 4: Standard Mode (TL250 only)	9
2.3.5	Mode 5: DVACS®* Mode (V1.10 or later) (TL250 Only)	9
2.3.6	Telephone Simulation (TL300 only)	9
2.4	T-Link Console Software	10
2.4.1	Local and Remote Programming	11
2.5	DLS/DLS SA Software	11
2.6	Sur-Gard System III	11
2.6.1	SG DRL3-IP Line Card	12
2.6.2	System III Console Software	12
Section 3: Installation		14
3.1	General	14
3.2	Wiring	15
3.2.1	KEYBUS Wiring	16
3.2.2	Zone/Input Wiring	16
3.2.3	PGM Wiring	17
3.3	Mode 1: Bell Follower Configuration	18
3.4	Mode 2: 4-zone Stand-alone Configuration	18
3.5	Mode 3: 12-zone Stand-alone Configuration	19
3.6	Mode 4: Standard Configuration	21
3.6.1	Power864 and Maxsys Panel Setup and Installation	21
3.6.2	Standard Connection with PC4020(CF)/PC5020(CF)	21
3.6.3	Wiring T-Link to a DSC Compatible Control Panel	21
3.6.4	Programming the PC5020 V3.2 for T-Link Communication	22
3.6.5	Programming Steps:	23
3.6.7	Maxsys	23
3.6.8	CE Installations	23
3.6.9	UL/ULC Installations	23
3.6.6	Programming Maxsys (PC4020)	23
3.7	Mode 5: DVACS Installation	25
3.7.1	DVACS Panel Installation.	25
3.7.2	DVACS Events	25
3.8	TL300 Simulated Phone Installation	27
3.8.1	T-Link TL300 Panel Installation.	27
3.8.2	T-Link TL300 Operation.	27
Section 4: Programming		28
4.1	System III - DRL3-IP Programming	28
4.2	T-Link Programming	29
4.3.1	T-Link Console Software Programming	32
4.3.2	Keypad Programming	32
4.3.3	PC5108	32
4.4	MAXSYS (PC4020) Programming	30
4.4.1	Keypad Programming	30
4.4.2	DLS Programming	30

Section 4: Programming (Cont.)

4.5	PowerSeries (PC5020) Programming	31
4.6	T-Link TL 250/300 Programming	32
4.6.1	Keypad - For Maxsys Accessing	32
4.6.2	T-Link Console Software on LAN/WAN	32
4.6.3	T-Link Console Software direct connection.	32

Section 5: T-Link Programming Options.....33

Section 6: Testing & Troubleshooting.....39

6.1	Testing	39
6.1.1	Mode1: Bell Follower Configuration	39
6.1.2	Mode 2: 4-zone Stand-alone Configuration	39
6.1.3	Mode 3: 12-zone Stand-alone Configuration	39
6.1.4	Mode 4: Standard Configuration	39
6.1.5	Mode 5: DVACS Configuration	39
6.2	Troubleshooting	40
6.3	Resetting to Factory Defaults	41
6.3.1	Modes 1, 2, 3 and 5:	41
6.3.2	Mode 4 and TL300 Simulated Telephone:	41

Glossary 42

App A: . Network Information Work Sheet 44

App B: . T-Link Compatibility Chart 45

App C: . T-Link Events..... 46

App D: . Network Protection 47

App E: . Cat5 Crossover Cable..... 48

List of Illustrations

Figure	Description	Page
1.1	T-Link Module	1
2.1	Simple System Configurations	5
2.2	System Overview	7
2.3	System III Console Software	13
3.1	Controls & Indicators	15
3.2	KEYBUS Wiring	16
3.3	PGM Wiring	17
3.4	Bell Follower Installation.	18
3.5	4-zone Stand-alone Installation	18
3.6	12-zone Stand-alone Installation	19
3.7	PC5108 Expander Module	19
3.8	PC4020/PC5020 Standard Wiring Connections.	21
3.9	Battery and AC Power Lead Routing for UL Listed Commercial Fire Systems	22
3.10	Standard DVACS Installation.	25
3.11	T-Link TL250/DVACS Installation.	25
4.1	T-Link Console Software	32

List of Tables

Table	Description	Page
Table 1.1:	T-Link Version Differences	1
Table 1.2:	Installation Kit Parts List	1
Table 1.3:	T-Link Specifications	3
Table 2.1:	T-Link Console Software Functions	10
Table 2.2:	DLS Functions:	11
Table 5.1:	T-Link Programming Options	33
Table 6.1:	Status Indicators	40

Section 1: Introduction

The T-Link TL250/300 modules are network internet communicators that sends alarm system information to a DSC Surgard System III central station receiver. The module is pre-programmed with the most commonly used settings for quick installation. Default options can be custom programmed using T-Link Console software if required.

1.1 T-Link Version Differences

The TL250 version 1.0 supports 4 operating modes and is compatible with all versions of T-Link Console software and all versions of the SG-DRL3-IP receiver line card. The TL250 CE version 1.10 supports DVACS panel conversion (Canada only). The TL300 Version 1.20 supports Modes 2, 3, 4 and simulated telephone communication for third party control panels. The TL300 also has a new zone type (98, Panel Absent) and supports direct programming with an LCD 5500 keypad. Corresponding version numbers for SG DRL3-IP and T-Link Console are required to ensure compatibility (e.g., SG DRL3-IP v1.10 and T-Link Console v1.10 are required for corresponding T-Link TL250 v1.10).

Table 1.1: T-Link Version Differences

Feature	Version 1.00	Version 1.10	Version 1.20	Version 1.30
Mode 1: Bell Follower	✓	✓	✓	✓
Mode 2: 4-zone	✓	✓	✓	✓
Mode 3:12-zone	✓	✓	✓	✓
Mode 4:Standard (Maxsys/PowerSeries)	✓	✓	✓	✓
Mode 5:DVACS	✗	✗	✓	✓
T-Link Console Software	✗	✗	✓	✓
SG DRL3-IP Line Card	All versions	v1.1 and higher	v1.2 and higher	v1.3 and higher
Account Codes	All versions	v1.1 and higher	v1.2 and higher	v1.3 and higher
Telephone Simulation	6-digit	10-digit	10-digit	10-digit
Default Installer Code	✗	✗	✓	✓
Zone 98 support (Panel Absent)	✗	✗	✓	✓

T-Link TL250 is supported by two installation kits. The TL250/TL300CE hardware also includes a ferrite core for EMI suppression and an RJ-45 to RJ-45 connector mounted on a mounting bracket to facilitate internal/external connection to a LAN/WAN.

Table 1.2: Installation Kit Parts List

TL250	TL250/TL300CE	TL300
T-Link TL250 module..... Qty 1	T-Link TL250 module Qty 1	T-Link TL300 module Qty 1
Standoffs Qty 4	Standoffs Qty 4	Standoffs Qty 4
Ground Wire Kit..... Qty 1	Ground Wire Kit..... Qty 1	Ground Wire Kit..... Qty 1
	*TL250 Network Protection Qty 1	
	*RJ45 to RJ45 Mounting Plate Qty 1	

*Refer to Appendix D for installation details.

Figure 1.1: T-Link Module



1.2 Panel Connection (Mode 4)

The T-Link module and the control panel are connected with a cable that snaps onto the PC-Link header on the T-Link module and the control panel. Screw terminals on the unit provide the connection for the 12VDC from the panel. The T-Link module will draw 250mA in normal operation and 275mA when the PGM output is active.

1.3 Secure IP Environment

The IP communication from the T-Link module to the central station is a secure polling environment. If the unit is replaced/substituted, tampered or damaged, the central station will either receive a signal from the panel over the backup phone line and/or have an indication that the account is not present on the network. If a network user tries to block or mimic (hack) the signals from the T-Link module, the SG DRL3-IP receiver line card will report the tampering to the automation software.

1.4 Call Directions

The T-Link module is intended to be the primary means of communication to the receiver/central station. However the call direction options are functions of the panel that the unit is attached to (Modes 4,5 only). If the T-Link module fails to communicate the event to the central station the panel will redirect the call via its digital dialer. Because the panel sees the T-Link module as just another phone number to call, all programming options regarding telephone backup and call directions are still available.

1.5 Supervision

The panel, T-Link and the central station are in constant communication with each other. By using network status checks or normal signals the communication path is confirmed. This provides the panel or the central station receiver (if using the SG DRL3-IP) a complete picture of the status of the site and the communications. If any point is broken the panel will display the trouble on the keypad and report a trouble using the dialer, and the central station will flag the missing account.

1.6 Programming

The only programming required on the unit is the IP configuration. This is done from the control panel's keypad or T-Link Console software. When the T-Link is programmed it should not require changes. All other programming is in the control panel and can be programmed from a keypad or through DLS.

1.7 Remote functions

The connection to the panel uses the PC-Link header, all DLS communications, commands and events are available. Using the SA software, the end user has the ability to administer the panel(s) over the network remotely.

1.8 Specifications/Requirements

The maximum allowable current draw from a compatible DSC panel on the Aux terminal Output is 500 mA @ 12VDC. Operational current draw of the T-Link TL250/TL300 is 250 mA. The T-Link TL250/TL300 module has 2 switched negative programmable outputs (50 mA @ 12 VDC).

Table 1.3: T-Link Specifications	
Input Voltage:	12 VDC
Input Current:	250 mA (275 mA with PGM or PC5108)
Dimensions:	3.25" x 5.25" (8.3 cm x 13.3 cm)
Operating Temperature:	32°-122°F (0°-49°C)
Output Protocols:	UDP/IP 10/100 BaseT half duplex, TCP/IP for Console and DLS communications
Input Protocols:	PC-Link (SIA format), DVACS (V1.10 and higher)
Digital Inputs:	4-digital inputs (can be increased to 12 using the PC5108)
Connectors:	4-pin header for the PC-Link and RJ-45 for Ethernet, DVACS adaptor (DVACS kit only)
Programming:	Panel keypad, or remote T-Link console.
Network:	Ethernet LAN/WAN 10 BaseT or 10/100 BaseT
E-mail:	sends alarm messages to maximum 2 E-mail addresses (NOT available for DVACS installations)
Downloading Support for DSC Panels:	DLS-2002, DLS2000 and/or System Administrator software
Multiple Central Stations:	primary and backup via phone line* (NOT available for DVACS installations).
Call Direction Options: primary or backup communicator using panel call direction (NOT available for DVACS installations).
Approval Listings: FCC, IC, CEUL (Grade of Service AA, Encrypted Line Security)ULC (Signal Channel Security Level 4/5)
Network Loading	See Section 2.2 Network Loading/Bandwidth Impact, Page 6

NOTE: This manual shall be used with the Installation Manual of the associated Alarm Controller for installation.

NOTE: For UL Listed fire installations, shared on-premises communication equipment is required to be UL Listed for Information Technology Equipment. The communication medium between protected property and communications service provider must be for the exclusive use of the protected property and not shared with other communications service provider subscriber.

NOTE: When a hub or router/gateway is used on the premises with the T-Link TL250/TL300, 24-hr. standby power is required for these devices (i.e., UL listed UPS, battery backup).

NOTE: This equipment (T-Link TL250/TL300) shall be installed and used within an environment that provides the POLLUTION DEGREE MAX 2 and OVERVOLTAGES CATEGORY II NON-HAZARDOUS LOCATIONS, indoor only. The equipment must be FIXED and permanently connected, and is intended to be installed by SERVICE PERSONS (i.e., having the appropriate technical training and experience necessary to be aware of hazards which that person may be exposed to in performing the task, and of measures to minimize the risks to that person or other persons).

CAUTION

NOTE: Ethernet communication lines must be connected to an approved (acceptable to local authorities) type NID (Network Interface Device) before leaving the premises (e.g., UL installations, UL60950 Listed NID).


This page is intentionally left blank

Section 2: System Overview

2.1 Introduction

The T-Link series of Network Communicators are intended to transmit Alarm information via Local Area Network (LAN). T-Link modules must operate within an Ethernet LAN/WAN. Constant monitoring provides a fully supervised environment. The minimum LAN requirements are a router/firewall (e.g., D-Link 704D) and broadband modem (Cable/ADSL). PCs with DLS SA System Administrator software and/or T-Link Console software. Network addresses for the T-Link, Router/Firewall, and PCs can have Dynamic (DHCP) or static addresses.

Figure 2.1 Simple System Configurations



In the simple network configuration (Mode 2), the T-Link functions as a stand alone 4-zone panel. Alarm information is transmitted to a System III receiver located at the Central monitoring station via the customer LAN. This system can be expanded to 12-zone coverage with the T-Link mode 3 configuration or can be connected to an alarm panel to provide all of the features available by telephone connection. Refer to Figure 2.2, System Overview.

T-Link modules can be configured as a static or dynamic (DHCP) IP address. The number of T-Link modules that can be connected to a LAN/WAN network is limited only by the network data traffic capacity.

2.2 Network-Loading / Bandwidth Impact

The following data is required by the Network Administrator to assess T-Link communication impact on the existing network.

NOTE: To ensure that alarm communications do not “mix” with other traffic on the network T-Link communications should occur on a dedicated subnet. If multiple layers of security are required; individual traffic patterns may be more or less than those identified in the following tables. The following traffic calculations are based on the minimum layers of security necessary to support T-Link communications.

Network utilization is determined by upon the following factors:

- the number of T-Links connected on the network
- the presence or absence of a logging receiver
- the amount of alarm traffic per T-Link
- the amount of E-mails sent (1Kbyte per E-mail)
- the enabling/disabling of network supervision
- the enabling/disabling of encryption
- the speed of the network (10Mbps/100Mbps)

Supervision of accounts for the greatest use of network bandwidth with a transmission occurring every ten seconds, actual alarm events produce negligible traffic. Supervision of 512 T-Link Accounts results in a total transfer of less than 700 Mbytes in a 24 Hr. period. Alarm Data + Openings/Closings reporting + Periodic Test for 512 T-Link Accounts is Typically less than 1 Mbyte per 24-hour period.

The following tables outline the average daily bandwidth required to bring T-Link modules on-line, and provide TCP/IP communications for a maximum installation of 512 supervised and 512 unsupervised totalling 1024 T-Link accounts per receiver line card.

	Overhead Bytes:	= (IP 20 Bytes) + (UDP 8 Bytes) + (Ethernet 14 Bytes)	= 42 Bytes
Supervision	Encrypted:	= 42 Bytes (Overhead) + 37Bytes (Heartbeat)	= 79 Bytes
	Unencrypted:	= 42 Bytes (Overhead) + 27Bytes (Heartbeat)	= 69 Bytes
Alarm Data	Encrypted:	= 42 Bytes (Overhead) + 69 Bytes (SIA Data)	= 111 Bytes
	Unencrypted:	= 42 Bytes (Overhead) + 58 Bytes (SIA Data)	= 100 Bytes
RX ACK	Encrypted:	= 42 Bytes (Overhead) + 37Bytes (ACK)	= 79 Bytes
	Unencrypted:	= 42 Bytes (Overhead) + 35 Bytes (ACK)	= 77 Bytes

Supervision:	Encrypted		Unencrypted	
	10 Mbps	100 Mbps	10 Mbps	100 Mbps
Bytes Per Second	15.8		13.8	
Bits Per Second	126.4		110.4	
Daily Transfer Bytes (1 T-Link)	1,365,120		1,192,320	
Network Utilization (1 T-Link)	0.001264%	0.0001264%	0.001104%	0.0001104%
Daily Transfer Bytes (512 T-Links)	698,941,440		610,467,840	
Network Utilization (512 T-Links)	0.650%	0.065%	0.560%	0.056%

***Data Transmission & Acknowledge (ACK)**

1 Event (Bytes)	190	177
10 Events (Bytes)	1,900	1770
1 Event (512 T-Links)	97,280	90,624
10 Events (512 T-Links)	972,800	906,240

- *The number of Alarm events varies depending on the specific installation
- Actual Alarm Events are typically less than 1 event per day
 - Periodic Test typically will generate 5 events per day if enabled
 - Opening/Closing reporting typically will generate 2 events if enabled

Figure 2.2, System Overview




Table 1, Port Usage

Description		Default Port#	Programming Location
T-Link TL250	T-Link Source Port	3060	Section[009] T-Link Options from Keypad
	T-Link Destination Port	3061	Section[010] T-Link Options from Keypad
SG-DRL3_IP	T-Link Port	3061	Section[0B] [0C] from Console Software
	DLS 2000 Port	3062	Section[0D] [0E] from Console Software
	DLS SA Port	3063	Section[11] [12] from Console Software
	T-Link Console Software Port	3064	Section[14] [15] from Console Software
DLS2002	DLS 2000 Port	3062	Modem Configuration Options
DLS SA	DLS SA Port	3063	Modem Configuration Options
T-Link Console Software	T-Link Console Software Port	3064	
T-Link Console Software	TFTP Firmware Upgrade	69	

[Back of System Overview](#)

2.3 T-Link Operating Modes

Five configurations are available for the T-Link. All T-Link configurations can be programmed remotely using T-Link Console software or locally (direct connection) using T-Link Console software. Limited programming of the T-Link can be performed with the keypad of the associated control panel in mode 4: Refer to “T-Link Programming” on page 29 for details.

2.3.1 Mode 1: Bell Follower (TL250 Only)

The Mode 1: Bell follower configuration is intended for use with any control panel with a Bell Follower Output. The T-Link TL-250 decodes the Bell Output cadence and transmits the corresponding Fire or Burglar alarm reporting code to the central station. Refer to “Mode 1: Bell Follower Configuration” on page 18 for installation details.

NOTE: Mode 1 Does not meet the requirements for UL or ULC listed installations.

2.3.2 Mode 2: 4-zone Stand-alone (TL250 and TL300)

In the Mode 2: 4-zone Stand Alone configuration the T-Link performs the function of the control panel. The 4 zone inputs can be programmed for normally open (NO) or normally closed (NC) contacts in any of 8 preset zone input definitions. Refer to “Mode 2: 4-zone Stand-alone Configuration” on page 18 for installation details.

2.3.3 Mode 3: 12-zone Stand-alone (TL250 and TL300)

Mode 3: 12-zone Stand Alone configuration performs similarly to Mode 2 described above. If the T-Link TL250/TL300 detects a PC5108 zone expander module on power up, it will automatically configure itself for 12-zone stand alone operation with normally open (NO) contacts. Refer to “Mode 3: 12-zone Stand-alone Configuration” on page 19 for installation details.

2.3.4 Mode 4: Standard Mode (TL250 only)

In Mode 4: Standard configuration, the T-Link TL250 is connects directly to a Power864 (PC5020/CF) or MAXSYS (PC 4020/CF) via the PC-Link header. All DLS programming/monitoring functions and all alarm data, troubles etc. communication to the central station can be performed in this format. Refer to “Mode 4: Standard Configuration” on page 21 for installation details.

2.3.5 Mode 5: DVACS®* Mode (V1.10 or later) (TL250 Only)

In the Mode5:DVACS configuration, the system is configured as a communicator with a compatible DVACS alarm panel. Refer to “Mode 5: DVACS Installation” on page 25 for installation details. Refer to “Appendix B: T-Link Compatibility Chart” on page 45 for a list of compatible DVACS panels and modules.

NOTE: T-Link TL250 zone events are transmitted using the standard T-Link SIA protocol. DVACS generated events are transmitted using the DVACS protocol.

NOTE: DVACS Mode 5 is used in ULC listed installations.

* DVACS is a registered trademark of Electro Arts Ltd. Scarborough Ontario, Canada

2.3.6 Telephone Simulation (TL300 only)

The T-Link TL300 connects directly to the telephone output of a control panel and simulates a telephone connection, providing a IP connection that sends predefined Contact ID codes to the central station. The T-Link TL300 on-board zones can be used as in mode 2 (4-zone stand-alone) and mode 3 (12-zone stand-alone). Modes 1 and 5 are not supported.

2.4 T-Link Console Software

T-Link Console Software is a stand-alone application that provides remote and local support for the configuration of T-Link TL250/300 devices and IP Receiver line cards. T-Link Console generates and deploys unique encryption keys and protocols for communication between T-Link Console and T-Link modules. A summary of features is listed below.

- Stand-alone application
- Generation and deployment of unique encryption keys to IP Receivers.
- User management
- Software upgrades via network
- Advanced T-Link search and management.
- Local and remote programming of T-Link options
- Remote setup, control and TCP/IP configuration of the SG-DRL3-IP and T-Link accounts.
- Management of of the IP receiver's T-Link tables
- Three operational modes
- Database backup/restore
- Database repair/compact
- Windows 98/NT/2000/XP/2003 compatible
- Multiple database support

Refer to the T-Link Console User Manual for details SG-DRL3-IP Options and Settings - Line card must be changed through the CPM3 or using System III Console v2.0 (and higher) Software. The System III Console software provides additional support for different types of line cards including SG-DRL3 and SG-DRL3-IP.

- The T-Link Console V1.0 updates T-Link modules using TFTP session
- The T-Link accounts table and data encryption keys will be stored in the local database.

Refer to the *T-Link Console User Manual* for details.

T-Link Console software functions in three operational modes; Operator Mode, Unattended Mode and Database Absent Mode. Operator mode includes Supervisor, Administrator and User access levels listed below.

Table 2.1: T-Link Console Software Functions				
T-Link Console Functions		Supervisor	Administrator	User
T-Link Accounts	Add Accounts	✗	✓	✓
	Edit Accounts	✗	✓	✓
	Delete Accounts	✗	✓	✓
	T-Link Template	✗	✓	✓
	Local Programming	✗	✓	✓
	Remote Programming	✗	✓	✓
	Update Receivers	✗	✓	✓
	Import Accounts	✗	✓	✓
	Export Accounts	✗	✓	✓
	IP Receivers	Add Receivers	✗	✓
Edit Receivers		✗	✓	✓
Delete Receivers		✗	✓	✓
Receiver T-Link Table		✗	✓	✓
User Management	Add User	✓	✓	✗
	Edit User	✓	✓	✗
	Delete User	✓	✓	✗
	Change Password	✓	✓	✓
Logs	Delete Log Entry	View Logs Only	✓	View Logs Only
	Delete All Logs		✓	
	Export To Excel		✓	
Configuration	Access Settings	✗	✓	✗
	Serial Settings	✗	✓	✗

2.4.1 Local and Remote Programming

Local programming is done via the CAT 5 cross over cable connected to the RJ45 connector on the computer running T-Link Console software and the RJ45 connection on the T-Link TL250/TL300. The T-Link TL250/TL300 can be locally programmed by connection of a LCD5500 keypad to the keybus terminals.

Remote programming is done via TCP-IP. The Console connects to the T-Link IP programmed for the T-Link account. This can be used to connect remotely or locally through a reversed cable. This method also allows programming an encryption key if required by the user. An encryption Key of all zeroes (0's) disables encryption. The T-Link and the T-Link Console must have the same encryption key for valid communication.

2.5 DLS/DLS SA Software

DLS downloading software is intended for use by a system installer or central station personnel. DLS allows the user to program, monitor and control all DSC Panels and their associated modules. Using DLS software, the user can perform many of function on a DSC control panel and associated modules that can be performed on the system keypad. In addition, The user can create templates that can be downloaded to quickly program alarm systems in predetermined configurations and create batch files to perform repetitive tasks. Refer to the the associated DLS Software Helpfile for details.

Table 2.2: DLS Functions:

- Login
- Account Maintenance
- Account Searching
- Accounts General
- System Options
- Operations Log
- User Maintenance
- Language Maintenance
- Accounts General
- Account Editing
- Accounts Editing: Controls
- Accounts Modules
- Accounts Event Buffer
- Accounts Status
- Communications
- Printing
- Automatic DLS
- Error Checking
- Miscellaneous

2.6 Sur-Gard System III

The SG-System III is a digital receiver intended for use by a Central Station for remote monitoring of commercial fire and burglary alarm systems over telephone lines or a LAN/WAN network. Received alarm data is transmitted to a central station computer via 10/100BaseT Ethernet connection or RS232 port.

The System III receiver can be configured to use SG-DRL3 linecards for telephone communication, SG-DRL3-IP linecards for LAN/WAN/Internet communication or a combination of the two. Refer to the *System III Installation Manual* for additional information.

2.6.1 SG DRL3-IP Line Card

The SG-DRL3-IP Receiver Module functions as a LAN or WAN server to many remote clients (the Transmitters). The Receiver receives alarm events from the transmitter/panel (or from the transmitter when the transmitter is in stand-alone mode) and forwards them to the CPM3 for subsequent output to the printer and automation outputs.

After a Receiver has been configured and installed, it will run on a predefined port and await communications from Transmitters which have been configured to connect to that specific Receiver. When communication has been established, the Transmitter will enter its normal operating mode (waiting for panel polls, transmit heartbeat signals, alarm messages and DLS/SA download messages). The Receiver will log the connection and generate the appropriate connection event for forwarding to the CPM3.

When an alarm message is generated, the Transmitter will send the message in a UDP/IP/Ethernet frame and pass it along to the Receiver encrypted. When an alarm message is received from the Transmitter/panel, the Receiver will strip off the UDP/IP/Ethernet frame and decrypt the message. It will then send an appropriate response (ACK or NAK) back to the Transmitter/panel. The timing will follow the standard timing requirements of the panel. If the message was a valid alarm event, the event will be buffered in the printer and automation buffers until they have been successfully retrieved by the CPM3 (on the CPM3 to line card poll) and sent to the appropriate output device(s).

The Receiver receives heartbeats from all network supervision enabled Transmitters periodically. This allows the Receiver to determine whether the Transmitters are still online. The Receiver maintains a table of all installed Transmitters and monitors their status (presence/absence, installed software versions, MAC addresses for swap detection purposes, and other network statistics).

The Receiver can be programmed with various configuration parameters and options, including Receiver IP address, Receiver sub net mask, and default gateway address. Configuration parameters are password protected. The default password can be changed during initial installation for maximum security.

The receiver is programmed with a globally unique MAC address during production. This MAC address is **NOT** re-programmable

NOTE: Each SG DRL3-IP receiver module can monitor up to a maximum of 512 supervised accounts and up to 1024 unsupervised accounts for a total of 1024 accounts. SG-DRL3-IP line card features include the following:

- Provides higher line security than conventional dial up panels with the polling feature.
- Provides fast transmission (dialing or handshaking not required).
- The control panel is the originator of the signals and as such will be the one requesting the ACK from the central station.
- Network trouble detection is displayed on LCD/printer/automation software.
- Disconnect trouble detection.
- Static IP for programming of network protocols.
- Data network polling environment for replacement of an existing DVACS network. Meets the 90 second ULC requirement for this option.
- SIA event descriptors are used when transmitting information to the central station from the control panel through the PC-Link connection.
- A security function communicates to the central station when a module is removed and replaced

NOTE: The SG DRL3-IP receiver line card will only receive data from a T-Link TL250 or higher network communicator. The SG DRL3-IP is NOT compatible with the T-Link TL100


2.6.2 System III Console Software

The Sur-Gard System III Console Software is intended for use with the Sur-Gard System III receiver. The Console software provides primary support for the SG DRL3 and SG DRL3-IP modules, DSP, Options, CLASS (ANI, Caller ID, and DNIS) table, and System code uploading. SG-DRL3-IP Options and Settings must be changed through the CPM3 (manually) or using System III Console v2.0 (and higher) Software. Refer to the **System III Installation Manual** for detailed programming information and System III SG DRL3-IP programming in Section 4.2.

Additional features include the following:

- Full Windows 98/ME/NT 4.0 (or higher)/2000/XP integration.
- TCP/IP connectivity to the System III.
- Provides an alternate printer connection for the System III through a TCP/IP connection.
- Provides the capability to view and change individual options.
- Provides an interface for grouping the active line cards into hunt groups or line pools.
- Support for the storage and programming of the static and dynamic options of the DRL3 line cards.
- Support for the storage and programming of the C.L.A.S.S. table of the DRL3 line cards.
- Provides interactive communication with the entire system for status messages and hardware/software queries.
- Provides CPM3 status verification
- Displays and set CPM3 Debug Flags
- Time and date synchronize from the PC with the CPM3 modules.
- Configuration and control of all redundancy options in the CPM3s.
- Restarting of the CPM3(s) for verification of redundancy.

Figure 2.3: System III Console Software



Section 3: T-Link TL-250/300 Installation

3.1 General

T-Link installation consists of the following steps:

- 1** Get DRL3-IP Information and Network information from Central Station.
See **"Appendix A: Network Data Worksheet" on page 44**

- 2** Determine TL-250 Operating Mode
Mode 1 Bell Follower
Mode 2 Stand-alone 4 Zone
Mode 3 Stand-alone 12 Zone
Mode 4 PC4020/PC5020
Mode 5 (DVACS)

- 3** Install T-Link
Mode 1 Bell Follower. See "Mode 1: Bell Follower Configuration" on page 18
Mode 2 Stand-alone 4-zone. See "Mode 2: 4-zone Stand-alone Configuration" on page 18
Mode 3 Stand-alone 12-zone. See "Mode 3: 12-zone Stand-alone Configuration" on page 19
Mode 4 PC4020/PC5020. See "Mode 4: Standard Configuration" on page 21
Mode 5 (DVACS). See "Mode 5: DVACS Installation" on page 25
TL300 Simulated Telephone. See "TL300 Simulated Telephone Installation on page 27

- 4a** **For Modes 1, 2, 3, 5 and TL300 simulated telephone**
Program The TL-250 with T-Link Console Software
"T-Link Console Software" on page 10

Program The TL-250 with PC4020 or PC 5020 Keypad
See "Keypad Programming" on page 31

Verify Communication with Central Station
See "Testing" on page 39

- 4b** **For Mode 4**
Program The TL-250 with PC4020 or PC 5020 Keypad
See "Keypad Programming" on page 31


Program the PC4020 or PC5020 system with keypad
See *"MAXSYS (PC4020) Programming" on page 30 or "PowerSeries (PC5020) Programming" on page 31 as required*

Program the PC4020 or PC 5020 system DLS2002/SA Software.

- 5** Verify Communication with Central Station
See "Testing" on page 39

3.2 Wiring

Figure 3.1: Controls & Indicators



Control/Indicator	Pin	Function
CON1, CON2		Factory Programming
CON3 (PCLINK)		Connects to the PC-LINK connector on Power864 (PC4020) and MAXSYS (PC5020) control panels. in Mode 3 Operation.
CON4 (Terminal Strip)	+12V GND TX/RX GND	From ULC Listed Power Supply or from Control Panel Return Future Use Return
KEYBUS	RED BLK YEL GRN	KEYBUS +12 Vdc: The Red, Black, Yellow and Green terminals form the KEYBUS KEYBUS Return: Connects to corresponding connection on PC5108 for (Mode 3) operation. Clock: Connects to corresponding connections on PC5108 for (Mode 3) operation. Data: Connects to corresponding connections on PC5108 for (Mode 3) operation.
PGMs	PGM1 PGM2	PGM1 Switched negative programmable outputs (50 mA @ 12 Vdc). This programmable output is dedicated to T-Link Trouble Indications. To enable, Program Option [035] as 01 (Required for for modes 2 and 3) PGM2 Programmable Output - This programmable output is dedicated as an Input Follower that triggers on all input alarms including Bell Follower It does not trigger on Key Switch Zones
Zones	IN1 GND	IN1 Zone #1 input - This is the only zone input that can be configured for Bell Follower Input (Mode 1). This Zone can be set for NC or NO inputs independently of zones 2, 3 & 4 See Programming Section [048]. GND Return for Zone Inputs
Chassis Ground (Earth)	IN2-IN4 EARTH	IN2-IN4 Zones 2, 3, 4 are collectively configured for Normally Open (NO) or Normally Closed (NC) EARTH Must be connected to cabinet in the Bell Follower and Standard configurations. Connect to Earth ground in stand-alone configurations.
CON5 (RJ45 Connector - Connects T-Link to the Local Area network
STATUS LEDs	STAT SPD ACT LNK	STAT Status - blinking at 5 second intervals indicates normal (No Troubles). The Status LED will blink a number of times (as per table) with a one second pause before restarting the sequence if a trouble is present. If more than one trouble is present, the LED will blink at a rate that is equal to the highest priority. See "Trouble-shooting" on page 40. SPD Speed Status - (Speed Status) Off indicates 10BaseT network connection. On indicates 100BaseT network connection. ACT Activity/Network Traffic Status - blinking indicates network activity. LNK Link Status - activates when network is present, blinks when there is network activity.

3.2.1 KEYBUS Wiring

The KEYBUS connects the PC5108 8-zone expander module to the T-Link TL250/TL300 in the Mode 3: 12-zone stand alone configuration and connects the PC4020 or PC5020 to the T-Link in Mode 3: Standard configuration. The KEYBUS is NOT connected in Modes 1, 2, or 5.

Connect the RED, BLK, YEL, and GRN terminals of the T-Link Module to the corresponding terminals of the PC5108 8-zone expander module or PC4020/PC5020 with #22AWG hookup wire. The distance of the wire run shall not exceed 1000' (305m) Refer to the control panel *Installation Manual* for wire run details

Figure 3.2: KEYBUS Wiring



3.2.2 Zone/Input Wiring

The four T-Link zones can be configured for Normally Open (NO) contacts or Normally Closed (NC) contacts in two groups.

Group one consists of Input (zone) 1 programmed in section [048] and group 2 consists of Inputs (zones) 2, 3 and 4 programmed in Section [049]. Single End-of Line (SEOL) and Double End of Line (DEOL) resistor terminations are not supported.

The eight PC5108 zone expander zones are limited to Normally Closed (NC) contacts. Panel zones in Modes 1, 4 and 5 are be programmed in accordance with the associated panel *Installation manual*.

The following Zone definitions apply to the T-Link and to the PC5108. Zone definitions are programmed in Sections [036] -[047] with the 2-digit code indicated.

- **[00] Null Input:** Inputs on these zones are ignored. Program unused inputs as Null Input.
- **[03] Instant Input:** This input type send a report code if the T-Link is armed. This input supports forced arming. When forced armed the t-Link will arm even if the input is activated.
- **[08] Standard 24 Hr. Fire:** When this input is violated, the panel immediately communicates SIA reporting code FA/FH to the central station.
- **[11] Standard 24 Hr. Burglary:** When this input is violated, the panel immediately communicates SIA reporting code BA/BH to the central station.
- **[16] 24 Hr. Panic Input:** Regardless of whether the system is armed or unarmed, when this input is violated, the panel immediately communicates SIA reporting code PA/PH to the central station.
- **[21] 24 Hr. Tamper:** Regardless of whether the system is armed or unarmed, when this input is violated, the panel immediately communicates SIA reporting code TA/TH to the central station.

- **[23] Maintained Keyswitch Arm Input (Input 2 Only):** When this input is violated the the system will arm, When this input is secured, the system will disarm. This input supports forced arming. SIA reporting code CS/OS is sent to the central station.
- **[98] 24 Hr. Panel Absent:** When this input is violated, the T-Link immediately communicates to the central station.
SIA Reporting Code: CS/OS

- **[99] 24 Hr. Bell Follower Input:** This Input is only valid for Input 1. This input follows the Bell Output for burg/fire monitoring. Connect Input 1 to the control panel Bell+ output.


3.2.3 PGM Wiring

The T-Link TL250/TL300 has two PGM outputs.

PGM1 is a switched negative programmable output dedicated to T-Link Trouble indications. To enable program option [035] as "01". Required for modes 2 and 3

Figure 3.3: PGM Wiring

Trouble indication for Modes 1, 2 and 3



PGM2 is dedicated as an Input follower that triggers on all input alarms including Bell Follower. It does not trigger on Keyswitch zones.


3.3 Mode 1: Bell Follower Configuration

Install the T-Link TL250 in a DSC enclosure (model PC5003C) when used in a Bell Follower configuration. Refer to section [036][99].

Connect the 12VDC and GND terminals to the external 12V power source.

NOTE: Bell Follower mode can not be used in UL or ULC listed installations

Figure 3.4: Bell Follower Installation.



Refer to options [062] through [065].


3.4 Mode 2: 4-zone Stand-alone Configuration

Install the T-Link TL250/TL300 in a DSC enclosure (model PC5003C) when used in a stand-alone configuration or with the PC5108 module.

Connect the 12VDC and GND terminals to the external 12V power source.

NOTE: For UL Listed installations, the power supply used must be UL Listed for the application.

Figure 3.5: 4-zone Stand-alone Installation




3.5 Mode 3: 12-zone Stand-alone Configuration

Connecting a PC5108 module to T-Link adds up to 8 additional hard-wired zones to the T-Link for a total of 12 stand-alone zones.

To expand from the 4-zone inputs a PC5108 must be connected to the T-Link. Connect the KEYBUS from the PC5108 to the KEYBUS of the T-Link TL250/TL300. Any devices that require 12VDC, motion detectors, glass break detectors, etc., will require an external 12VDC power supply.

Figure 3.6: 12-zone Stand-alone Installation




NOTE: In modes 2 & 3, the connections between the PC5108 inputs or T-Link inputs and the alarm control unit outputs (relay contacts) shall be done in metal conduit, within 20 ft. Stand-alone operation will still require the inputs to be programmed with the desired alarm types.

Specifications:

- Module Current Draw: 35 mA
- Auxiliary Current: 100 mA (PTC protected - fuseless design)

Figure 3.7: PC5108 Expander Module



Terminal Descriptions:

TAM - This can be used to provide tamper protection for the cabinet where the PC5108 is mounted. Connect a normally closed (NC) switch across TAM and BLK. If the tamper is not being used connect a piece of wire across TAM and BLK to remove the trouble condition.

NOTE: *There is a built-in tamper switch on the expander module located in the top left corner of the circuit board. If the cabinet where the PC5108 Zone Expander is mounted has the hardware required to depress this tamper switch, DO NOT connect anything to the TAM terminal.*

VAUX - Used to provide power for devices. Maximum current draw must not exceed 100 mA. Connect the positive lead of powered devices to VAUX and the negative to BLK or any COM terminal.

KEYBUS - The 4 wire KEYBUS connection is used by the panel to communicate with the module. Connect the RED, BLK, YEL and GRN terminals to the KEYBUS terminals on the PC5009.

Z1-Z8 - Wire the zones according to the description found in the control panel *Installation Manual*.

Switch Settings

Switch SW1 - SW6

Switch Settings SW1 through SW6 determine which zones will be assigned to the expander.

Expander Zones	Switch Sw1 - SW6			System Zones Assigned
Group A (Zones 1-4) Group A (Zones 5-8)	1 4	2 5	3 6	
Not used	ON OFF	ON ON	ON ON	Zones Disabled Zones Disabled
Default Settings	ON OFF	OFF OFF	ON ON	Zones 9-12 Zones 13-16
Not used	ON OFF ON OFF	ON ON OFF OFF	OFF OFF OFF OFF	Zones 17-21 Zones 21-24 Zones 25-28 Zones 29-32

To Add Hard-wired Zones to a Control Panel

1. Connect module to the KEYBUS (with the panel powered down).
2. Set the jumpers on the module.
3. Power up the system.
4. Enter section [902] and wait 1 minute.
5. Enter section [903] to verify that the module is supervised.
6. Define the zones in section [002].

3.6 Mode 4: Standard Configuration

3.6.1 Power864 and Maxsys Panel Setup and Installation

Refer to the *PC4020(CF) or PC5020(CF) Installation Manuals* for control panel installations. Mount the T-Link on the side wall of the PC4050C or PC4050CR cabinet. Refer to appendix C for Network Protection installation instructions.

Remove power from the control panel before any connections are made to the T-Link TL250. Connect the 12Vdc and GND terminals to the panel auxiliary power output. Connect the supplied cable from the T-Link TL250 white connector to the PC-Link header of the control panel.


The black wire of the PC-Link cable is pin 1 on the PC-Link header for the PC5020 v3.2 or higher control panels. The PC-Link header is polarized on the PC4020 v3.31 or higher control panel. Connect the e-ground to a proper earth-ground connection.

3.6.2 Standard Connection with PC4020(CF)/PC5020(CF)

NOTE: All circuits are supervised and power limited. Refer to section 5.4, UL Listed Commercial Fire Systems diagram for wire routing. Do NOT route any wiring over the circuit boards. Maintain at least 1" (25.4mm) separation between circuit board and wiring.

A minimum of 1/4" (7mm) separation must be maintained at all points between non power limited wiring and power limited wiring

Figure 3.8: PC4020/PC5020 Standard Wiring Connections.




3.6.3 Wiring T-Link to a DSC Compatible Control Panel

Secure the T-Link module to the side of the cabinet using the supplied standoffs.

- With AC power and battery disconnected removed from the DSC control panel, wire the T-Link to the panel using 4 wires from the PC-Link of the panel to the "PANEL" connector on the T-Link.
- Wire the panel's AUX+ and - to 12Vdc and GND terminals of T-Link.
- Apply AC and DC to the main control panel. Both the T-Link and the panel should power up.
- Do the necessary programming that is required.

NOTE: If a Bell/Siren will not be used, wire the Bell/Siren terminals on the panel with a 1000 ohm resistor. For Commercial Fire installation, when a bell/siren is used in the application, it should be connected to the DSC module PC4702BP. Refer to the PC4020 Installation manual. The keypad or any other accessory connected to the COMBUS shall be connected within 3 feet / 0.9 m and in conduit.

Figure 3.9: Battery and AC Power Lead Routing for UL Listed Commercial Fire Systems



T-Link board must be mounted on the side of the cabinet. Refer to the mounting instructions in the associated Installation Manual.

3.6.4 Programming the PC5020 V3.2 for T-Link Communication

Communicator Programming [301]-[304] 'Communicator - Telephone Numbers': the panel can call 3 different telephone numbers for communication to central station. The first telephone number is the primary number, the second telephone number is the secondary number and the third telephone number will back up the first telephone number if enabled. NOTE: The third telephone Number will NOT back up the second telephone number. If Alternate Dial is enabled the panel will alternate between the first and third telephone numbers when attempting to call the central station. If disabled, the panel will only attempt to call the third telephone number after failing to communicate on the first telephone number. NOTE: For Alternate Dial to work properly the third telephone number must be both enabled and programmed. Telephone numbers can be up to 32 digits, which will allow you to add special digits if required. To program the telephone number enter numbers 0 through 9 as required. To communicate events over a LAN or WAN network using the T-Link module, program the desired phone number with DCAA. This allows the panel to send events to the T-Link module in the SIA format via the PC-Link connection.

NOTE: To perform DLS functions via the T-Link module:

- Option [1], Section 401 must be enabled or the number of rings in section 406 must be programmed.
- Option [2] Section 401 applies to DLS via T-Link as well.
- Options [3] and [4] Section 401 cannot be used with T-Link.

3.6.5 Programming Steps:

Step 1	Program the hex digits [DCAA] in the telephone number that will be used for T-Link communications (section [301] to [303], 'Telephone Phone Number Programming'). NOTE: The leading digit [D] in the telephone number for dial tone detection is already programmed.
Step 2	Program the communication format as SIA FSK format in section [350] and Auto SIA, option 3 in section [381].
Step 3	Program the call direction options in section [367] to [374] for the phone number being used to communicate using T-Link.
Step 4	Section [380] Option 5 'PC-Link Active' option must be ON to enable T-Link communication.
Step 5	Enter section [851] for T-Link module programming options. NOTE: Option [5] in Section [382] must be enabled to access this section.
Step 6	Program the IP address for the T-Link module in section [001].
Step 7	Program the subnet mask for the T-Link module in section [002].
Step 8	Program the IP address of the receiver (SG DRL3-IP module or the PC running the Reporter IP software) in section [003].
Step 9	If the receiver (DRL-IP or Reporter IP software) is on a different network segment to the T-Link module, the gateway address associated with the T-Link module must be programmed in section [004]. This is an optional step, please discuss with the network administrator if this is required.
Step 10	After all T-Link module programming is complete, you must restart the module so the programming changes will take effect. To restart the T-Link module, enter the digits [55] in T-Link programming section [999] and wait 15 seconds for the module to reboot. Once complete press the [#] key to exit T-Link programming.

IMPORTANT:

If you are using a telephone line to back up communication, it is important to note that only phone number one has a backup phone number (Phone number 3). It is recommended that T-Link communication be programmed to transmit first as it is faster than land line communication. If the land line communication is programmed to communicate first, then the T-Link communication will be delayed for the duration of the land line call (about 30-45 seconds).

3.6.6 Programming Maxsys (PC4020)

Programming the PC4020 V3.31 for T-Link Communication

T-Link (TCP/IP Communications): The T-Link module can be used as a backup or primary communicator. The T-Link module can also be used as a secondary or primary downloading source. The T-Link module uses a TCP/IP network on a LAN/WAN to communicate to a receiver or DLS-3 software. The module is connected to the PC-Link header on the PC4020A board. NOTE: PC-Link and T-Link cannot be used at the same time. The following sections must be programmed for T-Link communications. The T-Link uses the same telephone numbers as the land line communicator (refer to section 12.1 'Telephone numbers'). Any phone number that the T-Link uses must be programmed with 'CAAA'; to program this, remove the dial tone search 'D' and enter [*5] [*2] [*2] [*2] in the phone number area. The T-Link option must also be enabled in the communicator toggle options (refer to section 12.4 'T-Link Enabled') If downloading is used with the T-Link module, you must program the system as stated in section 13 'Downloading'. The T-Link module will not connect with DLS via user call-up, DLS call-back or periodic DLS. The downloading connection must be established from the computer without call-back enabled.

Step 1	Step 1:Program the hex digits [CAAA] in the telephone number that will be used for T-Link communications (section [0004000000] 'Communicator + Main Items Phone Numbers'). NOTE: You must delete the [D] in the telephone number first (this is the dial tone detection).
Step 2	Program YES for 'T-Link Enabled' option, section [000401] 'Communication Toggles'.
Step 3	If using DLS communication over T-Link then program YES for 'DLS Enabled' in section [000300], 'DLS Section +DLS Toggles'.
Step 4	Step 4:Program the dialer direction options for the phone number that has been programmed to send T-Link communications in section [000400XX02], where XX = telephone number 00-02 in the 'Communicator + Main Options'.
Step 5	Step 5:Enter section [000406] for T-Link module programming options.
Step 6	Step 6: Program the IP address for the T-Link module in section [001].
Step 7	Step 7:Program the subnet mask for the T-Link module in section [002].
Step 8	Step 8: Program the receiver IP address (DRL-IP line card or the PC running the Reporter IP software) in section [003].
Step 9	Step 9: If the receiver (DRL-IP or Reporter IP software) is on a different network segment to the T-Link module, the gateway address associated with the T-Link module must programmed in section [004]. This is an optional step, please discuss with the network administrator if this is required.
Step 10	Step 10:After all T-Link module programming is complete, you must restart the module so the programming changes will take effect. To restart the T-Link module enter the digits [55] in T-Link programming section [999] and wait 15 seconds for the module to reboot. Once complete, press the [#] key to exit T-Link programming.

IMPORTANT!

If you are using a telephone line to back up communication, ensure that the phone number you want to use as a backup is programmed in the dial direction option in section [0004010] 'Communication Toggle Options'. DSC recommends programming T-Link communication to transmit first because it is faster than land line communication. If the land line communication is programmed to communicate first, then the T-Link communication will be delayed for the duration of the land line call (about 30-45 seconds).


3.7 Mode 5: DVACS Installation

3.7.1 DVACS Panel Installation.

Remove power from the control panel before wiring connections to the T-Link TL250 module. Connect the 12Vdc and GND terminals to the panel auxiliary power output. Connect the DVACS cable from the T-Link TL250 Adaptor on the PC-Link header to the DVACS connector on the control panel. Connect the e-ground to a proper earth-ground connection.


In a typical DVACS Installation, a DVACS panel is connected to an F1/F2 subset that communicates the alarm information to the central station comprising an SG MRL2 receiver with an SG DVL2A module installed

Figure 3.10: Standard DVACS Installation.



To send DVACS Alarm information over the internet, the T-Link TL250 performs the equivalent functions of the F1/F2 subset and the polling function of the SG DVL2A. DVACS alarm information is sent to the T-Link TL250 by connecting the existing RJ-45 terminated cable to the PC-Link Header on the TL250 module with an RJ-45 to PC-Link adaptor. The T-Link transmits DVACS alarm information in the DVACS protocol and T-Link Alarm information in the SIA protocol over the internet to a System III Receiver with SG-DRL3-IP line card installed

Figure 3.11: T-Link TL250/DVACS Installation.



3.7.2 DVACS Events

DVACS events generated on DVACS panels connected through the T-Link TL250 follow the same protocols used on the SG-DVL2A module. Refer to Appendix C for T-Link Events that are sent to the central Station. See "Appendix C: T-Link Events" on page 46 for a list of DVACS events

DVACS Alarms Examples

Example 1 (DVACS with receiver set as 1 digit line number)

Printer	01 Nov 2004-11:38:22-01/02-SG -01-1-001--Burgl Alm Zn#02
Computer	1011 001 A 02

Example 2 (DVACS with receiver set as 3 digit line number)

Printer: 01/02-SG -01-001-014--Burgl Alm Zn#13
Computer: 101001 014 A 13

SIA DVACS Alarms Examples

Example 1 (DVACS with receiver set as 1 digit line number)

Printer: 01 Nov 2004-13:50:51-01/02-SG -01-1-0456--Fire Alm Zn999
Computer: 3011 0456FA 999

Example 2 (DVACS with receiver set as 3 digits line number)

Printer: 01 Nov 2004-13:51:03-01/02-SG -01-001-0456--Medical Alm Zn001
Computer: 3011 0456MA 001

Additional Events:

If the T-Link TL250 transmitter does not receive polls (response) from the panel, the T-Link will generate the events previously generated by the SG-DVL2A for DVACS panel and restoration.

SIA

Printer: 01 Nov 2004-13:50:51-01/02-SG -01-1-001--Account Absent
Computer: 3011 0001YC 000
Printer: 01 Nov 2004-13:50:51-01/02-SG -01-1-001--Account Present
Computer: 3011 0001YK 000

Standard

Printer: 01 Nov 2004-13:50:51-01/02-SG -01-1-001--IDcde IncResp
Computer: 1011 001 A 0A
Printer: 01 Nov 2004-13:50:51-01/02-SG -01-1-001--IDcde Restore
Computer: 1011 001 R 0A


NOTE: The SG-DRL3-IP will use 10-digit account identifications in its IP table for DVACS transmitters. The first four digits represents the receiver and line number originally used on the SG-DVL2A and are programmed as the first four digits of the T-Link account (refer to appendix F of SG-DRL3-IP Installation Manual).

NOTE: If the automation protocol in the form of 1RRL, 3RRL is required when using the DRL3-IP in the DVACS configuration, set DRL3-IP Option [11]=1 and CPM3 Options [10] & [11] = 03

3.8 TL300 Simulated Phone Installation

3.8.1 T-Link TL300 Panel Installation.

- Secure the T-Link module to the side of the cabinet of the control panel or install the T-Link TL300 in a DSC enclosure (model PC5003C). Refer to Appendix B: T-Link TL300 Compatibility Chart for a list of panels supported
- With AC power and battery disconnected removed from the control panel, connect the T-L300 to the RJ31 phone jack from the panel to the RJ31 connector on the T-Link.
- Wire the panel's 12VDC and GND terminals of T-Link or Power unit with a 12VDC 225 mA UL Listed Power supply.
- Wire the panel's Tip and Ring terminals to the T1 and R1 terminals of T-Link TL300.
- Apply AC and DC to the main control panel. Both the T-Link and the panel should power up.
- Do the necessary programming that is required.



3.8.2 T-Link TL300 Operation.

Communication events between the panel, T-Link and the Central Station receiver are as follows:

- When an alarm triggers, the panel goes off-hook
- The T-Link module sends a dial tone to the panel
- The Panel dials the telephone number of the central station
- The T-Link detects the DTMF dialing and stops sending the dial tone.
- The T-Link sends a request to the Receiver.
- The Receiver responds with the command to the T-Link to generate the corresponding handshake.
- After receiving the handshake, the Panel transmits the alarm message in DTMF Contact ID format
- The T-Link decodes and transforms DTMF digits into an IP packet and sends it to the Receiver over IP.
- The Receiver acknowledges alarm and sends command to the T-Link to generate a corresponding kiss-off signal.
- After the T-Link generates kiss-off, the Panel goes on-hook if no more alarms need to be sent.

Section 4: Programming

The following information is required Before programming the T-Link TL250/TL300 modules.

1. The static IP address for the T-Link module (Section [001]).
2. The subnet mask for the T-Link module (Section [002]).
3. The static IP address of the receiver (Section [007]).
4. The static IP address of the static gateway for the LAN that the T-Link module is connected to in a WAN configuration (Section [008]).

NOTE: For DHCP networks, the above items are not required. Consult your network administrator for information about the DHCP settings.

Important!: If a telephone line is used to back up communication, program the phone number you want to use as a backup or dial direction option in section [000401] 'Communication Toggle Options'. If using a PC4020 or a PC5020 [380] option 5, enables 3rd number to backup. DSC recommends programming the T-Link module to transmit first for faster communication. If the land line communication is programmed to communicate first, then the T-Link communication will be delayed for the duration of the land line call (30-45 seconds). This also applies when using the phone line for backup only.

4.1 System III - DRL3-IP Programming

Step 1: With power applied to the System III, insert the SG DRL3-IP Line card module into the rack while simultaneously pressing the [ACK] and [SELECT] buttons (4 seconds minimum required). Refer to the SG DRL3 IP *Installation Manual* and the System III *Installation Manual*.

NOTE: *Note: This will cause a "Cold Boot" and load the default software*

Step 2: Program the static IP options for each line card using the CPM-3 Keypad or System III Console Software. You will need to obtain IP addresses from the Network Administrator. Refer to the 'DRL-IP STATIC OPTIONS' in the *Installation and Operation Manual* for detailed descriptions of each option.

Step 3: When all the options have been programmed, wait 35 seconds for the programming changes to take effect, then reset the line card by pulling the unit out of the rack for 10 seconds and then pushing it back into the rack to be powered up.

The new parameters will be loaded into the system and T-Link communications will now be enabled.

4.1.1 CPM3 Keypad Programming

Information required

- The IP address for the DRL3-IP (options[03] -[06])
- The subnet mask for the DRL3-IP (options[07] - [0A])
- The gateway of the DRL3-IP if the DRL-IP is connected through a gateway (options[20]-[23])

Example: To program the IP address of '10.20.30.40', the appropriate options should be set as below:

- Option [03]: 0A
- Option [04]: 14
- Option [05]: 1E
- Option [06]: 28

4.1.2 System III Console Programming

Step 1: Configure the console software to communicate with a selected DRL3-IP by setting the System Type to DRL3-IP

Step 2: Select the COM port used to connect to the receiver based on your PC configuration.

Step 3: Set the Line Number to the line number of the DRL-IP that is being programmed.

Step 4: Refresh the system. The console is on line when the color of the selected module changes from red to green.

When using the TCP/IP (network) to connect the System III Console Software to the receiver for programming, ensure that the console IP address and the console port number have been programmed in the DRL-IP (static options #[14] -- #[19]. Refer to the SG DRL3-IP STATIC OPTIONS' in the System III *Installation and Operation Manual*).

Example: If the console software PC has the IP address '10.20.30.40' and is to be connected to the DRL3-IP through port 3060, the static options should be programmed as follows:

- Option# [14]: 0B
- Option# [15]: F4
- Option# [16]: 0A
- Option# [17]: 14
- Option# [18]: 1E
- Option# [19]: 28

4.2 T-Link Programming

4.2.1 T-Link DVACS Programming

Obtain the following information from the station monitoring the DVACS alarm panel:

1. The SG-DVL2A Receiver number and line number that the DVACS panel is connected to.
2. The DVACS panel ID (Account Number).
3. The programmed value of the SG-DVL2A extended format (option 07) for step 2 below.

Step 1: Program the Account Number of the DVACS control panel in the DVACS account option of the T-Link (option 067). The T-link will use this number to supervise the control panel and poll for DVACS signals from the panel.

NOTE: Alarms generated by the DVACS panel will be sent using the T-Link account.

Step 2: Program the T-Link DVACS extended option 068 so that it is identical to the SG-DVL2A extended option 07.

Step 3: Program the T-Link Account (option 003). To use the DVACS account number for alarm reporting, program the T-Link account option with this value.

When an alarm is sent from the DVACS control panel to the central station, the account number is expanded to a 10-digit value. The first four digits emulate the line number and receiver number on the MLR2/DVL2A. These four digits overwrite the SG-DRL3-IP receiver and line number before being sent to the printer and computer. This allows existing DVACS accounts to be sent to the automation software without alteration and account duplication on the same SG DRL3-IP line card using a different line and/or receiver number.

NOTE: If a new account is created, the first four digits must be programmed as '0000'.

4.4 MAXSYS (PC4020) Programming

4.4.1 Keypad Programming

NOTE: PC4020 v3.3 or higher required (Rev04B hardware).

DSC recommends changing the reporting code transmission delay from 20s to 40s on the PC4020:

Step 1 Power down the MAXSYS panel.

Step 2 Power up the MAXSYS panel. Enter installers programming ([*] + 8 + Installers Code) within the first 10 minutes of power up.

Step 3 Scroll to Diagnostics (04) and press [*].

Step 4 Scroll to Binary Programming (01) and press [*].

Step 5 Enter the address of the address location 03044 and change the value to 40 seconds (0x28).

Programming Steps:

Step 1: Program the Hex digits [CAAA] in the telephone number that will be used for T-Link TL250 communications (section [0004000000] 'Communicator + Main Items Phone Numbers').

NOTE: You must delete the [D] in the telephone number first (this is the dial tone detection).

Step 2: Program YES for 'T-Link Enabled' option, section [000401] 'Communication Toggles'.

Step 3: If using DLS communication over T-Link then program YES for 'DLS Enabled' in section [000300], 'DLS Section +DLS Toggles'.

Step 4: Program the dialer direction options for the phone number that has been programmed to send T-Link communications in section [000400XX02], where XX = telephone number 00-02 in the 'Communicator + Main Options'.

NOTE: Auto report SIA section [000401] must be enabled in order for the T-Link TL250 to communicate. The communication format must be programmed for SIA [000400XX01].

Step 5: Enter section [000406] for T-Link module programming options.

Step 6: Program the static IP address for the T-Link module in section [001]. Program 000.000.000.000 for DHCP.

Step 7: Program the subnet mask for the T-Link module in section [002]. This option will be ignored if the unit is set for DHCP.

Step 8: Program the receiver static IP address (DRL3-IP line card or the PC running The Reporter IP software) in section [007].

Step 9: If the receiver (DRL3-IP) is on a different network segment than the T-Link module, the gateway address associated with the T-Link module must be programmed in section [008]. This is an optional step; determine if this is required with the network administrator.

Step 10: Program the T-Link's account number in section [003].

Step 11: After all T-Link TL250 module programming is complete, you must restart the module so the programming changes will take effect. To restart the T-Link module enter the digits [55] in T-Link programming section [999] and wait 15 seconds for the module to reboot. Once complete, press the [#] key to exit T-Link TL250 programming.

Maxsys V3.5 Only:

CAAA = Receiver 0 CCCC = Receiver 2

CBBB = Receiver 1 CDDD = Receiver 3

If the panel sends events to Receiver 0, the T-Link will perform backups automatically to IPs from Receiver 1 and Receiver 2. If the panels sends events to specific receivers then the panel will be responsible for all backup/alternate dial functions.

NOTE: The IP Receiver addresses are programmed in the T-Link TL250.

4.4.2 DLS Programming

NOTE: When a DLS or SA session begins communicating with a T-Link account through the DRL-IP, the communication status window will be displayed on the DLS or SA computer. During the communication time the DRL-IP will display a message on the bottom LCD, indicating that a DLS session is in progress. Example: L01-1234-RB-RM PRG BEGIN*DLS*.

Once the DLS or SA software has successfully downloaded or uploaded, a message will be displayed on the bottom LCD of the DRL-IP indicating that the DLS session has finished the remote communication. Example: **L01-1234-RS-RM PRG END*DLS***.

4.5 PowerSeries (PC5020) Programming

NOTE: PC5020 software version 3.2 or higher required (Rev03 hardware).

Programming Steps:

Step 1: Program the hex digits [DCAA] in the telephone number that will be used for T-Link TL250 communications (section [301] to [303], 'Telephone Phone Number Programming').

NOTE: The leading digit [D] in the telephone number for dial tone detection is already programmed.

Step 2: Program the communication format as SIA FSK format in section [350] and Auto SIA, option 3 in section [381] has to be OFF.

Step 3: Program the call direction options in section [351] to [376] for the phone number being used to communicate using T-Link TL250.

Step 4: Section [382] Option 5 'PC-Link Active' option must be ON to enable T-Link TL250 communication.

Step 5: Enter section [851] for T-Link TL250 module programming options.

NOTE: Option [5] in Section [382] must be enabled to access this section.

Step 6: Program the static IP address for the T-Link TL250 module in section [001]. Program 000.000.000.000 for DHCP.

Step 7: Program the subnet mask for the T-Link TL250 module in section [002]. This option will be ignored if the unit is set for DHCP.

Step 8: Program the static IP address of the receiver (DRL3-IP line card) in section [007].

Step 9: If the receiver (DRL3-IP) is on a different network segment than the T-Link TL250 module, the gateway address associated with the T-Link TL250 module must be programmed in section [008]. This is an optional step; verify with the network administrator if this is required.

4.6T-Link TL 250/300 Programming

4.6.1 Keypad - For Maxsys Accessing

Step 1: Program the static IP address for the T-Link TL250/TL300 module in section [001].

Program 000.000.000.000 for DHCP

Step 2: Program the subnet mask for T-Link TL250/TL300 in section [002] if required.

This option will be ignored if the unit is set for DHCP (Section [001])

Step 3: Program the static IP address of the receiver (DRL3-IP line card) in section [007].

Step 4: If the receiver (DRL3 -IP line card) is on a different network segment than the T-Link TL300 module, Program the gateway address associated with the T-Link TL250/TL300 in section [008].

NOTE: *This step is optional. Verify with the Network Administrator if this step is required.*

Step 5: If a specific dial tone is required for the panel connected to T-Link TL-300 T1/R1, refer to section [071].

4.6.2 T-Link Console Software on LAN/WAN

Refer to the T-Link TL250/TL300 Console Software Helpfile for programming details.

Section 5: T-Link Programming Options

Sect	Description	Default	Static IP	Dynamic IP	Mode 1	Mode 2	Mode 3	Mode 4	Mode 5	TL300
[001]	Module IP (Static IP address for the T-Link module) Unique IP address for the module. The network administrator will provide this information. To enable DHCP program the address as 000.000.000.000.	192.168.000.099 For DHCP set to: 000.000.000.000		✓						
[002]	Subnet Mask Must equal the subnet mask for the local subnet. For any single subnet, there is only one valid subnet mask; all nodes on the same subnet will use the same subnet mask. The network administrator will provide this information. <i>NOTE: If DHCP is enabled then this section will be ignored.</i>	255.255.000.000	✓							
[003]	T-Link Account Code The account number is used by the central station to distinguish between transmitters. There is one account numbers programmable for the T-Link. This account number is only used when transmitting signals from the inputs or internal troubles. Any signal received on the PC-LINK will utilize the panel's account number. <i>NOTE: Account code FFFFFF and 000000 are not valid accounts.</i>	0000FFFFFF	✓	✓						
[004]	[004]-[005] Encryption Password (32 Hex characters max.) Once programmed the T-Link will use this data to encrypt and decrypt all receiver and DLS messages. The user can program a value from 1 to 8 bytes long in each sections. To disable the encryption program both sections with zeros. If the encryption key does not match the central station key then the communication will FTC. <i>NOTE: E-mail messages are not encrypted.</i>	0000000000000000 Disabled								
[006]	T-Link Installer Code This code is used when using the T-Link Console to remotely or locally program the T-Link.	CAFE								
[007]	Receiver #1 IP (Static IP address for the receiver). Enter the IP address of the central station receiver.	000.000.000.000	✓							
[008]	T-Link Gateway If the T-Link must communicate through a local gateway to connect with the receiver (WAN network), this is the IP address of the local gateway. The IP address of the gateway must also be a valid IP address for the local subnet.	000.000.000.000	✓							
[009]	Receiver #1 T-Link Source Port Number	3060	✓							
[010]	Receiver #1 T-Link Destination Port Number	3061	✓							
[011]	Receiver #2 IP (Static IP address for the second receiver). Enter the IP address of the second receiver.	000.000.000.000	✓							
[012]	Receiver #2 Gateway If the T-Link must communicate through a local gateway to connect with the second receiver WAN network), this is the IP address of the local gateway. The IP address of the gateway must also be a valid IP address for the local subnet.	000.000.000.000	✓							
[013]	Receiver #2 T-Link Source Port Number	3065	✓							
[014]	Receiver #2 T-Link Destination Port Number	3061	✓							

Table 5.1: T-Link Programming Options (Cont.)

Sect	Description	Default	Static IP	Dynamic IP	Mode 1	Mode 2	Mode 3	Mode 4	Mode 5	TL300
[015]	Receiver #3 IP (Static IP address for the third receiver).Enter the IP address of the third receiver.	000.000.000.000	✓	✓						
[016]	Receiver #3 Gateway If the T-Link must communicate through a local gateway to connect with the third receiver (WAN network), this is the IP address of the local gateway. The IP address of the gateway must also be a valid IP address for the local subnet.	000.000.000.000	✓	✓						
[017]	Receiver #3 T-Link Source Port Number	3066	✓	✓						
[018]	Receiver #3 T-Link Destination Port Number	3061	✓	✓						
[019]	Console Port Number	3064	✓	✓						
[020]	TFTP Port Port used for remote flash upload and direct connection of PC with T-Link Console software to the T-Link Module.	69	✓	✓						
[021]	DLS Port Number (DLS2000)	3062	✓	✓						
[022]	SA Port Number (DLS SA)	3063	✓	✓						
[023]	T-Link Supervision Enable/Disable When set to 1, the T-Link is supervised by the central station receiver.	0			✓	✓	✓	✓	✓	✓
[024]	Receiver Failure Debounce Time The amount of time that must elapse with no heartbeat responses from the receiver before the T-Link will generate a Receiver#1 absent condition. NOTE:For UL Installations set to B4H (180 seconds.) For Security Level 4 set to 5AH (90 Seconds) For Security Level 5 set to 4BH (70 Seconds)	0x0078			✓	✓	✓	✓	✓	✓
[025]	Receiver Restoral Debounce Time The amount of time that must elapse with heartbeat responses from the receiver before the T-Link will generate a Receiver #1 restoral condition.	0x003C			✓	✓	✓	✓	✓	✓
[026]	E-mail Address 1 (64 characters max.) The T-Link can send alarm messages to two E-mail addresses. The T-Link only supports SMTP to transmit E-mails in the MIME format. T-Link does not support UUENCODE message formats. The T-Link will not accept any incoming messages. NOTE:Some steps taken by ISP providers to combat SPAM may affect T-Link setup and/or operation. T-Link does NOT support TLS/SSL connections. ISP's not using "Open Relay" in their SMTP E-mail setup require that either the FROM address or the TO address is part of the domain address. To ensure correct operation use the following formats (Rogers.com is the ISP): From: anybody@Rogers.com to anybody@anywhere.com From: anybody@anywhere.com to anybody@rogers.com The following format will only work with "Open Relay" ("Insecure Relay" or "3rd Party Relay") From: anybody@anywhere.com to anybody@anywhere.com This option can only be programmed with console software.	NULL			✓	✓	✓	✓	✓	✓

Table 5.1: T-Link Programming Options (Cont.)										
Sect	Description	Default	Static IP	Dynamic IP	Mode 1	Mode 2	Mode 3	Mode 4	Mode 5	TL300
	<p>The following is an example of the information contained in an E-mail from the T-Link module. For more details on the SIA reporting codes, refer to the control panel Installation Manual.</p> <p>From: T-Link 123456 To: recipient@address.com Subject: T-Link v1.0.30; 123456 Event Report Message: #6789 [Nri0/LS000]</p> <p>The account number in the Subject line is the T-Link's account number. The account number in the message body is from either the originator of the signal. In this example it the originator was the panel connected on the PC-LINK with account number 6789. If the T-Link would have been the originator the account number in the message body would match the account number in the Subject line</p>									
[027]	E-mail Address 2 (See Section [026].)	Null			✓	✓	✓	✓	✓	✓
[028]	E-mail From: The E-Mail From option is used for the FROM field in E-mails sent out by the T-Link module. If the option is not programmed (all 0's) then the from field of the T-Link module will look as follows: T-Link AAAAAA where A is the account code of that T-Link module. If the option is programmed with any ASCII character string, the from field will be what is programmed in the option.				✓	✓	✓	✓	✓	✓
[029]	DNS Server Address In order to communicate to a T-LINK via a host name program the IP address of the DNS server. The DNS lookup for the T-LINK module will only work for T-LINK modules with Static IP addresses (Dynamic DNS is not supported).	000.000.000.000	✓							
[030]	SMTP Server Name (64 characters max.) A valid outgoing e-mail server is required to send e-mail to the Internet. Contact your Internet service provider or system administrator for this information. <i>NOTE:This option can only be programmed via the Console software or the Web-browser</i>	None	✓	✓						
[031]	E-mail Account (64 characters max.) Some e-mail servers will require an account name to allow outgoing messages to be sent. Contact your Internet service provider or system administrator for this information. <i>NOTE: This option can only be programmed via the console software or the web browser.</i>	None	✓	✓						
[032]	E-mail Account Password (20 characters max.) Some e-mail servers will require a password as with the account name to allow outgoing messages to be sent. Contact your Internet service provider or system administrator for this information <i>NOTE: This option can only be programmed via the console software or the web browser.</i>	None	✓	✓						
[033]	Trouble Toggle Option Section 1 Options [033] and [034] set the trouble reporting toggles. To enable specific troubles, toggle option ON. To disable, toggle option OFF. (1) Network Trouble (2) Invalid Account (set as FFFFFFFF) (3) Receiver 1 Absent (4) Panel Communication Trouble(5) (5) Input Alarm (6) FTC to Receiver 1 (7) PC5108 Absent (8) PC5108 Tamper <i>NOTE:Note: Options 6, 7, 8 must be set to ON for UL/ULC Installations</i>	ON ON ON ON OFF OFF OFF OFF								

Table 5.1: T-Link Programming Options (Cont.)

Sect	Description	Default	Static IP	Dynamic IP	Mode 1	Mode 2	Mode 3	Mode 4	Mode 5	TL300
[034]	Trouble Toggle Option Section 2 (1) FTC to Receiver 2 (2) Keyswitch Arm/Disarm Reporting (3) T-Link Remote Programming (4) T-Link Local Programming (5) Receiver 2 Absent (6)-(8) Future Use	OFF OFF OFF OFF OFF OFF								
[035]	PGM1 Enable/Disable This PGM can be enabled (01) or disabled (00). When the PGM is enabled, the output will activate when any of the trouble conditions enabled in the T-LINK Trouble Toggle Options are present. It will deactivate when all the selected trouble conditions are cleared. <i>NOTE: If a trouble condition occurs that is not enabled in the T-LINK Trouble Reporting option, the PGM will not turn on for that trouble condition nor will it be required to turn off the PGM.</i> PGM - The PGM1 output is dedicated for T-LINK TL250 trouble indications and T-Link TL300 network loss indication. The PGM2 output is dedicated as an input follower for the T-LINK TL250. If a control panel is not monitoring the T-LINK TL250, an LED or a buzzer can be connected between this terminal and the RED terminal for trouble indication. The PGM terminal switches low from an open-collector state. <i>NOTE: The PGM output can sink 50mA (max.). For UL installations, use DSC RM-1 Relay Module.</i>	Enabled			✓	✓	✓	✓	✓	✓
[036]- [047]	Digital input 1 - 12 configuration for T-Link modules Program a 2-digit code for the definition of the inputs. Select a definition from the list below. [00] Null Input The input is vacant. Unused inputs should be programmed as Null inputs. Any activity on this input is ignored. [03] Instant Input This input type will only report if the T-Link is armed, it also supports force arming. When forced armed the T-Link will arm even if the input is open. Once the input is closed it will be treated as a normal instant input. SIA Reporting Code: BA/BH. [08] Standard 24-hr. Fire Input When this input is violated, the panel will immediately communicate to the central station. SIA Reporting Code: FA/FH. [11] Standard 24-hr. Burglary When this input is violated, the panel will immediately communicate to the central station. SIA Reporting Code: BA/BH. [16] 24-hr. Panic Input If this input is violated, when the system is either armed or disarmed, the panel will report to the central station. SIA Reporting Code: PA/PH. [21] 24-hr. Tamper When this input is violated, the panel will immediately communicate to the central station. SIA Reporting Code: TA/TH. [23] Maintained Keyswitch Arm Input (Input 2 Only) When this input is violated, the system will arm. When this input is secured, the system will disarm. All instant type inputs have force arming support. SIA Reporting Code: CS/OS. [99] 24-hr. Bell Follower Input Input 1 can only be programmed to follow the Bell output for burg/fire monitoring. Connect Input 1 to the Control Panel Bell+ output. This will disable signal sending when arm and disarm squawks are generated. See Options [055] - [059].				✓	✓	✓	✓	✓	✓

Table 5.1: T-Link Programming Options (Cont.)										
Sect	Description	Default	Static IP	Dynamic IP	Mode 1	Mode 2	Mode 3	Mode 4	Mode 5	TL300
[048]	Input 1 Configuration - Default: 0 Set to 0 for normally open inputs. Set to 1 for normally closed inputs. <i>NOTE: Select this option only if Normally Closed (NC) detection devices or contacts are being used on Input 1.</i>	0 (Normally Open)				✓	✓	✓	✓	
[049]	Input 2 to 4 Configuration - Default: 0 Set to 0 for normally open inputs. Set to 1 for normally close inputs.	0 (Normally Open)				✓	✓	✓	✓	
[050]- [061]	SIA Reporting Input If 00 is entered, central station reporting is disabled. All other actions for PGM outputs and status are still activated. If FF is entered, default reporting codes are enabled using the input definitions, with the hard coded input number. All programming between 01 and 99 will supersede the hard coded default value.					✓	✓	✓	✓	
[062]	Fire On Time - Default: 05 The Bell Pulse On Time is used with Digital Input#1 when configured for Bell Follower mode. The Bell Pulse On/Off Time is the time of the pulse width. This option is programmed in hex times 100 milliseconds.	05			✓					
[063]	Fire Off Time Default: 05 The Bell Steady On Time is used with Digital Input #1 when configured for Bell Follower mode. This the minimum time in 100ms increments that the bell must be active/sounding before it will be considered a steady on state and generate the Burglary Alarms. This option is programmed in hex times 100 milliseconds.	05			✓					
[064]	Restoral Delay Time The Restoral Delay Time is used with Digital Input#1 when configured for Bell Follower mode. It is the minimum time the bell must be INACTIVE before it will be considered a Fire/Burglary Restoral.	00			✓					
[065]	Fire Pulse Count The Fire Pulse Count is used with Digital Input #1 when configured for Bell Follower mode. The pulsed count will be the minimum number of pulses (high and low forming 1 cycle) before the T-Link will consider it an alarm state.	00 x 02			✓					
[066]	SIA ACK Time The SIA ACK Time option is the maximum wait time for a response from a receiver for messages sent to the receiver.	00 x 02								
[067]	DVACS Account The T-Link uses this number to receive DVACS signals from the control panel and to supervise the panel									✓
[068]	DVACS Extended Some software versions support group arm/disarm option. If a value other than '00' is programme, here The T-Link will poll the control panel to get the the transmitter group number arm/disarm status change and the user number. This information is combined then sent to the receiver. This allows the automation software to keep track of partition arm/disarm Status	01 (enabled)								✓
[069]	TL300 Contact ID Kiss-off Duration Some control panels may require a different kiss-off duration than the default of 800ms. Program this option for the duration of the Contact ID kiss off provided to the panel. Each unit has increments of 100 ms in hex, from 100 ms to a maximum of 8.1 seconds. For example: 08 = 800 ms 0A = 1000 ms (1 second) <i>NOTE: Kiss-off durations greater than 1.5 seconds may not be compatible with some alarm panel. This may be required for special applications. Kiss-off durations higher than 8.1 seconds will not be accurate and may not match the duration programmed.</i>	08								✓

Table 5.1: T-Link Programming Options (Cont.)

Sect	Description	Default	Static IP	Dynamic IP	Mode 1	Mode 2	Mode 3	Mode 4	Mode 5	TL300																																				
[070]	TL300 Contact ID Handshake Selection 1400Hz or Dual tone Handshake can be selected. Enter "2D" for Dual Tone or Enter "14" for 1400Hz	2D								↙																																				
[071]	TL300 Dial-tone Selection Enter the 2-digit code corresponding to country indicated in the table below. <table border="0" data-bbox="272 625 753 863"> <thead> <tr> <th>Code</th> <th>Country</th> <th>Code</th> <th>Country</th> </tr> </thead> <tbody> <tr> <td>00</td> <td>United States/ Canada</td> <td>08</td> <td>Norway</td> </tr> <tr> <td>01</td> <td>The Netherlands</td> <td>09</td> <td>Sweden</td> </tr> <tr> <td>02</td> <td>United Kingdom</td> <td>0A</td> <td>Switzerland</td> </tr> <tr> <td>03</td> <td>South Korea</td> <td>0B</td> <td>Australia</td> </tr> <tr> <td>04</td> <td>Taiwan</td> <td>0C</td> <td>France</td> </tr> <tr> <td>05</td> <td>Italy</td> <td>0D</td> <td>Belgium</td> </tr> <tr> <td>06</td> <td>Brazil</td> <td>0E</td> <td>Future Use</td> </tr> <tr> <td>07</td> <td>Germany</td> <td>0F</td> <td>Future Use</td> </tr> </tbody> </table>	Code	Country	Code	Country	00	United States/ Canada	08	Norway	01	The Netherlands	09	Sweden	02	United Kingdom	0A	Switzerland	03	South Korea	0B	Australia	04	Taiwan	0C	France	05	Italy	0D	Belgium	06	Brazil	0E	Future Use	07	Germany	0F	Future Use	00								↙
Code	Country	Code	Country																																											
00	United States/ Canada	08	Norway																																											
01	The Netherlands	09	Sweden																																											
02	United Kingdom	0A	Switzerland																																											
03	South Korea	0B	Australia																																											
04	Taiwan	0C	France																																											
05	Italy	0D	Belgium																																											
06	Brazil	0E	Future Use																																											
07	Germany	0F	Future Use																																											
[901]	Current T-Link IP Address The Current T-Link IP Address is not a programmable options, but rather a read only option. If this option is selected through the panel programming, the T-Link module will respond with the current IP address of the T-Link module and display it on the keypad for the user.	00 x 00	✓	✓																																										

Section 6: Testing & Troubleshooting

6.1 Testing

6.1.1 Mode1: Bell Follower Configuration

Ensure that the T-Link TL250 Input 1 is programmed in accordance with the settings outlined in Sections 9, Programming Descriptions. Simulate Burglar and Fire Zone violation on the alarm panel. Verify that the T-Link TL250 transmits the events to the central station.

6.1.2 Mode 2: 4-zone Stand-alone Configuration

Simulate Inputs violations in accordance with the settings outlined in Sections 9, Programming Descriptions. Verify that the T-Link module transmits the events to the central station.

6.1.3 Mode 3: 12-zone Stand-alone Configuration

Simulate Inputs violations in accordance with the settings outlined in Sections 9, Programming Descriptions. Verify that the T-Link module transmits the events to the central station.

6.1.4 Mode 4: Standard Configuration

Ensure that the PC5040 or PC5020 panel is programmed to use the T-Link TL250 in accordance with the settings outlined in section 8, Programming Guide.

Simulate Burglar and Fire Zone violation on the DSC alarm panel. Verify that the T-Link TL250 transmits the events to the central station.

6.1.5 Mode 5: DVACS Configuration

Simulate Inputs violations in accordance with the settings outlined in Sections 9, Programming Descriptions. Verify that the T-Link TL250 transmits the events to the central station.

6.1.6 T-Link TL300 Telephone Simulation

Simulate Burglar and Fire Zone violation on the alarm panel. Verify that the T-Link TL300 transmits the events to the central station.

6.2 Troubleshooting

The T-Link modules and the System III Receiver can be connected directly With an Ethernet crossover cable. An Ethernet crossover cable can be made by taking a standard Ethernet cable (which will have wires attached to pins 1, 2, 3 and 6 only on the 8 pin RJ-45 connector) and swapping pin 1 with pin 3, and also swapping pin 2 with pin 6, on one end of the cable only. This effectively reverses the transmit and receive pairs, and allows two hosts to communicate without the use of a network hub. See “Appendix E: CAT5 Ethernet Cross Over Cable Schematic.” on page 48

Upon T-Link power-up (without the Ethernet cable connected), LED2 will blink periodically, approximately once every 12 seconds. This indicates the T-Links attempt to send a connection request to the receiver. The T-Link module will try to connect to the receiver until it succeeds.

The **Activity** and **Link LED**'s are normally OFF in their default state after power-up (i.e. when no Ethernet cable is connected, and there are no packets being transmitted or received, respectively). Refer to the Status Indicator table below for details. There are 4 LEDs on the board to indicate connection, traffic and trouble conditions.

- **LK LED** (Link Status) will turn on when the network is present and will blink when there is network activity.
- **ACT LED** (Activity/Network Traffic Status) will blink to show network activity.
- **SPD LED** (Speed Status) will remain off for 10BaseT network connection and will be on to indicate 100BaseT network connection.
- **STAT (Status) LED** will normally blink once every 5 seconds. If a trouble is present, the LED will blink a number of times (as per table) with a one second pause before restarting the sequence. If there is more then one trouble present, the LED will blink at a rate that is equal to the highest priority.

The transmitter has a number of individually maskable trouble conditions that report various troubles present on the transmitter. For the corresponding trouble toggle option, refer to section [033] and [034]. Options [033] and [034] can be set to ignore for any or all trouble conditions. Once a trouble is ignored, it will no longer generate a signal or have any affect on the Status LED.

Example: The network is not present and inputs are in alarm. The LED will blink once with a one-second pause. When the network trouble is cleared the LED will blink five times with a one-second pause.

Table 6.1: Status Indicators

Status	Blinks/ Priority	Description
Network Absent	1	The Ethernet link between the transmitter and local hub or router is absent. This is equivalent to the link LED on the Ethernet chip being off.
Invalid Account	2	The transmitter account code is still set to the default value of FFFFFF.
Receiver 1 Absent	3	The transmitter is not receiving Receiver Heartbeat commands from the receiver.
Panel Absent	4	The transmitter is not receiving polls from the DSC 4020, 5020 or DVACS panel through the PC-Link interface. Generic panels are not supervised by the transmitter.
Input Alarms	5	There are inputs on the T-Link which are in 'alarm' condition
FTC 1	6	T-Link failed to communicate with Receiver#1
PC5108 Absent	7	The PC5108 Module is not responding to the transmitter.
PC5108 Tamper	8	The PC5108 Module Tamper has been activated
FTC 2	9	T-Link failed to communicate with Receiver#2
Keyswitch Arm	10	The system was armed by the keyswitch zone
T-Link Remote Programming	11	T-Link is being programmed remotely
T-Link Local Programming	12	T-Link is being programmed locally
Receiver #2 Absent	13	The transmitter is not able to connect to Receiver#2 on power-up

6.3 Resetting to Factory Defaults

6.3.1 Modes 1, 2, 3 and 5:

- Remove Power from the T-Link TL250/TL300 module; disconnect battery and control panel if applicable
- Disconnect all wiring from the PGM1 and IN1 terminals. Connect a jumper wire between the PGM1 and IN1 terminals
- Apply power to the system
- Remove power from the system
- Reconnect all original wiring and reapply power to the system
- Test System - refer to section 2.2

NOTE: A restart is required for the programming changes to take effect. Allow up to 15 seconds for a restart.

6.3.2 Mode 4 and TL300 Simulated Telephone:

- Enter section 999 of the T-Link TL250
- Enter 00 to default the unit to factory settings
- Enter 55 to restart the unit.

Glossary

Console

A PC application program which can connect to the receiver and provide diagnostic and programming abilities to the user.

DHCP

Dynamic Host Configuration Protocol, a protocol for assigning dynamic IP addresses. With dynamic addressing, a device can have a different IP address every time it connects to the network. In some systems, the device's IP address can even change while it is still connected. DHCP also supports a mix of static and dynamic IP addresses.

Dynamic addressing simplifies network administration because the server keeps track of IP addresses rather than requiring an administrator to manage the task. This means that a new computer can be added to a network without the hassle of manually assigning it a unique IP address.

Encryption

The translation of data into a secret code usually based on a key. Encryption is the most effective way to achieve data security. To read an encrypted file, you must have access to a secret key or password that enables you to decrypt.

Ethernet

A local-area network (LAN) protocol developed by Xerox Corporation in cooperation with DEC and Intel in 1976. Ethernet uses a bus or star topology and supports data transfer rates of 10 Mbps. A newer version of Ethernet, called 100BaseT (or Fast Ethernet), supports data transfer rates of 100 Mbps. The newest version, Gigabit Ethernet, supports data rates of 1 Gigabit (1,000 Megabits) per second.

IEEE

Abbreviation of *Institute of Electrical and Electronics Engineers*, pronounced I-triple-E. Founded in 1963, the IEEE is an organization composed of engineers, scientists, and students. The IEEE is best known for developing standards for the computer and electronics industry.

IETF

Internet Engineering Task Force: (IETF) develops and promotes Internet Standards with the W3C and ISO/IEC standard bodies.

Intranet

A network based on TCP/IP protocols belonging to an organization, usually a corporation, accessible only by the organization's members, employees, or others with authorization.

IP

Abbreviation of *Internet Protocol*, pronounced as two separate letters. IP specifies the format of packets, and the addressing scheme. Most networks combine IP with a higher-level protocol called Transport Control Protocol (TCP), which establishes a virtual connection between a destination and a source.

IP by itself is something like the postal system. It allows you to address a package and drop it in the system, but there's no direct link between you and the recipient. TCP/IP, on the other hand, establishes a connection between two devices so that they can send messages back and forth for a period of time.

IP Address

An identifier for a computer or device on a TCP/IP network. Networks using the TCP/IP protocol route messages based on the IP address of the destination. The format of an IP address is a 32-bit numeric address written as four numbers separated by periods. Each number can be zero to 255.

LAN

A computer network that spans a relatively small area. Most LANs are confined to a single building or group of buildings. However, one LAN can be connected to other LANs over any distance via telephone lines and radio waves. A system of LANs connected in this way is called a wide area network (WAN).

MAC

Short for *Media Access Control* address, a hardware address that uniquely identifies each device of a network. The address is not programmable by the user and the manufacturer of the device must register with IEEE before receiving an assigned group of addresses.

Mime

Multipurpose Internet Mail Extensions, a specification for formatting non-ASCII messages so that they can be sent over the internet.

Network

Two or more computer systems connected together.

Packet

A piece of a message transmitted over a packet-switching network. One of the key features of a packet is that it contains the destination address in addition to the data.

SSL

Secure Sockets Layer. A security protocol developed by Netscape.

Subnet

A portion of a network that shares a common address component. On TCP/IP networks, subnets are defined as all devices whose IP addresses have the same prefix. Dividing a network into subnets is useful for both security and performance reasons.

Subnet Mask

A mask used to determine to what subnet an **IP address** belongs.

TCP

Abbreviation of *Transport Control Protocol*, and pronounced as separate letters. TCP is one of the main protocols in TCP/IP networks. Whereas the IP protocol deals only with packets, TCP enables two devices to establish a connection and exchange data. TCP guarantees delivery of data and also guarantees that packets will be delivered in the same order in which they were sent.

TFTP

Trivial File Transfer Protocol. A version of the FTP protocol that has no directory or password capability. Most commonly used protocol to upgrade firmware of network devices.

TLS

Transport Layer Security. A security protocol developed by IETF that is based on the SSL protocol. TLS uses security certificates to authenticate users.

UDP

User Datagram Protocol. A TCP/IP protocol which allows for connectionless communications between two network hosts. Retries are not handled and packet delivery is not guaranteed. Packets may also arrive out of sequence.

WAN

A computer network that spans a relatively large geographical area. Typically, a WAN consists of two or more local area networks (LANs).

Computers connected to a wide area network are often connected through public networks, such as the telephone system. They can also be connected through leased lines or satellites.

Appendix A: Network Data Worksheet

T-Link #	Sect.	Static IP Address
T-Link Address	[001] Default DHCP	_____ 1 9 2 1 6 8 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0

T-Link Acct. Code	Sect.	Static IP Address
	[003] Default	_____ 0 0 0 0 F F F F F F F

Rx#1 Address	Sect.	Static IP Address
	[007] Default	_____ 0 0 0 0 0 0 0 0 0 0 0 0
		Source Port #
	[009] Default	_____ 0 0 0 0 3 0 6 0

Rx#2 Address	Sect.	Static IP Address
	[011] Default	_____ 0 0 0 0 0 0 0 0 0 0 0 0
		Source Port #
	[013] Default	_____ 0 0 0 0 3 0 6 5

Rx#3 Address	Sect.	Static IP Address
	[015] Default	_____ 0 0 0 0 0 0 0 0 0 0 0 0
		Source Port #
	[017] Default	_____ 0 0 0 0 3 0 6 6

Sect.	Subnet Mask
[002]	_____ 2 5 5 2 5 5 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0

Sect.	Receiver Gateway Address
[008] Default	_____ 0 0 0 0 0 0 0 0 0 0 0 0
	Destination Port #
[010] Default	_____ 0 0 0 0 3 0 6 1

Sect.	Receiver Gateway Address
[012] Default	_____ 0 0 0 0 0 0 0 0 0 0 0 0
	Destination Port #
[014] Default	_____ 0 0 0 0 3 0 6 1

Sect.	Receiver Gateway Address
[016] Default	_____ 0 0 0 0 0 0 0 0 0 0 0 0
	Destination Port #
[018] Default	_____ 0 0 0 0 3 0 6 1

Appendix B: T-Link Compatibility Chart

Compatible Control Panels	
MAXSYS PC4020	<ul style="list-style-type: none"> • Software V3.31 or higher • Hardware Rev 04B
Power864 PC5020	<ul style="list-style-type: none"> • Software V3.2 or higher • Hardware Rev 03
DVACS Panels	<ul style="list-style-type: none"> • DV1660 LCD V5.03 • DV1660 LED V3.01 • DV4420 V1.11 • DVCOM • DV4T • PC5400DV • PC4400DV • PC4401DV
IP Communicator	
T-Link TL250/TL300	<ul style="list-style-type: none"> • 10/100 BaseT • TCP/IP communication module • Static or DHCP IP configurable • Additional zone inputs using PC5108 • Program locally using PowerSeries keypad.
IP Communication Routing / Receiver	
SG-DRL3-IP	<ul style="list-style-type: none"> • Supports 1024 accounts, maximum 512 accounts can be supervised • Static IP required for DRL3-IP
Downloading Software	
DLS2002	<ul style="list-style-type: none"> • Required • CD from distributor or free download from dsc.com with a valid password
Maxsys PC4020 V3.3 (with TCP/IP support) Driver Pack	<ul style="list-style-type: none"> • Required • Free download from dsc.com with a valid password
Power864 PC5020 V3.2 DLS-3 Driver	<ul style="list-style-type: none"> • Required • Free download from dsc.com with a valid password
System Administration Software	
DLS-3 SA V1.3	<ul style="list-style-type: none"> • Required • Kit with modem or PC4401 from distributor
DLS-3 SA V1.3 Service Pack 1 for Maxsys V3.31 support	<ul style="list-style-type: none"> • Required • Included in the kit or free download from dscsec.com/dls3drivers.htm
DLS-3 SA V1.3 Service Pack 2 for Power864 v3.2 support	<ul style="list-style-type: none"> • Required • Included in the kit or free download from dscsec.com/dls3drivers.htm
Configuration Software	
T-Link Console V1.10	<ul style="list-style-type: none"> • Required • Free download from dsc.com with a valid password
NOTE: The DLS software can only be used with UL Listed installations when service personnel are on-site.	

Appendix C: T-Link Events

T-Link events sent to the central station.

Description	SIA Event Code
Panel Absent	ET0001
Panel Restored	ER0001
FTC1 Alarm	YC0001
FTC1 Restoral	YK0001
FTC2 Alarm	YC0002
FTC2 Restoral	YK0002
PC5108 Tamper Alarm	ES0000
PC5108 Tamper Restoral	EJ0000
PC5108 Absent	ET0002
PC5108 Restored	ER0002
Keyswitch Arm	CS0000
Keyswitch Disarm	OS0000
Remote Programming Start	RB0000
Remote Programming End	RS0000
Local Programming Start	LB0000
Local Programming End	LS0000
Internal Comm. Error	YC0000

Appendix D: Network Protection

INSTALLATION of CAT-5 Ethernet Cable

Important:

The following requirements for installation of CAT5 ethernet cable must be observed for correct operation of connected equipment.

Do **NOT** strip off cable sheathing more than required for proper termination.

Do **NOT** kink or knot cable.

Do **NOT** crush cable with cable ties.

Do **NOT** splice cable.


Do **NOT** bend cable at right angles or make any other sharp bends.

Note: All cable bends must have a minimum 2" (50mm.) radius.

Do **NOT** untwist CAT5 pairs more than ½" (12mm.)

Do **NOT** exceed maximum 6" (150mm.) from center of ferrite to T-Link Network Connector

CAT5 Ethernet Cable



Note:

Install the ferrite inside the control panel as close to the T-Link network connector as allowable.


6" (150 mm.) max from center of ferrite to the network connector).

INSTALLATION of RJ45 to RJ45 Mounting Plate

Note:

1. Remove the knockout located on the top right hand side of the cabinet.
2. Drill 2 holes in cabinet location using the drill template and 2.5mm (3/16") drill bit.
3. Secure the mounting plate externally to the cabinet using the #6 Type F, self-tapping screws provided.
4. Connect RJ-45 cables observing the "Caution" indicated above.
5. Verify operation.


Drilling Template



Appendix E: CAT5 Ethernet Cross Over Cable Schematic.

This cable is required for direct local connection of a PC with T-Link console software to the T-Link TL250/TL300 module

Straight Through CAT5 Ethernet Cable
RJ-45 - RJ-45



CAT5 Ethernet Cross Over Cable
RJ-45 - RJ-45

