


CP-90

**FOR CP-90
VERSION 2.5
AND LATER**

Supervised Wireless Security Control/Communicator



Programming Instructions

Linear[®]

(760) 438-7000 • FAX (760) 438-7043
USA & Canada (800) 421-1587 & (800) 392-0123
Toll Free FAX (800) 468-1340

TABLE OF CONTENTS

| | | | |
|---|----|--|----|
| PROGRAMMING OUTLINE | 2 | PROGRAMMING THE CP-90 | 12 |
| SYSTEM POWER-UP | 3 | Entering Program Level | 12 |
| First Time Power-up | 3 | Exiting Programming Level | 12 |
| Restoring Factory Defaults | 3 | Programming Level Timer | 12 |
| Internal Diagnostic Checks | 3 | Control Station Keys During Programming | 12 |
| Watchdog Monitor | 3 | Programming Cycle | 12 |
| CONTROL STATION OVERVIEW | 4 | Function Field | 13 |
| Power-up Indications | 4 | Selector Field | 13 |
| Keypad Lighting | 4 | Value Field | 13 |
| Keypad Supervision | 4 | Changing Values | 13 |
| Keypad Lockout Timer | 4 | CP-90 MEMORY LAYOUT | 14 |
| Programming Level Timer | 4 | About Sensor Numbers | 14 |
| Control Station Operation | 4 | About Control Station Numbers | 14 |
| SYSTEM ZONES | 5 | SENSOR SETUP | 14 |
| Exterior | 5 | SX Format | 14 |
| Interior | 5 | MegaCode Format | 14 |
| Restricted Interior | 5 | S1 Format | 14 |
| Fire | 5 | Motion Detector Programming | 14 |
| Emergency | 5 | PROGRAM DESCRIPTIONS | 15 |
| Police/Hold-up | 5 | Sensor Installation | 15 |
| Arm/Disarm Toggle | 5 | TK-90 Wireless Keypads | 15 |
| Delayed Remote Emergency | 5 | Accessory (Keypad) Installation | 20 |
| Delayed Remote Police/Hold-up | 5 | General Communicator Operation | 22 |
| Guard Zone | 5 | Opening & Closing Report Option Overview | 22 |
| Environmental Type A | 5 | Communicator Routing, Telephone #'s & Account #'s | 26 |
| Environmental Type B | 5 | Reporting Codes For All Formats | 30 |
| Environmental Type C | 5 | Except SuperSpeed & SIA | 30 |
| Chime Only Zone | 5 | Changing Report Codes Overview | 30 |
| Automation #1 | 5 | SuperSpeed, SIA & Ademco Contact ID Format Reporting Options | 34 |
| Automation #2 | 5 | Reporting Codes for Extended Formats | 36 |
| Access Only | 5 | Extended Format Examples | 36 |
| Tx Type Transmitter Button Disable Zone | 5 | SuperSpeed, SIA & Ademco Contact ID Format Reporting Codes | 36 |
| SECURITY LEVELS | 6 | Personal Access Code (PAC) Installation | 38 |
| Programming Level (For Installers Only) | 6 | Changing PACs Outside of Level 9 | 39 |
| Test Levels | 6 | Changing Temporary PAC Outside of Level 9 | 39 |
| Disarm/Cancel and Low Security Levels | 6 | Control Panel Configuration | 40 |
| High Security Arming Levels | 6 | Special Installer Functions | 44 |
| KEYPAD SOUNDS | 7 | SYSTEM TESTING | 45 |
| Audible Signals and Sirens | 7 | Level 7 Telephone Test | 45 |
| KEYPAD COMMANDS | 8 | Level 8 Sensor Test | 45 |
| Status Key Commands | 8 | Standard Complete System Test | 45 |
| Special Keypad Commands | 8 | Individual Sensor Test | 45 |
| TROUBLE DISPLAYS | 9 | How to Test Door and Window Sensors | 45 |
| Sensor Trouble Codes | 9 | How to Test Motion Detectors | 45 |
| Control Panel Trouble Codes | 9 | How to Test Smoke Detectors | 45 |
| Internal System Trouble Codes | 9 | How to Test Keypads (Sensors 65-72) | 45 |
| PROGRAMMING OVERVIEW | 10 | How to Test Portable Sensors | 45 |
| Program Functions | 10 | How to Test Panic Buttons | 45 |
| Program Selectors | 10 | INDEX | 46 |
| Program Values | 10 | REGULATORY INFORMATION | 47 |
| Default Values | 10 | LINEAR LIMITED WARRANTY | 48 |
| Notation for Functions, Selectors & Values | 10 | NOTES | 49 |
| FACTORY DEFAULTS & UL PROGRAMMING REQUIREMENTS | 11 | | |

PROGRAMMING OUTLINE

The following outline is intended to guide the alarm installer through the programming of a CP-90 system.

If you don't read anything else, read this outline!

Use the following outline in conjunction with this copy of the CP-90 Programming Instructions to guide you through the CP-90 installation.

Because of the many programming options of the CP-90, thoroughly reading this manual is very important. Understanding the CP-90 programming structure will result in many saved hours during the installation.

1

1. Hold the **MASTER RESET** switch down and turn the **MASTER POWER** switch on while still holding down the **MASTER RESET** switch. **Wait up to 45 seconds while still holding down the MASTER RESET switch.** You should hear a relay click then chatter. The system now has the factory defaults installed.

NOTE: The keypads will reset after the master reset of the control panel is complete.

2. Close the control panel door.

3. Check that all of the keypads are running; the green **POWER** light should be lit on each one.

4. Press "STATUS 97" to clear trouble displays.



5. Read the "Control Station Overview", "System Zones" and "Security Levels" sections of this manual to learn how to use the system.

6. Program the CP-90.

A. Fill out the "CP-90 Programming Worksheet" with the desired values for the system.

B. Thoroughly review the "Programming Overview" section of this manual.

C. Execute program Function 21 to install all wired keypads.

D. Program the keypad(s) lighting and sound levels using the "Accessory Installation Table" (Functions 24-35).

E. Program the first part of the communicator using the "General Communicator Operation Table" (Functions 50-51). **Leave the communicator turned off (Function 050.001) until installation is complete.**

F. Program any special reporting codes (if different from the defaults). Use the correct "Reporting Codes Table" (Functions 70, 72, 74, 75, 77 & 79) for the communicator format(s) being used.

G. Program the rest of the communicator using the "Communicator Routing, Telephone #'s and Account #'s Table" (Functions 60-69).

H. Program the personal access codes (PAC) using the "Personal Access Code (PAC) Installation Table" (Functions 90-101). Write the codes on the CP-90 User's PAC Card.

I. Program the exit/entry delays and other options using the "Control Panel Configuration Table" (Functions 120-121).

J. Program the wireless and hardwired sensors using the "Sensor Installation Table" (Functions 0-17). **Be sure to perform steps 6E & 6F before performing this step.**

K. Fill out the user's "Sensor Number Card" with types and locations of sensors.

7. Test the system locally.

8. Turn the communicator on by programming Function 050.001 to a value of 1 (if system is monitored).

9. Test the system again, verifying that the central station receives the correct report codes.

10. Instruct the user on system operation.

SYSTEM POWER-UP

First Time Power-up

If the unit is new out-of-the-box, just turn the MASTER POWER switch on. The factory loaded defaults are already installed in memory.

Restoring Factory Defaults

If the unit has previously been programmed, and you want to reset the system back to the factory defaults, follow these steps:

- STEP 1** Be sure the MASTER POWER switch is off (see Figure 1 for switch location).
- STEP 2** Use a small tool to press and hold down the MASTER RESET switch.
- STEP 3** Turn the MASTER POWER switch on while still holding down the MASTER RESET switch. Wait up to 45 seconds while still holding down the MASTER RESET switch. You should hear a relay click then chatter. The system now has the factory defaults installed.

NOTE: The MASTER RESET switch will not function if master reset disable is turned on with programming function 121.020 (see the CP-90 Programming Instructions for details).

Internal Diagnostic Checks

The CP-90 performs an automatic internal diagnostic check when the system is first powered up. The system checks itself to be sure everything is in order. The internal check takes about 10 seconds. If something is wrong, the keypad's TROUBLE LED will flash and a supervisory condition will occur. Press the STATUS button for one second to display the condition.

NOTE: When the system is first powered up, the keypad's TROUBLE light may flash. Press "STATUS 97" to clear the indication before proceeding.

Watchdog Monitor

While the system is operating, an internal "watchdog" circuit monitors the system. If for some reason (lightning strike, etc.) the system's memory is upset, the watchdog monitor will reset the system, restoring system integrity. If a watchdog reset occurs, the keypad's TROUBLE light will flash and a "Supervisory Condition 89" will occur. The security level will remain at the previously set level.




Figure 1. CP-90 Parts Locator

CONTROL STATION OVERVIEW




Figure 2. KD-90 Keypad

Power-up Indications

When the CP-90 MASTER POWER switch is turned on, the keypad's POWER LED will blink until the CP-90 initializes the keypads. This takes about 10-20 seconds.

NOTE: When the system is first powered up, the keypad's TROUBLE light may flash. Press "STATUS 97" to clear the indication before proceeding.

Keypad Lighting

Each keypad (except the wireless TK-90) has programmable downlights that light up the keys and programmable display lighting. Each keypad in the system can be programmed for different lighting levels. An active level is set when the keypad is in use. A standby level is set when the keypad is idle.

The keypad will automatically assume standby lighting level after 45 seconds of inactivity.

Keypad Supervision

Every minute, each wired keypad is checked by the CP-90 to be sure that it's still there. If the control finds a keypad missing, a "Supervisory Condition" will occur. Remaining keypads can display the condition and a central station trouble report will be sent (if programmed for that type of report).

Keypad Lockout Timer

Control station keypads have a five second timer that automatically locks out further keypad entries after an incorrect command sequence or access code is entered. The control station will automatically unlock five seconds after the last keystroke. At any time during a keystroke sequence, the keypad and display may be reset, unlocked and cleared by pressing the * key.

NOTE: If the keypad doesn't seem to respond to your commands, press * before entering the command again.

Programming Level Timer

While programming the CP-90 from a keypad, if no keystrokes are made for four minutes, the system will automatically leave the programming level mode.

Control Station Operation

Refer to the CP-90 User's Guide (P/N 207417) for complete details on system and control station operation. The following pages of this manual contain some basic CP-90 system information that should be understood before programming the CP-90.

SYSTEM ZONES

This page is similar to the information presented in the CP-90 User's Guide. This general information is presented so that the installer can become familiar with the CP-90's zones.

Each sensor installed in the system is programmed to a specific "sensor number" and "sensor zone".

The *sensor number* (01-64) identifies the specific sensor when displayed on the keypad(s) and to the central monitoring station (if system is monitored). This allows pin-point information about any sensor in the system.

The *sensor zone* determines how and when the Control Panel responds to signals from the sensor. Some sensors are armed all the time, others are armed only in certain security levels. Some sensors cause central station reports in certain security levels, some cause central station reports anytime their activated. The sensor's programmed zone along with other programming options determines this.

The sensor zones are:

Exterior

For perimeter doors and windows.

Interior

For motion detectors, mat switches, interior doors and other sensors that detect human presence inside the building.

Restricted Interior

For special interior areas that are not normally occupied during nighttime. Sensors used in this zone would be located in an attic, basement, inside a detached garage or other similar areas.

Fire

Continuously armed 24-hour zone for smoke detectors, heat sensors, pull stations, etc. Can also be triggered directly from keypad.

Emergency

Continuously armed 24-hour zone for personal or other types of emergencies. Can also be triggered directly from keypad.

Police/Hold-up

Continuously armed 24-hour zone for panic, police or hold-up. Can also be triggered directly from keypad.

Arm/Disarm Toggle

++ Sensors programmed to this zone can arm and disarm the system. This zone alternately arms the system to Level 4 and disarms the system to Level 1. Automatic bypassing occurs if other sensors are open. Hardwire loops can be programmed to this zone for keyswitch use.

Delayed Remote Emergency

Continuously armed 24-hour zone for personal or other types of emergencies. Portable sensor must be activated for 3 seconds to trigger emergency alarm. Use an LMT-1, TX-91, TX-92 or TX-94.

☞ **NOTE: LMT-1 Not tested by UL for emergency signaling.**

Delayed Remote Police/Hold-up

Continuously armed 24-hour zone for panic, police or hold-up. Portable sensor must be activated for 3 seconds to trigger panic alarm. Use an LMT-1, TX-91, TX-92 or TX-94.

☞ **NOTE: LMT-1 Not tested by UL for emergency signaling.**

Guard Zone

++ For protecting areas or objects that are not normally entered or moved when the burglary portion of the system is disarmed. Used for gun cabinets, artworks, museum pieces, liquor cabinets, etc. This zone is also suitable for glass break sensors. Local alarm will sound when this zone is armed; causes central station reports in Level 4 only.

Environmental Type A

++ Continuously armed 24-hour zone for environmental sensors (flood, freeze, etc.). Causes local annunciation, alarm and central station reports.

Environmental Type B

++ Continuously armed 24-hour zone for environmental sensors (flood, freeze, etc.). Causes local annunciation and alarm but no central station reports.

Environmental Type C

++ Continuously armed 24-hour zone for environmental sensors (flood, freeze, etc.). Causes local annunciation only.

Chime Only Zone

++ This zone causes a local chime when triggered. Can be used for wireless doorbell, mailbox mail detector, driveway vehicle sensor, etc. Active 24-hours in Security Levels 1, 2 and 3.

Automation #1

++ Sensors programmed for this zone cause the Automation Output #1 to activate on the control output connector. Output may be timed or toggle on/off (programming option).

Automation #2

++ Sensors programmed for this zone cause the Automation Output #2 to activate on the control output connector. Output may be timed or toggle on/off (programming option).

Access Only

++ Sensors programmed for this zone cause the Access Output to activate on the control output connector. Output may be timed or toggle on/off (programming option).

☞ **NOTE: ++ Indicates a supplementary zone type for UL Listed residential fire and burglar alarm.**

Tx Type Transmitter Button Disable Zone

This is a special zone used to disable desired buttons on TX type portable transmitters. This special zone disables unneeded transmitter buttons on multi-button transmitters.

SECURITY LEVELS

This page is similar to the information presented in the CP-90 User's Guide. This general information is presented so that the installer can become familiar with the CP-90's security levels. The CP-90 System can be armed (or disarmed) to different levels of security protection. Each security level arms or disarms a specific group of sensor zones.

The security levels are named after their most common use. When changing to a security level, the keypad will sound a level change gong then count a number of beeps (in groups of three) to match the selected level. The security levels are:

Programming Level (For Installers Only)

LEVEL 9 PROGRAMMING MODE (Gong & 9 beeps)

- Used to program the system from a keypad.
- Allows reviewing and changing of the program Functions, Selectors and Values.
- Press and hold the "★" key for 5 seconds to exit program mode.
- Mode exits automatically after 4 minutes of inactivity.

Test Levels

LEVEL 7 PHONE TEST (Gong & 7 beeps)

- Level 7 sends a telephone "test" message to the central monitoring station (if system is monitored).
- All intrusion detection is off.
- All 24-hour sensors (fire, panic and environmental) are armed.
- Upon successful phone test, keypad will sound accept tones and the system will return to Level 0.

LEVEL 8 SENSOR TEST (Gong & 8 beeps)

- Used to test each of the system's sensors.
- Activating sensor causes keypad beep.
- Display shows sensors that need to be tested.
- Pressing the STATUS button displays last sensor activated.
- Press STATUS again to resume displaying sensors to be tested.

Disarm/Cancel and Low Security Levels

LEVEL 0 DISARM/CANCEL (Gong only)

- All intrusion detection is off.
- All 24-hour sensors (fire, panic and environmental) are armed.
- Disarms system (cancels any alarm in progress).

LEVEL 1 GUARD/CANCEL (Gong & 1 beep)

- Guard Zone is armed (gun cabinet, safe, etc.) and will cause a local alarm only.
- All intrusion detection is off.
- All 24-hour sensors (fire, panic and environmental) are armed.
- Chime Only Zone is active.
- Disarms system (cancels any alarm in progress).

LEVEL 2 CHIME (Gong & 2 beeps)

- A two-tone "chime" will sound whenever windows or an exterior door is opened.
- Guard Zone is armed (gun cabinet, safe, etc.) and will cause a local alarm only.
- All intrusion detection is off.
- All 24-hour sensors (fire, panic and environmental) are armed.
- Chime Only Zone is active.

High Security Arming Levels

LEVEL 3 HOME (Gong & 3 beeps)

- All windows and exterior doors are armed.
- All interior sensors are off.
- Delayed sensors allow "Secure Entry" when the user enters a PAC and rearms to Level 3, 5 or 6 during the entry delay.
- "Secure Exit" starts an exit delay for delayed sensors when the user enters a PAC and rearms to Level 3 from Level 3.
- Guard Zone is armed (gun cabinet, safe, etc.) and will cause a local alarm only.
- All 24-hour sensors (fire, panic and environmental) are armed.
- Chime Only Zone is active.

LEVEL 4 AWAY (Gong & 4 beeps)

- All sensors (interior and exterior) are armed.
- Delayed sensors allow timed exit and entry of premises without sounding an alarm.
- Guard Zone is armed (gun cabinet, safe, etc.) and will cause a local alarm and central station reports.
- All 24-hour sensors (fire, panic and environmental) are armed.

LEVEL 5 NIGHT (Gong & 5 beeps)

- All windows and exterior doors are armed.
- Delayed sensors allow "Secure Entry" when a user enters a PAC and rearms to Level 3, 5 or 6 during the entry delay.
- "Secure Exit" starts an exit delay for delayed sensors when the user enters a PAC and rearms to Level 5 from Level 5.
- Restricted interior sensors are armed (garage, downstairs interiors, other areas not normally entered at night).
- Guard Zone is armed (gun cabinet, safe, etc.) and will cause a local alarm only.
- All 24-hour sensors (fire, panic and environmental) are armed.

LEVEL 6 NIGHT SECURE (Gong & 6 beeps)

- All windows and exterior doors are armed as instant.
- Delayed sensors activate as "instant" unless "Secure Exit" is used.
- The system must be disarmed prior to entry or an instant alarm will occur.
- "Secure Exit" starts an exit delay for delayed sensors when the user enters a PAC and rearms to Level 6 from Level 6.
- Restricted interior sensors are armed (garage, downstairs interiors, other areas not normally entered at night).
- Guard Zone is armed (gun cabinet, safe, etc.) and will cause a local alarm only.
- All 24-hour sensors (fire, panic and environmental) are armed.

SECURITY LEVEL ARMING TABLE

| | LEVEL 0 | LEVEL 1 | LEVEL 2 | LEVEL 3 | LEVEL 4 | LEVEL 5 | LEVEL 6 |
|--|---------|---------|---------|---------|---------|---------|---------|
| ✓ = ARMED * = ARMED INSTANT ▲ = CHIMES | | | | | | | |
| EXTERIOR | | | ▲ | ✓ | ✓ | ✓ | * |
| INTERIOR | | | | | ✓ | | |
| RESTRICTED INTERIOR | | | | | ✓ | ✓ | ✓ |
| FIRE | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| EMERGENCY | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| POLICE/HOLD-UP | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| REMOTE EMERGENCY | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| REMOTE POLICE/HOLD-UP | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| GUARD ZONE | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| ENVIRONMENTAL TYPE A | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| ENVIRONMENTAL TYPE B | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| ENVIRONMENTAL TYPE C | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| CHIME ONLY | | ▲ | ▲ | ▲ | | | |

Figure 3. Security Level Arming Table

KEYPAD SOUNDS

This page is similar to the information presented in the CP-90 User's Guide. This general information is presented so that the installer can become familiar with the CP-90's keypad sounds.

Audible Signals and Sirens

Audible signals are used to sound system status, alert the user of an emergency and frighten away an intruder. The sounds come from the speakers in the hardwire keypads. The different sounds are:

Emergency Fire Alarm

Loud, rapid two-tone siren.

Emergency Intrusion Alarm

Loud, intermittent siren.

Personal Emergency Sounder

A two-tone high/low chime sound.

Police/Hold-up Emergency Alarm

Loud, high/low siren sound.

Environmental Alarm Sounder/Trouble Sounder

A short, single-tone triple beep repeated at 1 minute intervals. This sound is used for environmental alarms and for sensor/accessory low battery or supervisory trouble (Function 121.022). Silence by pressing the * key.

Accept Tones

A three-tone sound which indicates that the system has accepted a command.

Rejection Tones

Low volume, short two-tone sound which sometimes occurs when a keypad command is entered. It indicates that the command was not directly accepted. Normally this occurs when trying to arm the system with an open sensor. The sensor(s) must be closed or bypassed, then the system will arm.

Exit Delay Beeps

Short, single-tone beeps repeated at 1 second intervals during the exit delay. An exit delay allows time for you to leave the premises through a door programmed as "delayed". **The premises must be vacated before the exit delay time expires or an alarm will occur.**

Entry Delay Beeps

Short, single-tone beeps repeated at 1/2 second intervals during the entry delay. Entering the protected premises through an exterior door programmed for "delay" will start the entry beeps. **The system must be disarmed before the entry delay time expires or an alarm will occur.**

Entry Delay After Alarm Beeps

Short, two-tone beeps repeated at 1/2 second intervals during the entry delay after an alarm has occurred. **This is to alert you to exercise caution when entering the premises, as the intruder may still be present.**

Level Change Gong

A single gong tone sound that occurs after changing security levels.

Level Count Beeps

Short, low volume single-tone beeps that come after a level change gong or when the STATUS key is pressed. **Count** the number of beeps to determine the current security level.

Chime Tones

Low volume two-tone chime which indicates a door or window sensor has been opened when the system is armed in Level 2. Also used as sounder for the Chime Only Zone.

Sensor Test Beep

Loud single-beep heard when testing the sensors in Level 8 (Sensor Test Mode).

Ready to Program Sensor Tone

Low volume two-tone chime which indicates that the CP-90 is ready to program one or more RF sensors (Functions 001, 002 & 017 only).


Panel Connection Warning Chirps

If the keypad sounds continuous chirps, there is trouble in the connection between the keypad and the control panel. Check the keypad cable if this occurs.

KEYPAD COMMANDS

This page is similar to the information presented in the CP-90 User's Guide. This general information is presented so that the installer can become familiar with the CP-90's keypad commands.

Status Key Commands



The STATUS key has four functions:

- ☞ If the STATUS key is pressed on a wireless keypad (keypad with no display), the current security level count beeps will sound from the hardwired keypads.
- ☞ If the STATUS key is pressed on a hardwired keypad (keypad with display), the current security level count beeps will sound and the display will show "— —". A sensor number or special keypad command can be entered. Entering a sensor number displays the current state of that sensor. Enter two digits (04 = Sensor #4).
- ☞ If the STATUS key is pressed and held for about 1 second, the display will cycle to show the status of all of the sensors. If all sensors are closed and no trouble conditions exist, the display will show "SYSTEM READY".
- ☞ If the STATUS key is pressed during the status display cycle, the display will freeze on the sensor displayed. Press STATUS again to restart the display cycling.

After using the STATUS key, the display will return to normal after 45 seconds of keypad inactivity.

Special Keypad Commands

Special keypad commands are used for resetting functions and performing system tests. **The system must be in Level 0 to use these commands.** The special keypad commands are:

- ☞ **??? → 8 → 0** Press STATUS then "80"
Sets clock minutes - enter two digits (01 = 1).
- ☞ **??? → 8 → 1** Press STATUS then "81"
Sets clock hours - enter two digits (01 = 1).
- ☞ **??? → 8 → 2** Press STATUS then "82"
Sets calendar day - enter two digits (01 = 1).
- ☞ **??? → 8 → 3** Press STATUS then "83"
Sets calendar month - enter two digits (01 = 1).
- ☞ **??? → 8 → 4** Press STATUS then "84"
Sets calendar year - enter two digits (01 = 1).
- ☞ **??? → 8 → 5** Press STATUS then "85"
Sets day of week - enter 01-07 (01=Sunday).
- ☞ **??? → 8 → 6** Press STATUS then "86"
Adjusts clock 1 second per day faster.
- ☞ **??? → 8 → 7** Press STATUS then "87"
Adjusts clock 1 second per day slower.
- ☞ **??? → 9 → 0** Press STATUS then "90"
Displays version of CP-90 firmware.
- ☞ **??? → 9 → 6** Press STATUS then "96"
Displays alarm memory of up to nine alarm events in order of occurrence.
- ☞ **??? → 9 → 7** Press STATUS then "97"
Clears all trouble displays on the keypad.
- ☞ **??? → 9 → 8** Press STATUS then "98"
Starts a manual system backup battery test.
- ☞ **??? → 9 → 9** Press STATUS then "99"
Resets latching wired smoke detectors.

TROUBLE DISPLAYS

This page is similar to the information presented in the CP-90 User's Guide. This general information is presented so that the installer can become familiar with the CP-90's trouble codes.

Special situations will cause the TROUBLE light on the keypad(s) to blink. To identify the trouble, press and hold the STATUS key for one second. On a KD-90 keypad, the display will show a "Supervisory Code" and the trouble condition. **To clear troubles, fix the problem and press "STATUS 97" from Level 0.**

The system can identify trouble from three areas: Sensors and accessories (RF transmitters, hardwired loops and wired keypads), the control panel hardware (fuses, tamper, backup battery and AC power) and internal system functions (radio decoding, EEPROM memory and watchdog circuitry).

Sensor Trouble Codes

The table in Figure 4 shows the possible trouble codes that occur from sensors. These kind of trouble conditions can be corrected by taking the actions shown in the table.

Control Panel Trouble Codes

The table in Figure 5 shows the possible control panel trouble codes that might occur. These kind of trouble conditions can be corrected by replacing blown fuses and correcting the problem, etc.

Internal System Trouble Codes

The table in Figure 6 shows the possible internal system trouble codes that might occur under rare system conditions. If these kind of trouble codes show up more than once, call the Linear Technical Services Department for instructions.

| SENSOR TROUBLE CODES (xx = SENSOR NUMBER) | | | |
|---|---|---|---|
| CODE # | DISPLAY DESCRIPTION | CAUSE | ACTION |
| 4-64 | SENSOR xx LOW BATTERY (Accompanied by an audible trouble warning in UL systems.) | Sensor has sent a low battery signal. | Replace battery in sensor number displayed. Trouble clears when sensor's battery is replaced. |
| 4-64 | SENSOR xx SUPERVISORY (Accompanied by an audible trouble warning in UL systems.) | Sensor has not reported to CP-90 in eight hours. May be caused by a missing or inoperative sensor or a radio reception problem. | Check the sensor's condition. Try the EXA-1000 remote antenna if reception is a problem. |
| 1-64 | SENSOR xx TAMPER | Sensor case has been opened and tamper has been reported to the CP-90. | Check the sensor's condition. Trouble indication must be cleared with "STATUS 97". |
| 65-72 | ACCESSORY xx SUPERVISORY (Accompanied by an audible trouble warning in UL systems.) | Accessory (keypad) has not reported to CP-90 in one minute. May be caused by an inoperative or missing keypad. | Check the keypad's condition. Check the keypad wiring. |
| 65-72 | ACCESSORY xx TAMPER | Accessory (keypad) has been removed from its mounting plate. | Check the keypad's condition. Trouble indication must be cleared with "STATUS 97". |

Figure 4. Sensor Trouble Codes

| CONTROL PANEL TROUBLE CODES | | | |
|-----------------------------|---|--|---|
| CODE # | DISPLAY DESCRIPTION | CAUSE | ACTION |
| 73 | SUPERVISORY CODE 73 COMMUNICATION FAILURE | CP-90 has failed to fully connect to the central station after all call attempts. | Check the telephone connection. Check the telephone line. |
| 74 | SUPERVISORY CODE 74 PANEL LOW BATTERY | CP-90 has a low or missing control panel backup battery. | Check battery fuse, battery charge voltage and battery condition. May have been caused by lack of AC power. |
| 75 | SUPERVISORY CODE 75 PANEL AUXILIARY FUSE FAILURE | CP-90 auxiliary power fuse is blown or missing. Too much current has been drawn from auxiliary power output. | Replace auxiliary power fuse with a 2 Amp fuse. |
| 76 | SUPERVISORY CODE 76 PANEL FIRE FUSE FAILURE | CP-90 fire power fuse is blown or missing. Too much current has been drawn from fire power output. | Replace fire power fuse with a 2 Amp fuse. |
| 78 | SUPERVISORY CODE 78 PANEL POWER FAILURE | CP-90 has had a complete loss of AC and DC power. | Be sure transformer is connected to an unswitched outlet that provides power 24 hours-a-day. |
| 79 | SUPERVISORY CODE 79 PANEL TAMPER CONDITION | The CP-90 control panel cabinet has been opened. | Close the control panel door and reset the trouble indication with "STATUS 97". |
| 80 | SUPERVISORY CODE 80 PANEL AC POWER FAILURE | CP-90 has had a loss of AC power. | Be sure transformer is connected to an unswitched outlet that provides power 24 hours-a-day. |
| 87 | SUPERVISORY CODE 87 UNINSTALLED ACCESSORY | A keypad has been wired to the CP-90 but has not been installed into the system memory. | See Programming Instructions for how to install accessories with Function 21. |

Figure 5. Control Panel Trouble Codes

| INTERNAL SYSTEM TROUBLE CODES | | | |
|-------------------------------|---|---|---|
| CODE # | DISPLAY DESCRIPTION | CAUSE | ACTION |
| 77 | SUPERVISORY CODE 77 PANEL RADIO FAILURE | The CP-90 has detected a problem in the radio receiver circuitry. | Call Technical Services if this happens more than once. |
| 86 | SUPERVISORY CODE 86 PANEL RAM CHECK ERROR | The CP-90 has detected a RAM memory error. | |
| 88 | SUPERVISORY CODE 88 EEPROM WRITE FAILURE | The CP-90 has detected an error when updating its memory. | |
| 89 | SUPERVISORY CODE 89 WATCHDOG MONITOR RESET | The CP-90 has detected abnormal operation of the control panel software and has restarted itself. | |

Figure 6. Internal System Trouble Codes

PROGRAMMING OVERVIEW

Program Functions

Each programming step for the CP-90 has a *Function* number. The Function numbers start at 0 and end at 121. Each Function number programs a separate feature of the CP-90 (i.e. central station telephone number, central station account number, etc.). Figure 7 shows two Function numbers (62 & 63).

| FUNCTION | DESCRIPTION |
|----------|-------------------------------|
| 62 | PRIMARY LINE TELEPHONE NUMBER |
| 63 | PRIMARY LINE ACCOUNT NUMBER |

Figure 7. Each Programming Step has a Function Number

Program Selectors

Most of the Function numbers require programming more than one entry. The second number to be entered is called the *Selector*.

For example, Function 62 is the Primary Line Telephone Number. The telephone number can have up to 24 digits. Each telephone number digit is identified by a Selector number. Function 62 uses Selectors 1-24 to identify each of the telephone number digits, 1 = the first digit, 2 = the second digit and so on (See Figure 8).

| FUNCTION | SELECTOR | DESCRIPTION |
|----------|----------|-------------------------------|
| 62 | 1-24 | PRIMARY LINE TELEPHONE NUMBER |

Figure 8. Program Functions have Selectors

Program Values

The third number to be entered is called the *Value*. Some Functions may not require a Value entry.

The range of valid Value numbers that can be entered for a given Function/Selector combination depends on the specific Function/Selector Chosen.

For example, Function 62 (Primary Line Telephone Number) has 24 Selectors that can be programmed with the telephone number digits (see Figure 9).

Each Selector can be programmed with Values of 0-15 (0-9 are telephone digits, 11-15 are special dialing codes).

| FUNCTION | SELECTOR | VALUE | DESCRIPTION |
|----------|----------|-------|-------------------------------|
| 62 | 1-24 | 0-15 | PRIMARY LINE TELEPHONE NUMBER |

Figure 9. Function's Selectors have Values

Default Values

Many of the CP-90's programming Functions have Selector Values already set at the factory. These are called the "Factory Default Values".

The Factory Default Values are typical settings used in most security systems (exit/entry delays, alarm cutoffs, etc.). Most of these pre-programmed Values will not have to be changed by the installer.

For example, the default value for the Fire Output cutoff time is 5 minutes. The programming step is Function 120, Selector 6. The default Value is pre-set at 5 and can be changed to a new Value from 0 to 250 (see Figure 10).

Using the factory defaults speeds up programming the CP-90. The commonly used defaults are shown in Figure 11. Refer to the CP-90 Programming Key for all of the default values.

| FUNCTION | SELECTOR | VALUE | DEFAULT | DESCRIPTION |
|----------|----------|-------|---------|------------------------------------|
| 120 | 6 | 0-250 | 5 | FIRE OUTPUT CUTOFF TIME IN MINUTES |

Figure 10. Default Value of 5 for Fire Alarm Cutoff

Notation for Functions, Selectors & Values

In this manual, when a programming Function is shown the format "Function FFF" is used, where:

FFF = the Function Number
(i.e. Function 120).

When a specific Function and Selector are shown the format "FFF.SSS" is used, where:

FFF = the Function number
SSS = the selector number.
(i.e. 120.006)

When a specific Function, Selector and Value are shown the format "FFF.SSS.VVV" is used, where:

FFF = the Function number
SSS = the selector number
VVV = the value number.
(i.e. 120.006.005)

For example, 120.006.005 is the notation for Function 120, Selector 6, Value 5 (used in Figure 10).

FACTORY DEFAULTS & UL PROGRAMMING REQUIREMENTS

| FACTORY SET DEFAULTS | |
|--|-------------------------------|
| FEATURE | DEFAULT |
| HARDWIRE LOOP RESPONSE TIME | 400 MILLISECONDS |
| KEYPAD EMERGENCY KEYS | ALL ENABLED |
| ACTIVE DISPLAY INTENSITY | MEDIUM |
| ACTIVE DOWNLIGHT INTENSITY | MEDIUM |
| STANDBY DISPLAY INTENSITY | OFF |
| STANDBY DOWNLIGHT INTENSITY | OFF |
| KEYPAD LIGHTS DURING ENTRY DELAY | ON |
| KEYPAD LIGHTS DURING EXIT DELAY | ON |
| DIGITAL COMMUNICATOR | DISABLED |
| DIALING FORMAT | tone |
| DIALING ATTEMPTS BEFORE ROUTING CHANGE | 2 |
| DIALING ATTEMPTS BEFORE SLEEP CYCLES | 2 |
| NUMBER OF SLEEP CYCLES | 2 |
| SLEEP CYCLE TIME | 10 MINUTES |
| ANTI-JAM TIME | 40 SECONDS |
| AUTOMATIC TEST REPORTS | DISABLED |
| MANUAL TEST REPORTS | ENABLED (FOR SUPERSPEED ONLY) |
| INSTALLER PAC | 98765 |
| ENTRY DELAY TIME #1 | 30 SECONDS |
| ENTRY DELAY TIME #2 | 45 SECONDS |
| EXIT DELAY TIME | 45 SECONDS |
| BURGLARY OUTPUT CUTOFF | 5 MINUTES |
| FIRE OUTPUT CUTOFF | 5 MINUTES |
| EMERGENCY OUTPUT CUTOFF | 5 MINUTES |
| ACCESS OUTPUT ON-TIME | 5 SECONDS |
| AUTOMATION OUTPUT #1 ON-TIME | 5 SECONDS |
| AUTOMATION OUTPUT #2 ON-TIME | 5 SECONDS |
| FIRE OUTPUT | PULSING |
| BURGLARY OUTPUT | CONSTANT |
| ENTRY DELAY KEYPAD BEEPS | ON |
| EXIT DELAY KEYPAD BEEPS | ON |
| QUICK ARMING | ENABLED |
| AUTOMATIC RESTORAL | BYPASSES CLEAR ON RESTORAL |
| AUTO BYPASS ARMING | AUTO BYPASS THEN ARM |
| REMOTE PROGRAMMING LOCKOUT | REMOTE ACCESS ENABLED |
| REMOTE ACCESS CODE | 987654 |
| AUDIBLE SENSOR TROUBLE | DISABLED |
| 24 HR SYSTEM STATUS DISPLAY | DISABLED |

Figure 11. Factory Default Value Settings
(Partial listing, see CP-90 Programming Key for all defaults)

| GENERAL UL PROGRAMMING REQUIREMENTS | |
|---|--|
| FEATURE | VALUE |
| BELL CUTOFF (120.005, 120.006, 120.007, 120.008) | 4 MINUTES MINIMUM |
| DIALING DELAY (050.008) | 45 SECONDS MAXIMUM |
| DIAL ATTEMPTS BEFORE SLEEP CYCLE (050.010) | 5 TO 10 |
| NUMBER OF SLEEP CYCLES ALLOWED (050.011) | 1 |
| ANTI-JAM TIME (050.013) | 3-7 SECONDS |
| SWINGER ELIMINATOR (050.015) | 0 (ALL VIOLATIONS) |
| AUTOMATIC TEST REPORTS (070.017, 075.017 OR 072.004, 077.004 OR 074.004, 079.004) | ENABLED |
| AUTOMATIC TEST REPORT INTERVAL (050.018) | 1 (24 HRS) |
| BELL OUTPUT DELAY (120.004) | 0 SECONDS |
| RECEIVER DESENSE (121.015) | 0 (NORMAL) |
| 24 HR SYSTEM STATUS DISPLAY (121.018) | 1 (ACTIVE) |
| AUDIBLE SENSOR TROUBLE (121.022) | 1 (AUDIBLE & VISUAL) |
| SENSOR SUPERVISION (007.004-064) | 0 (SUPERVISED FOR ALL FIXED SENSORS) |
| LOOP RESPONSE TIME (012.001-003) | 10 (1 SECOND) |
| REMOTE PROGRAMMING LOCKOUT | NO REMOTE PROG. |
| COMPATIBLE CENTRAL STATION FORMATS (UL TESTED WITH LINEAR 3000R) | 10,20,40 PPS 3x1, 4x1, 4x2 3x1 EXTENDED SESCOA SUPERSPEED |

| UL PROGRAMMING REQUIREMENTS FOR RESIDENTIAL FIRE | |
|--|---------------------------------|
| FEATURE | VALUE |
| FIRE OUTPUT (121.002) | STEADY |
| SENSOR LOCAL ALARM (008.001-064) | 0 (AUDIBLE) |
| SENSOR BYPASSING (009.001-064) | 1 (NO BYPASS ON ALL FIRE ZONES) |

NOTE: HARDWIRED FIRE LOOPS NOT ALLOWED IN CP-90 UL INSTALLATIONS, USE WIRELESS SMOKE DETECTORS.

| UL PROGRAMMING REQUIREMENTS FOR RESIDENTIAL BURGLARY | | |
|--|--------------------|----------|
| FEATURE | VALUE | |
| MAXIMUM ENTRANCE DELAY (120.001-002) | 45 SECONDS | |
| MAXIMUM EXIT DELAY (120.003) | 60 SECONDS | |
| BURGLARY OUTPUT (121.001) | PULSING | |
| MULTIPLE BURGLARY OUTPUT SHUTDOWN (121.003) | 0 (NO LIMITS) | |
| SILENT BURGLARY ALARMS (121.011) | 0 (AUDIBLE) | |
| AUTO BYPASS ARMING (121.014) | 1 (MUST BE MANUAL) | |
| QUICK BYPASS (121.023) | 1 (MUST BE MANUAL) | |
| USER PAC PROGRAMMING | 3 DIGITS MINIMUM | |
| SENSOR LOCAL ALARM (008.001-064) | 0 (AUDIBLE) | |
| LOOP SUPERVISION CHOICES | FCTN #13 | FCTN #14 |
| NORMALLY CLOSED WITHOUT EOL RESISTOR | 1 | 0 |
| NORMALLY OPEN WITHOUT EOL RESISTOR | NOT ALLOWED | |
| NORMALLY CLOSED WITH EOL RESISTOR | 0 | 2 |
| NORMALLY OPEN WITH EOL RESISTOR | 0 | 1 |

Figure 12. UL Programming Requirements

PROGRAMMING THE CP-90




Figure 13. Entering Programming Mode

Entering Program Level

Security Level 9 is for CP-90 programming. The installer access code default value is 98765 (see Figure 13).

To enter Level 9 follow these steps:

- STEP 1** Turn MASTER POWER switch on.
- STEP 2** Be sure system is in Level 0 (Level 9 can only be reached from Level 0). If system is not in Level 0 press 0 for Level 0, then 98765 to switch to Level 0.
- STEP 3** Enter 9 for Level 9, then 98765 to switch to Level 9.

NOTE: If the system does not respond to a keypad command, try pressing * to clear the keypad before entering the command again.

Exiting Programming Level

Hold the * key down for about 4 seconds to exit the program mode. This causes the system to leave Level 9 and go back to Level 0.

Programming Level Timer

While programming the CP-90 from a keypad, if no keystrokes are made for four minutes, the system will automatically leave the programming Level 9 and return to Level 0.

Control Station Keys During Programming

When the system is in Level 9 the keypad keys perform different functions than normal (see Figure 14). A keypad template overlay (P/N 208247) is supplied with the CP-90 for placing over the keypad keys during programming. The template makes it easier to remember what functions the keys perform during programming.

BYPASS = STORE

Pressing the BYPASS key stores the displayed value into memory.

STATUS = CYCLE

Pressing the STATUS key cycles the display through the Function, Selector and Value fields.

1, 2, 3, 4, 5, 6, 7, 8, 9 & 0 KEYS

The number keys are used to enter Function, Selector and Value numbers directly.

FIRE = COUNT UP

Each time the FIRE key is pressed the displayed number (Function, Selector or Value) counts up by one.




Figure 14. Control Station Keys During Programming

EMERGENCY = RESET TO DEFAULT

Pressing the EMERGENCY key resets the displayed Value to the default number (factory value).

POLICE = COUNT DOWN

Each time the POLICE key is pressed the displayed number (Function, Selector or Value) counts down by one.

* = CLEAR/EXIT

Pressing * during programming clears the display and sends you back to Function 000, Selector 000. Use this key if the wrong key is pressed or if you're lost.

Holding the * key down for about 4 seconds causes the system to leave programming Level 9 and go back to Level 0.

Programming Cycle

Programming is performed by setting three fields:

Function, Selector and Value.

You can cycle through the fields by pressing the CYCLE (STATUS) key.

You can modify the displayed fields by using the keypad number keys or with the UP (FIRE) and DOWN (POLICE) keys. Pressing the * key at any time clears all three fields and returns the display back to the Function field.

When the Value field is displayed, pressing the DEFAULT (EMERGENCY) key replaces the displayed Value with the factory default Value.

KD-90 keypads display the Function, Selector and Value fields at the same time on the first line of the LCD display. The second line of the display is used to describe the current Function, display status or show data. The active field (the field that is being modified) is indicated by the flashing equal sign (=). See Figure 15.




Figure 15. KD-90 Display During Programming

FUNCTION FIELD DISPLAYED




Figure 16. Display Showing Function Field

Function Field

Enter the desired Function number and press CYCLE. If the keypad sounds the rejection tones and doesn't move to the Selector field, then the number in the Function field is out of range. This means that the Function number you have entered is not valid. Enter the correct number and press CYCLE again, or press the * key to clear the display and start over.

SELECTOR FIELD DISPLAYED




Figure 17. Display Showing Selector Field

Selector Field

Enter the desired Selector number and press CYCLE. If the keypad sounds the rejection tones and doesn't move to the Value field, then the number in the Selector field is out of range. This means that you have selected an invalid action, invalid sensor or the action you're attempting can't be performed. Enter the correct number and press CYCLE again, or press the * key to clear the display and start over.

VALUE FIELD DISPLAYED




Figure 18. Display Showing Value Field

Value Field

Once the Value field is displayed, pressing the STORE (BYPASS) key activates the function or stores the Value in memory. If no Value entry is required, pressing the STORE key is all that you need to do. If a Value entry is required, enter the new Value before pressing the STORE key; this will replace the current Value setting in memory with the new Value entered. **The Value field must be displayed before pressing the STORE key.** If you press the STORE key in any other field, the rejection tones will sound.

Changing Values

When the Value field is displayed or selected, the programmed Value can be changed to any number *within the range for that Value*. Use the CP-90 Programming Worksheet (P/N 207744) to decide which Values need to be changed.

The new Value will be displayed as it is entered on the keypad. Remember, the new Value is not stored into the CP-90 memory until the STORE key is pressed and the *accept tones* sound. If the new Value is out of range or is entered incorrectly, the keypad will sound the *rejection tones*.

Figure 19 shows an example of changing the Fire Output cutoff from the default Value of 5 to a new Value of 10 minutes. The Function is 120, Selector is 6 and the new Value entered is 10.




Figure 19. Example of Changing Fire Output Cutoff Time

CP-90 MEMORY LAYOUT

About Sensor Numbers

The CP-90 system groups sensor numbers according to their type (see Figure 20). The sensor number groups are:

- 1-3 Hardwire Loops 1, 2 & 3
- 4-64 Wireless Sensors (61 maximum)
- 65-72 Control Stations (Keypads)




Figure 20. Sensor Number Groups

About Control Station Numbers

Control station (keypad) sensor numbers are always between 65 and 72. Wireless TK-90 keypads are programmed in as a wireless device and get a sensor number from 4-64. The CP-90 knows when a wireless TK-90 is installed so it also gives the TK-90 a keypad sensor number from 65 to 72 (see Figure 21). **Wireless TK-90 sensors will have an RF sensor number as well as a keypad accessory number. Always refer to the TK-90 by its accessory number.**




Figure 21. Wireless Keypad Sensor Numbers




Figure 22. ST-23A Transmitter Coding Switches
(Not Tested by UL)

SENSOR SETUP

Some of the sensors (transmitters) that are used with the CP-90 system must be set up to customize their installation. There are three radio formats that this system accepts. Each format's transmitters are set up in a different way.

NOTE: For complete details on installation and setup for each sensor type refer to the Installation Instructions provided with the sensor.

SX Format

The T-90D door/window, TX series portable and TK-90 wireless keypad and all other SX format transmitters are pre-coded at the factory. There is no coding switch to set, although the T-90D does have an option switch. The transmitters can be programmed into the CP-90 memory without any additional setup. These transmitters can be programmed into the CP-90 in manual or autoinstall mode by sending a test or violation transmission.

MegaCode Format

The LMT-1 portable transmitter is pre-coded at the factory. There is no coding switch to set. The transmitter can be programmed into the CP-90 memory without any additional setup. This transmitter can be programmed into the CP-90 in the manual or autoinstall mode by pressing the transmitter button.

S1 Format

Linear's S1 format transmitters are becoming obsolete. S1 format transmitters contain two eight-position switches. These switches are labeled CHANNEL and SYSTEM (see Figure 22). These transmitters can still be programmed into the CP-90 in manual or autoinstall mode.

IMPORTANT NOTE: You can set the CHANNEL and SYSTEM switches in the S1 format transmitters to any code you like, as long as each S1 transmitter used in the system is set to a different code.

Consider the two eight-position switches as one sixteen-position switch, allowing you set a unique code from over 65,000 possible combinations for each transmitter.

NOTE: Don't set the switches to all ON, all OFF, or alternating ON/OFF because it is too often duplicated.

NOTE: S1 transmitters were not tested by UL.

Motion Detector Programming

When the CP-90 is in the autoinstall mode, each time a transmitter sends a signal the CP-90 installs it as a new sensor. Because PIR motion detectors trigger each time motion is detected, the CP-90 could install more than once for a single sensor. Therefore, **use the Manual Install RF Sensor mode (Function 002, explained in the next section) when installing PIR motion detectors.** Cover the PIR's lens after programming to prevent it from transmitting again until the installation is complete.

PROGRAM DESCRIPTIONS

In the following descriptions the Function, Selector and Value fields are notated as 000.000.000. If the description has no Value field (000.000) then no value needs to be entered. If the field can accept various Values (a range of Values) then the range is shown.

Pressing CLEAR (★) at any time during any program step terminates that step and sets the Function, Selector and Value fields to 0.

This section gives detailed descriptions of each CP-90 programming function. **Follow along using the CP-90 Programming Key sheet (P/N 207418). Installers familiar with this system should be able to program the system just using the CP-90 Programming Key sheet along with the CP-90 Programming Worksheet (P/N 207744).** Linear has provided all of the details for each of the functions here for advanced users and reference.

Sensor Installation

Use the following functions to install sensors including hardwire loops.

* **IMPORTANT: Before installing sensors make sure that the communicator reporting formats (Functions 050.002 & 050.003) and sensor reporting codes (Functions 070 & 075) are programmed to the desired values prior to installing sensors, so that the default reporting codes can be set correctly when zone assignments are made to the sensors.**

In the Autoinstall sensor mode, it is possible to program the same sensor multiple times, with different sensor numbers. To avoid this, make sure that each sensor is tripped (or test button pressed) only once. Use the Manual Install RF Sensor (Function 002) for PIR motion detectors.

TK-90 Wireless Keypads

Wireless keypads are assigned two numbers, a sensor number (4-64) and an accessory number (65-72). After the keypad is programmed, it always displays its accessory number, not its sensor number. **Press the ★ key to install the TK-90 when in Function 001 or 002.**

000.000

Display Installed Sensors

The displayed Value field is the number of sensors installed (including hardwire loops). Pressing STORE starts the display scrolling through each installed sensor number. Pressing STORE stops the display and returns the display to the Value field.

001.000

Auto-install RF Sensors

Automatically installs RF sensors and RF control stations at the next available sensor number. **Prior to using this step make sure that Function 050.002 and 050.003 have been set to the correct reporting formats and any report codes that are not the same as the factory defaults have been programmed.**

Press CYCLE twice to display the Value field. See Figure 23. The Value field shows the number of sensors currently installed. Press STORE. A high-low tone will sound, indicating that the system is ready to accept a transmission. After the sensor transmission is received, the display will show the sensor number sequentially assigned by the CP-90 to that sensor. The display will continue to show the last sensor number programmed. Each time a sensor transmission is received the accept tones will sound to signal the installer that a transmitter was entered.

Supervisory and tamper transmissions are not programmed; only test or violation (open) signals trigger the programming activity. Pressing STORE terminates the auto-install and displays the Function field again.

⚠ **IMPORTANT: The CP-90 will program the same transmitter more than once if multiple transmissions are received. Also, do not trigger portable transmitters for longer than one second while auto-installing.**




Figure 23. Entering Transmitters in Auto-install Mode

002.000 Manually Install RF Sensor

[Selector range 4-64]

Installs an RF sensor or RF control station at a particular sensor number (Selector 4-64 = sensor 4-64). See Figure 24. Press CYCLE, enter the sensor number you want into the Selector field and press CYCLE again. If that number is free (no sensor already installed there) then the display will advance to the Value field and display the number of installed sensors. Pressing STORE will place the CP-90 into sensor program mode. A high-low tone will sound, indicating that the system is ready to accept a transmission. After a sensor is programmed the accept tones will sound and the display will show the sensor number. Pressing STORE during program mode (before a transmission is received) or after a sensor is programmed returns the display to the Function field. If, during Selector field entry, a selected sensor number is already assigned, the rejection tones will sound and the display will not advance to the Value field. Supervisory and tamper transmissions are not programmed; only test or violation (open) signals can be programmed.




Figure 24. Entering Transmitters in Manual Install Mode

003.000 Manually Remove RF Sensor

[Selector range 4-64]

Removes an RF sensor from the system. Enter the desired sensor (Selector 4-64 = sensor 4-64) into the Selector field and press CYCLE, the display will show the total number of sensors installed. To remove the sensor press STORE. If a sensor was installed at that number then the accept tones will sound and the display will return to the Function field. If the selected sensor does not exist (or it's a wireless keypad) then the rejection tones will sound and the display remains on the Value field. **Use the accessory delete (Function 023.000) to delete wireless (TK-90) keypads using the accessory number.**

NOTE: For each of the following functions, unless otherwise stated, pressing the STORE key causes the new Value to be stored into the CP-90's memory and the display will return to the Function field. If the command is accepted, the accept tones will sound.

004.000.000 Sensor Zone Type

[Selector range 1-64]

[Value range 0-16, default = 0]

Assigns a zone type to a hardwired loop or RF sensor. See Figure 25. The Selector field specifies which sensor or loop to use (Selector 1-64 = sensor 1-64) and the Value field specifies the zone type. 17 different zone types are provided; a detailed description of each zone type can be found in the System Zones section of this manual. The Value numbers are shown in the Sensor Zone Table on the next page. If the specified sensor does not exist or the Value is out of range, the rejection tones will sound and the display remains on the Selector field. Use Function 017 to assign zone types to keys on TX type handheld remote transmitters.

NOTE: Changing the sensor zone type will replace its reporting code with the default reporting code for the new zone type.




Figure 25. Example of Entering Sensor Zone Type

| SENSOR INSTALLATION TABLE | | | | | |
|---------------------------|----------|----------------------------|---------|--|---|
| FUNCTION | SELECTOR | VALUE | DEFAULT | DESCRIPTION | ACTION/VALUE |
| 0 | 0 | | | DISPLAY INSTALLED SENSOR | PRESS STATUS TWICE FOR TOTAL # OF SENSORS, THEN PRESS STORE, DISPLAY WILL SHOW ALL INSTALLED SENSOR #'S |
| 1 | 0 | | | AUTO-INSTALL RF SENSORS | PRESS STORE, TEST SENSOR TO INSTALL, ASSIGNS DEFAULTS TO SENSOR AND REPORT CODES ** WARNING ** SET COMMUNICATOR FORMAT BEFORE USING |
| 2 | 4-64 | | | MANUALLY INSTALL RF SENSOR | SET SELECTOR TO SENSOR #, TEST SENSOR TO INSTALL, ASSIGNS DEFAULTS TO SENSOR AND REPORT CODES ** WARNING ** SET COMM. FORMAT BEFORE USING |
| 3 | 4-64 | | | MANUALLY REMOVE RF SENSOR | SET SELECTOR TO SENSOR #, PRESS STORE TO DELETE SENSOR |
| 4 | 1-64 | 0-16 | 0 | SENSOR ZONE | USE ZONE TABLE TO CHOOSE ZONE TYPE #0-16, PRESS STORE TO ENTER |
| 5 | 1-64 | 0-2 | 0 | SENSOR ENTRANCE DELAY | 0 = INSTANT 1 = DELAY ONE (SEE FUNCTION 120.001) 2 = DELAY TWO (SEE FUNCTION 120.002) 3 = INTERIOR FOLLOWER (SENSOR ZONE TYPES 1 & 2 ONLY) |
| 6 | 4-64 | 0-1 | 0 | SENSOR TYPE | 0 = NORMAL OPEN/CLOSE SENSOR 1 = PIR OR NON-RESTORING SENSOR |
| 7 | 4-64 | 0-1 | 0 | SENSOR SUPERVISION | 0 = SUPERVISED 1 = UNSUPERVISED |
| 8 | 1-64 | 0-1 | 0 | SENSOR LOCAL ALARM | 0 = AUDIBLE 1 = SILENT |
| 9 | 1-64 | 0-1 | 0 | SENSOR BYPASSING | 0 = CAN BE BYPASSED 1 = CANNOT BE BYPASSED |
| 10 | 1-64 | 0-2 | 0 | SENSOR AUDIO REPORTING | 0 = NO SENSOR AUDIO 1 = LISTEN IN 2 = TWO-WAY AUDIO |
| 11 | 0 | | | HARDWIRE LOOP AUTO SETUP | PRESS STORE WHEN "00" IS DISPLAYED TO INSTALL ALL HARDWIRE LOOPS |
| 12 | 1-3 | 1-100 | 4 | HARDWIRE LOOP RESPONSE TIME | VALUE TIMES 100ms = LOOP RESPONSE TIME; SELECTOR 1-3 = LOOP 1-3 |
| 13 | 1-3 | 0-1 | 0 | HARDWIRE LOOP SUPERVISION | 0 = EOL RESISTOR SUPERVISED (2.2K); 1 = NO EOL RESISTOR |
| 14 | 1-3 | 0-3 | 0 | HARDWIRE LOOP TROUBLE TYPE | 0 = NO TROUBLE 1 = TROUBLE ON OPEN 2 = TROUBLE ON SHORT 3 = TROUBLE ON OPEN OR SHORT |
| 15 | 1-3 | 0-1 | 0 | HARDWIRE LOOP DISABLE | 0 = LOOP DISABLED 1 = LOOP ENABLED |
| 16 | 1-64 | 0-255 | | KD-90 LCD CAPTIONS | ENTER SENSOR NAMES TO BE DISPLAYED ON KD-90 LCD KEYPAD |
| 17 | 3-17 | TOTAL # OF TX TYPE REMOTES | | ZONE SELECT FOR TX-91, TX-92 & TX-94 REMOTE TRANSMITTERS | SET ZONE TYPE IN SELECTOR FIELD, PRESS DESIRED REMOTE BUTTON; REMOTE MUST HAVE BEEN ENTERED IN FUNCTIONS 001 OR 002 |

| SENSOR ZONE TABLE | | |
|-------------------|--------------------------|---|
| VALUE | ZONE TYPE | DESCRIPTION |
| 0 | EXTERIOR | ARMED IN LEVELS 3, 4, 5 & 6 - CHIMES IN LEVEL 2 |
| 1 | RESTRICTED INTERIOR | ARMED IN LEVELS 4, 5 & 6 |
| 2 | INTERIOR | ARMED IN LEVEL 4 ONLY |
| 3 | FIRE | CONTINUOUSLY ARMED (24-HOUR FIRE ZONE) |
| 4 | EMERGENCY | CONTINUOUSLY ARMED (24-HOUR EMERGENCY ZONE) |
| 5 | POLICE/HOLD-UP | CONTINUOUSLY ARMED (24-HOUR POLICE/HOLDUP ZONE) |
| 6 | ARM/DISARM TOGGLE | SENSOR IS A PUSHBUTTON THAT ALTERNATELY ARMS TO LEVEL 4 AND LEVEL 1 (AUTOMATIC FORCED BYPASSING GOING TO LEVEL 4) |
| 7 | REMOTE PANIC/EMERGENCY | HOLDING FOR 3-SECONDS TRIGGERS 24-HOUR EMERGENCY ZONE |
| 8 | REMOTE PANIC/POLICE | HOLDING FOR 3-SECONDS TRIGGERS 24-HOUR POLICE ZONE |
| 9 | GUARD ZONE | ARMED IN LEVELS 1, 2, 3, 4, 5 & 6 - REPORTS AS BURG IN LEVEL 4; ALSO SUITABLE FOR GLASS BREAK |
| 10 | ENVIRONMENTAL TYPE A | CONTINUOUSLY ARMED 24-HOUR ENVIRONMENTAL ZONE TRIGGERS ANNUNCIATE, VIOLATION & REPORTS |
| 11 | ENVIRONMENTAL TYPE B | CONTINUOUSLY ARMED 24-HOUR ENVIRONMENTAL ZONE TRIGGERS ANNUNCIATE, VIOLATION & NO REPORTS |
| 12 | ENVIRONMENTAL TYPE C | CONTINUOUSLY ARMED 24-HOUR ENVIRONMENTAL ZONE TRIGGERS ANNUNCIATE ONLY, NO VIOLATION & NO REPORTS |
| 13 | CHIME ONLY | ACTIVE IN LEVELS 1, 2 & 3 TRIGGERS CHIME ONLY, NO VIOLATION, NO REPORTS |
| 14 | AUTOMATION #1 | TRIGGERS AUTOMATION #1 OUTPUT ON CONTROL OUTPUT |
| 15 | AUTOMATION #2 | TRIGGERS AUTOMATION #2 OUTPUT ON CONTROL OUTPUT |
| 16 | ACCESS ONLY | TRIGGERS ACCESS OUTPUT ON CONTROL OUTPUT |
| 17 | TX REMOTE BUTTON DISABLE | "DEAD" ZONE TO DISABLE DESIRED BUTTONS ON TX-92 & TX-94 REMOTE TRANSMITTERS |

Figure 26. Sensor Installation & Zone Tables

005.000.000 **Sensor Entry Delay**
[Selector range 1-64] [Value range 0-3, default = 0]
Selector 1-64 = sensor 1-64. Makes sensors delayed or instant.
For exterior sensors, Default Value of 0 makes the sensor instant, a Value of 1 gives the sensor entry delay time #1 specified by Function 120.001, and a Value of 2 gives the sensor entry delay time #2 specified by programming Function 120.002.

☞ A Value of 3 is for interior followers, **do not enter a Value of 3 for exterior sensors** (the sensor will act as an instant sensor).

For interior sensors, Default Value of 0 makes the sensor instant (alarms during entry and exit delays), a Value of 1 gives the sensor entry delay time #1 specified by Function 120.001, and a Value of 2 gives the sensor entry delay time #2 specified by programming Function 120.002.

A Value of 3 is for interior followers, this causes the sensor to be delayed during exit delays and entry delays, but instant if it is triggered first.

006.000.000 **RF Sensor Type**
[Selector range 4-64] [Value range 0-1, default = 0]
Selector 4-64 = sensor 4-64. Makes the selected sensor a non-restoring type such as a PIR, panic button or glass break detector. Default Value of 0 specifies a restoring sensor such as a door or window. Enter a Value of 1 to specify a non-restoring sensor. MegaCode format and TX series portable transmitters are automatically set up as non-restoring sensors when they are installed with Functions 001 or 002.

007.000.000 **RF Sensor Supervision**
[Selector range 4-64] [Value range 0-1, default = 0]
Selector 4-64 = sensor 4-64. Enables or disables sensor supervision. Default Value of 0 is for supervised. Enter a Value of 1 for unsupervised. Sensors should be supervised unless they can be taken out of range of the receiver. MegaCode format portable transmitters are automatically set up as unsupervised sensors when they are installed with Functions 001 or 002.

008.000.000 **Sensor Local Alarm**
[Selector range 1-64] [Value range 0-1, default = 0]
Selector 1-64 = sensor 1-64. Makes the selected sensor report audible or silent alarms. Default Value of 0 sets the sensor for audible alarms. Enter a Value of 1 for silent alarms. Sensors programmed for silent alarms *will not sound entry delay beeps* or activate the pre-alarm or alarm outputs on the control output connector. **Silent sensors will still trigger the violation output.**

009.000.000 **Sensor Bypassing**
[Selector range 1-64] [Value range 0-1, default = 0]
Selector 1-64 = sensor 1-64. Allows a sensor to be bypassed or not. Default Value of 0 allows the selected sensor to be bypassed. Enter a Value of 1 to disable bypassing.

010.000.000 **Sensor Audio Report**
[Selector range 1-64] [Value range 0-2, default = 0]
Allows a sensor to trigger central station audio reporting. If the optional two-way audio feature is installed and an alarm is caused by one of these sensors, on completion of the central station report, the system will enter an audio mode as specified by this Value. Default Value of 0 selects no audio response. Enter Value of 1 to select listen in audio only and a Value of 2 to select two-way audio.
2-way audio does not trigger with non-reporting sensors.

011.000 **Hardwire Loop Auto Setup**
Installs any connected hardwire loops into the CP-90 memory. **First, be sure all of the hardwire loops are wired correctly and their doors/windows are closed (contacts in restored state).** Enter 0 for Selector and Value fields, then press STORE to install the loops. The accept tones will sound when the loops are entered into memory. All loops will be installed; disable unused loops using Function 015 to remove them from sensor test displays.

012.000.000 **Hardwire Loop Response Time**
[Selector range 1-3] [Value range 1-100, default = 4]
Selector 1-3 = loop 1-3. Sets the delay time before the loop will cause a violation. Default Value of 4 gives each loop 400 mS delay. The Value selected times 100 mS equals the loop delay. The shortest delay is 100 ms. The longest delay is 10 seconds. This delay is for loop stability with different types of sensors and is *not* to be used for an entry delay.

013.000.000 **Hardwire Loop Supervision**
[Selector range 1-3] [Value range 0-1, default = 0]
Selector 1-3 = sensor/loop 1-3. Allows setting up non-supervised hardwire loops (loops without end-of-line (EOL) resistor termination). The default Value of 0 sets loops for a 2.2K EOL resistor. Enter a Value of 1 for non-EOL loops.

014.000.000 **Hardwire Loop Trouble Type**
[Selector range 1-3] [Value range 0-3, default = 0]
Selector 1-3 = sensor/loop 1-3. Selects the loop condition that will cause a supervisory trouble report. The default Value of 0 sets loops for no trouble reporting. Enter a Value of 1 for trouble when the loop is open (N/O loop with EOL resistor); 2 for trouble when loop is shorted (N/C loop with EOL resistor); 3 for trouble when loop is opened or shorted (trouble only loop with EOL resistor).

015.000.000 **Hardwire Loop Disable**
[Selector range 1-3] [Value range 0-1, default = 0]
Selector 1-3 = sensor/loop 1-3. All three hardwire loops are enabled when Function 011 is used. Any unused loops that weren't connected when Function 011 was used would be recognized as normally open loops. These unused loops can be disabled so that they won't show up when testing sensors in Level 8. **Enter a Value of 0 for any unused hardwire loops.**

016.000.000 **KD-90 LCD Keypad Captions**
[Selector range 1-64] [Value range 0-255]
Selector 1-64 = sensor 1-64. Refer to the table on the next page and Figure 28 to select words that describe each sensor's location or function. Use a KD-90 keypad to program this step. Enter the word number as the Value for each sensor. **More than one Value can be entered for each sensor for multiple word entries.** Press STORE after each Value number is entered. Up to 24 characters total can be entered. As each Value is entered, the word with a blank space after it will appear on the bottom line of the KD-90 display. Single characters do not have a blank space after them.

Use the # key to forward space the display cursor. Use the EMERGENCY key to move the cursor to position one. Enter 255 as a Value to erase all characters to the right of the cursor. To erase the entire line, press EMERGENCY, then 255, then STORE.

| KD-90 LCD KEYPAD ENGLISH CAPTION VALUES | | | | | | | |
|---|-----------------|-----|----------------|-----|----------------|-----|-------------------|
| VAL | WORD DISPLAYED | VAL | WORD DISPLAYED | VAL | WORD DISPLAYED | VAL | WORD DISPLAYED |
| 0 | 0 | 64 | # | 128 | Garage | 192 | Pump |
| 1 | 1 | 65 | & | 129 | Gas | 193 | Quarters |
| 2 | 2 | 66 | ' | 130 | Gate | 194 | Ramp |
| 3 | 3 | 67 | (| 131 | Glass | 195 | Rear |
| 4 | 4 | 68 |) | 132 | Guest | 196 | Receiving |
| 5 | 5 | 69 | * | 133 | Gun | 197 | Recreation |
| 6 | 6 | 70 | + | 134 | Hallway | 198 | Relay |
| 7 | 7 | 71 | . | 135 | Heat | 199 | Remote |
| 8 | 8 | 72 | - | 136 | Hobby | 200 | Restroom |
| 9 | 9 | 73 | . | 137 | Hold | 201 | RF |
| 10 | ONE BLANK SPACE | 74 | / | 138 | Hold-up | 202 | Right |
| 11 | a | 75 | = | 139 | House | 203 | Roof |
| 12 | b | 76 | Access | 140 | Ice | 204 | Room |
| 13 | c | 77 | Alarm | 141 | Infrared | 205 | Safe |
| 14 | d | 78 | Area | 142 | Inside | 206 | Screen |
| 15 | e | 79 | Arm | 143 | Interior | 207 | Second |
| 16 | f | 80 | Attic | 144 | Intrusion | 208 | Security |
| 17 | g | 81 | Audio | 145 | Janitor | 209 | Sensor |
| 18 | h | 82 | Auxiliary | 146 | Key | 210 | Shipping |
| 19 | i | 83 | Back | 147 | Keypad | 211 | Shock |
| 20 | j | 84 | Basement | 148 | Keypad | 212 | Shop |
| 21 | k | 85 | Bathroom | 149 | Kitchen | 213 | Shutter |
| 22 | l | 86 | Beam | 150 | Laundry | 214 | Side |
| 23 | m | 87 | Bedroom | 151 | Left | 215 | Silent |
| 24 | n | 88 | Breakfast | 152 | Level | 216 | Silver |
| 25 | o | 89 | Button | 153 | Library | 217 | Skylight |
| 26 | p | 90 | Cabinet | 154 | Lift | 218 | Sliding |
| 27 | q | 91 | Carpport | 155 | Light | 219 | Smoke |
| 28 | r | 92 | Ceiling | 156 | Liquor | 220 | South |
| 29 | s | 93 | Chime | 157 | Living | 221 | Spa |
| 30 | t | 94 | Closet | 158 | Loading | 222 | Sprinkler |
| 31 | u | 95 | Computer | 159 | Lobby | 223 | Stairs |
| 32 | v | 96 | Control | 160 | Locker | 224 | Station |
| 33 | w | 97 | Den | 161 | Loft | 225 | Steam |
| 34 | x | 98 | Detector | 162 | Lower | 226 | Stereo |
| 35 | y | 99 | Dining | 163 | Main | 227 | Stock |
| 36 | z | 100 | Dock | 164 | Maintenance | 228 | Storage |
| 37 | A | 101 | Door | 165 | Master | 229 | Study |
| 38 | B | 102 | Downstairs | 166 | Mat | 230 | Sump |
| 39 | C | 103 | Drawer | 167 | Medical | 231 | System |
| 40 | D | 104 | Dressing | 168 | Microwave | 232 | Tamper |
| 41 | E | 105 | Driveway | 169 | Middle | 233 | Temperature |
| 42 | F | 106 | East | 170 | Monitor | 234 | Third |
| 43 | G | 107 | Electric | 171 | Motion | 235 | Tool |
| 44 | H | 108 | Elevator | 172 | Mud | 236 | Transmitter |
| 45 | I | 109 | Emergency | 173 | North | 237 | Trap |
| 46 | J | 110 | Employee | 174 | Nursery | 238 | Ultrasonic |
| 47 | K | 111 | Entrance | 175 | Office | 239 | Upper |
| 48 | L | 112 | Exercise | 176 | On/Off | 240 | Upstairs |
| 49 | M | 113 | Exit | 177 | Outside | 241 | Utility |
| 50 | N | 114 | Exterior | 178 | Overhead | 242 | Valve |
| 51 | O | 115 | Factory | 179 | Panic | 243 | Vault |
| 52 | P | 116 | Family | 180 | Parking | 244 | Vibration |
| 53 | Q | 117 | Fire | 181 | Passive | 245 | Video |
| 54 | R | 118 | First | 182 | Patio | 246 | Violation |
| 55 | S | 119 | Floor | 183 | Perimeter | 247 | Wall |
| 56 | T | 120 | Flow | 184 | Photo | 248 | Warehouse |
| 57 | U | 121 | Fluid | 185 | PIR | 249 | Water |
| 58 | V | 122 | Foil | 186 | Play | 250 | West |
| 59 | W | 123 | Foyer | 187 | Plant | 251 | Window |
| 60 | X | 124 | Freezer | 188 | Police | 252 | Yard |
| 61 | Y | 125 | Front | 189 | Pool | 253 | Zone |
| 62 | Z | 126 | Furnace | 190 | Power | 254 | NULL (NOTHING) |
| 63 | ! | 127 | Game | 191 | Proximity | 255 | ERASE ENTIRE LINE |

Figure 27. KD-90 LCD Captions




Figure 28. Special Keys for KD-90 Caption Programming

017.000 TX Type Transmitter Zone Select [Selector range 3-17]

Sets the zones that each button on a TX-91, TX-92 or TX-94 portable transmitter will trigger. The Value numbers are shown in the Sensor Zone Table. Set the zone type value number in the Selector field, press CYCLE (Value displays the total # of TX units) then STORE. After pressing STORE, a high-low tone will sound, indicating that the system is ready to accept a transmission. Press the desired transmitter button. As each key is accepted, the keypad will display the sensor # of the TX transmitter and the accept tones will sound (see Figure 29). More than one transmitter may be installed using one Function 017 operation. **The TX transmitter must have already been entered with Function 001 or 002 before this step will work. All buttons are disabled (sensor zone 17) on TX type transmitters when first installed.**




Figure 29. Example of Entering a TX Type Transmitter

Accessory (Keypad) Installation

Use the following functions to install accessories such as Control Stations (keypads). Only Functions 023 & 024 affect TK-90 wireless keypads (installed by Function 001 or 002).

020.000 Display Accessories

The Value field displays the number of accessories recognized as being wired to the CP-90, but not necessarily installed yet. Even though the CP-90 recognizes connected keypads, they must be *installed* using Function 021. Pressing STORE starts the display scrolling through each accessory number. Pressing STORE stops the display and returns the display to the Value field. Accessories are numbered 65 through 72.

021.000 Install Connected Accessories

The Value field displays the number of installed accessories. Pressing the STORE key permanently installs all connected accessories. You must use this function after connecting any control station or other accessory to store the accessory's identification number in memory. **Always use this step after initial installation and after connecting a new accessory, even if the accessory appears to be responding normally.**

023.000 Remove Installed Accessory

[Selector range 65-72]
Selector 65-72 = keypad 65-72. The Value field will display the accessory number (65-72) of the controlling keypad. Use this step to determine the accessory number of a keypad if it is not known. Pressing the STORE key causes the accessory specified by the Selector field to be deleted from the system. The rejection tones will sound if the selected accessory does not exist, or if an attempt is made to delete the controlling keypad (you can't delete the keypad you are using to program the system). Uninstalled accessories must be installed (Function 021) before they can be removed with this function.

024.000.000 Keypad Emergency Keys

[Selector range 65-72] [Value range 0-7, default = 7]
Selector 65-72 = keypad 65-72. Each keypad can have its three emergency keys independently enabled or disabled. Use the Keypad Emergency Key Table on the next page to choose a Value corresponding to the desired option. Keypad stickers are provided to cover the unused buttons.

025.000.000 Standby Display Intensity

[Selector range 65-72] [Value range 0-3, default = 0]
Selector 65-72 = keypad 65-72. The standby lighting intensity is set by this Value. Control Station display lighting is turned on when someone presses a key or during entry/exit delays (Functions 029 & 030). The display remains on for a period of 45 seconds after the last keystroke, then the display goes into standby mode. Default Value of 0 is for off. Enter 1 for low, 2 for medium, 3 for high.

026.000.000 Standby Downlight Intensity

[selector range 65-72] [Value range 0-3, default = 0]
Selector 65-72 = keypad 65-72. The standby lighting intensity is set by this Value. Control Station downlights are turned on when someone presses a key or during entry/exit delays (Functions 029 & 030). The downlights remain on for a period of 45 seconds after the last keystroke, then the downlights go into standby mode. Default Value of 0 is for off. Enter 1 for low, 2 for medium, 3 for high.

027.000.000 Active Display Intensity

[Selector range 65-72] [Value range 0-3, default = 2]
Selector 65-72 = keypad 65-72. The active display intensity is set by this Value. Control Station displays are made active when someone presses a key or during entry/exit delays (Functions 029 & 030). Default Value of 2 is for medium. Enter 1 for low, 3 for high.

028.000.000 Active Downlight Intensity

[Selector range 65-72] [Value range 0-3, default = 2]
Selector 65-72 = keypad 65-72. The active downlight intensity is set by this Value. Control Station downlights are made active when someone presses a key or during entry/exit delays (Functions 029 & 030). Default Value of 2 is for medium. Enter 1 for low, 3 for high.

029.000.000 Lights During Entry Delay

[Selector range 65-72] [Value range 0-1, default = 1]
Selector 65-72 = keypad 65-72. Default Value of 1 causes the selected keypad's display and downlights to be set to the programmed active intensity during entry delays. Enter a Value of 0 to cause lights to be off during the entry delay.

030.000.000 Lights During Exit Delay

[Selector range 65-72] [Value range 0-1, default = 1]
Selector 65-72 = keypad 65-72. Default Value of 1 causes the selected keypad's display and downlights to be set to the programmed active intensity during exit delays. Enter a Value of 0 to cause lights to be off during the exit delay.

031.000.000 Keystroke Beep Loudness

[Selector range 65-72] [Value range 0-3, default = 2]
Selector 65-72 = keypad 65-72. Each keypad can be individually set for keystroke beep loudness. When a keypad key is pressed, a beep is made to provide the operator with audible feedback. Default Value of 2 is for medium. Enter 0 for off, 1 for low, 3 for high.

032.000.000 Annunciation Loudness

[Selector range 65-72] [Value range 0-3, default = 2]
Selector 65-72 = keypad 65-72. System annunciation tone loudness can be individually set for each selected keypad. Default Value of 2 is for medium. Enter 0 for off, 1 for low, 3 for high.

033.000.000 Alarm Tone Loudness

[Selector range 65-72] [Value range 0-3, default = 2]
Selector 65-72 = keypad 65-72. System alarm tone loudness can be individually set for each selected keypad. Default Value of 2 is for medium. Enter 0 for off, 1 for low, 3 for high.

034.000.000 Emergency Key Audio

[Selector range 65-72] [Value range 0-2, default = 0]
Selector 65-72 = keypad 65-72. If the optional two-way audio feature is installed, and an alarm is caused by one of the keypad emergency keys, then, on completion of the central station report, the system will enter an audio mode as specified by this value. Default Value of 0 selects no audio response. Enter 1 to select listen in audio only and 2 selects two-way audio.

035.000.000 KD-90 LCD Captions for Keypads

[Selector range 65-72] [Value range 0-255]
Selector 65-72 = keypad 65-72. Refer to the table in Figure 27 on the previous page to select words that describe each keypad's location. To program the sensor captions, follow the instructions for Function 016.

| ACCESSORY INSTALLATION TABLE | | | | | |
|------------------------------|----------|-------|---------|--|--|
| FUNCTION | SELECTOR | VALUE | DEFAULT | DESCRIPTION | ACTION/VALUE |
| 20 | 0 | | | DISPLAY ACCESSORIES | PRESS STORE, DISPLAY WILL SHOW ALL ACCESSORIES IN MEMORY |
| 21 | 0 | | | AUTOINSTALL ACCESSORIES | PRESS STORE, CONNECTED ACCESSORIES ARE PERMANENTLY INSTALLED |
| 23 | 65-72 | | | MANUALLY REMOVE ACCESSORY | SET SELECTOR TO ACCESSORY #, PRESS STORE TO REMOVE FROM MEMORY |
| 24 | 65-72 | 0-7 | 7 | KEYPAD EMERGENCY KEYS ENABLE | USE KEYPAD EMERGENCY KEY TABLE TO CHOOSE DESIRED OPTION. ENTER VALUE 0-7 |
| 25 | 65-72 | 0-3 | 0 | STANDBY DISPLAY INTENSITY | |
| 26 | 65-72 | 0-3 | 0 | STANDBY DOWNLIGHT INTENSITY | 0 = OFF (STANDBY DEFAULT) 1 = LOW |
| 27 | 65-72 | 0-3 | 2 | ACTIVE DISPLAY INTENSITY | 2 = MEDIUM (ACTIVE DEFAULT) 3 = HIGH |
| 28 | 65-72 | 0-3 | 2 | ACTIVE DOWNLIGHT INTENSITY | |
| 29 | 65-72 | 0-1 | 1 | KEYPAD LIGHTS DURING ENTRY DELAY | 0 = LIGHTS OFF DURING ENTRY DELAY 1 = LIGHTS ON DURING ENTRY DELAY |
| 30 | 65-72 | 0-1 | 1 | KEYPAD LIGHTS DURING EXIT DELAY | 0 = LIGHTS OFF DURING EXIT DELAY 1 = LIGHTS ON DURING EXIT DELAY |
| 31 | 65-72 | 0-3 | 2 | KEYPAD KEYSTROKE BEEP LOUDNESS | 0 = OFF/SILENT |
| 32 | 65-72 | 0-3 | 2 | KEYPAD SYSTEM ANNUNCIATION TONE LOUDNESS | 1 = LOW 2 = MEDIUM 3 = HIGH |
| 33 | 65-72 | 0-3 | 2 | KEYPAD ALARM TONE LOUDNESS | |
| 34 | 65-72 | 0-2 | 0 | KEYPAD EMERGENCY KEY AUDIO RESPONSE | 0 = NO AUDIO 1 = LISTEN IN 2 = TWO WAY AUDIO |
| 35 | 65-72 | 0-250 | | KD-90 LCD CAPTIONS FOR KEYPADS | ENTER VALUE NUMBERS FROM LCD CAPTION TABLE FOR ACCESSORY NAMES TO BE DISPLAYED ON KD-90 LCD KEYPAD |

| KEYPAD EMERGENCY KEY TABLE | | | |
|----------------------------|----------------------------------|-------|---------------------------------|
| VALUE | OPTION | VALUE | OPTION |
| 0 | DISABLE ALL THREE EMERGENCY KEYS | 4 | FIRE KEY ACTIVE ONLY |
| 1 | POLICE KEY ACTIVE ONLY | 5 | FIRE & POLICE KEYS ACTIVE |
| 2 | EMERGENCY KEY ACTIVE ONLY | 6 | FIRE & EMERGENCY KEYS ACTIVE |
| 3 | EMERGENCY & POLICE KEYS ACTIVE | 7 | ENABLE ALL THREE EMERGENCY KEYS |

Figure 30. Accessory Installation & Emergency Key Tables

General Communicator Operation

Use the following Functions and Selectors to change Values for general communicator operation. Refer to the table in Figure 32. The default values already in memory should be correct for most applications.

NOTE: For each of the following functions, unless otherwise stated, pressing the STORE key causes the new value to be stored into the CP-90's memory and the display will return to the Function field. If the command is accepted, the accept tones will sound.

050.001.000 Communicator On/Off [Value range 0-1, default = 0]

Enables or disables the CP-90's built-in digital communicator. Default Value of 0 is for a local alarm system. Enter a Value of 1 to enable the communicator to report to one or more central stations. **This Value must be set to 1 if the system is to be monitored. Do not set this Value to 1 until all other programming is completed.**

NOTE: When re-entering Programming Level 9 to make program adjustments, set this Value to 0 first to disable the communicator during programming.

050.002.000 Communication Format 1 [Value range 0-13, default = 5]

Selects the first central station communications format. All telephone numbers programmed can select either communications format 1 or 2 (see Functions 061.001, 061.002 & 061.003). Enter a Value matching the desired format from the Communicator Format Table on the next page.

NOTE: Executing this function also installs the default sensor report codes and report code options for the selected format (see Figures 37 & 39).

050.003.000 Communication Format 2 [Value range 0-13, default = 5]

Selects the second central station communications format. All telephone numbers programmed can select either communications format 1 or 2 (see Functions 061.001, 061.002 & 061.003). Enter a Value matching the desired format from the Communicator Format Table on the next page.

NOTE: Executing this function also installs the default sensor report codes and report code options for the selected format (see Figures 37 & 39).

SIMULATED CENTRAL STATION TAPE




Figure 31. Reporting Code Examples for Different Formats

050.004.000

Dialing Format

[Value range 0-1, default = 0]

Selects how the telephone will be dialed. Default Value of 0 is for tone (DTMF) dialing (be sure the phone system supports tone dialing). Enter a Value of 1 for pulse (rotary) dialing.

Opening & Closing Report Option Overview

The CP-90 can report openings and closings a variety of ways. The system defaults program the system for a closing report each time the system is armed and an opening report each time the system is disarmed.

Opening reports can be programmed to occur only after an alarm (exception reporting) with Function 050.005.

Closing reports can be programmed to occur only after an the system is armed with one or more sensors bypassed (exception reporting) with Function 050.006.

To disable all opening and closing reports for standard formats, program Functions 070 & 075, Selectors 014, 015 & 034 to 0.

To disable all opening and closing reports for SuperSpeed format, program Functions 074 & 079, Selectors 001, 002 & 003 to 0.

To disable all opening and closing reports for SIA format, program Functions 072 & 077, Selectors 001, 002 & 003 to 0.

To disable all alarm cancel reports (disarming during an alarm), program Functions 070 & 075, Selector 016 to 0.

050.005.000 Opening Reports by Exception [Value range 0-1, default = 0]

Selects whether opening reports will be sent each time the system is disarmed or only after an alarm has occurred. This is helpful in commercial accounts so that the central station knows when the subscriber has arrived on-site to check the cause of the alarm. Default Value of 0 is for standard opening reports. Enter a Value of 1 for opening reports only after an alarm.

050.006.000 Closing Reports by Exception [Value range 0-1, default = 0]

Selects whether closing reports will be sent each time the system is armed or only after the system is armed with bypassed sensors. This is helpful in commercial and residential accounts so that the central station knows when the subscriber has partially armed the system without complete protection. Bypassed sensors are reported with extended reporting formats. Default Value of 0 is for standard closing reports. Enter a Value of 1 for closing reports only after sensors have been bypassed.

050.007.000 Tamper Report Routing [Value range 0-1, default = 0]

Tamper reports normally use the supervisory call routing path (Function 060.006) to send their messages to the central station. By setting this Value to 1, tamper reports will use the alarm call routing path (Function 060.001).

050.008.000 Dialing Start Delay [Value range 0-250, default = 0]

The Value number entered equals the number of seconds of delay after an alarm before the communicator will start dialing out. This setting allows time for the subscriber to disarm the system after accidentally triggering the alarm before it dials out. Don't set this value too long, because actual alarm reports caused by real intruders will also be delayed. Enter a Value in seconds if a dialing delay is required.

| GENERAL COMMUNICATOR OPERATION | | | | | |
|--------------------------------|----------|-------------------|---------|---|---|
| FUNCTION | SELECTOR | VALUE | DEFAULT | DESCRIPTION | ACTION/VALUE |
| 50 | 1 | 0-1 | 0 | COMMUNICATOR ON/OFF | 0 = LOCAL ALARM OPERATION ONLY 1 = DIGITAL COMMUNICATOR SENDS CENTRAL STATION REPORTS |
| 50 | 2 | 0-13 | 5 | COMMUNICATIONS FORMAT #1 | USE COMMUNICATOR FORMAT TABLE TO CHOOSE DESIRED FORMAT, ENTER VALUE 0-13 |
| 50 | 3 | 0-13 | 5 | COMMUNICATIONS FORMAT #2 | |
| 50 | 4 | 0-1 | 0 | DIALING FORMAT | 0 = DTMF (TONE) DIALING; 1 = PULSE DIALING |
| 50 | 5 | 0-1 | 0 | OPENING REPORTS BY EXCEPTION | 0 = NORMAL OPENING REPORTS 1 = OPENING REPORTS ONLY WHEN DISARMING AFTER AN ALARM |
| 50 | 6 | 0-1 | 0 | CLOSING REPORTS BY EXCEPTION | 0 = NORMAL CLOSING REPORTS 1 = CLOSING REPORTS ONLY WHEN FORCE ARMING |
| 50 | 7 | 0-1 | 0 | TAMPER REPORTING | 0 = TAMPERS REPORT ON SUPERVISORY ROUTING 1 = TAMPERS REPORT ON ALARM ROUTING |
| 50 | 8 | 0-250 | 0 | DIALING START DELAY | ENTER NUMBER OF SECONDS FOR DELAY AS VALUE |
| 50 | 9 | 1-250 | 2 | DIALING ATTEMPTS BEFORE ROUTING CHANGE | ENTER NUMBER OF UNSUCCESSFUL ATTEMPTS TO CONNECT BEFORE ALTERNATE CALL ROUTING IS TRIED |
| 50 | 10 | 1-250 | 2 | DIALING ATTEMPTS BEFORE SLEEP CYCLE (ALL LINES) | ENTER NUMBER OF UNSUCCESSFUL ROUTING CHANGES BEFORE SLEEP CYCLE |
| 50 | 11 | 0-250 | 2 | NUMBER OF SLEEP CYCLES ALLOWED | ENTER NUMBER OF SLEEP CYCLES MADE BEFORE COMMUNICATIONS FAILURE |
| 50 | 12 | 0-250 | 10 | SLEEP CYCLE TIME | ENTER NUMBER OF MINUTES TO SLEEP BEFORE ATTEMPTING NEXT DIALING CYCLE |
| 50 | 13 | 1-250 | 40 | ANTI-JAM TIME | ENTER NUMBER OF SECONDS TO REMAIN ON-HOOK AFTER FAILURE TO DETECT DIAL TONE |
| 50 | 14 | 0-250 | 0 | AUTOMATIC TEST REPORT DELAY | ENTER NUMBER OF HOURS FROM PRESENT TIME UNTIL FIRST TEST REPORT IS SENT |
| 50 | 15 | 0-10 | 0 | SWINGER ELIMINATOR COUNT | 0 = ALL VIOLATIONS REPORTED 1-10 = THE NUMBER OF REPORTED VIOLATIONS ANY SENSOR/LOOP CAN HAVE IN ONE ARM/DISARM CYCLE |
| 50 | 16 | 0-1 | 1 | REMOTE PROGRAMMING LOCKOUT | 0 = NO REMOTE PROGRAMMING 1 = REMOTE PROGRAMMING ALLOWED |
| 50 | 17 | 20-50 | 20 | INVALID ACCESS TIMEOUT | TIME IN SECONDS TO DISCONNECT AFTER CP-90 ANSWERS FOR REMOTE PROGRAMMING AND COMMUNICATION IS NOT ESTABLISHED |
| 50 | 18 | 0-7 | 1 | AUTOMATIC TEST REPORT INTERVAL | 0 = TEST REPORTS EVERY 12 HOURS 1-7 = TEST REPORTS EVERY 1-7 DAYS |
| 50 | 19 | 0-1 | 0 | INHIBIT SUPERSPEED END-OF-TX SIGNAL | 0 = ETX AT END OF REPORT 1 = NO ETX SENT AT END OF REPORT |
| 50 | 20 | 0-1 | 0 | LISTEN-ONLY AUDIO AFTER DURESS PAC | 0 = NO AUDIO AFTER DURESS PAC 1 = LISTEN-ONLY AUDIO AFTER DURESS PAC |
| 51 | 1-6 | 000000- 999999 | 987654 | REMOTE PROGRAM ACCESS CODE | PASSWORD FOR REMOTE PROGRAMMING ACCESS, MUST BE PROGRAMMED IF VALUE FOR FUNCTION 050.016 IS 1 |

| COMMUNICATOR FORMAT TABLE | | |
|---------------------------|---|---------------------------------|
| VALUE | FORMAT | FORMAT SPECIFICATIONS |
| 0 | 10PPS 3x1 (ADEMCO STANDARD) | 1400 Hz HANDSHAKE, 1900 Hz DATA |
| 1 | 10PPS 3x1 TWO LINE EXTENDED | |
| 2 | 10PPS 4x1 | |
| 3 | 10PPS 4x2 (SILENT KNIGHT) | |
| 4 | 20PPS 3x1 (SESCOA STANDARD) | 2300 Hz HANDSHAKE, 1800 Hz DATA |
| 5 | 20PPS 3x1 TWO LINE EXTENDED | |
| 6 | 20PPS 4x1 | |
| 7 | 20PPS 4x2 | |
| 8 | 40PPS 3x1 | |
| 9 | 40PPS 3x1 TWO LINE EXTENDED | STANDARD RADIONICS FORMAT |
| 10 | BFSK 3x2 (NOT TESTED FOR UL INSTALLATIONS) | |
| 11 | SIA (NOT TESTED FOR UL INSTALLATIONS) | |
| 12 | SESCOA SUPERSPEED | 2300 Hz HANDSHAKE, 1800 Hz DATA |
| 13 | ADEMCO CONTACT ID (NOT TESTED FOR UL INSTALLATIONS) | PROPRIETARY |

THE ABOVE UL DATA FORMATS WERE TESTED WITH THE SESCOA 3000C AND 3000R CENTRAL STATION RECEIVERS

Figure 32. General Communicator Operation Table




Figure 33. Example of Entering Remote Program Access Code

Communicator Routing,

Telephone #'s & Account #'s

Use the following Functions to set up the communicator telephone and account numbers and the way the calls are routed. Two copy steps (Functions 064 & 067) are provided to make it easier to duplicate the primary line information to the secondary and supervisory lines. See Figure 35 for example keystrokes for entering phone numbers. Also refer to the Table in Figure 34.

NOTE: For each of the following functions, unless otherwise stated, pressing the STORE key causes the new value to be stored into the CP-90's memory and the display will return to the Function field. If the command is accepted, the accept tones will sound.

060.001.000

Alarm Call Routing

[Value range 0-3, default = 0]

This Value directs which telephone line(s) alarm calls and alarm cancels will go out on. Default Value of 0 is for primary line only. Enter 1 for primary then secondary if the primary fails, 2 for secondary then primary if the secondary fails and 3 for secondary only.

060.002.000

Open/Close Call Routing

[Value range 0-6, default = 0]

This Value directs which telephone line(s) opening and closing calls will go out on. Default Value of 0 is for primary line only. Enter 1 for primary then secondary if the primary fails; 2 for secondary then primary if the secondary fails; 3 for secondary only; 4 for supervisory only; 5 for supervisory then primary if the supervisory fails; 6 for supervisory then secondary if the supervisory fails.

060.003.000

Restore Call Routing

[Value range 0-6, default = 0]

This Value directs which telephone line(s) restore calls will go out on. Default Value of 0 is for primary line only. Enter 1 for primary then secondary if the primary fails; 2 for secondary then primary if the secondary fails; 3 for secondary only; 4 for supervisory only; 5 for supervisory then primary if the supervisory fails; 6 for supervisory then secondary if the supervisory fails.

060.004.000

Automatic/Manual Test Call Routing

[Value range 0-6, default = 0]

This Value directs which telephone line(s) automatic and manual test calls will go out on. Default Value of 0 is for primary line only. Enter 1 for primary then secondary if the primary fails; 2 for secondary then primary if the secondary fails; 3 for secondary only; 4 for supervisory only; 5 for supervisory then primary if the supervisory fails; 6 for supervisory then secondary if the supervisory fails.

060.005.000

Audio Events Call Routing

[Value range 0-6, default = 0]

This Value directs which telephone line(s) audio calls will go out on. Default Value of 0 is for primary line only. Enter 1 for primary then secondary if the primary fails; 2 for secondary then primary if the secondary fails; 3 for secondary only; 4 for supervisory only; 5 for supervisory then primary if the supervisory fails; 6 for supervisory then secondary if the supervisory fails.

060.006.000

Supervisory/Trouble Call Routing

[Value range 0-6, default = 0]

This Value directs which telephone line(s) supervisory and trouble calls will go out on. Default Value of 0 is for primary line only. Enter 1 for primary then secondary if the primary fails; 2 for secondary then primary if the secondary fails; 3 for secondary only; 4 for supervisory only; 5 for supervisory then primary if the supervisory fails; 6 for supervisory then secondary if the supervisory fails.

061.001.000

Primary Line Format

[Value range 1-2, default = 1]

Selects which communicator format the primary telephone number will use. The formats 1 & 2 are selected with Function 050.002 & 050.003. Default Value is 1 for format 1. Enter a Value of 2 for format 2.

061.002.000

Secondary Line Format

[Value range 1-2, default = 1]

Selects which communicator format the secondary telephone number will use. The formats 1 & 2 are selected with Function 050.002 & 050.003. Default Value is 1 for format 1. Enter a Value of 2 for format 2.

061.003.000

Supervisory Line Format

[Value range 1-2, default = 1]

Selects which communicator format the supervisory telephone number will use. The formats 1 & 2 are selected with Function 050.002 & 050.003. Default Value is 1 for format 1. Enter a Value of 2 for format 2.

| COMMUNICATOR ROUTING, TELEPHONE #'S AND ACCOUNT #'S | | | | | |
|---|----------|-------------------|---------|-------------------------------------|---|
| FUNCTION | SELECTOR | VALUE | DEFAULT | DESCRIPTION | ACTION/VALUE |
| 60 | 1 | 0-3 | 0 | ALARM CALL ROUTING | 0 = PRIMARY LINE ONLY 1 = PRIMARY THEN SECONDARY 2 = SECONDARY THEN PRIMARY 3 = SECONDARY ONLY |
| 60 | 2 | 0-6 | 0 | OPEN/CLOSE CALL ROUTING | 0 = PRIMARY LINE ONLY 1 = PRIMARY THEN SECONDARY 2 = SECONDARY THEN PRIMARY 3 = SECONDARY ONLY 4 = SUPERVISORY ONLY 5 = SUPERVISORY THEN PRIMARY 6 = SUPERVISORY THEN SECONDARY |
| 60 | 3 | 0-6 | 0 | RESTORE CALL ROUTING | |
| 60 | 4 | 0-6 | 0 | AUTOMATIC/MANUAL TEST CALL ROUTING | |
| 60 | 5 | 0-6 | 0 | AUDIO EVENTS CALL ROUTING | |
| 60 | 6 | 0-6 | 0 | SUPERVISORY/TROUBLE CALL ROUTING | |
| 61 | 1 | 1-2 | 1 | PRIMARY LINE FORMAT | |
| 61 | 2 | 1-2 | 1 | SECONDARY LINE FORMAT | |
| 61 | 3 | 1-2 | 1 | SUPERVISORY LINE FORMAT | |
| 62 | 1-24 | 0-15 | | PRIMARY LINE TELEPHONE NUMBER | ENTER TELEPHONE NUMBER UP TO 24 DIGITS, END WITH A "15", SEE DIALING TABLE FOR SPECIAL DIALING CODES |
| 63 | 1-6 | SEE ACCT. # TABLE | | PRIMARY LINE ACCOUNT NUMBER | ENTER UP TO A 6 -DIGIT ACCOUNT # FOR THIS TELEPHONE NUMBER, END WITH A "15", SEE ACCOUNT NUMBER TABLE |
| 64 | | | | COPY PRIMARY SETUP TO SECONDARY | PRESS STORE TO COPY PRIMARY TELEPHONE & ACCOUNT NUMBERS TO THE SECONDARY LINE |
| 65 | 1-24 | 0-15 | | SECONDARY LINE TELEPHONE NUMBER | ENTER TELEPHONE NUMBER UP TO 24 DIGITS, END WITH A "15", SEE DIALING TABLE FOR SPECIAL DIALING CODES |
| 66 | 1-6 | SEE ACCT. # TABLE | | SECONDARY LINE ACCOUNT NUMBER | ENTER UP TO A 6 -DIGIT ACCOUNT # FOR THIS TELEPHONE NUMBER, END WITH A "15", SEE ACCOUNT NUMBER TABLE |
| 67 | | | | COPY SECONDARY SETUP TO SUPERVISORY | PRESS STORE TO COPY SECONDARY TELEPHONE & ACCOUNT NUMBERS TO THE SUPERVISORY LINE |
| 68 | 1-24 | 0-15 | | SUPERVISORY LINE TELEPHONE NUMBER | ENTER TELEPHONE NUMBER UP TO 24 DIGITS, END WITH A "15", SEE DIALING TABLE FOR SPECIAL DIALING CODES |
| 69 | 1-6 | SEE ACCT. # TABLE | | SUPERVISORY LINE ACCOUNT NUMBER | ENTER UP TO A 6 -DIGIT ACCOUNT # FOR THIS TELEPHONE NUMBER, END WITH A "15", SEE ACCOUNT NUMBER TABLE |

| SPECIAL DIALING VALUES | |
|------------------------|---|
| TELEPHONE NUMBER VALUE | DIALING RESULT |
| 11 | EQUAL TO TOUCH TONE "*" |
| 12 | EQUAL TO TOUCH TONE "#" |
| 13 | 3-SECOND DIALING PAUSE |
| 14 | WAIT FOR DIAL TONE |
| 15 | END OF PHONE NUMBER, ALWAYS ENTER A "15" AT THE END OF EACH PHONE NUMBER, DISPLAY WILL RETURN TO FUNCTION FIELD |
| ACCOUNT NUMBER TABLE | |
| FORMAT USED | VALID ACCOUNT NUMBERS |
| 3x1 OR 3x2 | ENTER 3 DIGITS - 0-9 AND 10-15 (A-F) |
| 4x1 OR 4x2 | ENTER 4 DIGITS - 0-9 AND 10-15 (A-F) |
| SUPERSPEED | ENTER 4 DIGITS - 0000 TO 3374 |
| BFSK | ENTER 4 DIGITS - 0 PLUS 3 ACCOUNT NUMBER DIGITS |
| SIA | ENTER 1 TO 6 DIGITS - 000000 TO 999999 |
| ADEMCO CONTACT ID | ENTER 4 DIGITS - 0000 TO 9999 |
| ALL | ALWAYS ENTER A "15" AT THE END OF THE ACCOUNT NUMBER |

Figure 34. Communicator Routing, Phone Number and Account Number Tables

062.000 Primary Line Telephone Number
 [Selector range 1-24]
 Programs the primary line telephone number. Up to 24 digits can be used. Start at Selector 1, enter digit, press STORE, enter next digit, press STORE, repeat (see Figure 35). **Always enter a 15 after the last digit to end the Values.** The display will return to the Function field after entering the 15.

Special Values are: 11 equals “*”; 12 equals “#”; 13 is a 3-second dialing pause; 14 is an additional wait for dial tone.

063.000 Primary Line Account Number
 [Selector range 1-6]
 Enters the account number for the primary line. Up to 6 digits can be entered. Each communicator format requires different length account numbers. All digits of the account number must be entered (with the exception of leading zeros). Refer to the Account Number Table for account number length. Start at Selector 1, enter digit, press STORE, enter next digit, press STORE, repeat (see Figure 36). **Always enter a 15 after the last digit of the account number.** The display will return to the Function field after entering the 15.

064.001 Copy Primary Setup to Secondary
 Copies the primary line telephone and account number information to the secondary line Functions 65 & 66. Advance display to Value field and press STORE to copy.

065.000 Secondary Line Telephone Number
 [Selector range 1-24]
 Programs the secondary line telephone number. Up to 24 digits can be used. Start at Selector 1, enter digit, press STORE, enter next digit, press STORE, repeat (see Figure 35). **Always enter a 15 after the last digit to end the Values.** The display will return to the Function field after entering the 15.

Special Values are: 11 equals “*”; 12 equals “#”; 13 is a 3-second dialing pause; 14 is an additional wait for dial tone.

066.000 Secondary Line Account Number
 [Selector range 1-6]
 Enters the account number for the secondary line. Up to 6 digits can be entered. Each communicator format requires different length account numbers. All digits of the account number must be entered (with the exception of leading zeros). Refer to the Account Number Table on the previous page for account number length. Start at Selector 1, enter digit, press STORE, enter next digit, press STORE, repeat (see Figure 36). **Always enter a 15 after the last digit of the account number.** The display will return to the Function field after entering the 15.

067.001 Copy Secondary Setup to Supervisory
 Copies the secondary line telephone and account number information to the supervisory line Functions 65 & 66. Advance display to Value field and press STORE to copy.




Figure 35. Example of Entering Phone Numbers

068.000 Supervisory Line Telephone Number

[Selector range 1-24]

Programs the supervisory line telephone number. Up to 24 digits can be used. Start at Selector 1, enter digit, press STORE, enter next digit, press STORE, repeat (see Figure 35).

Always enter a 15 after the last digit to end the Values. The display will return to the Function field after entering the 15.

Special Values are: 11 equals “*”; 12 equals “#”; 13 is a 3-second dialing pause; 14 is an additional wait for dial tone.

069.000 Supervisory Line Account Number

[Selector range 1-6]

Enters the account number for the supervisory line. Up to 6 digits can be entered. Each communicator format requires different length account numbers. All digits of the account number must be entered (with the exception of leading zeros).

Refer to the Account Number Table for account number length. Start at Selector 1, enter digit, press STORE, enter next digit, press STORE, repeat (see Figure 36). **Always enter a 15 after the last digit of the account number.** The display will return to the Function field after entering the 15.




Figure 36. Example of Entering Account Numbers

Reporting Codes For All Formats

Except SuperSpeed & SIA

The following Functions and Selectors set the reporting codes for all of the communicator formats *except* SuperSpeed and SIA formats. The default values already in memory should be correct for most applications. Refer to the table in Figure 37. If the central station(s) that this system reports to require different codes, enter their Values for each format (#1 & #2). If only one format is being used, the format #2 settings need not be changed. **A Value of 0 disables that report.** Extended reporting formats will send the sensor number (1-15) after the report code.

Some formats will accept "hexadecimal" data (base 16 0-F). When entering hex Values, 10=A (sends 0), 11=B, 12=C, 13=D, 14=E, 15=F.

NOTE: Changing communicator formats with Functions 050.002 or 050.003 will install the default reporting codes. Select the format first, then change any reporting codes.

NOTE: For each of the following functions, unless otherwise stated, pressing the STORE key causes the new value to be stored into the CP-90's memory and the display will return to the Function field. If the command is accepted, the accept tones will sound.

Changing Report Codes Overview

Changing report codes for sensor violations (fire, intrusion, police, emergency and environmental) will not modify the report codes for sensors that have already been installed.

Reporting codes for sensors that have already been installed can be changed two ways:

1. Change the desired report codes with these Functions and then re-enter the effected sensor(s) zone type with Function 004. The sensor(s) will acquire the new report codes that have been set.
2. Use the sensor specific default report code override (Functions 071 & 076) to change the report code sensor by sensor. The sensor(s) zone type does not have to be re-entered.

Fire Sensor/Loop [Value range 0-15, default = 1]

070.001.000 for Format #1

075.001.000 for Format #2

Sets the reporting code for the fire loop or sensors programmed to the Fire Zone. Enter a new Value if a different reporting code than the default Value is required.

Exterior Intrusion [Value range 0-15, default = 3]

070.002.000 for Format #1

075.002.000 for Format #2

Sets the reporting code for the Exterior Zone sensors. Enter a new Value if a different reporting code than the default Value is required.

Interior Intrusion [Value range 0-15, default = 6]

070.003.000 for Format #1

075.003.000 for Format #2

Sets the reporting code for the Interior Zone sensors. Enter a new Value if a different reporting code than the default Value is required.

Police/Hold Up [Value range 0-15, default = 2]

070.004.000 for Format #1

075.004.000 for Format #2

Sets the reporting code for the Police/hold up Zone sensors. Enter a new Value if a different reporting code than the default Value is required.

Emergency [Value range 0-15, default = 4]

070.005.000 for Format #1

075.005.000 for Format #2

Sets the reporting code for the Emergency Zone sensors. Enter a new Value if a different reporting code than the default Value is required.

Environmental [Value range 0-15, default = 0]

070.006.000 for Format #1

075.006.000 for Format #2

Sets the reporting code for the Environmental Type "A" sensors. **This report is disabled by the default Value of 0.** Enter a new Value if this type of report is required.

Restore [Value range 0-15, default = 14(E)]

070.007.000 for Format #1

075.007.000 for Format #2

Sets the reporting code for sensor restoral. Enter a new Value if a different reporting code than the default Value is required.

Sensor Tamper [Value range 0-15, default = 0]

070.008.000 for Format #1

075.008.000 for Format #2

Sets the reporting code for sensor tampers. **This report is disabled by the default Value of 0.** Enter a new Value if this type of report is required.

Bypassed Sensor/Loop [Value range 0-15, default = 0]

070.009.000 for Format #1

075.009.000 for Format #2

Sets the reporting code for bypassed sensors and loops. **This report is disabled by the default Value of 0.** Enter a new Value if this type of report is required.

| REPORTING CODES FOR ALL FORMATS EXCEPT SUPERSPEED, SIA & ADEMCO CONTACT ID | | | | | | |
|--|---------|----------|-------|---------------------|-------------------------------|---|
| FUNCTION | | SELECTOR | VALUE | DEFAULT REPORT CODE | REPORT CODE DESCRIPTION | ACTION/VALUE ENTER NEW CODE IF DIFFERENT THAN DEFAULT (0 = NO REPORT) |
| FRMT #1 | FRMT #2 | | | | | |
| 70 | 75 | 1 | 0-15 | 1 | FIRE SENSOR/LOOP | EXTENDED SENSOR ID REPORT 1-15 |
| 70 | 75 | 2 | 0-15 | 3 | EXTERIOR INTRUSION | |
| 70 | 75 | 3 | 0-15 | 6 | INTERIOR INTRUSION | |
| 70 | 75 | 4 | 0-15 | 2 | POLICE/HOLDUP | |
| 70 | 75 | 5 | 0-15 | 4 | EMERGENCY | |
| 70 | 75 | 6 | 0-15 | 0 | ENVIRONMENTAL | |
| 70 | 75 | 7 | 0-15 | 14 (E) | RESTORE | |
| 70 | 75 | 8 | 0-15 | 0 | SENSOR TAMPER | |
| 70 | 75 | 9 | 0-15 | 0 | BYPASSED SENSOR/LOOP | |
| 70 | 75 | 10 | 0-15 | 1 | KEYPAD FIRE | |
| 70 | 75 | 11 | 0-15 | 2 | KEYPAD POLICE/HOLD-UP | |
| 70 | 75 | 12 | 0-15 | 4 | KEYPAD EMERGENCY | |
| 70 | 75 | 13 | 0-15 | 0 | DURESS | EXTENDED PAC ID REPORTING 1-15 |
| 70 | 75 | 14 | 0-15 | 11 (B) | OPENING | |
| 70 | 75 | 15 | 0-15 | 12 (C) | CLOSING | |
| 70 | 75 | 16 | 0-15 | 13 (D) | CANCEL | |
| 70 | 75 | 17 | 0-15 | 0 | COMMUNICATOR AUTOMATIC TEST | |
| 70 | 75 | 18 | 0-15 | 0 | COMMUNICATOR MANUAL TEST | |
| 70 | 75 | 19 | 0-15 | 0 | CONTROL PANEL DOOR TAMPER | |
| 70 | 75 | 20 | 0-15 | 0 | KEYPAD TAMPER | |
| 70 | 75 | 21 | 0-15 | 15 (F) | SUPERVISORY TROUBLE | EXTENDED SUPERVISORY TROUBLE REPORT CODE PREFIX |
| 70 | 75 | 22 | 0-15 | 0 | CONTROL PANEL LOW BATTERY | |
| 70 | 75 | 23 | 0-15 | 0 | CONTROL PANEL BATTERY RESTORE | |
| 70 | 75 | 24 | 0-15 | 0 | AC FAILURE | |
| 70 | 75 | 25 | 0-15 | 0 | AC RESTORE | |
| 70 | 75 | 26 | 0-15 | 0 | MEMORY ERROR | |
| 70 | 75 | 27 | 0-15 | 0 | AUXILIARY FUSE BLOWN | |
| 70 | 75 | 28 | 0-15 | 0 | FIRE POWER FUSE BLOWN | |
| 70 | 75 | 29 | | | | |
| 70 | 75 | 30 | 0-15 | 0 | COMMUNICATION FAILURE | |
| 70 | 75 | 31 | 0-15 | 0 | KEYPAD TROUBLE | |
| 70 | 75 | 32 | 0-15 | 0 | SENSOR LOW BATTERY | EXTENDED SENSOR ID REPORT 1-15 |
| 70 | 75 | 33 | 0-15 | 0 | SENSOR SUPERVISORY/TROUBLE | |
| 70 | 75 | 34 | 0-15 | 12 (C) | FORCE CLOSE | EXTENDED PAC ID REPORT 1-15 |
| 70 | 75 | 35 | 0-15 | 0 | SUPERVISORY RESTORE | EXTENDED SUPERVISORY RESTORAL REPORT CODE PREFIX |
| 71 | 76 | 1-64 | 0-15 | | DEFAULT REPORT CODE OVERRIDE | ENTER DESIRED REPORT CODE FOR SPECIFIC SENSOR(S) |

Figure 37. Reporting Codes for All Formats Except SuperSpeed, SIA and Ademco Contact ID

Keypad Fire [Value range 0-15, default = 1]

070.010.000 for Format #1
075.010.000 for Format #2

Sets the reporting code for the keypad fire button. Enter a new Value if a different reporting code than the default Value is required.

Keypad Police/Hold Up [Value range 0-15, default = 2]

070.011.000 for Format #1
075.011.000 for Format #2

Sets the reporting code for the keypad police/hold up button. Enter a new Value if a different reporting code than the default Value is required.

Keypad Emergency [Value range 0-15, default = 4]

070.012.000 for Format #1
075.012.000 for Format #2

Sets the reporting code for the keypad emergency button. Enter a new Value if a different reporting code than the default Value is required.

Duress [Value range 0-15, default = 0]

070.013.000 for Format #1
075.013.000 for Format #2

Sets the reporting code for the keypad duress code. **This report is disabled by the default Value of 0.** Enter a new Value if this type of report is required.

Opening [Value range 0-15, default = 11(B)]

070.014.000 for Format #1
075.014.000 for Format #2

Sets the reporting code for all opening reports. Enter a new Value if a different reporting code than the default Value is required.

Closing [Value range 0-15, default = 12(C)]

070.015.000 for Format #1
075.015.000 for Format #2

Sets the reporting code for normal closing reports. Enter a new Value if a different reporting code than the default Value is required.

NOTE: These Functions do not affect forced closing reports (see Function 034).

Cancel [Value range 0-15, default = 13(D)]

070.016.000 for Format #1
075.016.000 for Format #2

Sets the reporting code for alarm cancel. Enter a new Value if a different reporting code than the default Value is required.

NOTE: Alarm cancels use alarm routing.

Communicator Automatic Test

[Value range 0-15, default = 0]

070.017.000 for Format #1
075.017.000 for Format #2

Sets the reporting code for the automatic test reports. **This report is disabled by the default Value of 0.** Enter a new Value if this type of report is required.

NOTE: A reporting code must be entered in these selectors if automatic communicator tests are going to be used.

Communicator Manual Test [Value range 0-15, default = 0]

070.018.000 for Format #1
075.018.000 for Format #2

These selectors set the reporting code for the Level 7 manual test reports. **This report is disabled by the default Value of 0.** Enter a new Value if this type of report is required.

NOTE: A reporting code must be entered in these selectors if manual communicator tests are going to be used.

Control Panel Door Tamper [Value range 0-15, default = 0]

070.019.000 for Format #1
075.019.000 for Format #2

Sets the reporting code for control panel cabinet door tamper. **This report is disabled by the default Value of 0.** Enter a new Value if this type of report is required.

Keypad Tamper [Value range 0-15, default = 0]

070.020.000 for Format #1
075.020.000 for Format #2

Sets the reporting code for keypad tamper. **This report is disabled by the default Value of 0.** Enter a new Value if this type of report is required.

Supervisory Trouble [Value range 0-15, default = 15(F)]

070.021.000 for Format #1
075.021.000 for Format #2

Sets the reporting code for supervisory trouble events. Enter a new Value if a different reporting code than the default Value is required.

Control Panel Low Battery [Value range 0-15, default = 0]

070.022.000 for Format #1
075.022.000 for Format #2

Sets the reporting code for control panel low battery. **This report is disabled by the default Value of 0.** Enter a new Value if this type of report is required.

Control Panel Battery Restore [Value range 0-15, default = 0]
070.023.000 for Format #1
075.023.000 for Format #2
Sets the reporting code for control panel battery restore. **This report is disabled by the default Value of 0.** Enter a new Value if this type of report is required.

AC Failure [Value range 0-15, default = 0]
070.024.000 for Format #1
075.024.000 for Format #2
Sets the reporting code for AC power failure. **This report is disabled by the default Value of 0.** Enter a new Value if this type of report is required.

AC Restore [Value range 0-15, default = 0]
070.025.000 for Format #1
075.025.000 for Format #2
Sets the reporting code for AC power restoral. **This report is disabled by the default Value of 0.** Enter a new Value if this type of report is required.

Memory Error [Value range 0-15, default = 0]
070.026.000 for Format #1
075.026.000 for Format #2
Sets the reporting code for system memory error. **This report is disabled by the default Value of 0.** Enter a new Value if this type of report is required.

Auxiliary Fuse Blown [Value range 0-15, default = 0]
070.027.000 for Format #1
075.027.000 for Format #2
Sets the reporting code for blown auxiliary power fuse. **This report is disabled by the default Value of 0.** Enter a new Value if this type of report is required.

Fire Fuse Blown [Value range 0-15, default = 0]
070.028.000 for Format #1
075.028.000 for Format #2
Sets the reporting code for blown fire power fuse. **This report is disabled by the default Value of 0.** Enter a new Value if this type of report is required.

Communication Failure [Value range 0-15, default = 0]
070.030.000 for Format #1
075.030.000 for Format #2
Sets the reporting code for failed communications after all attempts. **This report is disabled by the default Value of 0.** Enter a new Value if this type of report is required.

Keypad Trouble [Value range 0-15, default = 0]
070.031.000 for Format #1
075.031.000 for Format #2
Sets the reporting code for supervisory trouble from a keypad. **This report is disabled by the default Value of 0.** Enter a new Value if this type of report is required.

Sensor Low Battery [Value range 0-15, default = 0]
070.032.000 for Format #1
075.032.000 for Format #2
Sets the reporting code for low battery from a wireless sensor. **This report is disabled by the default Value of 0.** Enter a new Value if this type of report is required.

Sensor Supervisory Trouble [Value range 0-15, default = 0]
070.033.000 for Format #1
075.033.000 for Format #2
Sets the reporting code for supervisory reports from a wireless sensor. **This report is disabled by the default Value of 0.** Enter a new Value if this type of report is required.

Force Close [Value range 0-15, default = 12(C)]
070.034.000 for Format #1
075.034.000 for Format #2
Sets the reporting code for arming the system with one or more bypassed sensors. Enter a new Value if a different reporting code than the default Value is required.

Supervisory Restore [Value range 0-15, default = 0]
070.035.000 for Format #1
075.035.000 for Format #2
Sets the reporting code for supervisory restoral events. Enter a new Value if a different reporting code than the default Value is required.

Default Report Code Override
[Selector range 1-64] [Value range 0-15, default = 0]
071.000.000 for Format #1
076.000.000 for Format #2
These Selectors (1-64) set special reporting codes for each sensor/loop. Selectors 1-64 = sensors 1-64. The default Value of 0 allows the sensor to use the reporting code for the zone that it is programmed to. Enter a Value from 0 to 15 for any sensor that needs a special reporting code that's different from its zone reporting code.

SuperSpeed, SIA & Ademco Contact ID Format Reporting Options

These selectors are only valid if SIA, SuperSpeed or Ademco Contact ID format has been selected as format #1 or #2 (Functions 050.002 & 050.003). Do not use these Functions if other formats have been selected. Use the following Functions and Selectors to enable and disable different SIA and SuperSpeed reporting options. Refer to the table in Figure 38.

NOTE: Changing communicator formats with Functions 050.002 or 050.003 will install the default report codes. Select the format first, then change any report codes.

Opening [Value range 0-1, default = 1]

072.001.000 For Format #1 SIA & Ademco Format #2 077.001.000
074.001.000 For Format #2 SuperSpeed Format #2 079.001.000

Default Value of 1 enables opening reports. Enter Value of 0 to disable opening reports.

Closing [Value range 0-1, default = 1]

072.002.000 For Format #1 SIA & Ademco Format #2 077.002.000
074.002.000 For Format #2 SuperSpeed Format #2 079.002.000

Default Value of 1 enables closing reports. Enter Value of 0 to disable closing reports (normal arming only).

Force Arm [Value range 0-1, default = 1]

072.003.000 For Format #1 SIA & Ademco Format #2 077.003.000
074.003.000 For Format #2 SuperSpeed Format #2 079.003.000

Default Value of 1 enables force arming and bypassed sensor reports. Enter Value of 0 to disable force arming reports.

Automatic Test [Value range 0-1, default = 0]

072.004.000 For Format #1 SIA & Ademco Format #2 077.004.000
074.004.000 For Format #2 SuperSpeed Format #2 079.004.000

Default Value of 0 disables automatic communicator test reports. Enter Value of 1 to enable automatic communicator test reports.

Manual Test [Value range 0-1, default = 1]

072.005.000 For Format #1 SIA & Ademco Format #2 077.005.000
074.005.000 For Format #2 SuperSpeed Format #2 079.005.000

Default Value of 1 enables manual communicator test reports. Enter Value of 0 to disable manual communicator test reports.

AC Failure [Value range 0-1, default = 1]

072.006.000 For Format #1 SIA & Ademco Format #2 077.006.000
074.006.000 For Format #2 SuperSpeed Format #2 079.006.000

Default Value of 1 enables AC failure reports. Enter Value of 0 to disable AC failure reports.

AC Restore [Value range 0-1, default = 1]

072.007.000 For Format #1 SIA & Ademco Format #2 077.007.000
074.007.000 For Format #2 SuperSpeed Format #2 079.007.000

Default Value of 1 enables AC restoral reports. Enter Value of 0 to disable AC restoral reports.

Control Panel Low Battery [Value range 0-1, default = 1]

072.008.000 For Format #1 SIA & Ademco Format #2 077.008.000
074.008.000 For Format #2 SuperSpeed Format #2 079.008.000

Default Value of 1 enables control panel low battery reports. Enter Value of 0 to disable control panel low battery reports.

Control Panel Battery Restore [Value range 0-1, default = 1]

072.009.000 For Format #1 SIA & Ademco Format #2 077.009.000
074.009.000 For Format #2 SuperSpeed Format #2 079.009.000

Default Value of 1 enables control panel battery restore reports. Enter Value of 0 to disable control panel battery restore reports.

Sensor/Loop Restore [Value range 0-1, default = 1]

072.010.000 For Format #1 SIA & Ademco Format #2 077.010.000
074.010.000 For Format #2 SuperSpeed Format #2 079.010.000

Default Value of 1 enables sensor/loop restoral reports. Enter Value of 0 to disable sensor/loop restoral reports.

Sensor/Loop Tamper [Value range 0-1, default = 1]

072.011.000 For Format #1 SIA & Ademco Format #2 077.011.000
074.011.000 For Format #2 SuperSpeed Format #2 079.011.000

Default Value of 1 enables sensor/loop tamper reports. Enter Value of 0 to disable sensor/loop tamper reports.

Sensor/Loop Supervisory [Value range 0-1, default = 1]

072.012.000 For Format #1 SIA & Ademco Format #2 077.012.000
074.012.000 For Format #2 SuperSpeed Format #2 079.012.000

Default Value of 1 enables sensor/loop supervisory reports. Enter Value of 0 to disable sensor/loop supervisory reports.

Sensor Low Battery [Value range 0-1, default = 1]

072.013.000 For Format #1 SIA & Ademco Format #2 077.013.000
074.013.000 For Format #2 SuperSpeed Format #2 079.013.000

Default Value of 1 enables sensor low battery reports. Enter Value of 0 to disable sensor low battery reports.

Supervisory Trouble [Value range 0-1, default = 1]

072.014.000 For Format #1 SIA & Ademco Format #2 077.014.000
074.014.000 For Format #2 SuperSpeed Format #2 079.014.000

Default Value of 1 enables supervisory trouble reports. Enter Value of 0 to disable supervisory trouble reports.

SIA & Ademco Contact ID Default Report Code Override

073.000.000 For Format #1 SIA & Ademco Format #2 078.000.000
[selector range 1-64] [Value range 0-12, default = 0]

For SuperSpeed: Not Supported

Selectors 1-64 = sensors 1-64. These selectors set special reporting codes for each sensor/loop. The codes are shown in the Report Code Override Table on the next page. The default Value of 0 allows the sensor to use the reporting code for the zone that it is programmed to. Enter a Value for any sensor that needs a special reporting code. The message to the central station will have 2 characters for the type of alarm, followed by 2 digits for the sensor number.

| SIA & SUPERSPEED FORMAT REPORTING OPTIONS | | | | | | | | |
|---|---------|-------------------------|---------|----------|-------|---------|-------------------------------|--|
| FUNCTION FOR SIA & ADEMCO | | FUNCTION FOR SUPERSPEED | | SELECTOR | VALUE | DEFAULT | REPORT DESCRIPTION | ACTION/VALUE |
| FRMT #1 | FRMT #2 | FRMT #1 | FRMT #2 | | | | | |
| 72 | 77 | 74 | 79 | 1 | 0-1 | 1 | OPENING | 0 = NO REPORT 1 = REPORT |
| 72 | 77 | 74 | 79 | 2 | 0-1 | 1 | CLOSING | |
| 72 | 77 | 74 | 79 | 3 | 0-1 | 1 | FORCE ARM | |
| 72 | 77 | 74 | 79 | 4 | 0-1 | 0 | AUTOMATIC TEST | |
| 72 | 77 | 74 | 79 | 5 | 0-1 | 1 | MANUAL TEST | |
| 72 | 77 | 74 | 79 | 6 | 0-1 | 1 | AC FAILURE | |
| 72 | 77 | 74 | 79 | 7 | 0-1 | 1 | AC RESTORE | |
| 72 | 77 | 74 | 79 | 8 | 0-1 | 1 | CONTROL PANEL LOW BATTERY | |
| 72 | 77 | 74 | 79 | 9 | 0-1 | 1 | CONTROL PANEL BATTERY RESTORE | |
| 72 | 77 | 74 | 79 | 10 | 0-1 | 1 | SENSOR/LOOP RESTORE | |
| 72 | 77 | 74 | 79 | 11 | 0-1 | 1 | SENSOR/LOOP TAMPER | |
| 72 | 77 | 74 | 79 | 12 | 0-1 | 1 | SENSOR/LOOP SUPERVISORY | |
| 72 | 77 | 74 | 79 | 13 | 0-1 | 1 | SENSOR LOW BATTERY | |
| 72 | 77 | 74 | 79 | 14 | 0-1 | 1 | SUPERVISORY TROUBLE | |
| 73 | 78 | | | 1-64 | 0-12 | | DEFAULT REPORT CODE OVERRIDE | USE SIA REPORT CODE TABLE TO SELECT CODE FOR SPECIFIC SENSOR |

NOTE: THE VALUES IN THIS TABLE ARE ONLY VALID IF SIA, SUPERSPEED OR ADEMCO CONTACT ID FORMATS ARE SELECTED (SIA FORMAT HAS NOT BEEN TESTED BY UL FOR CENTRAL STATION REPORTING CAPABILITY)

| SIA REPORT CODE OVERRIDE TABLE | | | | | |
|--------------------------------|--------------------------|-------------------------------------|----------------|--------------------------|-------------------------------------|
| OVERRIDE VALUE | REPORT CODE xx=SENSOR | DESCRIPTION (VALUE OF 0=DEFAULT) | OVERRIDE VALUE | REPORT CODE xx=SENSOR | DESCRIPTION (VALUE OF 0=DEFAULT) |
| 1 | BAxx | BURGLARY ALARM | 7 | PAxx | PANIC ALARM |
| 2 | FAxx | FIRE ALARM | 8 | SAxx | SPRINKLER ALARM |
| 3 | GAxx | GAS ALARM | 9 | TAxx | TAMPER ALARM |
| 4 | HAxx | HOLDUP ALARM (DURESS) | 10 | UAxx | UNTYPED ALARM |
| 5 | KAxx | HEAT ALARM | 11 | WAxx | WATER ALARM |
| 6 | MAxx | MEDICAL ALARM | 12 | ZAxx | FREEZE ALARM |

| ADEMCO CONTACT ID REPORT CODE OVERRIDE TABLE | | | | | |
|--|--------------------------|-------------------------------------|----------------|--------------------------|-------------------------------------|
| OVERRIDE VALUE | REPORT CODE xx=SENSOR | DESCRIPTION (VALUE OF 0=DEFAULT) | OVERRIDE VALUE | REPORT CODE xx=SENSOR | DESCRIPTION (VALUE OF 0=DEFAULT) |
| 1 | 130 0xx | BURGLARY ALARM | 7 | 123 0xx | PANIC ALARM (122 0xx IF SILENT) |
| 2 | 110 0xx | FIRE ALARM | 8 | 113 0xx | SPRINKLER ALARM |
| 3 | 141 0xx | GAS ALARM | 9 | 137 0xx | TAMPER ALARM |
| 4 | 121 0xx | HOLDUP ALARM (DURESS) | 10 | 140 0xx | 24-HOUR NON-BURGLARY ALARM |
| 5 | 147 0xx | HEAT ALARM | 11 | 144 0xx | WATER ALARM |
| 6 | 100 0xx | MEDICAL ALARM | 12 | 148 0xx | FREEZE ALARM |

Figure 38. SIA, SuperSpeed and Ademco Contact ID Format Options and Report Code Overrides

Reporting Codes for Extended Formats

The 3 x 1 and 4 x 2 extended reporting formats are limited to 16 different reporting codes for the 64 possible CP-90 sensors. The CP-90 uses a reporting code matrix (see the Table in Figure 39) to define which reporting code will be sent for a specific sensor.

Extended Format Examples

For example, a CP-90 with account number 123 has a sensor #41 programmed as exterior and it causes an alarm then restores.

See Figure 40 for a 3 x 1 extended format reporting example. See Figure 41 for a 4 x 2 extended format reporting example.

| REPORTING CODE SENSOR MATRIX FOR EXTENDED FORMATS | | | | |
|---|--------------------------------------|----|----|----|
| REPORTING CODE SENT | SENSOR NUMBERS PROGRAMMED INTO CP-90 | | | |
| 0 | 64 | 16 | 32 | 48 |
| 1 | 1 | 17 | 33 | 49 |
| 2 | 2 | 18 | 34 | 50 |
| 3 | 3 | 19 | 35 | 51 |
| 4 | 4 | 20 | 36 | 52 |
| 5 | 5 | 21 | 37 | 53 |
| 6 | 6 | 22 | 38 | 54 |
| 7 | 7 | 23 | 39 | 55 |
| 8 | 8 | 24 | 40 | 56 |
| 9 | 9 | 25 | 41 | 57 |
| A (0) | 10 | 26 | 42 | 58 |
| B | 11 | 27 | 43 | 59 |
| C | 12 | 28 | 44 | 60 |
| D | 13 | 29 | 45 | 61 |
| E | 14 | 30 | 46 | 62 |
| F | 15 | 31 | 47 | 63 |

Figure 39. Reporting Code Sensor Matrix




Figure 40. 3 x 1 Extended Format Reporting Example




Figure 41. 4 x 2 Extended Format Reporting Example

SuperSpeed, SIA & Ademco Contact ID Format Reporting Codes

Refer to the Table in Figure 42 for details on central station reporting codes for SuperSpeed, SIA and Ademco Contact ID communicator formats.

These report codes are the default reporting code values. The report codes for SIA and Ademco Contact ID formats may be modified using the report code overrides (see Functions 073 and 078).

| SUPERSPEED SENSOR & SUPERVISORY REPORTING CODES | | | |
|---|--|----------------|--|
| REPORTING CODE | REPORT DESCRIPTION xx = SENSOR/LOOP # ppp = PAC ID # | REPORTING CODE | REPORT DESCRIPTION xx = SENSOR/LOOP # ppp = PAC ID # |
| 24H | AUTOMATIC COMMUNICATOR TEST | D77 | PANEL RADIO FAILURE |
| Axx | ALARM | D79 | PANEL TAMPER |
| A91 | KEYPAD AND TX-TYPE TRANSMITTER FIRE | D82 | FIRMWARE FAILURE |
| A92 | KEYPAD TX-TYPE TRANSMITTER EMERGENCY | D85 | EVENT LOG LIMIT REACHED |
| A93 | KEYPAD TX-TYPE TRANSMITTER POLICE | D88 | PANEL MEMORY ERROR |
| A94 | KEYPAD BURG CAUSED BY LOCK-IN | DU | DURESS |
| AC | AC POWER FAILURE | Exx | RESTORE |
| CH | MANUAL COMMUNICATOR TEST | EAC | AC POWER RESTORE |
| Dxx | SUPERVISORY/TROUBLE | ELO | PANEL LOW BATTERY RESTORE |
| D73 | COMMUNICATION FAILURE | IOP ppp | OPENING WITH PAC ID ppp |
| D75 | AUXILIARY FUSE BLOWN | ICL ppp | CLOSING WITH PAC ID ppp |
| D76 | FIRE POWER FUSE BLOWN | LO | PANEL LOW BATTERY |

| SIA SENSOR REPORTING CODES | | | | | | |
|----------------------------|-----------------------------|-------------------------------|------------------------------|-----------------------------------|----------------------------------|------------------------------|
| REPORT | ALARM xx = SENSOR/LOOP # | RESTORE xx = SENSOR/LOOP # | TAMPER xx = SENSOR/LOOP # | LOW BATTERY xx = SENSOR/LOOP # | SUPRVISORY xx = SENSOR/LOOP # | BYPASS xx = SENSOR/LOOP # |
| BURGLARY | BAxx | BRxx | TAxx | XTxx | BSxx | BBxx |
| FIRE | FAxx | FRxx | TAxx | XTxx | FSxx | FBxx |
| EMERGENCY | MAxx | MRxx | TAxx | XTxx | MSxx | MBxx |
| POLICE | PAxx | PRxx | TAxx | XTxx | PSxx | PBxx |
| ENVIRONMENT | UAxx | URxx | TAxx | XTxx | USxx | UBxx |
| TAMPER | TAxx | TRxx | TAxx | XTxx | TSxx | TBxx |

| SIA SUPERVISORY REPORTING CODES | | | |
|---------------------------------|--|----------|--|
| RPT CODE | REPORT DESCRIPTION xx = SENSOR/LOOP # pp = PAC ID # | RPT CODE | REPORT DESCRIPTION xx = SENSOR/LOOP # pp = PAC ID # |
| AR | AC RESTORE | TA79 | PANEL TAMPER |
| AT | AC FAIL | UT75 | AUXILIARY FUSE BLOWN |
| CFpp | FORCE ARM | UT77 | RECEIVER RADIO FAILURE |
| CLpp | CLOSING | UT80 | MEMORY ERROR |
| FT | FIRE FUSE BLOWN | UT85 | EVENT LOG LIMIT |
| HAXx | DURESS | UTxx | KEYPAD TROUBLE |
| OPpp | OPENING | YC | COMMUNICATIONS FAILURE |
| ORpp | CANCEL | YR | PANEL BATTERY RESTORE |
| RP | AUTOMATIC TEST | YT | PANEL LOW BATTERY |
| RX | MANUAL TEST | | |

| ADEMCO CONTACT ID SENSOR REPORTING CODES | | | |
|--|---|----------------|---|
| REPORTING CODE | REPORT DESCRIPTION (TRIGGERED BY ZONE) xx = SENSOR/LOOP # PREFIX 1 = VIOLATION PREFIX 3 = RESTORE | REPORTING CODE | REPORT DESCRIPTION (TRIGGERED BY ZONE) xx = SENSOR/LOOP # PREFIX 1 = VIOLATION PREFIX 3 = RESTORE |
| 100 0xx | MEDICAL (EMERGENCY) | 131 0xx | PERIMETER BURG (EXTERIOR) |
| 110 0xx | FIRE (FIRE) | 132 0xx | INTERIOR BURG (INTERIOR, RESTRICTED INTERIOR, KEYPAD BURG FROM LOCK-IN) |
| 122 0xx | SILENT PANIC (POLICE/HOLD-UP) | 133 0xx | 24-HOUR BURG (GUARD ZONE) |
| 123 0xx | AUDIBLE PANIC (POLICE/HOLD-UP) | 140 0xx | 24-HOUR NON-BURG (ENVIRONMENTAL A) |

| ADEMCO CONTACT ID OPEN/CLOSE REPORTING CODES | | | |
|--|--|----------------|--|
| REPORTING CODE | REPORT DESCRIPTION pp = PAC ID # PREFIX 1 = OPENING PREFIX 3 = CLOSING | REPORTING CODE | REPORT DESCRIPTION pp = PAC ID # PREFIX 1 = OPENING PREFIX 3 = CLOSING |
| 401 0pp | NORMAL OPEN/CLOSE BY USER | 408 000 | QUICK ARM OR WIRELESS TOGGLE ARM |
| 406 0pp | ALARM CANCEL (OPEN DURING ALARM) BY USER | 409 000 | REMOTE ARM FROM REMOTE ACCESS SOFTWARE |
| 407 0pp | FORCED ARM (ARM WITH BYPASS) BY USER | | |

| ADEMCO CONTACT ID SUPERVISORY REPORTING CODES | | | |
|---|---|----------------|---|
| REPORTING CODE | REPORT DESCRIPTION xx = SENSOR/LOOP # PREFIX 1 = NEW EVENT PREFIX 3 = RESTORE | REPORTING CODE | REPORT DESCRIPTION xx = SENSOR/LOOP # PREFIX 1 = NEW EVENT PREFIX 3 = RESTORE |
| 301 000 | PANEL AC FAILURE | 380 085 | EVENT LOG LIMIT REACHED |
| 302 000 | PANEL LOW BATTERY | 380 088 | PANEL MEMORY ERROR |
| 380 0xx | TROUBLE (HARDWARE LOOPS 1-3, KEYPADS 65-72) | 381 0xx | SENSOR SUPERVISORY |
| 380 000 | PANEL FIRE FUSE BLOWN | 383 0xx | KEYPAD OR SENSOR TAMPER |
| 380 073 | PANEL COMMUNICATION FAILURE | 384 0xx | KEYPAD OR SENSOR LOW BATTERY |
| 380 075 | PANEL AUXILIARY FUSE BLOWN | 570 0xx | SENSOR BYPASS |
| 380 077 | PANEL RADIO RECEIVER FAILURE | 601 000 | MANUAL TEST REPORT |
| 380 079 | PANEL TAMPER | 602 000 | AUTOMATIC 24-HOUR TEST REPORT |

**Figure 42. SuperSpeed, SIA & Ademco Contact ID
Format Reporting Codes**

Personal Access Code (PAC) Installation

Personal Access Codes (2 to 5 digits) are used to authorize different levels of system control. There are 32 different codes numbered 1 - 32 with number 1 assigned as a temporary PAC. Various levels of control authorization can be programmed for each PAC. PAC ID's (1 - 32) are reported to the Central Station with Opening/Closing reports, if the format allows. **PAC's can be changed by the installer or by the user without entering system programming level (Level 9). See next page.**

The factory defaults are PAC's 1-31 empty, PAC number 32 set to 98765 with Level 9 programming privilege. Refer to the Table in Figure 44.

NOTE: In each of the following steps pressing the STORE key causes the new Value to be assigned to the selected PAC code and the display returns to the Function field. If the command is accepted, the accept tones will sound.

090.000 Personal Access Code Entry

[Selector range 2-32]

Selector 2-32 = PAC 2-32. To enter a PAC, first select Function 090, press CYCLE and enter which PAC you want to create or change (2-32). Press CYCLE again and then start entering the new PAC, 2 to 5 digits. Then press the STORE key to accept the new value and the display returns to the Function field (see Figure 43 for example). The rejection tones will sound if two few or too many digits are entered. If you make a mistake, repeat the entire sequence. For security, PAC's are never displayed once entered.

091.000 Cancel a PAC

[Selector range 2-32]

Selector 2-32 = PAC 2-32. To cancel a PAC, select which PAC to delete and press STORE. The old PAC will be deleted and the accept tones will sound. When cancelling a PAC, all characteristics of that PAC will be canceled as well.

092.000.000 High Security Level Limit

[Selector range 2-32]

[Value range 0-9, default = 8]

Selector 2-32 = PAC 2-32. Sets the highest security level that a PAC may select. If "Quick Arming" (see Function 121.012) is enabled, it can override this setting. Value must be set to 9 if entry into system level programming (Level 9) is desired.

NOTE: PAC codes with Level 9 access cannot be changed outside of Level 9.

093.000.000 Low Security Level Limit

[Selector range 2-32]

[Value range 0-9, default = 0]

Selector 2-32 = PAC 2-32. Sets the lowest security level that a PAC may select. Only useful if Value is set to 0 or 1. Otherwise, the system could not be disarmed or alarms canceled.

094.000.000 Duress PAC

[Selector range 2-32]

[Value range 0-1, default = 0]

Selector 2-32 = PAC 2-32. The default Value of 0 programs a normal PAC. Setting the Value to 1 for the selected PAC, causes a duress report code to be sent to the Central Station when this PAC is used to arm or disarm the control (report code must be programmed). In all other respects the PAC operates normally.

095.000.000 Master PAC

[Selector range 2-32]

[Value range 0-1, default = 0]

Selector 2-32 = PAC 2-32. The default Value of 0 programs a normal PAC. Setting the Value to 1 for the selected PAC programs a Master PAC. If the control is armed to Level 4 with a Master PAC, then only that PAC or another Master PAC may disarm.

096.000.000 Arm Only PAC

[Selector range 2-32]

[Value range 0-1, default = 0]

Selector 2-32 = PAC 2-32. The default Value of 0 programs a normal PAC. Setting the Value to 1 for the selected PAC programs an Arm Only PAC. The PAC will only arm to Level 4. An Arm Only PAC may not disarm the control, independent of any other PAC settings.

097.000.000 No Bypass PAC

[Selector range 2-32]

[Value range 0-1, default = 0]

Selector 2-32 = PAC 2-32. The default Value of 0 programs a normal PAC. Setting the Value to 1 for the selected PAC programs a No Bypass PAC. A No Bypass PAC cannot arm the system if any sensors are violated. Likewise, this type of PAC may not directly bypass sensors. Only meaningful if "Quick Arm" is disabled (see Function 121.012).

098.000.000 Access Output PAC

[Selector range 2-32]

[Value range 0-1, default = 0]

Selector 2-32 = PAC 2-32. The default Value of 0 programs a normal PAC. Setting the Value to 1 for the selected PAC programs an Access Output PAC. If this feature is programmed, then each time this PAC is entered the Access Output is activated for the programmed time.

099.000.000 Access Output Only PAC

[Selector range 2-32]

[Value range 0-1, default = 0]

Selector 2-32 = PAC 2-32. The default Value of 0 programs a normal PAC. Setting the Value to 1 for the selected PAC programs an Access Output Only PAC. A PAC code programmed with this feature cannot perform any security level changes. The user must enter a security level followed by his PAC code to activate the Access Output. The security level digit is ignored (no level change takes place and no tones will sound).

100.000.000 Locked PAC

[Selector range 2-32]

[Value range 0-1, default = 0]

Selector 2-32 = PAC 2-32. The default Value of 0 programs a normal PAC. Setting the Value to 1 for the selected PAC programs a Locked PAC. This option keeps the user from changing their own PAC. Only a PAC set with programming privilege (Function 101) may change the code. Do not confuse this with Level 9 or system level programming access.

101.000.000 PAC Programming Enable

[Selector range 2-32]

[Value range 0-1, default = 0]

Selector 2-32 = PAC 2-32. The default Value of 0 programs a normal PAC. Setting the Value to 1 for the selected PAC allows this PAC to program other PAC's. Otherwise a PAC may only change it's own code.




Figure 43. Example for Programming PAC Codes

| PERSONAL ACCESS CODE (PAC) INSTALLATION | | | | | |
|---|----------|-------|---------|----------------------------|--|
| FUNCTION | SELECTOR | VALUE | DEFAULT | DESCRIPTION | ACTION/VALUE |
| 90 | 2-32 | | | PERSONAL ACCESS CODE ENTRY | ENTER 2 TO 5 DIGITS, THEN PRESS STORE (PAC #1 IS TEMPORARY PAC) |
| 91 | 2-32 | | | CANCEL A PAC | PRESS STORE TO REMOVE PAC SELECTED |
| 92 | 2-32 | 0-9 | 8 | HIGH SECURITY LEVEL LIMIT | HIGHEST SECURITY LEVEL THIS PAC CAN USE |
| 93 | 2-32 | 0-9 | 0 | LOW SECURITY LEVEL LIMIT | LOWEST SECURITY LEVEL THIS PAC CAN USE |
| 94 | 2-32 | 0-1 | 0 | DURESS PAC | 0 = NORMAL SECURITY LEVEL CONTROL 1 = THIS IS A DURESS PAC |
| 95 | 2-32 | 0-1 | 0 | MASTER PAC CODE | 0 = NORMAL PAC CODE 1 = MASTER PAC CODE |
| 96 | 2-32 | 0-1 | 0 | ARM ONLY PAC | 0 = NORMAL SECURITY LEVEL CONTROL 1 = ARMS TO LEVEL 4 ONLY |
| 97 | 2-32 | 0-1 | 0 | NO BYPASS PAC | 0 = FULL BYPASS AUTHORITY 1 = NO BYPASS AUTHORITY |
| 98 | 2-32 | 0-1 | 0 | ACCESS OUTPUT PAC | 0 = NO ACCESS CONTROL OUTPUT 1 = ACCESS CONTROL OUTPUT ACTIVATES |
| 99 | 2-32 | 0-1 | 0 | ACCESS OUTPUT ONLY | 0 = NORMAL SECURITY LEVEL CONTROL 1 = ACTIVATE ACCESS OUTPUT ONLY |
| 100 | 2-32 | 0-1 | 0 | LOCKED PAC CODE | 0 = USER CAN CHANGE OWN CODE 1 = USER CANNOT CHANGE OWN CODE |
| 101 | 2-32 | 0-1 | 0 | PAC PROGRAMMING ENABLE | 0 = THIS PAC CANNOT SET OTHER PAC'S 1 = PAC PROGRAM MODE ALLOWED |

Figure 44. Personal Access Code (PAC) Programming Table

Changing PACs Outside of Level 9

1. Disarm to Level 0 or 1 and press #
 2. Enter your current PAC.
 3. Press #
 4. Enter new PAC (2 to 5 digits long).
 5. Press #
 6. Listen for the accept tones.
- (Repeat steps or use a different code if not accepted.)

Changing Temporary PAC Outside of Level 9

1. Disarm to Level 0 or 1 with a non-temporary PAC and press #.
 2. Enter a permanent PAC and press #.
 3. Enter a digit from 1 to 9 for the number of times the PAC can be used (disarm then arm is two uses). Entering 0 will allow unlimited use.
 4. Press #.
 5. Enter desired temporary PAC (2 to 5 digits long).
 6. Press #.
 7. Listen for the accept tones.
- (Repeat steps or use a different code if not accepted.)

PRESS # PERMANENT PAC # # # # TO ERASE THE TEMPORARY PAC

Control Panel Configuration

Use the following Functions and Selectors to change Values for control panel configuration. Refer to the table in Figure 45. **The default values already in memory should be correct for most applications.**

NOTE: For each of the following functions, unless otherwise stated, pressing the STORE key causes the new Value to be stored into the CP-90's memory and the display will return to the Function field. If the command is accepted, the accept tones will sound.

120.001.000 **Entry Delay Time #1** [Value range 1-250, default = 30]

Sets the entry delay time #1. Delayed sensors can be programmed for entry delay #1 or #2 (Function 005). When the user enters the premises, violating sensors programmed for exit/entry delay, the entry timer is started. The keypad pre-alarm beeps may optionally be started at this time (Function 121.007). If the user has not disarmed the system before the entry time expires, an alarm will be triggered. Enter a Value in seconds if the default Value of 30 is unacceptable.

120.002.000 **Entry Delay Time #2** [Value range 1-250, default = 45]

Sets the entry delay time #2. Delayed sensors can be programmed for entry delay #1 or #2 (Function 005). When the user enters the premises, violating sensors programmed for exit/entry delay, the entry timer is started. The keypad pre-alarm beeps may optionally be started at this time (Function 121.007). If the user has not disarmed the system before the entry time expires, an alarm will be triggered. Enter a Value in seconds if the default Value of 45 is unacceptable.

120.003.000 **Exit Delay Time** [Value range 1-250, default = 45]

Sets the exit delay time. An exit delay is necessary in installations where the system control station is located inside the premises. When the user arms the CP-90, the exit delay timer is started in order to allow the user time to leave the premises and secure the entry/exit door. Enter a Value in seconds if the default Value of 45 is unacceptable.

NOTE: Be realistic! Allow enough time for the user to get out of the premises and secure the door.

If the entry/exit door is not secure when the exit time expires, an entry delay sequence will be started. If the CP-90 is not disarmed before the entry time expires, an alarm will be triggered.

120.004.000 **Burglary Output Delay** [Value range 0-250, default = 0]

Sets the delay for the Burglary Output on the control output connector. The delay gives the user time to disarm the system before the main audible alarm sounder starts. **This Value does not delay the keypad siren, only the Burglary Output.** The default Value of 0 gives the output no delay. Enter a different Value in seconds if a delay is required.

NOTE: In the following three Functions, entering 0 for the cutoff time will result in untimed alarms that will remain on until the system is disarmed. Untimed, unlimited alarms are not allowed by law in many locations. Check local ordinances for details.

120.005.000 **Burglary Output Cutoff Time** [Value range 0-250, default = 5]

Sets the cutoff time for the Burglary Output. The system will sound the alarm for the length of time specified by this Value. The default Value of 5 gives the output a 5 minute cutoff. Enter a different Value in minutes if a different time is required.

120.006.000 **Fire Output Cutoff Time** [Value range 0-250, default = 5]

Sets the cutoff time for the Fire Output. The system will sound the alarm for the length of time specified by this Value. The default Value of 5 gives the output a 5 minute cutoff. Enter a different Value in minutes if a different time is required.

120.007.000 **Police Alarm Cutoff Time** [Value range 0-250, default = 5]

Sets the cutoff time for the Police alarm. The system will sound the alarm for the length of time specified by this Value. The default Value of 5 gives the alarm a 5 minute cutoff. Enter a different Value in minutes if a different time is required.

120.008.000 **Emergency Output Cutoff Time** [Value range 0-250, default = 5]

Sets the cutoff time for the Emergency Output. The system will sound the alarm for the length of time specified by this Value. The default Value of 5 gives the output a 5 minute cutoff. Enter a different Value in minutes if a different time is required.

120.009.000 **Access Output On-Time** [Value range 0-250, default = 5]

Sets the Access Output on-time. Sensors programmed to the Access Only Zone will trigger the Access Output on the control output connector. This output is usually used to activate an electronic door strike. The default Value of 5 gives the output a 5 second on-time. Enter a different Value in seconds if a different time is required. Entering a Value of 0 causes the output to alternate from off to on and vice versa each activation.

120.010.000 **Automation #1 Output On-Time** [Value range 0-250, default = 5]

Sets the Automation #1 Output on-time. Sensors programmed to the Automation #1 Zone will trigger the Automation #1 Output on the control output connector. This output is usually used to activate an external device. The default Value of 5 gives the output a 5 second on-time. Enter a different Value in seconds if a different time is required. Entering a Value of 0 causes the output to alternate from off to on and vice versa each activation.

120.011.000 **Automation #2 Output On-Time** [Value range 0-250, default = 5]

Sets the Automation #2 Output on-time. Sensors programmed to the Automation #2 Zone will trigger the Automation #2 Output on the control output connector. This output is usually used to activate an external device. The default Value of 5 gives the output a 5 second on-time. Enter a different Value in seconds if a different time is required. Entering a Value of 0 causes the output to alternate from off to on and vice versa each activation.

121.001.000 **Pulsing Burglary Output** [Value range 0-1, default = 0]

Controls the Burglary Output on the control output connector. The default Value of 0 causes a steady output on alarm. Enter a Value of 1 for a pulsed output (one second on, one second off) on alarm.

CONTROL PANEL CONFIGURATION

| FUNCTION | SELECTOR | VALUE | DEFAULT | DESCRIPTION | ACTION/VALUE |
|----------|----------|-------|---------|---|---|
| 120 | 1 | 1-250 | 30 | ENTRY DELAY TIME #1 | ENTER VALUE IN SECONDS FOR DELAY |
| 120 | 2 | 1-250 | 45 | ENTRY DELAY TIME #2 | |
| 120 | 3 | 1-250 | 45 | EXIT DELAY TIME | |
| 120 | 4 | 0-250 | 0 | BURGLARY OUTPUT DELAY | |
| 120 | 5 | 0-250 | 5 | BURGLARY OUTPUT CUTOFF | ENTER VALUE IN MINUTES ENTER "0" FOR CONTINUOUS |
| 120 | 6 | 0-250 | 5 | FIRE OUTPUT CUTOFF | |
| 120 | 7 | 0-250 | 5 | POLICE ALARM CUTOFF | |
| 120 | 8 | 0-250 | 5 | EMERGENCY OUTPUT CUTOFF | |
| 120 | 9 | 0-250 | 5 | ACCESS OUTPUT ON-TIME | ENTER ACCESS OUTPUT TIME IN SECONDS 0 = TOGGLES ON/OFF EACH ACTIVATION |
| 120 | 10 | 0-250 | 5 | AUTOMATION #1 ON-TIME | |
| 120 | 11 | 0-250 | 5 | AUTOMATION #2 ON-TIME | |
| 121 | 1 | 0-1 | 0 | PULSING BURGLARY OUTPUT | 0 = STEADY 1 = ONE SECOND ON & ONE SECOND OFF |
| 121 | 2 | 0-1 | 1 | PULSING FIRE OUTPUT | |
| 121 | 3 | 0-1 | 0 | MULTIPLE BURGLARY OUTPUT SHUTDOWN | 0 = MULTIPLE OUTPUTS PER ARM/DISARM; 1 = ONLY ONE AUDIBLE OUTPUT PER ARM |
| 121 | 4 | 0-1 | 0 | DAY ALERT LATCH | 0 = TROUBLE LIGHT CLEARS WHEN NO TROUBLE; 1 = TROUBLE LIGHT LATCHES |
| 121 | 5 | 0-1 | 0 | BELL TEST ON ARMING | 0 = NO BELL TEST; 1 = BELL TEST IN LEVEL 4 AT CENTRAL STATION KISSOFF |
| 121 | 6 | 0-1 | 0 | KEYPAD BURGLARY FOR LOCK-INS | 0 = NORMAL; 1 = ANY KEY STARTS ENTRY DELAY #1 WHILE IN LEVEL 4 |
| 121 | 7 | 0-1 | 1 | ENTRY DELAY BEEPS | 0 = BEEPS OFF 1 = BEEPS ON |
| 121 | 8 | 0-1 | 1 | EXIT DELAY BEEPS | |
| 121 | 9 | 0-1 | 0 | SILENT POLICE ALARMS | 0 = ALARM WILL SOUND 1 = SILENT ALARM |
| 121 | 10 | 0-1 | 0 | SILENT EMERGENCY ALARMS | |
| 121 | 11 | 0-1 | 0 | SILENT BURGLARY ALARMS | |
| 121 | 12 | 0-1 | 0 | DISABLE QUICK ARMING | 0 = QUICK ARMING ALLOWED; 1 = QUICK ARMING NOT ALLOWED |
| 121 | 13 | 0-1 | 0 | AUTOMATIC RESTORAL | 0 = BYPASSES CLEAR ON RESTORAL; 1 = BYPASSES REMAIN ON RESTORAL |
| 121 | 14 | 0-1 | 0 | AUTO BYPASS ARMING | 0 = AUTO BYPASS THEN ARM; 1 = NO ARM UNTIL MANUAL BYPASS |
| 121 | 15 | 0-1 | 0 | RECEIVER DESENSE | 0 = NORMAL RECEIVER SENSITIVITY; 1 = REDUCED RECEIVER SENSITIVITY (-5 dB) |
| 121 | 16 | 0-1 | 0 | ALARM LATCH FOR NON-REPORTING SENSORS | 0 = NO ALARM MEMORY OR ALARM LED; 1 = ALARM MEMORY & LED LATCHES |
| 121 | 17 | 0-1 | 0 | AUTOMATIC ALARM MEMORY DISPLAY | 0 = MANUAL ALARM MEMORY DISPLAY ONLY WITH STATUS "96" 1 = AUTO ALARM MEMORY DISPLAY FOR 45 SECONDS AFTER ALARM |
| 121 | 18 | 0-1 | 0 | 24-HOUR SYSTEM STATUS DISPLAY | 0 = STATUS INDICATORS ONLY WHEN MANUALLY CHECKING STATUS 1 = SENSOR STATUS SHOWN ON INDICATORS AT ALL TIMES |
| 121 | 19 | 0-1 | 0 | KD-90 COMMUNICATOR STATUS DISPLAY | 0 = NO COMMUNICATOR STATUS DISPLAY 1 = COMM. STATUS DISPLAYED ON KD-90 |
| 121 | 20 | 0-1 | 0 | MASTER RESET DISABLE | 0 = MASTER RESET SWITCH ENABLED; 1 = MASTER RESET SWITCH DISABLED |
| 121 | 21 | 0-1 | 0 | EVENT LOG LIMITER | 0 = NO LIMITS ON ADDING TO THE EVENT LOG 1 = ONLY 200 EVENTS WILL BE LOGGED AFTER INITIAL ALARM UNTIL LOG IS CLEARED |
| 121 | 22 | 0-1 | 0 | AUDIBLE SENSOR TROUBLE | 0 = SENSOR TROUBLE ONLY LIGHTS LEDS ON KEYPADS 1 = SENSOR TROUBLE LIGHTS LEDS ON KEYPADS AND CHIMES EVERY MINUTE |
| 121 | 23 | 0-1 | 0 | QUICK BYPASS DISABLE | 0 = QUICK BYPASSING ALLOWED 1 = QUICK BYPASSING NOT ALLOWED (MANUAL SENSOR BYPASSING REQUIRED) |
| 122 | 1 | 0-1 | 1 | SENSOR VIOLATION & TEST LOGGING INCLUDING UNARMED SENSORS | 0 = LOG ONLY ARMED SENSORS ALARMS 1 = LOG ALL SENSOR VIOLATIONS & SENSOR TESTS |
| 122 | 2 | 0-1 | 1 | SENSOR RESTORAL LOGGING | 0 = NO LOGGING; 1 = LOG EVENTS |
| 122 | 3 | 0-1 | 1 | NORMAL OPENING & CLOSING LOGGING | 0 = NO LOGGING; 1 = LOG EVENTS |
| 122 | 4 | 0-1 | 1 | FORCED CLOSING LOGGING | 0 = NO LOGGING; 1 = LOG EVENTS |
| 122 | 5 | 0-1 | 1 | OPENING AFTER AN ALARM LOGGING | 0 = NO LOGGING; 1 = LOG EVENTS |
| 122 | 6 | 0-1 | 1 | SENSOR & ACCESSORY SUPERVISORY LOGGING | 0 = NO LOGGING; 1 = LOG EVENTS |
| 122 | 7 | 0-1 | 1 | PANEL RESET, TEST & SUPERVISORY LOGGING | 0 = NO LOGGING; 1 = LOG EVENTS |
| 122 | 8 | 0-1 | 1 | COMMUNICATOR LOGGING | 0 = NO LOGGING; 1 = LOG EVENTS |
| 122 | 9 | 0-1 | 1 | PANEL PROGRAMMING LOGGING | 0 = NO LOGGING; 1 = LOG EVENTS |
| 122 | 10 | 0-1 | 1 | FIRE, BURG AND EMERGENCY OUTPUTS LOGGING | 0 = NO LOGGING; 1 = LOG EVENTS (OUTPUT ON & OFF) |

Figure 45. Control Panel Configuration Table

121.002.000 **Pulsing Fire Output**
[Value range 0-1, default = 1]
Controls the Fire Output on the control output connector. The default Value of 1 causes a pulsed output (one second on, one second off) on alarm. Enter a Value of 0 for a steady output on alarm.

121.003.000 **Multiple Burglary Output Shutdown**
[Value range 0-1, default = 0]
Controls how many times the Burglary Output can activate during one arming period. The default Value of 0 allows unlimited alarm activations after each cutoff time (Function 120.005). Entering 1 for this Value allows only one activation of the Burglary Output for each time the system is armed. This Value only affects the Burglary Output on the control output connector and does not affect other types of alarms or alarm reports to the central station (they can be limited by the swinger count with Function 050.015).

121.004.000 **Day Alert Latch**
[Value range 0-1, default = 0]
Latches the TROUBLE light on keypads. When sensors or accessories report trouble, (supervisory, low battery, tamper, etc.) the TROUBLE light on the wired keypads will blink. The default Value of 0 causes the TROUBLE light to automatically clear (go out) when the cause of the trouble is corrected. Entering 1 for this Value will cause the TROUBLE light to latch on until it is manually reset with the command "STATUS 97" entered in Level 0 on any wired keypad.

121.005.000 **Bell Test on Arming**
[Value range 0-1, default = 0]
Causes the Burglary Output to activate for 1 second when the system is armed in Level 4 (away mode). The bell test occurs after the closing report communication to the central station is completed. If closing reports are disabled or the communicator is turned off, the bell test occurs as soon as Level 4 is entered. The default Value of 0 disables the bell test. Enter a Value of 1 if bell test is required.

121.006.000 **Keypad Burglary for Lock-ins**
[Value range 0-1, default = 0]
Causes entry delay #1 to start when any keypad key is pressed if the system is armed in Level 4 (away mode). This feature is useful in installations where someone might try to compromise the system by staying inside the secured premises. The default Value of 0 disables this feature. Enter a Value of 1 if keypad burglary for lock-ins is required.

121.007.000 **Entry Delay Beeps**
[Value range 0-1, default = 1]
Turns entry delay beeps on and off. The default Value of 1 causes the keypad(s) to sound beeps during the entry delay. This alerts the user that the system must be disarmed or an alarm will occur. Entering 0 for this Value will cause the entry delay to be silent. **Silent burglary sensors and alarms will not sound the entry delay beeps.**

121.008.000 **Exit Delay Beeps**
[Value range 0-1, default = 1]
Turns exit delay beeps on and off. The default Value of 1 causes the keypad(s) to sound beeps during the exit delay. This alerts the user that the premises must be vacated and secured before the delay time expires. Entering 0 for this Value causes the exit delay to be silent.

121.009.000 **Silent Police Alarms**
[Value range 0-1, default = 0]
Disables sounders for police alarms. The default Value of 0 allows for audible police alarms. Entering 1 for this Value will cause all sensors and keypad buttons that trigger the police/hold-up zone to produce silent alarms. The communicator must be turned on (Function 050.001) to use this feature.

121.010.000 **Silent Emergency Alarms**
[Value range 0-1, default = 0]
Disables sounders for emergency alarms. The default Value of 0 allows for audible emergency alarms. Entering 1 for this Value will cause all sensors and keypad buttons that trigger the emergency zone to produce silent alarms. The communicator must be turned on (Function 050.001) to use this feature.

121.011.000 **Silent Burglary Alarms**
[Value range 0-1, default = 0]
Disables sounders for burglary alarms. The default Value of 0 allows for audible burglary alarms. Entering 1 for this Value will cause all sensors that trigger the burglary zone to produce silent alarms. **Entry delay beeps will not sound.** The communicator must be turned on (Function 050.001) to use this feature.

121.012.000 **Disable Quick Arming**
[Value range 0-1, default = 0]
Disables the "Quick Arming" keypad feature. The default Value of 0 allows the user to arm the system to Levels 1-6 simply by holding down the associated keypad number button (1-6) for about 1 second. "Quick Arming" can only change the system into a higher security level than it's currently in. Enter a value of 1 to disable "Quick Arming".

121.013.000 **Automatic Bypass Restoral**
[Value range 0-1, default = 0]
Allows bypassed sensors to automatically remove their bypass when they restore. Violated sensors can be bypassed when the system is armed either automatically (when arming from a remote) or manually from the keypad. With the default Value of 0, when the sensor restores, the bypass will be removed. The formerly bypassed sensor will then be ready to cause a violation. Entering 1 for this Value causes the sensor(s) to remain bypassed until the system is disarmed.

121.014.000 **Automatic Bypass Arming**
[Value range 0-1, default = 0]
Allows for automatically bypassing violated sensors when arming. With the default Value of 0, if the system is armed with violated sensors, 45 seconds after the rejection tones sound the system will automatically bypass all violated sensors and arm to the security level selected. Entering 1 for this Value requires that sensors be manually bypassed before the system can be armed.

121.015.000 **Receiver Desense**
[Value range 0-1, default = 0]
Reduces the CP-90's RF receiver sensitivity for testing and high noise environments. The default Value of 0 allows for full receiver sensitivity. Entering 1 for this Value will reduce the receiver's sensitivity by 6 db (approximately 50%).

121.016.000 Alarm Latch for Non-reporting Sensors
[Value range 0-1, default = 0]

Allows latching of the ALARM light and alarm memory on the keypad for sensors that cause a violation but no report when the system is disarmed. The default Value of 0 only allows the ALARM light to latch and the alarm memory to display sensors that cause a violation and a report while the system is armed. Entering a Value of 1 causes non-reporting sensors (Guard Zone, Environmental B & C Zones) that cause a local alarm but no report to latch the ALARM light and show in the alarm memory.

☞ **NOTE:** The Guard Zone does report in Level 4 as an Interior Burg/Intrusion.

121.017.000 Automatic Alarm Memory Display
[Value range 0-1, default = 0]

Causes the keypads to automatically display the alarm memory sequence after an alarm. The keypad's display will show the alarm memory sequence for 45 seconds. The default Value of 0 disables this feature and pressing STATUS "96" is required to display the alarm memory. Enter a Value of 1 to enable the automatic alarm memory feature.

121.018.000 24-Hour System Status Display
[Value range 0-1, default = 0]

Causes the corresponding keypad status indicators to flash on idle keypads when one or more sensors or accessories are faulted. The default Value of 0 disables this feature. Enter a Value of 1 to enable the 24-hour system status display. This feature is disabled during duress alarms.

☞ **NOTE:** This Value must be set to 1 for UL installations.

121.019.000 KD-90 Communicator Status Display
[Value range 0-1, default = 0]

Causes KD-90 keypads to display the status of the communicator. Messages such as "COMMUNICATOR ON LINE", "COMMUNICATOR DIALING", "REMOTE PANEL ACCESS" are displayed on the bottom line of the KD-90 display. This feature lets the user know that the CP-90 is accessing the phone line. The default Value of 0 disables this feature. Enter a Value of 1 to enable the communicator status display. This feature is disabled during duress alarms.

121.020.000 Master Reset Disable
[Value range 0-1, default = 0]

Disables the master reset function preventing unauthorized erasing of the program memory. The default Value of 0 allows the MASTER RESET switch to operate as normal. Enter a Value of 1 to disable the master reset function invoked by the MASTER RESET switch.

121.021.000 Event Log Limiter
[Value range 0-1, default = 0]

Limits entries to the internal event log after an alarm. The CP-90 logs many system events. Logged events are time tagged with one minute resolution and are stored in chronological order. The event log buffer can store up to 300 events. After the first 300 events, as more events are stored, the oldest event is erased to make room for the new event.

The default Value of 0 allows unlimited entries to the event log. Entering a Value of 1 will limit the log to only accepting 200 more entries after the initial alarm. This prevents losing alarm history in the case of a runaway sensor. The log limit is reset clearing the log limit counter with the CP-90RA Remote Access Program.

121.022.000 Audible Sensor Trouble
[Value range 0-1, default = 0]

Causes the keypads to sound the trouble sounder every minute when any sensor has a low battery or supervisory trouble. The default Value of 0 disables audible sensor trouble. Entering a Value of 1 enables audible sensor trouble. The system warning beep can be canceled before fixing the sensor trouble by pressing the ★ key on the keypad.

☞ **NOTE:** This Value must be set to 1 for UL installations.

121.023.000 Quick Bypass Disable
[Value range 0-1, default = 0]

Disables the quick bypass feature. The default Value of 0 allows quick bypassing of violated sensors while arming. Entering a Value of 1 will disable quick bypassing, causing the user to manually bypass each violated sensor while arming.

☞ **NOTE:** This Value must be set to 1 for UL installations.

122.001.000 Sensor Violation & Test Logging
[Value range 0-1, default = 0]

Causes all sensor violations and test reports to be stored in the event log. **This includes unarmed sensors.** Violations from armed sensors, 24-hour zones and keypad emergencies are always logged. The default Value of 0 requires that the sensor be armed before violations will be entered into the event log. Entering a Value of 1 will cause all violations and test reports to be logged.

122.002.000 Sensor Restoral Logging
[Value range 0-1, default = 1]

Causes sensor restore reports from armed sensors to be stored in the event log. The default Value of 1 will cause these reports to be logged. Entering a Value of 0 prevents these reports from being logged. If a Value of 1 is entered for 122.001, all sensor restorals are logged.

122.003.000 Normal Opening & Closing Logging
[Value range 0-1, default = 1]

Causes all normal opening and closing events (closes without bypasses and openings without pending alarms) to be stored in the event log. The default Value of 1 will cause these events to be logged. Entering a Value of 0 prevents these events from being logged.

122.004.000 Forced Closing Logging
[Value range 0-1, default = 1]

Causes all forced closing events (closes with bypassed sensors) to be stored in the event log. The default Value of 1 will cause these events to be logged. Entering a Value of 0 prevents these events from being logged.

122.005.000 Opening After an Alarm Logging
[Value range 0-1, default = 1]

Causes all opening events occurring after an alarm and alarm cancels to be stored in the event log. The default Value of 1 will cause these events to be logged. Entering a Value of 0 prevents these events from being logged.

122.006.000 Sensor & Accessory Supervisory Logging
[Value range 0-1, default = 1]

Causes all sensor and accessory supervisory events to be stored in the event log. The default Value of 1 will cause these events to be logged. Entering a Value of 0 prevents these events from being logged.

| SPECIAL INSTALLER FUNCTIONS | | | | | |
|-----------------------------|----------|-------|---------|-------------------------------|--|
| FUNCTION | SELECTOR | VALUE | DEFAULT | DESCRIPTION | ACTION/VALUE |
| 123 | 1 | | | DELETE ALL SENSORS | CYCLE TO VALUE FIELD AND PRESS STORE TO DELETE ALL SENSORS |
| 123 | 2 | | | DELETE ALL ACCESSORIES | CYCLE TO VALUE FIELD AND PRESS STORE TO DELETE ALL ACCESSORIES |
| 123 | 3 | | | DELETE ALL PAC CODES | CYCLE TO VALUE FIELD AND PRESS STORE TO DELETE ALL PAC CODES |
| 123 | 4 | | | RE-ASSIGN SENSOR REPORT CODES | CYCLE TO VALUE FIELD AND PRESS STORE TO RE-ASSIGN SENSOR REPORT CODES TO VALUES IN REPORT CODE TABLE (SEE FUNCTIONS 70 & 75) |

Figure 46. Special Installer Functions Table

122.007.000 Panel Reset, Test & Supervisory Logging
 [Value range 0-1, default = 1]

Causes all control panel reset, test and supervisory events to be stored in the event log. The default Value of 1 will cause these events to be logged. Entering a Value of 0 prevents these events from being logged.

NOTE: Resetting the control panel will erase all data in the event log.

122.008.000 Communicator Logging
 [Value range 0-1, default = 1]

Causes all communicator attempts, successes and failures to be stored in the event log. The default Value of 1 will cause these events to be logged. Entering a Value of 0 prevents these events from being logged.

122.009.000 Panel Programming Logging
 [Value range 0-1, default = 1]

Causes all entries and exits, local and remote, to programming Level 9 to be stored in the event log. The default Value of 1 will cause these events to be logged. Entering a Value of 0 prevents these events from being logged.

122.010.000 Fire, Burglary & Emergency Outputs Logging
 [Value range 0-1, default = 1]

Causes all activations and deactivations of the fire, burglary and emergency control outputs to be stored in the event log. The default Value of 1 will cause these events to be logged. Entering a Value of 0 prevents these events from being logged.

Special Installer Functions

123.001.000 Delete All Sensors

Deletes all sensors from the CP-90 memory. Cycle to the Value field and press STORE to delete all sensors. The accept tones will sound when the sensors are deleted.

123.002.000 Delete All Accessories

Deletes all accessories from the CP-90 memory. Cycle to the Value field and press STORE to delete all accessories. The accept tones will sound when the accessories are deleted. The current keypad being used will be automatically re-installed as accessory #65.

123.003.000 Delete All PAC Codes

Deletes all PAC codes from the CP-90 memory. Cycle to the Value field and press STORE to delete all PAC codes. The accept tones will sound when the PAC codes are deleted. The default for PAC #32 is restored to 98765.

123.004.000 Re-assign Sensor Report Codes

Re-assigns all sensor report codes using current Values in the report code table. If sensors are installed prior to selecting the proper communicator format and/or changing the report code defaults, this will automatically assign new report codes for each sensor based on the sensor zone type and the corresponding value in the report code table.

Cycle to the Value field and press STORE to re-assign all sensor report codes. The accept tones will sound when the function is complete.

SYSTEM TESTING

To assure continued protection, Linear recommends that the CP-90 be tested weekly. The system features two special levels (Level 7 and Level 8) for testing.

Level 7 Telephone Test

If the system is monitored, this level tests the telephone connection between the system and the Central Monitoring Station.

NOTE: With all communicator formats except SuperSpeed and SIA the communicator manual test (Functions 070.018 & 075.018) must be enabled before this test will work.

- ① Switch to Level 7; the level change gong and seven level count beeps will sound.
- ② Wait for test to complete.
- ③ If the test passes, the system will sound the accept tones and switch to Level 0 when test is complete.
- ④ If the test fails, the system will switch to Level 0 in about 4 minutes *without* sounding the accept tones.
- ⑤ Verify that the central station received the call correctly.

Level 8 Sensor Test

This level tests the radio link between each sensor and the control panel. Two different types of tests can be made. The *standard test* is for testing all sensors. The *individual test* is for testing specific sensors.

Standard Complete System Test

- ① Switch to Level 8; the level change gong and eight level count beeps will sound.
- ② The display will show each sensor number in order.
- ③ Activate each sensor.
- ④ As each sensor is activated, the sensor test beep will sound and the sensor number will be *removed* from the display.
- ⑤ Test keypads by quickly pressing each emergency key.
- ⑥ Continue testing until all sensor numbers have been removed from the display.
- ⑦ When all sensors and accessories have been tested, the accept tones will sound.

Individual Sensor Test

- ① Switch to Level 8, the level change gong and eight level count beeps will sound.
- ② Press STATUS.
- ③ Display will show the last sensor activated.
- ④ Activate sensor(s); the sensor test beep will sound when a sensor is activated.
- ⑤ Check display for sensor number.

NOTE: The system will automatically switch from Level 8 back to Level 0 after 4 minutes.

How to Test Door and Window Sensors

- ① Open door or window or press the sensor's test button; listen for sensor test beep.
- ② Close door or window.

How to Test Motion Detectors

- ① Stay out of protected area for **at least 5 minutes**.
- ② Walk through the protected area; listen for sensor test beep.

How to Test Smoke Detectors

- ① Press and hold the smoke detector test button until detector starts beeping.
- ② Hold for an additional 15 seconds; listen for the sensor test beep.

How to Test Keypads (Sensors 65-72)

* **CAUTION: DO NOT HOLD THE KEYPAD EMERGENCY BUTTONS FOR MORE THAN 1 SECOND WHILE TESTING! THE ALARM WILL BE TRIGGERED.**

- ① Quickly press the fire button; listen for sensor test beep.
- ② Quickly press the emergency button; listen for sensor test beep.
- ③ Quickly press the police button; listen for sensor test beep.
- ④ Check display, the keypad's sensor number should be gone.

How to Test Portable Sensors

- ① Press the portable sensor's button; listen for sensor test beep.

How to Test Panic Buttons

- ① Transmitters programmed as zone types 7 or 8 require holding the transmitter's button down for approximately 3 seconds.

A

AC Power Failure 9, 32, 34
 AC Power Restore 32, 34
 Accept Tones 7
 Access Only Zone 5
 Access Output On Time 40
 Accessories 65-72 20
 Accessory Installation 20
 Accessory Supervisory Trouble 9
 Accessory Tamper 9
 Active Display Intensity 20
 Active Downlight Intensity 20
 Active Lighting Level 4
 Alarm Call Routing 26
 Alarm Latch for Non-reporting Sensors 43
 Alarm Light 43
 Alarm Memory 43
 Alarm Tone Loudness 20
 Annunciation Loudness 20
 Anti-Jam Time 24
 Arm/Disarm Toggle 5
 Audible Sensor Trouble 43
 Audible Signals and Sirens 7
 Audio Events Call Routing 26
 Audio Reporting 18
 Auto-install RF Sensors 15
 Automatic Alarm Memory Display 43
 Automatic Bypass Arming 42
 Automatic Bypass Restoral 42
 Automatic Test 34
 Automatic Test Report Delay 24
 Automatic Test Report Interval 24
 Automatic/Manual Test Call Routing 26
 Automation #1 Output On Time 40
 Automation #1 Zone 5
 Automation #2 Output On Time 40
 Automation #2 Zone 5
 Auxiliary Fuse Blown 33
 Auxiliary Fuse Failure 9
 Away Security Level 6

B

Backup Battery Testing 8
 Basic Keypad Operation 7
 Basic System Information 5
 Bell Test on Arming 42
 Burglar Alarm Output Delay 40
 Burglary Output Cutoff Time 40
 Bypass Key 12
 Bypassed Sensor/Loop 30
 Bypassing 18

C

Cancel 32
 Cancel a PAC 38
 Chime Only Zone 5
 Chime Security Level 6
 Chime Tones 7
 Clear/Exit Key 12
 Clearing Trouble Displays 8
 Clock, Setting the KD-90 8
 Closing 32, 34
 Closing Reports by Exception 22
 Communication Failure 33
 Communicator Automatic Test 32
 Communicator Format #1 22
 Communicator Format #2 22
 Communicator Logging 44
 Communicator Manual Test 32
 Communicator On/Off 22
 Communicator Routing & Phone Numbers 26
 Control Panel Battery Restore 32, 34
 Control Panel Configuration 40
 Control Panel Door Tamper 32
 Control Panel Low Battery 32, 34
 Control Station Keys During Programming 12
 Control Station Numbers 14
 Copy Primary Setup to Secondary 28
 Copy Secondary Setup to Supervisory 28
 Count Down Key 12
 Count Up Key 12
 Cycle Key 12

D

Day Alert Latch 42
 Default Report Code Override 33...34
 Delayed Remote Emergency 5
 Delayed Remote Police/Hold-up 5
 Delete All Accessories 44
 Delete All PAC Codes 44
 Delete All Sensors 44
 Dial Attempts Before Routing Change 24
 Dial Attempts Before Sleep Cycle 24
 Dialing Format 22
 Dialing Start Delay 22
 Disable Quick Arming 42
 Disarm/Cancel Security Level 6
 Display Accessories 20
 Displaying Installed Sensors 15
 Duress 32, 38

E

EEPROM Write Failure 9
 Emergency Fire Alarm 7
 Emergency Intrusion Alarm 7
 Emergency Key Audio 20
 Emergency Output Cutoff Time 40
 Emergency Zone 5
 Emergency Zone Report Code 30
 Entering Programming Level 12
 Entry Delay 18
 Entry Delay After Alarm Beeps 7
 Entry Delay Beeps 7, 42
 Entry Delay Time #1 40
 Entry Delay Time #2 40
 Environmental Alarm Sounder 7
 Environmental Type A Report Code 30
 Environmental Type A Zone 5
 Environmental Type B Zone 5
 Environmental Type C Zone 5
 Event Log Limiter 43
 Exit Delay Beep 42
 Exit Delay Beeps 7
 Exit Delay Time 40
 Exiting Programming Levels 12
 Exterior Intrusion 30
 Exterior Zone 5

F

Factory Defaults 3
 Fire Fuse Blown 33
 Fire Fuse Failure 9
 Fire Output Cutoff Time 40
 Fire Sensor/Loop 30
 Fire Zone 5
 Fire, Burglary & Emergency Outputs Logging 44
 First Time Power Up 3
 Force Arm 34
 Force Close 33
 Forced Closing Logging 43
 Function Field 13
 Functions, Selectors & Values 10

G

General Communicator Operation 22
 Guard Zone 5
 Guard/Cancel Security Level 6

H

Hardwire Loop Auto Setup 18
 Hardwire Loop Disable 18
 Hardwire Loop Response Time 18
 Hardwire Loop Supervision 18
 Hardwire Loop Trouble Type 18
 Home Security Level 6

I

Inhibit SuperSpeed ETX Signal 24
 Installed Connected Accessories 20
 Interior Intrusion 30
 Interior Zone 5
 Internal Diagnostic Checks 3
 Invalid Access Timeout 24

K

KD-90 Communicator Status Display 43
 Keypad Burglary for Lock-ins 42
 Keypad Code 38
 Keypad Emergency 30
 Keypad Emergency Keys 20
 Keypad Fire 30
 Keypad Lighting 4
 Keypad Lockout Timer 4
 Keypad Police/Hold Up 30
 Keypad Supervision 4
 Keypad Tamper 32
 Keypad Test 45
 Keypad Trouble 33
 Keystroke Beep Loudness 20

L

LCD Captions for Keypads 20
 LCD Keypad Captions 18
 Level Change Gong 7
 Level Count Beeps 7
 Lights On During Entry Delay 20
 Lights On During Exit Delay 20
 Listen-only Audio After Duress PAC 24
 Local Alarm 18
 Loop Response Time 18
 Low Backup Battery 9

M

Manual Backup Battery Test 8
 Manual Test 34
 Manually Install RF Sensors 16
 Manually Remove RF Sensors 16
 Master Reset Disable 43
 Master Reset Switch 3
 MegaCode Format 14
 Memory Error 33
 Multiple Burglary Output Shutdown 42

N

Night Secure Security Level 6
 Night Security Level 6
 Normal Opening & Closing Logging 43
 Number of Sleep Cycles Allowed 24

O

Open/Close Call Routing 26
 Opening 32, 34
 Opening After an Alarm Logging 43
 Opening Reports by Exception 22

P

PACs
 Access Output 38
 Access Output Only 38
 Arm Only 38
 Cancel 38
 Duress 38
 High Security Level Limit 38
 Locked 38
 Low Security Level Limit 38
 Master 38
 No Bypass 38
 PAC Programming Enable 38
 Panel AC Power Failure 9
 Panel Auxiliary Fuse Failure 9
 Panel Fire Fuse Failure 9
 Panel Low Battery 9
 Panel Power Failure 9
 Panel Programming Logging 44
 Panel Radio Failure 9
 Panel Reset, Test & Supervisory Logging 44
 Panel Tamper Condition 9
 Personal Access Code Entry 38
 Personal Access Code Installation 38
 Personal Emergency Sounder 7
 Phone Test Level 6
 Police Alarm Cutoff Time 40
 Police/Hold Up 30
 Police/Hold-up Emergency Alarm 7
 Police/Hold-up Zone 5
 Power Failure 9
 Power-up Indications 4
 Primary Line Account Number 28
 Primary Line Format 26
 Primary Line Telephone Number 28
 Program Descriptions 15
 Programming 12
 Programming Cycle 12
 Programming Level 12
 Programming Level Timer 4, 12
 Programming Mode 6
 Pulsing Burglary Output 40
 Pulsing Fire Output 42

Q

Quick Bypass Disable 43

R

Radio Failure 9
 Re-assign Sensor Report Codes 44
 Receiver Desense 42
 Rejection Tones 7
 Remote Program Access Code 24
 Remote Programming Lockout 24
 Remove Installed Accessories 20
 Reporting Codes 30
 AC Failure 32, 34
 AC Restore 32, 34
 Automatic Test 34
 Auxiliary Fuse Blown 33
 Bypassed Sensor/Loop 30
 Cancel 32
 Closing 32, 34
 Communication Failure 33
 Communicator Automatic Test 32
 Communicator Manual Test 32
 Control Panel Battery Restore 32, 34
 Control Panel Door Tamper 32
 Control Panel Low Battery 32, 34
 Default Report Code Override 33
 Duress 32
 Emergency 30
 Environmental 30
 Exterior Intrusion 30
 Fire Fuse Blown 33
 Fire Sensor/Loop 30
 Force Arm 34
 Force Close 33
 Interior Intrusion 30
 Keypad Emergency 30
 Keypad Fire 30
 Keypad Police/Hold Up 30
 Keypad Tamper 32
 Keypad Trouble 33
 Manual Test 34
 Memory Error 33
 Opening 32, 34
 Police/Hold Up 30
 Restore 30

Sensor Low Battery 33...34
 Sensor Supervisory Trouble 33
 Sensor Tamper 30
 Sensor/Loop Restore 34
 Sensor/Loop Supervisory 34
 Sensor/Loop Tamper 34
 Supervisory Trouble 32, 34
 Reporting Codes for Extended Formats 36
 Reset to Default Key 12
 Restore 30
 Restore Call Routing 26
 Restoring Factory Defaults 3
 Restricted Interior Zone 5
 RF Sensor Supervision 18
 RF Sensor Type 18

S

S1 Format 14
 Secondary Line Account Number 28
 Secondary Line Format 26
 Secondary Line Telephone Number 28
 Security Levels 6
 Selector Field 13
 Sensor & Accessory Supervisory Logging 43
 Sensor Audio Reporting 18
 Sensor Bypassing 18
 Sensor Entry Delay 18
 Sensor Installation 15
 Sensor Local Alarm 18
 Sensor Low Battery 9, 33...34
 Sensor Numbers 14
 Sensor Restoral Logging 43
 Sensor Setup 14
 Sensor Supervisory 9
 Sensor Supervisory Trouble 33
 Sensor Tamper 9, 30
 Sensor Test 45
 Sensor Test Beep 7
 Sensor Test Level 6
 Sensor Violation & Test Logging 43
 Sensor Zone Type 16
 Sensor/Loop Restore 34
 Sensor/Loop Supervisory 34
 Sensor/Loop Tamper 34
 Sensors 1-64 15
 Setting KD-90 Clock 8
 Silent Burglar Alarms 42
 Silent Burglary Alarms 42
 Silent Emergency Alarms 42
 Silent Police Alarms 42
 Sleep Cycle Time 24
 Special Keypad Commands 8
 Special Trouble Displays 9
 Standby Display Intensity 20
 Standby Downlight Intensity 20
 Standby Lighting Level 4
 Status Key 12
 Status Key Commands 8
 Store Key 12
 SuperSpeed, SIA & Ademco Reporting Codes 36
 Supervisory Line Account Number 29
 Supervisory Line Format 26
 Supervisory Line Telephone Number 29
 Supervisory Restore 33
 Supervisory Trouble 32, 34
 Supervisory/Trouble Call Routing 26
 Swinger Eliminator Count 24
 SX Format 14
 System Power Up 3
 System Testing 45
 System Zones 5

T

Tamper Condition 9
 Tamper Reports 22
 Telephone Test 45
 Test Levels 6
 Transmitter Setup 14
 Trouble Display Codes 9
 Trouble Light 3
 24-Hour System Status Display 43
 TX Button Disable Zone 5
 TX Type Transmitter Zone Select 19

U

Uninstalled Accessory 9

V

Value Field 13

W

Watchdog Monitor 3, 9

Z

Zones 5

REGULATORY INFORMATION

FCC NOTICE

This equipment generates and uses radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, may cause interference to radio and television reception. It has been type tested and found to comply with the limits for a Class B computing device in accordance with Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Relocate the CP-90 away from the TV/radio receiver.
- Plug the CP-90 into a different wall outlet so that the console is on a different branch circuit.
- Re-orient the TV/radio antenna.

If necessary, the user should consult the dealer or an experienced radio/television technician for additional suggestions.

DOC NOTICE

The Industry Canada (IC) label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operational and safety requirements. The IC does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. In some cases, the company's inside wiring associated with a single line individual service may be extended by means of a certified connector assembly (telephone extension cord). The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alternations made by the user to this equipment, or equipment malfunctions may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

CAUTION:

Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

The **Load Number** (LN) assigned to each terminal device denotes the percentage of the total load to be connected to a telephone loop which is used by the device to prevent overloading. The termination on a loop may consist of any combination of devices subject only to the requirement that the total of the Load Number of all the devices does not exceed 100.

- The load number for the CP-90 SSC00017 is equal to 7.

For warranty service, repairs or information contact:
1-800-421-1587

LINEAR LIMITED WARRANTY

This Linear product is warranted against defects in material and workmanship for twelve (12) months. The Warranty Expiration Date is labeled on the product. **This warranty extends only to wholesale customers** who buy direct from Linear or through Linear's normal distribution channels. **Linear does not warrant this product to consumers.** Consumers should inquire from their selling dealer as to the nature of the dealer's warranty, if any. **There are no obligations or liabilities on the part of Linear Corporation for consequential damages arising out of or in connection with use or performance of this product or other indirect damages with respect to loss of property, revenue, or profit, or cost of removal, installation, or reinstallation.** All implied warranties, including implied warranties for merchantability and implied warranties for fitness, are valid only until Warranty Expiration Date as labeled on the product. **This Linear Corporation Warranty is in lieu of all other warranties express or implied.**

All products returned for warranty service require a return Product Authorization Number (RPA#). Contact Linear Technical Services at 1-800-421-1587 for an RPA# and other important details.

IMPORTANT !!!

Linear radio controls provide a reliable communications link and fill an important need in portable wireless signalling. However, there are some limitations which must be observed.

- * For U.S. installations only: The radios are required to comply with FCC Rules and Regulations as Part 15 devices. As such, they have limited transmitter power and therefore limited range.
- * A receiver cannot respond to more than one transmitted signal at a time and may be blocked by radio signals that occur on or near their operating frequencies, regardless of code settings.
- * Changes or modifications to the device may void FCC compliance.
- * Infrequently used radio links should be tested regularly to protect against undetected interference or fault.
- * A general knowledge of radio and its vagaries should be gained prior to acting as a wholesale distributor or dealer, and these facts should be communicated to the ultimate users.

Linear[®]