

DVS1200 Has 12 Wireless Zones (01 to 12)
DVS2400 Has 24 Wireless Zones (01 to 24)
DVS2408 Has 24 8 Hardwired up to 24 Total Zones
(Hardwired Zones can be learned as ANY Zone Number)
Zone 1 to 8 = Location 301 to 308

To Assign Hardwire Zone 1 to System as Zone 1
Enter 301 + Home + 01 + AWAY

Programming Procedures

Enter Location then press = 

Enter Data then press = 

Deletes a Location = 

Hold 3 Seconds to
Exit Programming = 

When system is first powered up a Master User Code must be programmed
Press * + New 4 to 5 Digit Code + OFF Button

Enter Programming -

1. Press MASTER CODE + TEST (Keypad will sound 1 Gong + 5 Beeps)
2. Press MASTER CODE + TEST again (Keypad will sound 1 Gong + 5 Beeps)

Learning Sensors -

Sensor Status lights will turn on for any sensors programmed into Console

1. Enter Sensor Number to program (01 to 24) (that sensor light will flash)
2. Activate Sensor
3. Keypad will sound single "BING" sound and sensor indicator will stay lit

Deleting Sensors -

1. Enter Sensor Number to delete (01 to 24) (that sensor light will flash)
2. Press TEST, Keypad sounds "BING" sound, sensor indicator will turn off

Programming Sensor Types -

1. Enter Sensor Number to program (01 to 24) + HOME + <Zone Type> + AWAY
(Keypad will sound single "BING" (See list on previous page for zone types)

Programming Locations -

<Location> + HOME + <DATA> + AWAY

Deleting a Location - (Like Phone Number)

<Location> + HOME + AWAY

Exit Programming - Press OFF for 3 seconds

Linear DVS1200/2400/2408 Program Sheet M Leuck

User and Access Codes				
STEP	Programming Functions & Details	Range	Default	Program
99	Master User Code	1 to 5 Digits	Empty	????
93	Secondary User Code #1	1 to 5 Digits	Empty	
94	Secondary User Code #2	1 to 5 Digits	Empty	
95	Secondary User Code #3	1 to 5 Digits	Empty	
96	Secondary User Code #4	1 to 5 Digits	Empty	
97	Secondary User Code #5	1 to 5 Digits	Empty	
98	Secondary User Code #6	1 to 5 Digits	Empty	
92	Duress Code	1 to 5 Digits	Empty	
87	Remote Access Password	6 Digits	987654	987654
Control Panel Programming Options				
STEP	Programming Functions & Details	Range	Default	Program
25	Entry Delay	1 - 255 Sec.	45	60
26	Exit Delay	1 - 255 Sec.	30	30
30	Burglary Siren Time	1 - 30 Min.	5	5
31	Emergency Siren Time	1 - 30 Min.	5	5
32	Fire Siren Time	1 - 30 Min.	5	5
40	Automation Output Time	0 to 2500 Sec.	0 (Off)	
50	Remote Arming Mode	0=Home Mode, 3=Away Mode	3	3
51	Remote Disarming Mode	0=Off Mode, 1=Chime Mode	0	0
61	Entry Delay Beeps	0=Off, 1=On	1	1
62	Exit Delay Beeps	0=Off, 1=On	1	1
63	Silent Burglary Alarm	0=Audible, 1=Silent	0	0
64	Silent Emergency Alarm	0=Audible, 1=Silent	0	1
65	Quick Arming	0=Off, 1=On	1	1
66	Auto Restore	0=Off, 1=On	0	0
67	Auto Bypass	0=Off, 1=On	0	0
68	Automation Mode During Alarm	0 = Flash, Enable by Function 72 1 = Steady, Enable by Function 72	0	
69	Automation Bing Tone	0 = No Bings 1 = Bings	1	
70	Remote Arm/Disarm Chirp	0 = No Chirps 1 = Chirps, (1=Arm, 2=Disarm)	1	1
71	Automation Flashes After Alarm	0 = Standard 1 = Flashing After Alarm	0	
72	Automation Active During Alarm	0 = Standard 1 = Automation Active During Alarm (Flash or Steady by Function 68)	0	
73	Automation On While Armed	0 = No, 1 = Yes	0	
74	Automation On during E/E Delays	0 = No, 1= Yes	0	
75	Automation Output Polarity	0 = + When Off, 1 = + When On	1	
Hardwire Loops (DVS2408 Only)				
STEP	Programming Functions & Details	Range	Default	Program
301	Hardwire Loop #1 Sensor Number	1 to 24	NONE	
302	Hardwire Loop #2 Sensor Number	1 to 24	NONE	
303	Hardwire Loop #3 Sensor Number	1 to 24	NONE	
304	Hardwire Loop #4 Sensor Number	1 to 24	NONE	
305	Hardwire Loop #5 Sensor Number	1 to 24	NONE	
306	Hardwire Loop #6 Sensor Number	1 to 24	NONE	
307	Hardwire Loop #7 Sensor Number	1 to 24	NONE	
308	Hardwire Loop #8 Sensor Number	1 to 24	NONE	

Linear DVS1200/2400/2408 Program Sheet Page 2

General Communicator Options				
STEP	Programming Functions & Details	Range	Default	Program
76	2-Way Audio (Only if VB-2 Voice Module installed)	0 = None, 1 = Listen 2 = 2-Way Manual 3 = 2-Way Full Duplex	0	2
78	Voice Response From Speaker (And Remote Speaker if Used)	0 = Voice Response Disabled 1 = Voice Response Enabled	0	1
100	Remote Programming Lockout	0 = Unlock, 1 = Lock	0	0
101	Swinger Eliminator	0 = Off 1 = Five Alarms per Arming Period	0	1
103	Dialing Delay	0 = No Delay, 1 = 15 Second Delay	0	0
104	Dialing Method	0 = Tone, 1 = Pulse	0	0
107	Communicator Enable	0 = Communicator Off, 1 = On	0	1

Communicator Reporting Options				
STEP	Programming Functions & Details	Range	Default	Program
86	Call Routing	0 = All Calls to Primary or Sec. 1 = All Alarms to Primary or Sec. And All others to Supervisory Num.	0	
88	Account Number	4-Digits	Empty	????
89	Primary Phone Number	Up to 20 Digits (A key = 1 sec Delay)	Empty	????????
90	Secondary Phone Number	Up to 20 Digits (A key = 1 sec Delay)	Empty	Not Used
91	Supervisory Phone Number	Up to 20 Digits (A key = 1 sec Delay)	Empty	Not Used
105	Reporting Format	0 = 4/2, 1 = Ademco Contact ID	0	1
106	Report Console Trouble	0 = No, 1 = Yes	0	1
110	Report Force Arming	0 = No, 1 = Yes	0	0
113	Point ID Reporting by 4/2 Format	0 = No, 1 = Yes	1	1

Console And General Reporting Codes				
STEP	Programming Functions & Details	Possible Values	Default	Program
201	General Fire Report Code	0 to 99	1	1
202	General Emergency Report Code	0 to 99	2	2
203	General Silent Panic Report Code	0 to 99	3	3
204	General Burglary Report Code	0 to 99	4	4
206	General Trouble Report code	0 to 99	6	6
261	Console Fire Report Code	0 to 99	68	68
262	Console Emergency Report Code	0 to 99	69	69
263	Console Test/Cancel Report Code	0 to 99	70	70
264	Console Low Bat Restore Report Code	0 to 99	71	0
266	Console Low Battery Report Code	0 to 99	73	73
258	Force Arming Report Code	0 to 99	65	0
259	Duress Report Code	0 to 99	66	

Point ID Reporting Codes				
STEP	Programming Functions	Possible Values	Factory	Program
210	Sensor 1 Alarm Report code	0 to 99	11	11
211	Sensor 2 Alarm Report code	0 to 99	12	12
212	Sensor 3 Alarm Report code	0 to 99	13	13
213	Sensor 4 Alarm Report code	0 to 99	14	14
214	Sensor 5 Alarm Report code	0 to 99	15	15
215	Sensor 6 Alarm Report code	0 to 99	16	16
216	Sensor 7 Alarm Report code	0 to 99	17	17
217	Sensor 8 Alarm Report code	0 to 99	18	18
218	Sensor 9 Alarm Report code	0 to 99	19	19
219	Sensor 10 Alarm Report code	0 to 99	20	20
220	Sensor 11 Alarm Report code	0 to 99	21	21
221	Sensor 12 Alarm Report code	0 to 99	22	22
222	Sensor 13 Alarm Report code	0 to 99	23	23
223	Sensor 14 Alarm Report code	0 to 99	24	24
224	Sensor 15 Alarm Report code	0 to 99	25	25
225	Sensor 16 Alarm Report code	0 to 99	26	26
226	Sensor 17 Alarm Report code	0 to 99	27	27
227	Sensor 18 Alarm Report code	0 to 99	28	28
228	Sensor 19 Alarm Report code	0 to 99	29	29
229	Sensor 20 Alarm Report code	0 to 99	30	30

Linear DVS1200/2400/2408 Program Sheet Page 3

Point ID Reporting Codes (Cont.)				
STEP	Programming Functions	Possible Values	Factory	Program
230	Sensor 21 Alarm Report code	0 to 99	31	31
231	Sensor 22 Alarm Report code	0 to 99	32	32
232	Sensor 23 Alarm Report code	0 to 99	33	33
233	Sensor 24 Alarm Report code	0 to 99	34	34
234	Sensor 1 Trouble Report code	0 to 99	41	0
235	Sensor 2 Trouble Report code	0 to 99	42	0
236	Sensor 3 Trouble Report code	0 to 99	43	0
237	Sensor 4 Trouble Report code	0 to 99	44	0
238	Sensor 5 Trouble Report code	0 to 99	45	0
239	Sensor 6 Trouble Report code	0 to 99	46	0
240	Sensor 7 Trouble Report code	0 to 99	47	0
241	Sensor 8 Trouble Report code	0 to 99	48	0
242	Sensor 9 Trouble Report code	0 to 99	49	0
243	Sensor 10 Trouble Report code	0 to 99	50	0
244	Sensor 11 Trouble Report code	0 to 99	51	0
245	Sensor 12 Trouble Report code	0 to 99	52	0
246	Sensor 13 Trouble Report code	0 to 99	53	0
247	Sensor 14 Trouble Report code	0 to 99	54	0
248	Sensor 15 Trouble Report code	0 to 99	55	0
249	Sensor 16 Trouble Report code	0 to 99	56	0
250	Sensor 17 Trouble Report code	0 to 99	57	0
251	Sensor 18 Trouble Report code	0 to 99	58	0
252	Sensor 19 Trouble Report code	0 to 99	59	0
253	Sensor 20 Trouble Report code	0 to 99	60	0
254	Sensor 21 Trouble Report code	0 to 99	61	0
255	Sensor 22 Trouble Report code	0 to 99	62	0
256	Sensor 23 Trouble Report code	0 to 99	63	0
257	Sensor 24 Trouble Report code	0 to 99	64	0

Misc. Options

Sensor Zone Type	Type #
Automation	1
Emergency	2
Panic	3
Fire	4
Perimeter	5
Exit/Entry	6
Interior	7
Chime	8
Environmental	11

2-Button Arm/Disarm (Left)	9
2-Button Automation (Right)	
2-Button Arm (Left)	10
2-Button Disarm (Right)	

Sensor Supervisory Type	Type #
Non-Supervised	16
Supervised	17
Manual Restoring	18
Auto Restoring	10

Ademco Contact ID Report Codes (These cannot be changed)			
Event	Event Qualifier	Event Code	Zone/User #s
System Fire	E	110	25
Sensor Smoke	E	111	1 to 24
Duress	E	121	0
Burglary	E	130	1 to 24
System Emergency	E	120	26
Audible Panic	E	120	1 to 24
Silent Panic	E	122	1 to 24
System Low Battery	E = Low	302	0
System Low Battery Restoral	R = Restore	302	11
Sensor Low Battery	E	304	1 to 24
Supervisory Trouble	E	381	1 to 24
Open By User	E = Open	401	0 to 6
Remote Disarm	E - Open	407	7
Close By User	R = Close	401	0 to 6
Remote or Quick Arm	R = Close	407	7
Cancel By User	E	405	0
Force Arm	E	574	0
2-Way Audio	E	606	0