



Publicly traded on NASDAQ Symbol: NSSC
© NAPCO 2005

NAPCO FREEDOM F-8 CONTROL PANEL PROGRAMMING INSTRUCTIONS

WI1432 10/05

Quick Start Guide

➔ Refer to WI1438 and WI1431 for the Installation Instructions and wiring diagrams to install the F-8 Control Panel, F-TP Touchpad and F-TAB (deadbolt sensor and magnetic door contact).

➔ Connect the F-PROG Programming Console / Keypad to the control panel. ➔

F-PROG Wiring	
Wire	Terminal
Red	16
Black	17
Green	18

➔ Connect AC Power and the backup battery.

➔ The NAPCO F-8 Control Panel has been pre-programmed for standard residential applications. The four steps below represent the only additional programming required to configure a typical system:

1 Enter Program Mode ➔ Press **FUNCTION** **8 A** **ON** ➔

(4) (5) (6) (7)
Default Installer Code shown in parentheses

	ARMED	ON	Indicates the F-8 Control Panel is in Program Mode and ready for a programming block to be entered.
	STATUS	OFF	
	TROUBLE	FLASHING	

2 Program Central Station Account # ➔ Press **RESET** **3** **0**

Enter CS Account #

3 Program Central Station Telephone # ➔ Press **RESET** **3** **1**

Enter CS Telco. #

4 Exit Program Mode ➔ Press **RESET** **FUNCTION** **8 A** **ON**

(4) (5) (6) (7)

• **Note - If an additional motion sensor is required, use F-8 Control Panel Zone 5.**
Connections - Loop: terminals 6 & 7, Power: terminals 15(-) and 16 (+).

• **F-8 Panel Zone Defaults:**

Zone 1: Entry/Exit	Zone 3: Perimeter	Zone 5: Entry/Exit Fol-lower/Interior	Zone 7: Entry/Exit
Zone 2: Entry/Exit Fol-lower/Interior	Zone 4: Perimeter	Zone 6: Perimeter	Zone 8: Entry/Exit Fol-lower/Interior

• Refer to wiring diagram on rear cover for connections.

Enrolling the Master F-IFOB

The first F-IFOB enrolled into a new system will automatically be designated as the Master F-IFOB. The following procedure is used to enroll the Master F-IFOB into a new system (a system which has not yet had any F-IFOBs enrolled):

1. With the system disarmed, insert the Master F-IFOB into the F-IFOB slot on the F-TP Touchpad for approximately three (3) seconds and then remove.
2. Re-insert the Master F-IFOB and then remove.
3. The F-TP Touchpad will beep to indicate that the F-IFOB has been properly enrolled.

Test the Master F-IFOB by arming the system in the STAY mode and using it to disarm system (insert into the F-IFOB slot and then remove).


This manual contains the Programming Instructions for the NAPCO F-8 Control Panel. It is intended to be used in conjunction with the **F-8 Control Panel Installation Instructions (WI1431)**, the **F-TP Touchpad & F-TAB Installation Instructions (WI1430)**, and the **F-TP Touchpad, F-LTRANS and F-TAB Installation Instructions (WI1439)**.

PROGRAMMING INSTRUCTIONS

An **F-PROG** Programming Console must be used for local keypad programming of the **NAPCO F-8** system. Connect the **F-PROG** for programming purposes and then remove when programming is complete.

PROGRAM MODE - PROGRAMMER KEY DEFINITIONS

NOTE:
After 15 minutes of keypad inactivity the keypad will emit a steady tone indicating the panel has been left in Installer Program Mode. Enter Installer Code followed by to exit or press to return to the Installer Program Mode.



Scroll Key
Use this key to scroll through data that has been entered in Programming Blocks.

Blank Key
Press this key to disable all features within a LED type Programming Block or to blank out digits in a Direct Entry type Programming Block.

Set Key
Press this key before entering a Programming Block Number.

Hexadecimal Data Entry
For hexadecimal digits, enter the following:

A =			D =		
B =			E =		
C =			F =		

Types of Programming Blocks

LED Programming Block

Enable features by pressing the key that corresponds to the associated feature; the LED will turn ON. To disable a feature press the key again; the LED will turn OFF. To disable all features within a LED Type Programming Block press the key; all LEDs will turn OFF.

LED Programming Block Example

Program zones 3 and 4 as *Follower Zones*.


1. Enter Programming Block 02, by pressing (Beep), then (Beep).
2. Press the key to select zone 3.
3. Press the key to select zone 4.
4. Press or to program.

02 Exit/Entry Follower Zones	
Default	N/A Zone 1 /F-TP1 Door
	<input type="checkbox"/> Zone 2 /F-TP1 PIR
	<input checked="" type="checkbox"/> Zone 3
	<input checked="" type="checkbox"/> Zone 4
	<input type="checkbox"/> Zone 5 /Optional PIR
	<input type="checkbox"/> Zone 6
	N/A Zone 7 /F-TP2 Door
	<input type="checkbox"/> Zone 8 /F-TP2 PIR

LED Type Programming Block

Zone 3 and Zone 4 LEDs light to indicate that zones 3 and 4 have been selected as follower zones. (Be sure to press or to program your selection).

(Note: By default, Zones 2, 5 & 8 are already selected as Exit / Entry Follower zones).



Direct Entry Programming Block

Enter data directly. For hexadecimal entries of A-F, use the key + through keys, respectively. Use the key to blank out digits in Direct Entry type programming blocks. Default values are shown in parentheses.

① **Direct Entry Programming Example 1**
Program the panel for a 90 second *Exit Delay*.

1. Press (Beep) (Beep).
2. Press .

10 Exit Delay
 Exit Delay, seconds
(0) (6) (0) Maximum Entry 255

② **Direct Entry Programming Example 2**
(Hexadecimal data entry)
Program *Telephone Prefix Number* with a 9E.

1. Press (Beep) (Beep).
2. Press .
3. Press .
4. Press .

44 Dialing Prefix
 Dialing Prefix for Telco 1, Telco 2 & Telco 3.

Direct Entry Type Programming Blocks

Viewing Data in Programming Blocks

To view data within a programming block, press **RESET** and enter the program block number to view 1st digit of data. Press the **INTERIOR** key to view the 2nd digit and continue pressing **INTERIOR** until all digits within the block have been viewed. Data will be displayed in the binary format shown in the table below:

Value	Data Displayed	Value	Data Displayed
0/Blank		8	
1		9	
2		*A/0	
3		B	
4		C	
5		D	
6		E	
7		F	

*** NOTE:**
In the following Programming Blocks, data that has been entered as a '0' will be displayed as an 'A': *Subscriber ID Numbers, Phone Numbers, Pager Leading and Trailing digits and Report Codes.*

NOTE:
The Following Programming Options are not permitted for UL installations: [05], [06], [23-2], [26-3] and [26-4].

The symbol indicates the programming option is not permitted for UL installations.


Zone #	Bit Value
1	1
2	2
3	4
4	8

Example: Viewing the Dialing Prefix


A Dialing Prefix of 9E has been programmed at Programming Block Number 44 (outside access number). Follow the steps below to view the data:

- ① Press **RESET** **4** **4** to enter Programming Block 44. The 1st digit of Programming Block 44 is displayed.

44 Dialing Prefix 9 E




- ② Press the **INTERIOR** key to view the 2nd digit.



DEFAULTING THE F-8 CONTROL PANEL

DEFAULTING THE F-8 CONTROL PANEL

1. Remove power from the panel.
2. Remove all wiring from terminal 19 (PGM) and terminal 3.
3. Connect terminal 19 (PGM) to terminal 3.



4. Apply power to the F-8 Panel.
5. After a few seconds the ARMED, READY and SYSTEM TROUBLE LEDs will flash.

	ARMED	FLASHING	Indicates the F-8 Panel is loading system defaults.
	STATUS	FLASHING	
	TROUBLE	FLASHING	

6. The keypad will beep 3 times indicating the panel default values have been loaded.
7. Remove wiring between terminal 19 (PGM) and terminal 3.
8. Re-install original wiring for terminal 19 (PGM) and terminal 3.

Zone Features

00 Exit/Entry Zones

Default
 ON Zone 1 /F-TP1 Door
 OFF Zone 2 /F-TP1 PIR
 OFF Zone 3
 OFF Zone 4
 OFF Zone 5 /Optional PIR
 OFF Zone 6
 ON Zone 7 /F-TP2 Door
 OFF Zone 8 /F-TP2 PIR

05 40 ms Loop Response Zones

Default
 ON Zone 1 /F-TP1 Door*
 ON Zone 2 /F-TP1 PIR*
 OFF Zone 3
 OFF Zone 4
 ON Zone 5 / Optional PIR *
 OFF Zone 6
 ON Zone 7 /F-TP2 Door*
 ON Zone 8 /F-TP2 PIR

*See Note 1

09 Selective Bypass

Default
 ON Zone 1 /F-TP1 Door
 ON Zone 2 /F-TP1 PIR
 ON Zone 3
 ON Zone 4
 ON Zone 5 /Optional PIR
 ON Zone 6
 ON Zone 7 /F-TP2 Door
 ON Zone 8 /F-TP2 PIR

02 Exit/Entry Follower Zones

Default
 N/A Zone 1 /F-TP1 Door
 ON Zone 2 /F-TP1 PIR
 OFF Zone 3
 OFF Zone 4
 ON Zone 5 /Optional PIR
 OFF Zone 6
 OFF Zone 7 /F-TP2 Door
 ON Zone 8 /F-TP2 PIR

06 Disable EOL Resistor

Default
 N/A Zone 1 /F-TP1 Door
 N/A Zone 2 /F-TP1 PIR
 OFF Zone 3
 OFF Zone 4
 OFF Zone 5 /Optional PIR
 OFF Zone 6
 N/A Zone 7 /F-TP2 Door
 N/A Zone 8 /F-TP2 PIR

08 PGM Prog. Output (Term. 19)

Default
 ON Zone 1 /F-TP1 Door
 ON Zone 2 /F-TP1 PIR
 ON Zone 3
 ON Zone 4
 ON Zone 5 /Optional PIR
 ON Zone 6
 ON Zone 7 /F-TP2 Door
 ON Zone 8 /F-TP2 PIR

04 24 Hour Protection Zones

Default
 N/A Zone 1 /F-TP1 Door
 OFF Zone 2 /F-TP1 PIR
 OFF Zone 3
 OFF Zone 4
 OFF Zone 5 /Optional PIR
 OFF Zone 6
 OFF Zone 7 /F-TP2 Door
 OFF Zone 8 /F-TP2 PIR

07 Bell & F-TP Touchpad Siren on Alarm

Default
 ON Zone 1 /F-TP1 Door
 ON Zone 2 /F-TP1 PIR
 ON Zone 3
 ON Zone 4
 ON Zone 5 /Optional PIR
 ON Zone 6
 ON Zone 7 /F-TP2 Door
 ON Zone 8 /F-TP2 PIR

NOTE 1:

These options must remain programmed.
DO NOT UNPROGRAM

NOTE 2:

UL Installations: The Fire (Pulsed) Output Time-out must be un-timed (000) if fire devices other than smoke detectors are installed.

NOTE 3:

UL Installations: Block 16, Wireless Supervisory Timer must be set to 10 hours.

NOTE 4:

UL Installations: Block 17 must be set to 4 hours.

System Times

10 Exit Delay

Exit Delay, seconds
 (0) (6) (0) Maximum Entry 255

15-255 (For non-CP-01 installations) and 45-255 (CP-01 installations) are valid entries. (60 in UL Installations). SIA CP-01 Required Default: 60 seconds.

11 Entry Delay

Entry Delay, seconds
 (0) (0) (0) Maximum Entry 255

0-255 are valid entries. **Note:** Default time is actually 30 sec. Any time period programmed will be added to 30 sec. SIA CP-01 Required Default: 30 sec.

12 Bell, F-TP Siren Time-out

Sounder Output, minutes
 (0) (0) (5) Maximum Entry 255

13 Fire (Pulsed / Temporal) Output

Fire Output, minutes
 (0) (0) (0) Maximum Entry 255

*See Note 2

14 Test Timer Interval

Test Timer Interval, days
 (0) (0) (0) Maximum Entry 255

15 Line Cut Time-to-Fail (Disabled = 000)

Telco Line Cut Time-to-Fail,
 (0) (0) (0) To Enable Line Cut, program a
 valid entry from 10 to 255 seconds

16 Wireless Supervisory Timer

Supervisory Timer, hours
 (1) (2) Maximum Entry 26
 *See Note 3

17 Wireless Smoke Supervisory Timer

Smoke Supervisory Timer, hours
 (8) Maximum Entry 8
 *See Note 4

18 Test Timer Offset

Test Timer Offset, hours
 (1) (2) Maximum Entry 23

System Features

20 F-TP Features 1

- Default
 OFF Zn1 ON=TP Fire (🔥)*
 OFF Zn2 ON=TP AUX (A)†
 ON Zn3 ON=TP Panic (🚒)*
 OFF Zn4 ON=Ambush (TP&User 8)*

*See Note 1, † See Note 4

21 F-TP Features 2

- Default
 ON Zn1 ON=Audible TP Panic (🚒)
 ON Zn2 ON=Exit/Entry with Urgency
 ON Zn3 ON=Not used - Leave ON **
 OFF Zn4 ON=F-8 Service Report †

** See Note 5, † See Note 4

22 Miscellaneous Features 1

- Default
 OFF Zn1 ON=Dialer Delay
 ON Zn2 ON=Not used - leave ON **
 OFF Zn3 ON=Swinger Shutdown
 OFF Zn4 ON=Bell on Line Cut (Armed)

** See Note 5

23 PGM - Prog. Output (T 19) Features 1

- Default
 OFF Zn1 ON=PGM on Audio Verification
 OFF Zn2 Reserved
 OFF Zn3 ON=PGM Follows Chime*
 ON Zn4 ON=Chirp Bell on Remote (Keyfob) Arm

* See Note 2

24 PGM - Prog. Output (T 19) Features 2

- Default
 OFF Zn1 ON=PGM on Fire
 OFF Zn2 ON=PGM on TP AUX (A)
 OFF Zn3 ON=PGM on TP Panic (🚒)
 OFF Zn4 ON=PGM on Test Timer

25 PGM - Prog. Output (T 19) Features 3

- Default
 OFF Zn1 ON=PGM on AC Fail
 OFF Zn2 ON=PGM on Low Battery
 OFF Zn3 ON=PGM on Trouble *
 OFF Zn4 ON=PGM on System Armed

*See Note 3

26 Miscellaneous Features 2

- Default
 OFF Zn1 ON=Keyswitch on Zone 6
 OFF Zn2 Enable GEM-OUT8
 OFF Zn3 ON=Inhibit Fail to Comm.
 OFF Zn4 ON=Inhibit Low Batt Disp.

27 Miscellaneous Features 3

- Default
 OFF Zn1 Keypad Polarity
 ON Zn2 ON=Away to Stay PIR Zns
 ON Zn3 ON=Stuck PIR Supervised
 OFF Zn4 F-TP Touchpad Audible Supervision

29 Chime Time

- Chime Time, 1/4 seconds
 (4) Valid Entries 2-9

69 Miscellaneous Features 4

- Default
 OFF Zn1 Priority on all Zones
 OFF Zn2 Reserved
 OFF Zn3 Disable Chime on Power-Up
 OFF Zn4 Fire Alarm Verification

Telephone Number 1 Programming

30 Subscriber ID Number

31 Telephone Number 1

NOTE:

A fixed Dial Tone Detection "E" is included by default in the *Dialing Prefix* (Block Number 44). If dial tone detection is not desired, Remove the "E" from Block 44. Program a "D" if a 4 second delay is required.

32 Receiver Format

- [0] Disabled
- [1] Ademco Slow
- [2] Radionics Slow
- [3] Silent Knight Fast
- [4] Universal High Speed
- [5] Reserved
- [6] Ademco Contact ID
- [7] Pager

Note: For CP-01 compatibility, set for Contact ID [6] format.

 (6)

33 Receiver Options

- Default
 OFF Zn 1 LED ON = 2300 Hz Handshake/Kissoff
 OFF Zn 2 LED ON = Sumcheck
 OFF Zn 3 LED ON = Single Digit
 OFF Zn 4 LED ON = No Handshake

34 Zone Report, Telco 1

- Default
 ON Zone 1 /F-TP1 Door
 ON Zone 2 /F-TP1 PIR
 ON Zone 3
 ON Zone 4
 ON Zone 5 /Optional PIR
 ON Zone 6
 ON Zone 7 /F-TP2 Door
 ON Zone 8 /F-TP2 PIR

NOTE 1:

Additional programming required for reporting, see Blocks [36]&[56]. **UL Installations:** If Keypad Fire [20-1] is enabled, keypad must be mounted within 3ft. from Control Panel & [27-4] must be programmed. If [20-4] is enabled, [36-2] must also be enabled.

35 Zone Restore Report, Telco 1

- Default
 OFF Zone 1 /F-TP1 Door
 OFF Zone 2 /F-TP1 PIR
 OFF Zone 3
 OFF Zone 4
 OFF Zone 5 /Optional PIR
 OFF Zone 6
 OFF Zone 7 /F-TP2 Door
 OFF Zone 8 /F-TP2 PIR

36 System Reporting, Telco 1

- Default
 OFF Zn1 ON=TP Fire (🔥)
 OFF Zn2 ON=TP AUX (A)*
 ON Zn3 ON=TP Panic (🚒)
 OFF Zn4 ON=Test Timer / Comm. Test **

*See Note 4. If [36-2] is enabled, [20-4] must also be enabled.

**See Note 6. Note: For Keypad Ambush reporting, enable F-TP Touchpad AUX [36-2].

NOTE 2:

Cannot be programmed with any other Programmable Output (PGM) Feature.

NOTE 3:

Includes Bell Cut, Fire Trouble, Receiver/F-TP Fail-to-Respond, Receiver Tamper, Receiver JAM, Wireless Smoke Low Battery, Wireless Smoke Supervisory Failure, Wireless Low Battery, Wireless Supervisory Fail, Wireless Tamper, Stuck PIR Failure, Zone Trouble.

NOTE 4:

Touchpad AUX (A) button may be programmed for:

- Auxiliary Emergency Report (Contact ID Code 140-00) - enable [20-2] and [36-2].

--OR--

- F-8 Service Report (Contact ID Code 616-00) - enable [21-4] and [36-4].

37 System Reporting, Telco 1

- Default
 OFF Zn1 ON=AC Fail Rpt. (15min. delay)
 ON Zn2 ON=Low Battery Report
 OFF Zn3 ON=Trouble Report *
 ON Zn4 ON=Fire Zone Report

*See Note 3

38 System Restore Report, Telco 1

- Default
 OFF Zn1 ON=AC Fail Rest. Report
 OFF Zn2 ON=Low Batt. Rest. Report
 OFF Zn3 ON=Trouble Rest. Report *
 OFF Zn4 ON=Fire Zone Rest. Report

*See Note 3

39 Open / Close Report, Telco 1

- Default
 OFF Zn1 ON=User 1 Reporting
 OFF Zn2 ON=User 2 Reporting
 OFF Zn3 ON=User 3 Reporting
 OFF Zn4 ON=User 4 Reporting
 OFF Zn5 ON=User 5 Reporting
 OFF Zn6 ON=User 6 Reporting
 OFF Zn7 ON=User 7 Reporting
 OFF Zn8 ON=User 8 Reporting

NOTE 5:

These options **must** remain programmed. DO NOT UNPROGRAM

NOTE 6:

- Test Timer [36-4] must be enabled for:
- Periodic Test Timer report (ContactID Code 601-00).
 - F-TP Touchpad AUX (A) Service Report [21-4] (Contact ID Code 616-00)
 - Comm. Test (Hold Down BYPASS), (ContactID Code 601-00).

Report Codes

60 Format Zone Report Codes

- Zone 1 Alarm Code
(3) ←
- Zone 2 Alarm Code
(3)
- Zone 3 Alarm Code
(3)
- Zone 4 Alarm Code
(3)
- Zone 5 Alarm Code
(3)
- Zone 6 Alarm Code
(3)
- Zone 7 Alarm Code
(3)
- Zone 8 Alarm Code
(3)

NOTE:
For Pager Format reporting only:
The first Digit of the Zone Report Code is programmable in block 60. The second digit of the Zone Report Code is the number of the zone that is reporting.
For example zone 5 report code (default of 3) would be 35.

62 Zone Restore Codes

- Zone 1-8 Restore Code
(E)
- Zone 1-8 Trouble Code
(F)

63 System Report Codes

- TP Fire (🔥)
(1) (1)
 - TP AUX (A)
(2) (3)
 - TP Panic (🚒)
(2) (1)
 - Test Timer
(F) (F)
 - AC Fail
(F) (9)
 - Low Battery
(F) (8)
 - *Trouble
(F) (1)
 - Fire
(1) (1)
- *See Note 1

64 System Restore Code

- (E)

NOTE 1:

Includes Bell Cut, Fire Trouble, Receiver Fail-to-Respond, Receiver Tamper, Receiver JAM, Transmitter Low Battery, Transmitter Supervisory Failure, Transmitter Tamper, Wireless Smoke Low Battery, Wireless Smoke Supervisory Failure, and Stuck PIR Failure.

65 Format Opening and Closing Codes

- Closing Code
(C)
- Opening Code
(B)

66 Ambush Report

- (2) (2)

Enhanced Communicator Features

67 Telephone Number 1

- Default
- ON Zn1 ON = Send Cancel Report
 - OFF Zn2 ON = Conditional Closing
 - OFF Zn3 ON = Enable "F-KEYF-G"
 - OFF Zn4 ON = Enable "UL F-TPG"

68 Telco 3 / Pager Reporting

- Default
- OFF Zn1 ON = Cancel Code
 - OFF Zn2 ON = Conditional Closing
 - OFF Zn3 ON = Reserved
 - OFF Zn4 ON = Enable F-TP Ambush Sounder

70 SIA CP-01 Features

- Default
- ON Zn1 ON=Exit Restart Enabled
 - ON Zn2 ON=Convert Away to Stay if no Exit
 - OFF Zn3 OFF=Enable Bypass For Zn6 Supr Zone
 - OFF Zn4 OFF=Zn6 24Hr Supr Zone

Contact ID Reporting Codes

61

- Zone 1 Alarm Code
(3) ←
- Zone 2 Alarm Code
(3)
- Zone 3 Alarm Code
(3)
- Zone 4 Alarm Code
(3)
- Zone 5 Alarm Code
(3)
- Zone 6 Alarm Code
(3)
- Zone 7 Alarm Code
(3)
- Zone 8 Alarm Code
(3)

The Contact ID Zone Alarm Report Codes are programmable in block 61. Choose from the following zone types:

- 1 FIRE
- 2 PANIC
- (3) BURGLARY
- 4 HOLDUP
- 5 GENERAL ALARM
- 6 RESERVED
- 7 GAS ALARM
- 8 HEAT ALARM
- 9 RESERVED
- A AUXILIARY
- B 24 HOUR ALARM
- C RESERVED
- D BURG PERIMETER
- E BURG INTERIOR
- F TAMPER

Note: See Installation Manual for the effect on Audio Verification [23-1] and GEM-OUT8 outputs.

Wireless Programming

Transmitters

RF ID

Point

- 71 Zone 1
- 72 Zone 2
- 73 Zone 3
- 74 Zone 4
- 75 Zone 5
- 76 Zone 6
- 77 Zone 7
- 78 Zone 8

Enter the RF ID# located on the Transmitter, Key Fob and Smoke Detector labels.



Enter the point number to be associated with the zone. If only one point of GEM-TRANS2 is used, enter a 1 in this location. For GEM-GB, GEM-DT, GEM-PIR, enter a 1 in this location.

Programming Example

Map point 1 of a window door transmitter, with RF ID# 0012B0:0 to Zone 3.

- 73 Zone 3 0 0 1 2 B 0 : 0 1

1. Enter Dealer Mode.
2. Enter RESET (beeps) 7 F 3 (beeps)
3. Enter 0 0 1 2 * 2 0 0
4. Enter 1 (beeps) ↑ Hexadecimal B Entry

Note: If the RF ID# in step 3 is not entered correctly, the keypad will emit a 1 second tone indicating incorrect entry. Repeat steps 2 - 4 above.

Keyfobs

RF ID

Aux1 / Aux2

- 81 Keyfob 1
- 82 Keyfob 2
- 83 Keyfob 3
- 84 Keyfob 4

AUX 1 & 2 Programming

- 1 Panic
- 2 AUX
- 3 Bell ON
- 4 PGM
- 5 Instant
- 6 RESERVED
- 7 Full Set System
- 8 Interior

Smoke Detectors

RF ID

- 85 Smoke 1
- 86 Smoke 2
- 87 Smoke 3
- 88 Smoke 4

Hexadecimal Data Entry

To Enter a hexadecimal digit enter the following: A= * 1 B= * 2 C= * 3 D= * 4 E= * 5

