




# PROGRAMMING INSTRUCTIONS




## GEM-P9600 CONTROL PANEL/COMMUNICATOR


Programming the GEM-P9600 Control Panel with the  
"Classic" GEM-RP2ASe2, GEM-RP3DGTL, and GEM-RP4RFC/GEM-RP4C Keypads and  
the "K Series" GEM-K2AS, GEM-K3DGTL, and GEM-K4RF/GEM-K4 Keypads



"K Series" GEM-K4RF/GEM-K4



"K Series" GEM-K2AS



"K Series" GEM-K3DGTL

### Quick Start (for GEM-K2ASe2):

1. Refer to the wiring diagram, connect Siren, Aux. Power, PGM Output, Remote Bus, Earth Ground, Zone and Telephone Wiring. NOTE: See Installation Instructions (WI742).
2. Connect AC power first and then the battery.
3. Configure the keypad (see page 64).
4. Access the Easy Menu Driven (Dealer Program) Mode:

Press:



Press NO until "TURN ON PROG Y/N" appears on the keypad display.

Press NEXT/YES to enter Dealer Program Mode. See p. 5

### Quick Start (for GEM-K3DGTL):

1. Refer to the wiring diagram, connect Siren, Aux. Power, PGM Output, Remote Bus, Earth Ground, Zone and Telephone Wiring. NOTE: See Installation Instructions (WI742).
2. Connect AC power first and then the battery.
3. Configure the keypad (see page 64).
4. Access the Easy Menu Driven (Dealer Program) Mode:

Press:



Press NO until "17" appears on the keypad display.









Press NEXT/YES to enter Dealer Program Mode. See p. 5.

**THIS MANUAL INCLUDES FEATURES WHICH ARE ONLY AVAILABLE IN CONTROL PANEL FIRMWARE VERSION 20 OR LATER.**

**IMPORTANT NOTE**

This manual supports the keypad programming of the GEM-P9600 control panel with the NAPCO "classic" GEM-RP2ASe2, GEM-RP3DGTL and GEM-RP4RFC/GEM-RP4C keypads as well as the GEM-K2AS, GEM-K3DGTL and GEM-K4RF/GEM-K4 "K Series" keypads. The new "K Series" models offer the new STAY and AWAY buttons with simplified functionality, along with the new MENU and ENTER buttons. While the instructions in this manual are depicted using the "K Series" keypads, the manual applies to both the "classic" and the "K Series" keypads.

**Program Mode** is the same for both keypads--**only the button names have changed**, as follows:

- The  button and the  button operate identically (in Program Mode) for both keypads.
- The  button and the  button operate identically (in Program Mode) for both keypads.
- The  button and the  button operate identically (in Program Mode) for both keypads. The words "NEXT/YES button" are used in this manual.
- The  button and the  button operate identically (in Program Mode) for both keypads. The words "PRIOR/NO button" are used in this manual.

**CHANGES FROM PREVIOUS EDITION**

This manual (WI1185) contains revised Installation Instructions previously found in WI777D. The revisions are as follows:

Pages 6-21: Easy Program Menu includes new selections: 24 Hour Zones in Area 1, Chime Zones in Area 1, Chime 2 Zones in Area 1, Exit/Entry2 Zones in Area 1, 50 mS Loop Response Zones, Aux Output Activated on Alarm Zones, Sensor Watch Zones, Keypad Sounder On Alarm Zones, Auto Bypass Re-entry Zones, Enable No EOLR Zones, Enable Telco Line Fault Test, Enable Burg Output Chirp on KeyFob, Enable SIA CP-01 Features.

Page 39, address 2421, "Telco Answering Service Override" name changed to "2nd Call Answering Machine Override".

Page 46, added address 2417, bit 5, "Lug E4 Armed Away Only".

Panel includes added features to accommodate the SIA CP-01 False Alarm Reduction Standard. Therefore Direct Address Program Mode addresses have been modified or added, as follows:

Page 47, modified address 2422, bit 6, Enable Bell Output on Keyfob Arming  
Page 47, added address 2421, bit 3, Aux. Output Chirp on Keyfob Arm/Disarm  
Page 47, added address 2421, bit 4, Don't Clear Aux. Relay with Disarm  
Page 48, added address 3905, bit 1, Exit Time Restart  
Page 48, added address 3905, bit 2, Sound Alarm on Exit Error  
Page 48, added address 3905, bit 3, Rpt Exit Err/Recent Close  
Page 48, added address 3905, bit 4, Digital Dialer Rpt Enter/Exit Test Mode  
Page 48, added address 3905, bit 5, Enable CP-01 Limits  
Page 48, added address 3905, bit 6, Disable Call Waiting on First Attempt  
Page 48, added address 3905, bit 7, Enable Ambush in User Assignment Code Type

Page 28, modified address 4082, Report Cancel Window.

Address Number Index added at end of manual.

Page 4, the following statement added: **Note:** Unattended downloading from a computer is not allowed for Fire Alarm or UL installations."

Pages 4, 5, and 7, "50mS Loop Response Zones", since the time of 50 mS does

not meet the UL listing requirement of the panel, the following notation is made: "750 mS is required for Loop Response time in UL installations".

Page 7, "Auto Bypass Re-entry Zones" notation added: "Not evaluated by UL".  
Page 10, "Enter User Codes", instructions modified to enter a code from "3 to 6" digits.

Area Options/Explanation chart at the top of page 11: the following information added: "Ambush: Allows user code to send Ambush signal to Central Station".

In Zone Options (pages 40-45) and the wiring diagram (page 72), the following notation added: "Disable Auto-Reset on non-fire zones for SIA CP-01 installations".

Added to Zone Options (pages 40-45) and on page 47, address 2422, bit 0: "In UL installations, all Fire Zones must also be programmed for 'Pulsed Burg Output' and 'Fire Output Cadence' (Address 2422, bit zero)".

Page 59, Table 4: the following notation added: "Keypad Tamper must be enabled in UL installations".

Pages 40-44, added to Zone Options, "Interior (STAY) Bypass", addresses 1284, 1384, 1484, 1584, 1684, 1784, 1884, 1984, 2084, 2184, 2284, 2384.

Page 46, notation added to address 2419, bit 0: "Do not use on systems with "K Series" keypads".

Page 47, address 2422, bit 5, "Disable Exit/Entry Urgency Tone at Keypad" changed to "Disable Entry Urgency Tone at Keypad".



**NAPCO Security Systems, Inc.**  
333 Bayview Avenue, Amityville, New York 11701  
For Sales and Repairs, call toll free: (800) 645-9445  
For direct line to Technical Service,  
call toll free: (800) 645-9440  
Internet: <http://www.napcosecurity.com>

# TABLE OF CONTENTS

<b>IMPORTANT NOTE</b> .....	2	<b>Key Fob Transmitters (as Arm/Disarm &amp; Control Devices)</b> .....	20
<b>CHANGES FROM PREVIOUS EDITION</b> .....	2	<b>Key Fob Transmitters (as Zone Input Devices)</b> .....	21
<b>SYSTEM PROGRAMMING OPTIONS</b> .....	4	<b>Enter Zone Descriptions</b> .....	21
Introduction .....	4	<b>Enter Date</b> .....	21
Downloading From a Computer .....	4	<b>Enter Time</b> .....	21
<b>EASY MENU DRIVEN PROGRAM MODE</b> .....	5	<b>Dealer Code</b> .....	21
Dealer Program - Preliminary Information .....	5	<b>Exit Dealer Program Mode</b> .....	21
Accessing Dealer Program Mode.....	5	<b>Clear Dealer Program</b> .....	21
Customizing a Default Program .....	5	<b>Cold Start</b> .....	21
GEM-RP2ASe2/GEM-K2AS KEYPAD Easy Program Menu.....	6	<b>DIRECT ADDRESS PROGRAM MODE</b> .....	22
Total Number of Zones in Area 1 .....	6	Keypad Programming Overview .....	22
Total Number of Zones in Area 2 .....	6	Accessing Direct Address Program Mode.....	22
Fire Zones in Area 1.....	6	Keypad Address Program Mode Display.....	23
2-Wire Fire Zones in Area 1.....	6	Direct Address Program Mode Keypad Commands.....	23
Local or Central Station Reporting System.....	6	Conventions Used in this Manual .....	25
Exit/Entry Zones in Area 1 .....	6	<b>PROGRAMMING OPTIONS &amp; WORKSHEETS</b> .....	27
Interior Zones in Area 1 .....	6	SYSTEM DELAYS & TIMEOUTS (ADDRESS 0000-0002, 2402, 2406, 2414 & 3902).....	27
24 Hour Zones in Area 1 .....	7	SYSTEM DELAYS & TIMEOUTS (ADDRESS 2407, 2408 & 4088) .....	27
Chime Zones in Area 1 .....	7	SYSTEM DELAYS & TIMEOUTS (ADDRESS 2400, 2401, 2403-2405, 4082 & 4083).....	28
Chime 2 Zones in Area 1 .....	7	KEYPAD SYSTEM CODES (ADDRESS 0490, 0495 & 0500).....	28
Exit/Entry2 Zones in Area 1 .....	7	CS RECEIVER FORMAT OPTIONS (ADDRESS 0520, 0521, 0525, 0526, 0550, 0551, 0575 & 0576).....	29
50mS Loop Response Zones .....	7	CS RECEIVER TELEPHONE NUMBERS (ADDRESS 0527-0546, 0552-0571, 0577-0596).....	30
Aux Output Activated on Alarm Zones.....	7	DOWNLOAD/CALLBACK OPTIONS (ADDRESS 4089, 0600-0619, 0625-0647, 1022 & 1023).....	30
Sensor Watch Zones .....	7	CS SUBSCRIBER ID NUMBERS (ADDRESS 0650-0787).....	31
Keypad Sounder on Alarm Zones .....	7	CS SUBSCRIBER ID NUMBERS (ADDRESS 0790-0857).....	32
Auto Bypass re-entry Zones.....	7	CS REPORTING CODES (ADDRESS 0859-0907).....	32
Enable no EOLR Zones.....	8	CS REPORTING CODES (ADDRESS 0870-0904).....	33
Enable Telco Line Fault Test.....	8	CS AREA & SYSTEM REPORTING OPTIONS (ADDRESS 1024-1027).....	33
Enable Burg Output Chirp on Keyfob .....	8	CS ZONE REPORTING CODES (ADDRESS 0910-1005).....	34
Enable SIA CP-01 Features .....	8	CS USER REPORTING CODES (ADDRESS 1030-1055).....	35
Number of Keypads in Area 1.....	8	CS USER REPORTING CODES (ADDRESS 1056-1081).....	36
Number of Keypads in Area 2.....	8	GLOBAL SYSTEM TROUBLE REPORTING OPTIONS (ADDRESS 1082-1116).....	37
Central Station Receiver 1 Tel. Number.....	8	AREA SYSTEM TROUBLE REPORTING OPTIONS (ADDRESS 1120-1157).....	38
Easy Programming of Auto download ID #'s and PC Preset Callback Numbers .....	9	AREA SYSTEM TROUBLE REPORTING OPTIONS (ADDRESS 1160-1197).....	39
Central Station Receiver 1 Account Number .....	9	ZONE OPTIONS / ZONES 1-16 (ADDRESS 1200-1386).....	40
Central Station Receiver 1 Format .....	9	ZONE OPTIONS / ZONES 17-32 (ADDRESS 1402-1586).....	41
Enter User Codes.....	10	ZONE OPTIONS / ZONES 33-48 (ADDRESS 1602-1786).....	42
RF Transmitter Points .....	12	ZONE OPTIONS / ZONES 49-64 (ADDRESS 1802-1986).....	43
Quick Method .....	12	ZONE OPTIONS / ZONES 65-80 (ADDRESS 2002-2186).....	44
Key Fob Transmitters (as Arm/Disarm & Control Devices) .....	12	ZONE OPTIONS / ZONES 81-96 (ADDRESS 2202-2386).....	45
Key Fob Transmitters (as Zone Input Devices) .....	13	ZONE OPTIONS / ZONES 1-96 (ADDRESS 1200-2386).....	46
Enter Zone Descriptions .....	13	SYSTEM OPTIONS (ADDRESS 2415-2419).....	48
Enter Date .....	13	SYSTEM OPTIONS (ADDRESS 2420-2422, 3874 & 3879-3881).....	49
Enter Time.....	13	ALARM/TROUBLE REPORTING CODES (ADDRESS 3879-3881).....	50
Dealer Code .....	13	SYSTEM OPTIONS (ADDRESS 3882-3901, 3903-3905 & 4084).....	50
Exit Dealer Program Mode .....	13	KEYPAD OPTIONS (ADDRESS 2425-2454).....	51
Clear Dealer Program .....	13	USER AREA OPTIONS (ADDRESS 2500-2595).....	52
Cold Start.....	13	EZM GROUP OPTIONS (ADDRESS 2600-2621).....	53
GEM-RP3DGLT/GEM-K3DGLT and GEM-RP4RFC/GEM-K4RF KEYPAD Easy Program Menu.....	14	AREA ARMING OPTIONS (ADDRESS 2650-2657).....	54
Total Number of Zones in Area 1 .....	14	REMOTE ACCESS LOGGING (ADDRESS 3184).....	54
Total Number of Zones in Area 2 .....	14	AREA OUTPUT CONTROL OPTIONS (ADDRESS 2700-2739).....	55
Fire Zones in Area 1.....	14	RF RECEIVERS & SUPERVISORY TIMER OPTIONS (ADDRESS 3776 & 3760-3775).....	56
2-Wire Fire Zones in Area 1.....	14	EXTERNAL RELAY CONTROL / RELAYS 1-39 (ADDRESS 3778-3816 & 2800-2955).....	57
Local or Central Station Reporting System.....	14	EXTERNAL RELAY CONTROL / RELAYS 40-78 (ADDRESS 3817-3855 & 2856-3111).....	58
Exit/Entry Zones in Area 1 .....	14	EXTERNAL RELAY CONTROL / RELAYS 79-96 (ADDRESS 3856-3873 & 3112-3183).....	59
Interior Zones in Area 1 .....	15	NUMBER OF RELAY BOARD MODULES (ADDRESS 3777).....	62
24 Hour Zones in Area 1 .....	15	SYSTEM RESET OPTIONS (ADDRESS 4091-4093).....	63
Chime Zones in Area 1 .....	15	<b>USER PROGRAM MODE</b> .....	64
Chime 2 Zones in Area 1 .....	15	Preliminary Information .....	64
Exit/Entry2 Zones in Area 1 .....	15	Accessing User Program Mode .....	64
50mS Loop Response Zones .....	15	User Codes.....	65
Aux Output Activated on Alarm Zones.....	15	<b>KEYPAD CONFIGURATION MODE</b> .....	66
Sensor Watch Zones .....	15	Configuring the Keypads.....	66
Keypad Sounder on Alarm Zones .....	16	<b>ALPHABETICAL INDEX</b> .....	67
Auto Bypass re-entry Zones.....	16	<b>ADDRESS NUMBER LOCATION INDEX</b> .....	72
Enable no EOLR Zones.....	16	<b>GEM-P9600 WIRING DIAGRAM</b> .....	76
Enable Telco Line Fault Test.....	16		
Enable Burg Output Chirp on Keyfob .....	16		
Enable SIA CP-01 Features .....	16		
Number of Keypads in Area 1.....	16		
Number of Keypads in Area 2.....	16		
Central Station Receiver 1 Tel. Number.....	17		
Central Station Receiver 1 Account Number .....	17		
Central Station Receiver 1 Format .....	17		
Enter User Codes.....	18		
RF Transmitter Points .....	20		
Quick Method .....	20		

Refer to accompanying GEM-P9600 Installation Instructions (WI742) for installation information.



# SYSTEM PROGRAMMING OPTIONS

## INTRODUCTION

The GEM-P9600 control panel may be programmed by various means, each of which will be covered in detail in the sections that follow. Keypad displays shown are for a GEM-K2AS, the GEM-K3DGTL, and the GEM-K4/GEM-K4RF series. With the GEM-RP2ASe2/GEM-K2AS keypads, because of their reduced display capabilities, messages are abbreviated and will scroll through two or more screens. Zone descriptions cannot be programmed using GEM-K2AS/GEM-RP2ASe2, GEM-K3DGTL/GEM-RP3DGTL, nor a GEM-K4RF/RP4RFC series keypad, therefore a GEM-RP1CAe2 or GEM-K1CA keypad must be used.

- ✓ **Downloading From a Computer.** This is the preferred method of programming. The panel may be downloaded from (or uploaded to) an IBM PC-compatible computer, either locally or remotely. Napco's PCD-Windows Quickloader software features context-sensitive help screens as well as an error-checking utility that prevents programming of incompatible or conflicting data to ensure proper panel operation. **Note:** Unattended downloading from a computer is not allowed for Fire Alarm or UL installations.
- ✓ **Easy Menu-Driven Program (Dealer Program) Mode - Keypad Programming.** The Easy Menu-Driven Program Mode allows keypad programming of number of zones in area 1 and 2, panel zone doubling, number of fire zones (both 4-wire and 2-wire), local or Central Station reporting, number of exit/entry zones, number of interior zones, number of 24 hour zones, number of chime zones, Chime 2 zones, Exit/Entry2 zones, 50ms loop response zones (**Note: 750mS is required for Loop Response time in UL installations**), aux output activated on alarm zones, sensor watch zones, keypad sounder on alarm zones, auto bypass re-entry zones, EOLR zones, number of keypads in area 1 and 2, Central Station telephone number, Central Station account number, Central Station receiver format, User Codes, RF transmitter points, RF keyfob transmitters, zone descriptions, dealer code, Telco line fault test, Burg output chirp on keyfob, enable CP-01, and clear dealer program/cold start. For new panels, a custom default program may be created at the keypad. A menu-driven utility prompts the installer to configure the system. Further detailed customization is accomplished in the Direct Address Program Mode.
- ✓ **Direct Address (Dealer Program) Program Mode - Keypad Programming.** The Direct Address Program Mode is an extension of the Dealer Program Mode wherein data is entered at the keypad by specific location. This mode is accessed from the Easy Menu Driven Program Mode by pressing the **RESET** button at any time.
- ✓ **User Program Mode - Keypad programming.** The User Program Mode is intended for authorized users and is limited to keypad programming of User Codes, Time, Date and Zone Descriptions.

## DOWNLOADING FROM A COMPUTER

The control-panel program may be downloaded from the computer by any of the following methods.



### Local Downloading

(**Note:** This procedure should be used after installation, after peripheral devices are connected).

For direct high-speed data transfer to the control panel from a desktop computer, connect the download jack (JP2) on the panel to the LOCAL jack (J3) on the Napco PCI2000/3000 computer interface using the supplied 6-conductor cable. (Refer to PCI2000/3000 Installation Instructions WI443 for wiring diagram and procedures).

Similarly, a high-speed local download may be made in the field using a notebook or laptop computer. Connect JP2 on the control panel to a Napco PCI-MINI computer interface using the 6-conductor cable supplied. (Refer to PCI-MINI Installation Instructions WI767).

### Remote Downloading

(Also see PCI2000/3000 Installation Instructions WI443).

### Function Mode.

Start by establishing a telco connection between the computer operator and the installer. During this procedure, voice contact will be lost, therefore both the installer and the computer operator should be familiar with the operation. When a steady high-pitched tone is heard at the site phone, access the "ACTIVATE DOWNLOAD" Function (see Keypad Programming Modes), then press the **YES** button or the YES button; the site phone will go dead. Hang up the phone and wait for a call from the central station confirming a successful download.












### Callback Method.

An installed, unattended panel may be programmed or reprogrammed remotely using the Callback-Method Download feature of the PCD Windows software. Remote downloading requires a modem compatible with the PCI2000/3000. Upon answering the call from the computer, the panel will verify the Download Security Code and, if confirmed, will establish a connection. If a Callback Number is programmed into the panel, the panel will automatically disconnect and call the computer at this number before establishing a connection.





# EASY MENU DRIVEN PROGRAM MODE



## DEALER PROGRAM - PRELIMINARY INFORMATION


-  Only Keypad #1 may be used for both Dealer and User programming, however this keypad may be located in any area.
-  The Master Security Code is *printed on the panel's microprocessor can*. Use this code to enter the Dealer Program Mode to program a custom Dealer Security Code. Record the number, then remove the code label to prevent unauthorized access to the panel. If you forget your Dealer Security Code, use the Master Security Code to enter programming.
-  After entering codes or data, press the save  button. **Data will not be stored into memory unless  is pressed.**
-  If the keypad is in the Program Mode and no activity is detected for longer than 4 minutes, a steady tone will sound.
-  Silence the sounder by the  button to continue, or by pressing the  button to exit.
-  A panel that has been COLD STARTED (Address Location 4093) performs identically to a new panel.
-  When programming a Multiple Area System, Direct Address Programming Mode must be used to complete the program.

**KEYPAD #1:** For ease of programming, it is recommended that a GEM-RP1CAe2 or GEM-K1CA be used as Keypad #1. (Regardless of which keypad is selected, all *new* keypads are configured as Keypad #1 out of the box). If a GEM-RP2ASe2/ GEM-K2AS is used, configure address jumpers as Keypad #1 (see Configuring the GEM-RP2ASe2 Keypad, page 64).

## ACCESSING DEALER PROGRAM MODE

1. Press  

Master Security Code  
(on microshield)
2. Press "PRIOR/NO" button until "TURNON PROG Y/N" (GEM-RP2ASe2/ GEM-K2AS) or "17" (GEM-RP3DGTL/GEM-K3DGTL or GEM-RP4RFC/GEM-K4RF) appears on the LCD screen.
3. Press "NEXT/YES" button to Enter Dealer Program Mode.
4. Press   to exit Dealer Program Mode when finished.





## CUSTOMIZING A DEFAULT PROGRAM

For new panels, you can design a default program that will best suit your application. Using this procedure, you will configure the panel for:


- Number of Zones in Area 1
- Number of Zones in Area 2
- Fire Zones in Area 1
- 2-Wire Fire Zones in Area 1
- Local or Central Station Reporting System
- Exit/Entry Zones in Area 1
- Interior Zones in Area 1
- 24 Hour Zones in Area 1
- Chime Zones in Area 1
- Chime 2 Zones in Area 1
- Exit/Entry2 Zones in Area 1
- 50mS Loop Response Zones (Note: 750mS is required for Loop Response time in UL installations).
- Aux Output Activated on Alarm Zones
- Sensor Watch Zones
- Keypad Sounder on Alarm Zones
- Auto Bypass re-entry Zones
- Enable no EOLR Zones
- Number of Keypads in Area 1 and 2
- Central Station Receiver 1 Tel. Number
- Central Station Receiver 1 Account Number
- Central Station Receiver 1 Format
- Enter User Codes
- RF Transmitter Points
- Quick Method
- Key Fob Transmitters
- Enter Zone Descriptions
- Dealer Code
- Enable Telco Line Fault Test
- Enable Burg Output Chirp on Keyfob
- Enable CP-01
- Clear Dealer Program
- Cold Start

This procedure will automatically set up system keypads, EZMs, wireless transmitters, etc. After your basic default program has been loaded, you may alter it as necessary in the Direct Address Program Mode.

**NEW PANELS:** The custom default program may be created for new panels only. Once the panel has been programmed by any means, the number zones will be suppressed and cannot be changed. Should it be necessary to create a new custom default program, (a) from the Dealer Program Mode, press the  button to enter the Direct Address Program Mode; (b) access Location 4091 (Clear Program); (c) press the  button and start over.



## GEM-RP2ASe2/GEM-K2AS Keypad Easy Program Menu



Enter the Dealer Security Code (default = 456789) for a new panel or enter your custom Dealer Program Code if programmed. Press the PRIOR/NO button repeatedly until "TURNON/PROG" is displayed. **NOTE:** If you pass "TURNON/PROG", you can scroll back by pressing **[BYPASS]**. Press the NEXT/YES button to enter the Dealer Program Mode. In each of the following steps, press **[MENU]** to jump to the next screen, the NEXT/YES button to go forwards, the PRIOR/NO button to go backwards, **[ ]** to save and **[RESET]** twice to exit at any time.

Ent A1

#ZnXX

(Direct Entry)

Ent A2

#ZnXX

(Direct Entry)

Ent Fr

Zn#XX

(Direct Entry)

Ent2WF

Zn#XX

(Direct Entry)

Report

all Zn

Y/N

(Press YES or NO)

EntEE1

Zn#XX

(Direct Entry)

EntFol

Zn#XX

(Direct Entry)

### Total Number of Zones in Area 1 (New Program Only)

- Enter the total number of zones to be programmed for Area 1.
- Valid entries are from 01 to 96. Directly enter the total number of zones, including leading zeros.
- The system is based on groups of 4 zones each (after the first 8 zones), and will automatically round up to the next group of 4. For example, if you enter 18, it will automatically convert this to 20 zones. Press **[ ]** to save. Press the NEXT/YES button to proceed.

### Total Number of Zones in Area 2 (New Program Only)

- Enter the total number of zones to be programmed for Area 2.
- Valid entries are from 01 to 96. Directly enter the total number of zones, including leading zeros.
- The system is based on groups of 4 zones each (after the first 8 zones), and will automatically round up to the next group of 4. For example, if you enter 18, it will automatically convert this to 20 zones. Press **[ ]** to save. Press the NEXT/YES button to proceed.

### Fire Zones in Area 1 (New Program Only)

- Enter the zone number of any Fire Zones (including 2-wire, 4-wire or wireless).
- Valid entries are from 01 to 96.
- Directly enter each zone number, including leading zeros, and press **[ ]** to save, and then repeat for any additional zone(s). Press the NEXT/YES button to proceed.

### 2-Wire Fire Zones in Area 1 (New Program Only)

- Enter the zone number of any Fire Zone (from previous question) to be used with 2-wire smoke detectors.
- Valid entries are 07 and 08. Directly enter each zone number, including leading zeros.
- Press **[ ]** to save, and repeat for any additional zone(s); press NEXT to proceed.

**NOTE:** Only zones which have been designated as Fire Zones can be programmed as 2 Wire Fire zones. JP3 must be set to "2-WF" position for 2-wire fire. (refer to Installation Instructions).

### Local or Central Station Reporting System (New Program Only)

Press the NEXT/YES button for all zones to report; press the PRIOR/NO button for local system.

### Exit/Entry Zones in Area 1 (New Program Only)

- Enter the zone numbers of zones to be used as Exit/Entry zones.
- Valid entries are from 01 to 96. Directly enter each zone number, including leading zeros.
- Press **[ ]** to save and repeat for any additional zone(s); press the NEXT/YES button to proceed.

**NOTE:** Exit/Entry Entry time of 30 seconds will automatically be programmed.

### Interior Zones in Area 1 (New Program Only)

- Enter the zone numbers to be used as Interior Zones.
- Valid entries are from 01 to 96. Directly enter each zone number, including leading zeros.
- Press **[ ]** to save and then repeat for any additional zone(s).
- Press the NEXT/YES button to proceed.
- All Interior zones will also be automatically programmed as "Exit/Entry Follower" and as "Power Up Delay" zones.



Ent24H
Zn#XX

(Direct Entry)

EntCZ1
Zn#XX

(Direct Entry)

EntCZ2
Zn#XX

(Direct Entry)

EntEE2
Zn#XX

(Direct Entry)

Ent50m
Zn#XX

(Direct Entry)

EntAux
Zn#XX

(Direct Entry)

Ent SW
Zn#XX

(Direct Entry)


EntKPS
Zn#XX

(Direct Entry)


EntAUB
Zn#XX

(Direct Entry)


**24 Hour Zones in Area 1 (New Program Only)**

- Enter the zone numbers of zones to be used as 24 Hour zones.
- Valid entries are from 01 to 96. Directly enter each zone number, including leading zeros.
- Press  to save and repeat for any additional zone(s); press the NEXT/YES button to proceed.


**NOTE:** 24 Hour Zones will automatically be programmed as audible (Burg Output).**Chime Zones in Area 1 (New Program Only)**

- Enter the zone numbers which are to be used as Chime Zones.
- Valid entries are from 01 to 96. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), press the NEXT/YES button to proceed.


**NOTE:** A chime time of 2 seconds will be automatically programmed.**Chime 2 Zones in Area 1 (New Program Only)**

- Enter the zone numbers which are to be used as Chime 2 Zones.
- Valid entries are from 01 to 96. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), press the NEXT/YES button to proceed.


**NOTE:** A chime time of 2 seconds will be automatically programmed.  
Chime 2 zones give a distinct pulsating tone when zone is faulted.**Exit/Entry2 Zones in Area 1 (New Program Only)**

- Enter the zone numbers of zones to be used as Exit/Entry zones.
- Valid entries are from 01 to 96. Directly enter each zone number, including leading zeros.
- Press  to save and repeat for any additional zone(s), press the NEXT/YES button to proceed.


**NOTE:** An Exit/Entry 2 Entry Time of 30 seconds will automatically be programmed.**50 mS Loop Response Zones (New Program Only)**

- Enter the zone numbers of zones to have a 50mS loop response.
- Valid entries are from 01 to 08. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), press the NEXT/YES button to proceed. **Note:** Only panel zones 01-08 can be programmed for Quick Loop Response. All other zones can be programmed via their respective EZM's (hardwire). **Note: 750mS is required for Loop Response time in UL installations.**


**Aux Output Activated on Alarm Zones (New Program Only)**

- Enter the zone numbers of zones to activate the Aux Output upon alarm.
- Valid entries are from 01 to 96. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s); press the NEXT/YES button to proceed.


**NOTE:** An Aux Output Timeout of 15 minutes will automatically be programmed.**Sensor Watch Zones (New Program Only)**

- Enter the zone numbers of zones to be Sensor Watch zones.
- Valid entries are from 01 to 96. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), press the NEXT/YES button to proceed.

**NOTE:** A Sensor Watch Time of 24 hours will automatically be programmed.**Keypad Sounder On Alarm Zones (New Program Only)**

- Enter the zone numbers of all zones to activate the Keypad Sounder upon alarm.
- Valid entries are from 01 to 96. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), press the NEXT/YES button to proceed.

**Auto Bypass Re-entry Zones (New Program Only) (Not evaluated by UL)**

- Enter the zone numbers of zones to be Auto Bypass Re-entry zones.
- Valid entries are from 01 to 96. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), press the NEXT/YES button to proceed.
- Auto Bypass Re-entry Zones allow the system to be armed with the zone faulted but come back into the system (armed) when the zone is subsequently closed.

EnNEOL

Y/N

(Press YES or NO)

Telco

Ln Flt

Y/N

(Press YES or NO)

KF Out

Chirp

Y/N

(Press YES or NO)

Enable

CP01?

Y/N

(Press YES or NO)

Ent A1

#KP 01

(Direct Entry)

Ent A2

#KP 01

(Direct Entry)

Phone#

-----

-----

(Direct Entry)

**Enable No EOLR Zones (New Program Only)**

- Press YES to program all zones except 24 Hr & fire zones for No End Of Line Resistor. Press NO to continue.
- Do not program this feature for UL Installations.

**Enable Telco Line Fault Test?**

- Press YES to enable Telco Line Fault Test.
- Press NO to continue. **NOTE: If enabled, a Telco Line Fault Test Delay of 60 sec. will automatically be programmed.**


**Enable Burg Output Chirp on KeyFob?**

- Press the NEXT/YES button to enable Burg Output Chirp on KeyFob Arm / Disarm.
- Press the PRIOR/NO button to continue.


**NOTE:** The Burg Output will chirp once on Keyfob Arm and twice on Keyfob Disarm.**Enable SIA CP-01 Features?**

- Press the NEXT/YES button to enable.
- Press the PRIOR/NO button to continue.















The SIA CP-01 Features are designed to reduce the incidence of false alarms. **NOTE:** Do not enable unless reporting, otherwise system trouble *Fail to Communicate* may occur.**Number of Keypads in Area 1**

- Enter the total number of Keypads to be installed in Area 1.
  - Valid entries are from 01 to 15. Directly enter the number of keypads, including leading zeros.
- Press  to save. Press the NEXT/YES button to proceed.

**Number of Keypads in Area 2**

- Enter the total number of Keypads to be installed in Area 2.
  - Valid entries are from 01 to 15. Directly enter the number of keypads, including leading zeros.
- Press  to save. Press the NEXT/YES button to proceed.

**Central Station Receiver 1 Telephone Number**






- Enter telephone number of up to 16 digits.
- Press  through  for digits 1–9;   for a zero and  for a blank (\*).
- Press   through   for letters B–F, respectively.
- Pre-Dial Delay = "D" ( ); Dial-Tone Detection = "E" ( .
- Press  to save and press the NEXT/YES button to proceed.

**NOTE:** Central Station Receiver 2 and 3 Telephone Numbers must be entered in Direct Address Programming. See CS Receiver Options.



**Easy Programming of Auto download ID #'s and PC Preset Callback Numbers** (GEM-RP1CAe2 only)

For unattended PC Preset downloading, it is now possible to set the Auto download ID #'s and PC Preset Callback from the Keypad Easy Program Mode.

- At the field for CENTRAL PHONE #, program an "F" followed by the Auto Download ID # (2 digits) and then the Callback Telco # (up to 13 digits).
- Press  to save.
- Exit Program Mode ( ).
- Enter Master Code
- Press 
- Go to Function "ACTIVATE DOWNLOAD Y/N" and press YES ().
- The panel will automatically call the PC Preset computer and download the program on the specified Auto Download line # of PC Preset.

CENTRAL PHONE #  
F0715168429400

Example: Program an Auto download ID # of 07 and a PC Preset Callback # of 1-516-842-9400






- Go to Central Phone # input screen and press: [\*] [5] [0] [7] [1] [5] [1] [6] [8] [4] [2] [9] [4] [0] [0] [ON/OFF]

Acc #

{ \_ \_ \_ }

(Direct Entry)

**Central Station Receiver 1 Account Number**

- Enter an account number of up to four digits.
- Press  through  for digits 0–9, and   for a blank (\*).
- Press  to save and press the NEXT/YES button to proceed.










**NOTE:** Central Station Receiver 2 and 3 Account Numbers must be entered in Direct Address Programming. See CS Reporting Options.

RecFmt

( \_ )

(Direct Entry)

**Central Station Receiver 1 Format**

- From the table at the right enter the receiver format.
- Press  through , and   for blank (\*).
- Press   through   for letters B–E.
- Press  to save and press the NEXT/YES button to proceed.

DATA ENTRY	CS RECEIVER 1 FORMAT
blank(*)	Ademco Slow, Silent Knight Slow
1	Sescoa, Vertex, DCI, Franklin Fast
2	Radionics Fast
3	Silent Knight Fast
4	Radionics, DCI, Franklin Slow
5	Universal High Speed
8	Radionics BFSK

DATA ENTRY	CS RECEIVER 1 FORMAT
9	FBI 4/3/1
0	Radionics Modem 2
B	SIA
C	Ademco Point ID
D	Ademco Express
E	Pager

**NOTE:** Modem IIe is available only in Direct Address Programming. Central Station Receiver 2 and 3 Formats can only be entered in Direct Address Programming. See CS Receiver Options.

User01

-----

(Direct Entry)

OPT\_

(Direct Entry)

ACC \_

(Direct Entry)

### Enter User Codes (Press the **MENU** button to set cursor.)

Enter up to 96 User Codes with User Options, Authority Level and Access Control Options (if necessary) for each code. Refer to the tables below and on the next page for available data entries for User Options, Authority Level and Access Control Options. **Note:** All 96 Users must be assigned to areas in "Enable User Code by Area" (Address 2500-2595) in Direct Address Programming. By default, only User 1 is enabled in Area 1 and Area 2. User 2 - 8 are enabled in Area 1 and user 9 - 16 are enabled in Area 2.

Press the **MENU** button to set the cursor to the User Code. Use the number buttons **1** through **9P** to enter a code from 3 to 6 digits. Enter up to 6 digits in the first six boxes from left to right for each user code. Valid entries are: 0-9. **Note:** Press the **0** button for a zero. No blank spaces in between; leave blank (\*) any trailing boxes. If an "Ambush Code" (Address 0495) is entered, *do not* program the first two digits of ANY User Code as the same digits entered for the "Ambush Code".

- If the programmed code is less than 6 digits, press the **MENU** button to set the cursor to the OPTION/LEVEL.
- Refer to the tables below for the available User Option and User Level data entries. Enter the user options data in the left digit. Enter the level data (with arming options, if any, added) in the right digit. **Note:** For entries greater than 9, press the **\*** **1** buttons through the **\*** **5** buttons for B through F, respectively.
- For Keypad Access Control, press the **MENU** button once again to program applicable keypads. Refer to the tables below, use the number buttons to enter the data for Keypad 1-4 in the right digit; and the data for Keypad 5-8 data in the left digit. (Press the **0** buttons for blank).

Example: Enter a code of "123456" as "123456" (from left to right).

USER OPTIONS			
USER CODE (UP TO 6 DIGITS)	USER OPTION	USER LEVEL	ACCESS CONTROL KEYPADS

USER OPTIONS				
DATA ENTRIES	BLOCKED VIEW	USER PROGRAM	BYPASS	OVERVIEW
blank (*)	DISABLED			
1	Y			
2		Y		
3	Y	Y		
4			Y	
5	Y		Y	
6		Y	Y	
7	Y	Y	Y	
8				Y
9	Y			Y
0		Y		Y
B	Y	Y		Y
C			Y	Y
D	Y		Y	Y
E		Y	Y	Y
F	Y	Y	Y	Y

**Note:** "Y" indicates option is enabled.

DATA ENTRIES	AUTHORITY LEVEL	CODE TYPE
blank (*)	NONE	ARM/DISARM
1	LEVEL 1	ARM/DISARM
2	LEVEL 2	ARM/DISARM
3	LEVEL 3	ARM/DISARM
4	NONE	ARM ONLY
5	LEVEL 1	ARM ONLY
6	LEVEL 2	ARM ONLY
7	LEVEL 3	ARM ONLY
8	NONE	SERVICE
9	LEVEL 1	SERVICE
0	LEVEL 2	SERVICE
B	LEVEL 3	SERVICE

ACCESS CONTROL KEYPADS				
DATA ENTRIES	K.P. 5	K.P. 6	K.P. 7	K.P. 8
blank (*)	NONE			
1	Y			
2		Y		
3	Y	Y		
4			Y	
5	Y		Y	
6		Y	Y	
7	Y	Y	Y	
8				Y
9	Y			Y
0		Y		Y
B	Y	Y		Y
C			Y	Y
D	Y		Y	Y
E		Y	Y	Y
F	Y	Y	Y	Y

**Note:** "Y" indicates option is enabled.

ACCESS CONTROL KEYPADS				
DATA ENTRIES	K.P. 1	K.P. 2	K.P. 3	K.P. 4
blank (*)	NONE			
1	Y			
2		Y		
3	Y	Y		
4			Y	
5	Y		Y	
6		Y	Y	
7	Y	Y	Y	
8				Y
9	Y			Y
0		Y		Y
B	Y	Y		Y
C			Y	Y
D	Y		Y	Y
E		Y	Y	Y
F	Y	Y	Y	Y

**Note:** "Y" indicates option is enabled.



USER AUTHORITY LEVEL	
KEYPAD DISPLAY FUNCTION MENU	
FUNCTION	LEVEL*
DISPLAY ZN FAULTS	1
DISPLAY ZN BYPASSED	1
DISPLAY ZN DIRECTORY	1
ACTIVATE BELL TEST	1
DISPLAY PHONE #'S	1
DISPLAY SYS TRBL	1
DISPLAY FIRE ALARM	1
DISPLAY FIRE TRBL	1
DISPLAY OP/CL	3
ACTIVATE OVERVIEW	3**
ACTIVATE CHIME	1
ACTIVATE WATCH	2
RESET SYSTEM TRBL	3
RESET SENSOR MSG	3
START EXIT TIME	1
FAULT FIND	***
ACTIVATE LOCATE	***
EZM ZONE FIND	***
ACTIVATE DIALER TEST	3
DISPLAY ALARM LOG	3
DISPLAY TOTAL LOG	3
DISPLAY FIRE LOG	3
DISPLAY OP/CL LOG	3
DISPLAY SYSTEM LOG	3
AUTOARM IN 1-4HRS	2
DISPLAY AUTOARM SCHD	3
ACTIVATE PROGRAM	3**
ACTIVATE DOWNLOAD	3
DISPLY RF XMITTER STAT	1
RELAY CONTROL	1



**NOTES:**

- \* Minimum Level required to access function  
 \*\* Level-3 Code with appropriate user option  
 \*\*\* Requires Dealer Code

USER OPTIONS	
OPTIONS	EXPLANATION
Disabled	User Code not active in this area.
Blocked View	Allows User Code to block another code from being viewed by another user. An unblocked code cannot view a blocked code, but a blocked code can view all codes. The master user code and the dealer program code can view all codes.
User Program	User Program Option is enabled for Keypad 1 only, wherever it is connected (any area). If enabled, Level 3 must also be enabled.
Bypass	Allows User Code to bypass zones.
Overview	This option, along with Level 3 Authorization, enables selection of OVERVIEW mode at a keypad. This Mode provides a system status display of all areas at a glance.
Arm Only	Prevents User Code from disarming this area.
Service	A Service Code has restricted arm/disarm rights; if an area is armed with a Service Code, a "SERVICE ON" appears on the GEM-RP2ASe2 keypad (a "5" on the GEM-RP1CAe2 keypad) and the area can be disarmed with any valid User Code, including a Service Code. If the area is armed with OTHER than a Service Code, it CANNOT be disarmed with a Service Code. This is typically used to allow tradesmen access to premises under control of the owner.
Ambush	Allows User Code to send Ambush signal to Central Station.
Access	This is normally used to activate a door striker while an area is disarmed. A code with the access option will not function as an arm/disarm code. When the code is entered, the keypad will display "ENTER NOW" and the Brown Wire on the keypad will become Active Low (Ground Potential) for 7 seconds.

**Related User Options:** "Ambush Code" (Address 0495), "Panel Access Code" (Address 0490), "Dealer Security Code" (Address 0500) & "Enable User Code by Area" (Address 2500-2595).

**Example:** Program a code of "2222" for user 02, with User Option of "User Program", User "Level 3" and Access Control Option "Keypad No. 1". Enter "2222" for a user code, "2 3" for user option and "blank(•) 1" for access control option.

**CHANGING OR CANCELING A CODE:** To change any code, merely program over the existing code as described above and press  to save. Similarly, to cancel a code, blank out each number of the code and press  to save to save.

Zn# 01

000000

(Direct Entry)

:0 Pt

(Direct Entry)

\* 5

**RF Transmitter Points** (Press **MENU** to set cursor.)

For each transmitter enter: (For wireless systems only. Also see Quick Method, which follows)

- The **zone number** (01–96) to which the transmitter will be mapped.
- The **6-digit RF ID #** and **1-digit checksum number** printed on the transmitter and box,
- The **point number** (1–2); enter "9" for unsupervised (all points).
- Press **ENTER** to save and NEXT/YES button to proceed when all transmitters have been entered.

**NOTE:** When programming the ID Code number, "0" through "9" = **0** through **9P**; A = **\*** **0**; B = **\*** **1**; C = **\*** **2**; D = **\*** **3**; E = **\*** **4** and "F" =

ZN# XMIT#+CS P

Zn01- 000000:0-0

ZN# XMIT#+CS P

ZN01- ENROLL:A--

**Quick Method.** If a receiver is already installed in the panel, transmitter wireless points can be programmed automatically ("enrolled") using the following procedure. **NOTE:** The transmitter point will be enrolled only if the signal strength is 3 or greater.

1. Enter the zone number to which the transmitter point will be mapped.
2. Press **BYPASS** to enter the Enroll Mode. The red and green LEDs on the keypad will flash and the window will display as shown at left.
3. Open the loop of the point that is to be programmed (GEM-TRANS2 only).
4. Install the transmitter battery. The keypad will beep to indicate that the point has been successfully enrolled. Multi-point transmitters can be mapped to successive zones simultaneously.

*Example. A 2-point transmitter has the RF ID number 287613:1. Map point 1 to Zone 6 and point 2 to Zone 9.*

1. Enter the Enroll mode as described above.
2. Enter Zone "06".
3. Open point-1 loop.
4. Install the battery. The keypad will beep once to indicate that one point has been programmed. (Transmitter 287613:1, point 1 will be mapped

to Zone 6).

5. Enter Zone "09".

6. Close point-1 loop and open point-2 loop.

7. Remove the transmitter battery, then re-install it. The keypad will beep once to indicate that one point has been programmed. (Transmitter 287613:1, point 2 is mapped to Zone 9).

**KEY FOB ZONE ASSIGNMENT:** Key fobs can also be assigned to zones to allow multiple wireless panic buttons on one alarm system, each reporting to a central station, a pager or having a description on the keypad that describes the person holding the key fob, the location where the person holding the key fob is stationed, or the special purpose of the key fob button being depressed. See the next page on Key Fob Transmitters as Zone Input Devices.

KFob01

Area

(Direct Entry)

000000

(Direct Entry)

:0 0 0

(Direct Entry)

**Key Fob Transmitters as Arm/Disarm & Control Devices** (Press **MENU** to set cursor.)

Key fobs can be programmed as "Arm/Disarm" devices using their On/Off buttons (refer to WI752). For each Key Fob Transmitter, enter:

- The **Key Fob Transmitter number** (01–16).
- The **area number** to which transmitter is assigned (0 to disable keyfob, 1 or 2).
- The **6-digit RF ID #** and **1-digit checksum number** printed on the transmitter and box,
- The **Aux 1 Option** (see key fob aux 1 & aux 2 options).
- The **Aux 2 Option** (see key fob aux 1 & aux 2 options).
- Press **ENTER** to save and NEXT/YES button to proceed when all key fobs have been entered.

**NOTE:** When programming the ID Code number, "0" through "9" = **0** through **9P**; A = **\*** **0**; B = **\*** **1**; C = **\*** **2**; D = **\*** **3**; E = **\*** **4** and "F" = **\*** **5**.



### Key Fob Transmitters as Zone Input Devices

(Refer to display above: press the PRIOR button to go backwards).

Each of the 4 key fob buttons can be assigned to a zone. For example, On button = point 1; Off button = point 2; A1 = point 3; A2 = point 4. Up to 96 key fobs (using 1 button) or 48 key fobs (using 2 buttons) or 28 key fobs (using all 4 buttons) or any combination up to a maximum of 96 controlled zones can be assigned, providing multiple wireless panic buttons on a system, each reporting to a Central Station or a pager and/or annunciating on a keypad the key fob zone number with a description. *To assign a key fob to a zone:* program the key fob as you would a transmitter, entering the key fob's ID code, check sum and point number at the appropriate zone. The "Quick Method" is not allowed. The zone may be hardwired to an electrical sensor as well as assigned to a key fob (either one will activate the zone alarm output). **NOTE:** If assigning a key fob to a zone, the "ON/OFF" buttons on the key fob will no longer arm/disarm the system. The key fob is converted to a "panic only" device.

DATA ENTRY	AUX 1/AUX 2 OPTIONS
0	None
1	Relay Group 1 Toggle
2	Relay Group 2 Toggle
3	Relay Group 3 Toggle
4	Relay Group 4 Toggle
5	Relay Group 5 Toggle
6	Relay Group 6 Toggle
7	Relay Group 7 Toggle
8	Relay Group 8 Toggle
9	Panic
A	Auxiliary
B	Instant
C	Aux. Output Toggle
D	Access on Aux. Output
E	Arm STAY
F	Interior Bypass

**ZONE DESCRIPTIONS:** GEM-RP2ASe2/GEM-K2AS cannot be used to enter Zone Descriptions. To enter Zone Descriptions, you must use the GEM-RP1CAe2/GEM-K1CA Keypad (See WI777) or the PCD-Windows Quickloader Software.

Enter Date  
( / / )

(Direct Entry)

**Enter Date** (Press **MENU** to set cursor).

- Enter the current date in the format MM/DD/YY. (MM = month, DD = day and YY = year.
- Press **ENTER** to save. Press the NEXT/YES button to proceed.

Enter Time  
( : )

(Direct Entry)

**Enter Time** (Press **MENU** to set cursor).

- Enter the current time in format HH:MMA/P, where HH=hours (01–12); MM=minutes (00–59).
- Select AM or PM by pressing any number button.
- Press **ENTER** to save. Press the NEXT/YES button to proceed.

Dealer Code  
456789

DEALER CODE  
RE-ENTER

**Dealer Code**

- Directly enter the Dealer Code (default = 456789), using **0** through **9 P** buttons.
- Press **ENTER** to save.
- Re-enter the Dealer Code to verify the previous code.
- Press **ENTER** to save.
- Press the NEXT/YES button to proceed.

**EXIT DEALER PROGRAM MODE:** This completes the custom default program. Press **RESET** to enter the Direct Address Program Mode for further programming or press **RESET** once again to end all programming and resume normal keypad operation.

**CLEAR PROGRAM:** Should it be necessary to create a new custom default program, (a) from the Dealer Program Mode, press **RESET** to enter the Address Program Mode; (b) access Location 4091 (Clear Program) or 1093 (Cold Start); (c) press **ENTER** and then (d) press **RESET** to exit the Dealer Program Mode. A "SYSTEM TROUBLE/EQ9-00 SERVICE" will occur. Press **RESET** to silence the keypad.

4091 XX H

**Clear Dealer Program (Erases Dealer Program)**

Use this feature to erase the Panel Program, while maintaining Scheduled Data and Zone Descriptions. Access address 4091 and press **ENTER**. Data entry is not allowed. **NOTE:** Enter Easy Menu Driven Program Mode to reprogram system.

4093 XX H



**Cold Start (Erases Entire Program)**

This erases all programmed data (Dealer Program, Zone Description Data and Schedules). Access address 4093 and press **ENTER**. Data entry is not allowed. **NOTE:** Some features (schedules) can only be programmed again with the Downloading Software.

## GEM-RP3DGTL/GEM-K3DGTL and GEM-RP4RFC/GEM-K4RF Keypad Easy Program Menu

To enter Dealer Program Mode, see page 5. Once entered, press **[MENU]**, followed by [PRIOR/NO] repeatedly until "17" is displayed (scroll back by pressing **[BYPASS]**). Press **[NEXT]** to enter Easy Program Mode. For the GEM-RP3DGTL/GEM-K3DGTL (and GEM-RP4RFC/GEM-K4RF), questions are in the form of a 2-digit number flashing in the display. Press **[MENU]** to set the cursor into the next field to answer the question. Press **[MENU]** again to scroll through each segment. Press **[NEXT]** to go to the next question. To review your Easy Program Mode responses (before pressing **[ ]** to save), press **[MENU]** until the 2-digit question number flashes in the display again. If the data is correct, press **[ ]** to save.



If the data is incorrect, press **[MENU]** to set the cursor into the next field and again enter your data. **Note:** Review your Easy Program Mode responses after the initial programming of the control, except for questions marked "For New Panel Only". These questions set up the basic structure of the panel program ("Number of Zones in an Area", etc.) and cannot be viewed or altered once set. To exit Dealer Program Mode, press **[RESET]** twice. To return the panel to the factory default, enter the Direct Address Program Mode, go to location 1198 and press **[ ]**.



(Direct Entry)

### Total Number of Zones in Area 1 (New Program Only)



- Enter the total number of zones to be programmed for Area 1.
- Valid entries are from 01 to 96. Directly enter the total number of zones, including leading zeros.
- The system is based on groups of 4 zones each (after the first 8 zones), and will automatically round up to the next group of 4. For example, if you enter 18, it will automatically convert this to 20 zones. Press **[ ]** to save. Press the NEXT/YES button to proceed.



(Direct Entry)

### Total Number of Zones in Area 2 (New Program Only)



- Programming Area 2 is identical to Area 1 above. Press the NEXT/YES button to proceed.



(Direct Entry)

### Fire Zones in Area 1 (New Program Only)

- Enter the zone number of any Fire Zones (including 2-wire, 4-wire or wireless).
- Valid entries are from 01 to 96.
- Directly enter each zone number, including leading zeros, and press **[ ]** to save, and then repeat for any additional zone(s). Press the NEXT/YES button to proceed.





(Direct Entry)

### 2-Wire Fire Zones in Area 1 (New Program Only)

- Enter the zone number of any Fire Zone (from previous question) to be used with 2-wire smoke detectors.
- Valid entries are 07 and 08. Directly enter each zone number, including leading zeros.
- Press **[ ]** to save, and repeat for any additional zone(s); press NEXT to proceed.



**NOTE:** Only zones which have been designated as Fire Zones can be programmed as 2 Wire Fire zones. JP3 must be set to "2-WF" position for 2-wire fire. (refer to Installation Instructions).



(Direct Entry)

### Local or Central Station Reporting System (New Program Only)

Press the NEXT/YES button for all zones to report; press the PRIOR/NO button for local system.



(Direct Entry)

### Exit/Entry Zones in Area 1 (New Program Only)

- Enter the zone numbers of zones to be used as Exit/Entry zones.
- Valid entries are from 01 to 96. Directly enter each zone number, including leading zeros.
- Press **[ ]** to save and repeat for any additional zone(s); press the NEXT/YES button to proceed.

**NOTE:** Exit/Entry time of 30 seconds will automatically be programmed.








(Direct Entry)





(Direct Entry)




(Direct Entry)



(Direct Entry)



(Direct Entry)



(Direct Entry)




(Direct Entry)




(Direct Entry)


**Interior Zones in Area 1 (New Program Only)**

- Enter the zone numbers to be used as Interior Zones.
- Valid entries are from 01 to 96. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s).
- Press the NEXT/YES button to proceed.
- All Interior zones will also be automatically programmed as "Exit/Entry Follower" and as "Power Up Delay" zones.


**24 Hour Zones in Area 1 (New Program Only)**

- Enter the zone numbers of zones to be used as 24 Hour zones.
- Valid entries are from 01 to 96. Directly enter each zone number, including leading zeros.
- Press  to save and repeat for any additional zone(s); press the NEXT/YES button to proceed.


**NOTE:** 24 Hour Zones will automatically be programmed as audible (Burg Output).**Chime Zones in Area 1 (New Program Only)**

- Enter the zone numbers which are to be used as Chime Zones.
- Valid entries are from 01 to 96. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), press the NEXT/YES button to proceed.


**NOTE:** A chime time of 2 seconds will be automatically programmed.**Chime 2 Zones in Area 1 (New Program Only)**

- Enter the zone numbers which are to be used as Chime 2 Zones.
- Valid entries are from 01 to 96. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), Press the NEXT/YES button to proceed.


**NOTE:** A chime time of 2 seconds will be automatically programmed.  
Chime 2 zones give a distinct pulsating tone when zone is faulted.**Exit/Entry2 Zones in Area 1 (New Program Only)**

- Enter the zone numbers of zones to be used as Exit/Entry zones.
- Valid entries are from 01 to 96. Directly enter each zone number, including leading zeros.
- Press  to save and repeat for any additional zone(s); press the NEXT/YES button to proceed.


**NOTE:** An Exit/Entry 2 Entry Time of 30 seconds will automatically be programmed.**50 mS Loop Response Zones (New Program Only)**

- Enter the zone numbers of zones to be have a 50mS loop response.
- Valid entries are from 01 to 08. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), Press the NEXT/YES button to proceed. **Note:** Only panel zones 01-08 can be programmed for Quick Loop Response. All other zones can be programmed via their respective EZM's (hardwire). **Note: 750mS is required for Loop Response time in UL installations.**

**Aux Output Activated on Alarm Zones (New Program Only)**

- Enter the zone numbers of zones to activate the PGM2 upon alarm.
- Valid entries are from 01 to 96. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), Press the NEXT/YES button to proceed.

**NOTE:** A PGM2 Timeout of 15 minutes will automatically be programmed.**Sensor Watch Zones (New Program Only)**

- Enter the zone numbers of zones to be Sensor Watch zones.
- Valid entries are from 01 to 96. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), Press the NEXT/YES button to proceed.

**NOTE:** A Sensor Watch Time of 24 hours will automatically be programmed.

16	○	○	○	○	○
INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME	

(Direct Entry)

17	○	○	○	○	○
INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME	

(Direct Entry)

18	○	○	○	○	○
INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME	

(Press YES or NO)

19	○	○	○	○	○
INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME	

(Press YES or NO)

20	○	○	○	○	○
INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME	

(Press YES or NO)

21	○	○	○	○	○
INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME	

(Press YES or NO)

22	○	○	○	○	○
INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME	

1	○	○	○	○	○
INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME	


(Direct Entry)

23	○	○	○	○	○
INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME	


1	○	○	○	○	○
INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME	

(Direct Entry)

### Keypad Sounder On Alarm Zones (New Program Only)

- Enter the zone numbers of all zones to activate the Keypad Sounder upon alarm.
- Valid entries are from 01 to 96. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), Press the NEXT/YES button to proceed.

### Auto Bypass Re-entry Zones (New Program Only) (Not evaluated by UL)

- Enter the zone numbers of zones to be Auto Bypass Re-entry zones.
- Valid entries are from 01 to 96. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), Press the NEXT/YES button to proceed.
- Auto Bypass Re-entry Zones allow the system to be armed with the zone faulted but come back into the system (armed) when the zone is subsequently closed.

### Enable No EOLR Zones (New Program Only)

- Press YES to program all zones except 24 Hr & fire zones for No End Of Line Resistor. Press NO to continue.
- Do not program this feature for UL Installations.

### Enable Telco Line Fault Test?

- Press YES to enable Telco Line Fault Test.
- Press NO to continue. **NOTE: If enabled, a Telco Line Fault Test Delay of 60 sec. will automatically be programmed.**


### Enable Burg Output Chirp on KeyFob?

- Press the NEXT/YES button to enable Burg Output Chirp on KeyFob Arm / Disarm.
  - Press the PRIOR/NO button to continue.
- NOTE:** The Burg Output will chirp once on Keyfob Arm and twice on Keyfob Disarm.


### Enable SIA CP-01 Features?

- Press the NEXT/YES button to enable.
  - Press the PRIOR/NO button to continue.
- The SIA CP-01 Features are designed to reduce the incidence of false alarms. **NOTE:** Do not enable unless reporting, otherwise system trouble *Fail to Communicate* may occur.

### Number of Keypads in Area 1

- Enter the total number of Keypads to be installed in Area 1.
  - Valid entries are from 01 to 15. Directly enter the number of keypads, including leading zeros.
- Press  to save. Press the NEXT/YES button to proceed.

### Number of Keypads in Area 2

- Enter the total number of Keypads to be installed in Area 2.
  - Valid entries are from 01 to 15. Directly enter the number of keypads, including leading zeros.
- Press  to save. Press the NEXT/YES button to proceed.





24

INTERIOR

BYPASS

FIRE/TBL

SYS TBL

CHIME

-

INTERIOR

BYPASS

FIRE/TBL

SYS TBL

CHIME

(Direct Entry)

### Central Station Receiver 1 Telephone Number

- Enter telephone number of up to 16 digits.
- Press  through  for digits 1–9;  for a zero and  for a blank (\*).
- Press   through   for letters B–F, respectively.
- Pre-Dial Delay = "D" ( ); Dial-Tone Detection = "E" ( ).
- Press  to save and press the NEXT/YES button to proceed.

**NOTE:** Central Station Receiver 2 and 3 Telephone Numbers must be entered in Direct Address Programming. See CS Receiver Options.

25

INTERIOR

BYPASS

FIRE/TBL

SYS TBL

CHIME

-

INTERIOR

BYPASS

FIRE/TBL

SYS TBL

CHIME

(Direct Entry)

### Central Station Receiver 1 Account Number

- Enter an account number of up to four digits.
- Press  through  for digits 0–9, and   for a blank (\*).
- Press  to save and press the NEXT/YES button to proceed.

**NOTE:** Central Station Receiver 2 and 3 Account Numbers must be entered in Direct Address Programming. See CS Reporting Options.

26

INTERIOR

BYPASS

FIRE/TBL

SYS TBL

CHIME

6

INTERIOR

BYPASS

FIRE/TBL

SYS TBL

CHIME

(Direct Entry)


### Central Station Receiver 1 Format

- From the table at the right enter the receiver format.
- Press  through , and   for blank (\*).
- Press   through   for letters B–E.
- Press  to save and press the NEXT/YES button to proceed.

DATA ENTRY	CS RECEIVER 1 FORMAT
blank(*)	Ademco Slow, Silent Knight Slow
1	Sescoa, Vertex, DCI, Franklin Fast
2	Radionics Fast
3	Silent Knight Fast
4	Radionics, DCI, Franklin Slow
5	Universal High Speed
8	Radionics BFSK

DATA ENTRY	CS RECEIVER 1 FORMAT
9	FBI 4/3/1
0	Radionics Modem 2
B	SIA
C	Ademco Point ID
D	Ademco Express
E	Pager

**NOTE:** Modem IIe is available only in Direct Address Programming. Central Station Receiver 2 and 3 Formats can only be entered in Direct Address Programming. See CS Receiver Options.



### Enter User Codes (Press the **[MENU]** button to set cursor.)

Enter up to 96 User Codes with User Options, Authority Level and Access Control Options (if necessary) for each code. Refer to the tables below and on the next page for available data entries for User Options, Authority Level and Access Control Options. **Note:** All 96 Users must be assigned to areas in "Enable User Code by Area" (Address 2500-2595) in Direct Address Programming. By default, only User 1 is enabled in Area 1 and Area 2.

User 2 - 8 are enabled in Area 1 and user 9 - 16 are enabled in Area 2.

Press the **[MENU]** button to set the cursor to the User Code. Use the number buttons **[1]** through **[9P]** to enter a code from 3 to 6 digits. Enter up to 6 digits (4 digits is recommended) in the first six boxes from left to right for each user code.

Valid entries are: 0-9. **Note:** Press the **[0]** button for a zero. No blank spaces in between; leave blank (•) any trailing boxes. If an "Ambush Code" (Address 0495) is entered, *do not* program the first two digits of ANY User Code as the same digits entered for the "Ambush Code".

If the programmed code is less than 6 digits, press the **[MENU]** button to set the cursor to the OPTION/LEVEL.

Refer to the tables below for the available User Option and User Level data entries. Enter the user options data in the left digit. Enter the level data (with arming options, if any, added) in the right digit. **Note:** For entries greater than 9, press the **[\*]** **[1]** buttons through the **[\*]** **[5]** buttons for B through F, respectively.

For Keypad Access Control, press the **[MENU]** button once again to program applicable keypads. Refer to the tables below, use the number buttons to enter the data for Keypad 1-4 in the right digit; and the data for Keypad 5-8 data in the left digit. (Press the **[0]** buttons for blank).

Example: Enter a code of "123456" as "123456" (from left to right).

USER OPTIONS			
USER CODE (UP TO 6 DIGITS)	USER OPTION	USER LEVEL	ACCESS CONTROL KEYPADS
1 2 3 4 5 6			

USER OPTIONS				
DATA ENTRIES	BLOCKED VIEW	USER PROGRAM	BYPASS	OVERVIEW
blank (•)	DISABLED			
1	Y			
2		Y		
3	Y	Y		
4			Y	
5	Y		Y	
6		Y	Y	
7	Y	Y	Y	
8				Y
9	Y			Y
0		Y		Y
B	Y	Y		Y
C			Y	Y
D	Y		Y	Y
E		Y	Y	Y
F	Y	Y	Y	Y

**Note:** "Y" indicates option is enabled.

DATA ENTRIES	AUTHORITY LEVEL	CODE TYPE
blank (•)	NONE	ARM/DISARM
1	LEVEL 1	ARM/DISARM
2	LEVEL 2	ARM/DISARM
3	LEVEL 3	ARM/DISARM
4	NONE	ARM ONLY
5	LEVEL 1	ARM ONLY
6	LEVEL 2	ARM ONLY
7	LEVEL 3	ARM ONLY
8	NONE	SERVICE
9	LEVEL 1	SERVICE
0	LEVEL 2	SERVICE
B	LEVEL 3	SERVICE

ACCESS CONTROL KEYPADS				
DATA ENTRIES	K.P. 5	K.P. 6	K.P. 7	K.P. 8
blank (•)	NONE			
1	Y			
2		Y		
3	Y	Y		
4			Y	
5	Y		Y	
6		Y	Y	
7	Y	Y	Y	
8				Y
9	Y			Y
0		Y		Y
B	Y	Y		Y
C			Y	Y
D	Y		Y	Y
E		Y	Y	Y
F	Y	Y	Y	Y

**Note:** "Y" indicates option is enabled.

ACCESS CONTROL KEYPADS				
DATA ENTRIES	K.P. 1	K.P. 2	K.P. 3	K.P. 4
blank (•)	NONE			
1	Y			
2		Y		
3	Y	Y		
4			Y	
5	Y		Y	
6		Y	Y	
7	Y	Y	Y	
8				Y
9	Y			Y
0		Y		Y
B	Y	Y		Y
C			Y	Y
D	Y		Y	Y
E		Y	Y	Y
F	Y	Y	Y	Y

**Note:** "Y" indicates option is enabled.



USER AUTHORITY LEVEL	
KEYPAD DISPLAY FUNCTION MENU	
FUNCTION	LEVEL*
DISPLAY ZN FAULTS	1
DISPLAY ZN BYPASSED	1
DISPLAY ZN DIRECTORY	1
ACTIVATE BELL TEST	1
DISPLAY PHONE #'S	1
DISPLAY SYS TRBL	1
DISPLAY FIRE ALARM	1
DISPLAY FIRE TRBL	1
DISPLAY OP/CL	3
ACTIVATE OVERVIEW	3**
ACTIVATE CHIME	1
ACTIVATE WATCH	2
RESET SYSTEM TRBL	3
RESET SENSOR MSG	3
START EXIT TIME	1
FAULT FIND	***
ACTIVATE LOCATE	***
EZM ZONE FIND	***
ACTIVATE DIALER TEST	3
DISPLAY ALARM LOG	3
DISPLAY TOTAL LOG	3
DISPLAY FIRE LOG	3
DISPLAY OP/CL LOG	3
DISPLAY SYSTEM LOG	3
AUTOARM IN 1-4HRS	2
DISPLAY AUTOARM SCHD	3
ACTIVATE PROGRAM	3**
ACTIVATE DOWNLOAD	3
DISPLY RF XMITTER STAT	1
RELAY CONTROL	1



**NOTES:**


- \* Minimum Level required to access function
- \*\* Level-3 Code with appropriate user option
- \*\*\* Requires Dealer Code

USER OPTIONS	
OPTIONS	EXPLANATION
Disabled	User Code not active in this area.
Blocked View	Allows User Code to block another code from being viewed by another user. An unblocked code cannot view a blocked code, but a blocked code can view all codes. The master user code and the dealer program code can view all codes.
User Program	User Program Option is enabled for Keypad 1 only, wherever it is connected (any area). If enabled, Level 3 must also be enabled.
Bypass	Allows User Code to bypass zones.
Overview	This option, along with Level 3 Authorization, enables selection of OVERVIEW mode at a keypad. This Mode provides a system status display of all areas at a glance.
Arm Only	Prevents User Code from disarming this area.
Service	A Service Code has restricted arm/disarm rights; if an area is armed with a Service Code, a "SERVICE ON" appears on the GEM-RP2ASe2 keypad (a "5" on the GEM-RP1CAe2 keypad) and the area can be disarmed with any valid User Code, including a Service Code. If the area is armed with OTHER than a Service Code, it CANNOT be disarmed with a Service Code. This is typically used to allow tradesmen access to premises under control of the owner.
Ambush	Allows User Code to send Ambush signal to Central Station.
Access	This is normally used to activate a door striker while an area is disarmed. A code with the access option will not function as an arm/disarm code. When the code is entered, the keypad will display "ENTER NOW" and the Brown Wire on the keypad will become Active Low (Ground Potential) for 7 seconds.

**Related User Options:** "Ambush Code" (Address 0495), "Panel Access Code" (Address 0490), "Dealer Security Code" (Address 0500) & "Enable User Code by Area" (Address 2500-2595).

**Example:** Program a code of "2222" for user 02, with User Option of "User Program", User "Level 3" and Access Control Option "Keypad No. 1". Enter "2222" for a user code, "2 3" for user option and "blank(•) 1" for access control option.

**CHANGING OR CANCELING A CODE:** To change any code, merely program over the existing code as described above and press  to save. Similarly, to cancel a code, blank out each number of the code and press  to save to save.



### RF Transmitter Points (Press **MENU** to set cursor.)

For each transmitter enter: (For wireless systems only. Also see Quick Method, which follows)

- The **zone number** (01–96) to which the transmitter will be mapped.
- The **6-digit RF ID #** and **1-digit checksum number** printed on the transmitter and box,
- The **point number** (1–2); enter “9” for unsupervised (all points).
- Press **ENTER** to save and NEXT/YES button to proceed when all transmitters have been entered.

**NOTE:** When programming the ID Code number, “0” through “9” = **0** through **9 P**; A =

**\*** **0** ; B = **\*** **1** ; C = **\*** **2** ; D = **\*** **3** ; E = **\*** **4** and “F” = **\*** **5** .

**Quick Method.** If a receiver is already installed in the panel, transmitter wireless points can be programmed automatically (“enrolled”) using the following procedure. **NOTE:** The transmitter point will be enrolled only if the signal strength is 3 or greater.

ZN# XMIT#+CS P  
Zn01- 000000:0-0


1. Enter the zone number to which the transmitter point will be mapped.
2. Press **BYPASS** to enter the Enroll Mode. The red and green LEDs on the keypad will flash and the window will display as shown at left.
3. Open the loop of the point that is to be programmed (GEM-TRANS2 only).
4. Install the transmitter battery. The keypad will beep to indicate that the point has been successfully enrolled. Multi-point transmitters can be mapped to successive zones simultaneously.

ZN# XMIT#+CS P  
Zn01- ENROLL:A--

**Example.** A 2-point transmitter has the RF ID number 287613:1. Map point 1 to Zone 6 and point 2 to Zone 9.

1. Enter the Enroll mode as described above.
2. Enter Zone “06”.
3. Open point-1 loop.
4. Install the battery. The keypad will beep once to indicate that one point has been programmed. (Transmitter 287613:1, point 1 will be mapped
5. Enter Zone “09”.
6. Close point-1 loop and open point-2 loop.
7. Remove the transmitter battery, then re-install it. The keypad will beep once to indicate that one point has been programmed. (Transmitter 287613:1, point 2 is mapped to Zone 9).

**KEY FOB ZONE ASSIGNMENT:** Key fobs can also be assigned to zones to allow multiple wireless panic buttons on one alarm system, each reporting to a central station, a pager or having a description on the keypad that describes the person holding the key fob, the location where the person holding the key fob is stationed, or the special purpose of the key fob button being depressed. See the next page on Key Fob Transmitters as Zone Input Devices .



### Key Fob Transmitters as Arm/Disarm & Control Devices (Press **MENU** to set cursor.)

Key fobs can be programmed as “Arm/Disarm” devices using their On/Off buttons (refer to WI752).

For each Key Fob Transmitter, enter:

- The **Key Fob Transmitter number** (01–16).
- The **area number** to which transmitter is assigned (0 to disable keyfob, 1 or 2).
- The **6-digit RF ID #** and **1-digit checksum number** printed on the transmitter and box,
- The **Aux 1 Option** (see key fob aux 1 & aux 2 options).
- The **Aux 2 Option** (see key fob aux 1 & aux 2 options).

- Press **ENTER** to save and NEXT/YES button to proceed when all key fobs have been entered.

**NOTE:** When programming the ID Code number, “0” through “9” = **0** through **9 P**; A = **\*** **0** ; B = **\*** **1** ;

C = **\*** **2** ; D = **\*** **3** ; E = **\*** **4** and “F” = **\*** **5** .





**Key Fob Transmitters as Zone Input Devices**

(Refer to display above: press the **PRIOR** button to go backwards).

Each of the 4 key fob buttons can be assigned to a zone. For example, On button = point 1; Off button = point 2; A1 = point 3; A2 = point 4. Up to 96 key fobs (using 1 button) or 48 key fobs (using 2 buttons) or 28 key fobs (using all 4 buttons) or any combination up to a maximum of 96 controlled zones can be assigned, providing multiple wireless panic buttons on a system, each reporting to a Central Station or a pager and/or annunciating on a keypad the key fob zone number with a description. *To assign a key fob to a zone:* program the key fob as you would a transmitter, entering the key fob's ID code, check sum and point number at the appropriate zone. The "Quick Method" is not allowed. The zone may be hardwired to an electrical sensor as well as assigned to a key fob (either one will activate the zone alarm output). **NOTE:** If assigning a key fob to a zone, the "ON/OFF" buttons on the key fob will no longer arm/disarm the system. The key fob is converted to a "panic only" device.





DATA ENTRY	AUX 1/AUX 2 OPTIONS
0	None
1	Relay Group 1 Toggle
2	Relay Group 2 Toggle
3	Relay Group 3 Toggle
4	Relay Group 4 Toggle
5	Relay Group 5 Toggle
6	Relay Group 6 Toggle
7	Relay Group 7 Toggle
8	Relay Group 8 Toggle
9	Panic
A	Auxiliary
B	Instant
C	Aux. Output Toggle
D	Access on Aux. Output
E	Arm STAY
F	Interior Bypass



**ZONE DESCRIPTIONS:** GEM-RP2ASe2/GEM-K2AS cannot be used to enter the date or time or Zone Descriptions. To enter this information, you must use the GEM-RP1CAe2 or GEM-K1CA Keypad (See WI777) or the Napco Quickloader Software.







(Direct Entry)


**Dealer Code**

- Directly enter the Dealer Code (default = 456789), using  through  buttons.
- Press  to save.
- Re-enter the Dealer Code to verify the previous code.
- Press  to save.
- Press the NEXT/YES button to proceed.


**EXIT DEALER PROGRAM MODE:** This completes the custom default program. Press  to enter the Direct Address Program Mode for further programming or press  once again to end all programming and resume normal keypad operation.


**CLEAR PROGRAM:** Should it be necessary to create a new custom default program, (a) from the Dealer Program Mode, press  to enter the Address Program Mode; (b) access Location 4091 (Clear Program) or 4093 (Cold Start); (c) press  and then (d) press  to exit the Dealer Program Mode. A "SYSTEM TROUBLE/EO9-00 SERVICE" will occur. Press  to silence the keypad.

**Clear Dealer Program (Erases Dealer Program)**

Use this feature to erase the Panel Program, while maintaining Scheduled Data and Zone Descriptions. Access address 4091 and press . Data entry is not allowed. **NOTE:** Enter Easy Menu Driven Program Mode to reprogram system.

**Cold Start (Erases Entire Program)**

This erases all programmed data (Dealer Program, Zone Description Data and Schedules). Access address 4093 and press . Data entry is not allowed. **NOTE:** Some features (schedules) can only be programmed again with the Downloading Software.



## DIRECT ADDRESS PROGRAM MODE

This is an extension of the Dealer Program Mode. This method of programming is used in conjunction with the Keypad Programming Worksheets that follow. Refer to these worksheets to identify the 4-digit location (address) of the feature to be programmed. An illustrative example is provided on the next page.

ADDRESS LOCATIONS	DATA ENTRY LOCATIONS	
	LEFT DIGIT	RIGHT DIGIT
0000	3	C

Diagram illustrating the relationship between Address Locations and Data Entry Locations:

- The Address Locations are 0000 to 4095.
- The Data Entry Locations are defined by the Left Digit (3) and the Right Digit (C).
- The diagram shows that the Address Location 0000 corresponds to the Data Entry Location 3 (Left Digit) and C (Right Digit).





**HEXADECIMAL DATA:**


- BLANK (•) = No Options
- 1 to 9 = Entries 1 to 9
- 0 = Entry of 10
- B to F = Entries 11 to 15

## KEYPAD PROGRAMMING OVERVIEW


Direct Address Programming allows you to go directly to the address locations and change the data entries to customize your control panel options. Whereas the Easy Menu Program Mode is a simple quick start guide with limited options, the Direct Address Program Mode is more flexible allowing you to change all the options. It consists of multiple address locations with two data entry locations each (left and right) as shown in the adjacent diagram.

## ACCESSING DIRECT ADDRESS PROGRAM MODE


1. Press  Master Security Code  
(on microshield)
2. Press the **PRIOR/NO** () button until:  
"TURNON PROG Y/N" (GEM-RP2ASe2/GEM-K2AS)  
--or--  
"17" (GEM-RP3DGTL/GEM-K3DGTL or GEM-RP4RFC/GEM-K4RF) appears on the keypad display.
3. Press the **NEXT/YES** () button to enter Dealer Program Mode.  
(The panel and keypad version appears briefly on the keypad display).
4. Press  to exit Easy Menu Driven Program Mode & enter Direct Address Program Mode.  
(For keypad display examples when in Program Mode, see next page).



## KEYPAD ADDRESS PROGRAM MODE DISPLAY




GEM-RP2ASe2/GEM-K2AS Keypads



GEM-RP3DGTL/GEM-K3DGTL Keypads

Press **MENU** followed by (1) the 4 digit address location, and (2) the corresponding data shown.



GEM-RP4RFC/GEM-K4RF Keypads

Press **MENU** followed by (1) the 4 digit address location, and (2) the corresponding data shown. **Note:** A long beep sounds when in Address Program Mode.

① = ADDRESS LOCATION      ② = DATA ENTRY LOCATION (Left and Right Digits)

## DIRECT ADDRESS PROGRAM MODE KEYPAD COMMANDS

### A. GEM-K2AS (and GEM-RP2ASe2) Keypad

To access, press **RESET** in Dealer Program Mode

1. Toggle Cursor to 4-digit address field using the **MENU** button.
2. Enter address Number directly using number buttons (0-9).
3. Enter Data directly using number buttons.\*
4. Press the **ENTER** button to save.

To exit, press **RESET**.

**NOTE:** Press **0** button to clear character at cursor. \_\_\_\_\_

Select NEXT/PRIOR Address. \_\_\_\_\_


Press **\* STAY** to jump to next programming block.

\* Press **\* 0** through **\* 5** for 10-15, respectively.

## B. GEM-K3DGTL/GEM-RP3DGTL and GEM-RP4RFC/GEM-K4RF Keypads

To access Direct Address Program Mode, press **[RESET]** in the Easy Menu Mode.

1. Press **[MENU]**.
2. Enter the 4 digit Address location directly using number buttons (0-9).
3. Enter the 2 digit data directly using number buttons (0-9).
4. Press **[ENTER]** to save.  
To exit, press **[RESET]**.



**NOTE:** "A" = **[\*]** **[0]**; "B" = **[\*]** **[1]**; "C" = **[\*]** **[2]**; "D" = **[\*]** **[3]**; "E" = **[\*]** **[4]**; "F" = **[\*]** **[5]**. Press **[0]** for a zero or to clear.

**Example: GEM-RP2ASe2 / GEM-RP3DGTL / GEM-RP4RFC--Direct Address Programming**  
Program Zones 6, 7 and 8 as Exit/Entry Follower Zones.

### DETERMINE THE DATA ENTRIES

1. Referring to ZONE FEATURES in the Programming Worksheets that follow, Exit/Entry Follower for Zones 5 through 8 are located at address 0506, left digit. Circle the data values for Zones 5–8.
2. Add the data values for Zones 6, 7 and 8:  $2+4+8=14$ . From Tables 1 and 2, "14" (E) is entered as press **[\*]** **[4]**. The right digit (for Zones 1 through 4, none of which are Exit/Entry Follower Zones) is entered as a blank (\*).

ZONE OPTION	ZONES LEFT DATA VALUES SUM = 14 (CIRCLE)				ADDRESS 0506			ZONES RIGHT DATA VALUES SUM = 0 (CIRCLE)			
	ZN08	ZN07	ZN06	ZN05	L	ADDR	R	ZN04	ZN03	ZN02	ZN01
EXIT/ENTRY FOLLOWER	⑧	④	②	1	E	0506	BLANK (*)	8	4	2	1


ENTER DATA

### PROGRAM THE DATA ENTRIES


1. Enter the panel's Dealer Security Code (Address 0500), then press **[MENU]**.
2. Answer NO (**[INSTANT]**) to all questions until "ACTIVATE PROGRAM Y/N" is displayed; then press the NEXT/YES button.  
**NOTE:** If you pass "ACTIVATE PROGRAM", scroll backward using **[BYPASS]**.
3. Press **[RESET]** to enter the Address Program Mode. Address "0000" will display.
4. Press **[0]** **[5]** **[0]** **[6]** to access Address 0506. The data for both digits will display and the cursor will advance to the data field.
5. Press **[\*]** **[4]** to enter an "E" in the left digit and press **[0]** to enter a blank (\*) in the right digit.
6. Press **[ENTER]** to save. Address 0506 is now programmed with "E \*".
7. Enter another 4-digit address to continue programming or press **[RESET]** to exit and resume normal keypad operation.




The displays shown on the previous pages will appear after a brief delay.

 Use **MENU** to toggle the cursor between the 4-digit address field and the data entry locations.

 Enter the address directly using the number buttons.

 The contents of the address will be read automatically, along with the feature name and programming information. The cursor will advance to the data field. Enter the required data directly using the number buttons.

 Press **ENTER** to save the contents of each address.

**EXIT DIRECT ADDRESS PROGRAM MODE:** When done, press **RESET** to exit and resume normal keypad operation.





## CONVENTIONS USED IN THIS MANUAL

The Keypad Programming Worksheets in the back are provided as an address-programming reference to help the installer modify his custom default program or to make minor field alterations to an existing panel program. It is recommended that the panel be uploaded to NAPCO's PCD-Windows software following any keypad programming and that the PCD3000's error-check feature be utilized to reduce the possibility of programming omissions or conflicts.



**Note:** Most of the addresses shown comprise two data entry locations, left and right digits. Program the left digits on the left data-display segment, and the right digit on the right segment. For those addresses having only one programmable nibble, program the right segment only; the left segment should display a blank (•).

Keep the Keypad Programming Worksheets on file for future reference.

### General Programming Steps

-  1. Contact the central station to ascertain receiver format, data format, event codes, subscriber numbers and telephone number(s).
-  2. Select the desired features by circling  the respective "address" boxes. Refer to the Programming Options and Worksheets for guidance in selecting the "data" (1,2,4,8) to be entered into those boxes.
-  3. Program the data entered in the boxes on the worksheets into the respective addresses. The display will show the entry numerically, but will display "0" for the number 10, and letters "B", "C", "D", "E", and "F" for the numbers 11 through 15, respectively. To program a 10, press **\*** **0**. To program 11 through 15, press **\*** **1** through **\*** **5**, respectively.

**NOTE:** See the Direct Address Programming Example on the previous page.

DATA ENTRY SELECTIONS (BINARY VALUE CIRCLED) 				ENTRY TOTAL	PRESS 	KEYPAD DISPLAYS
8	4	2	1	blank	<b>0</b>	•
8	4	2	①	1	<b>1</b>	1
8	4	②	1	2	<b>2</b>	2
8	4	②	①	3	<b>3</b>	3
8	④	2	1	4	<b>4</b>	4
8	④	2	①	5	<b>5</b>	5
8	④	②	1	6	<b>6</b>	6
8	④	②	①	7	<b>7F</b>	7
⑧	4	2	1	8	<b>8A</b>	8
⑧	4	2	①	9	<b>9P</b>	9
⑧	4	②	1	10	<b>*</b> <b>0</b>	0
⑧	4	②	①	11	<b>*</b> <b>1</b>	B
⑧	④	2	1	12	<b>*</b> <b>2</b>	C
⑧	④	2	①	13	<b>*</b> <b>3</b>	D
⑧	④	②	1	14	<b>*</b> <b>4</b>	E
⑧	④	②	①	15	<b>*</b> <b>5</b>	F

**Table 1** (above). Determining data entry for a location (each "nibble"). Numbers in parentheses indicate data for selected zones or features. (See Programming Worksheets that follow).

THIS PAGE INTENTIONALLY LEFT BLANK

# SYSTEM DELAYS & TIMEOUTS (ADDRESS 0000-0002, 2402, 2406, 2414 & 3902)

EXIT DELAY (sec.)	ADDRESS 0000	
	LEFT	RIGHT

[Default = 3C]

ENTRY DELAY 1 (sec.)	ADDRESS 0001	
	LEFT	RIGHT

[Default = 1E]

ENTRY DELAY 2 (sec.)	ADDRESS 0002	
	LEFT	RIGHT

[Default = 1 E]

Aux. Output Access Control Timeout (sec.)	ADDRESS 2402	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

ABORT DELAY (sec.)	ADDRESS 2406	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

Telephone Line Test Delay (sec.)	ADDRESS 2414	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

CS Telco 3 Report Delay (sec.)	ADDRESS 3902	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

DATA ENTRIES		
LEFT	RIGHT	DELAY/ TIMEOUT
blank (•)	blank (•)	0 sec.
blank (•)	F	15 sec.
1	E	30 sec.
2	D	45 sec.
3	C	60 sec.
5	0	90 sec.
7	8	120 sec.
↓	↓	↓
F	F	255 sec.

1. Select delay/timeout (0-255 sec.) from the table shown.

2. Enter in corresponding address locations above (left and right digits).

3. For a desired delay/timeout not listed do the following:

$$\begin{array}{r}
 \textcircled{1} \text{ Quotient} \longrightarrow \text{Left Digit} \\
 16 \overline{) 20} \\
 \underline{-16} \phantom{0} \\
 \textcircled{4} \text{ Remainder} \longrightarrow \text{Right Digit}
 \end{array}$$

A. Choose a desired delay/timeout, ex: 20 sec.

B. Divide it by 16

**EXIT/ENTRY DELAYS:** Apply only to zones programmed with the following options "Entry/Exit 1, Entry/Exit 2, Exit/Entry Follower". For UL Installations, the maximum exit delay is 60 seconds and the maximum entry delay is 45 seconds.



PROGRAMMING TIMEOUTS: Either use the tables provide or calculate your own timeout using the steps indicated. WARNING: Timers have uncertainty of +/-1sec, so a "time" of 1 second may actually timeout IMMEDIATELY.

# SYSTEM DELAYS & TIMEOUTS (ADDRESS 2407, 2408 & 4088)

CHIME TIMEOUT (1/4sec.)	ADDRESS 2407	
	LEFT	RIGHT

[Default = blank (•) 2]

AC Fail Report Delay (min.)	ADDRESS 2408	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

Sensor Watch Delay (Hr.)	ADDRESS 4088	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

CHIME TIMEOUT OPTIONS		
DATA ENTRIES	TIMEOUT	
LEFT	RIGHT	
blank (•)	blank (•)	0 1/4sec. = 0 sec.
blank (•)	2	2 1/4sec. = 1/2 sec.
blank (•)	3	3 1/4sec. = 3/4 sec.
blank (•)	4	4 1/4sec. = 1 sec.
blank (•)	5	5 1/4sec. = 1.25 sec.
blank (•)	6	6 1/4sec. = 1.5 sec.
blank (•)	7	7 1/4sec. = 1.75 sec.
blank (•)	8	8 1/4sec. = 2 sec.
↓	↓	↓
F	F	255 1/4sec. = 63.25 sec.

AC FAIL REPORT DELAY OPTIONS		
DATA ENTRIES	DELAY	
LEFT	RIGHT	
blank (•)	blank (•)	0 min.
blank (•)	1	10 min.
blank (•)	2	20 min.
blank (•)	3	30 min.
blank (•)	4	40 min.
blank (•)	5	50 min.
blank (•)	6	60 min.
blank (•)	7	70 min.
↓	↓	↓
F	F	2550 min. = 42 Hr., 30 min.

SENSOR WATCH OPTIONS		
DATA ENTRIES	DELAY	
LEFT	RIGHT	
blank (•)	blank (•)	0 Hr.
blank (•)	1	1 Hr.
blank (•)	2	2 Hr.
blank (•)	3	3 Hr.
blank (•)	4	4 Hr.
blank (•)	5	5 Hr.
blank (•)	6	6 Hr.
blank (•)	7	7 Hr.
↓	↓	↓
F	F	255 Hr.

1. Select delay/timeout from the table shown.

2. Enter in corresponding address locations above (left and right digits).

3. For a desired delay/timeout not listed do the following:

$$\begin{array}{r}
 \textcircled{1} \text{ Quotient} \longrightarrow \text{Left Digit} \\
 16 \overline{) 20} \\
 \underline{-16} \phantom{0} \\
 \textcircled{4} \text{ Remainder} \longrightarrow \text{Right Digit}
 \end{array}$$

A. Choose a desired delay/timeout, ex: 20. **Note:** For Sensor Watch only divide it by 10, ex: 20/10 = 2.

B. Divide it by 16

## SYSTEM DELAYS & TIMEOUTS (ADDRESS 2400, 2401, 2403-2405, 4082 & 4083)

Reset Output Timeout (min.)	ADDRESS 2400	
	LEFT	RIGHT

[Default = blank

Aux. Output Timeout (min.)	ADDRESS 2401	
	LEFT	RIGHT

[Default = blank (\*)

Burg. Alarm Output Timeout (min.)	ADDRESS 2403	
	LEFT	RIGHT

[Default = 1 blank (\*)

Pulse Alarm Output Timeout (min.)	ADDRESS 2404	
	LEFT	RIGHT

[Default = blank (\*) 1]

Fire Output Timeout (min.)	ADDRESS 2405	
	LEFT	RIGHT

[Default = blank (\*)

DATA ENTRIES		DELAY/ TIMEOUT
LEFT	RIGHT	
blank (*)	blank (*)	0 min.
blank (*)	1	1 min.
blank (*)	2	2 min.
blank (*)	3	3 min.
blank (*)	4	4 min.
blank (*)	5	5 min.
blank (*)	6	6 min.
1	blank (*)	16 min.
↓	↓	↓
F	F	255 min.

1. Select delay/timeout (0-255 min.) from the table shown.

2. Enter in corresponding address locations above (left and right digits).

3. For a desired delay/timeout not listed do the following:

$$\begin{array}{r}
 \textcircled{1} \text{ Quotient} \longrightarrow \text{Left Digit} \\
 16 \overline{) 20} \\
 \underline{-16} \phantom{0} \\
 \textcircled{4} \text{ Remainder} \longrightarrow \text{Right Digit}
 \end{array}$$

A. Choose a desired delay/timeout, ex: 20 min.

B. Divide it by 16

**OUTPUT TIMEOUTS:** If a timeout of "0 min." is selected, then the output will remain active (ON) until the system is reset or disarmed. For UL Residential Installations, the minimum timeout is 4 minutes. For UL Commercial Installations, the minimum timeout is 15 minutes.

\*Address 4082: When "Enable CP-01 Features" is selected in the Easy Program menu, this time is set to 7 minutes.

Report Cancel Window (Min.)	ADDRESS 4082	
	LEFT	RIGHT

[Default = blank (\*) blank (\*)]  
Program for at least 5 minutes in a CP-01 installation.\*

Auto Disarm Rearm Delay (min.)	ADDRESS 4083	
	LEFT	RIGHT

[Default = blank (\*) blank (\*)]

## KEYPAD SYSTEM CODES (ADDRESS 0490, 0495 & 0500)

Panel Access Code	ADDRESS 0490-0492					
	0490		0491		0492	
	L	R	L	R	L	R

[Default = blank (\*) blank (\*) from address 0490-0492]

**PANEL ACCESS CODE:** Enter up to 6 digits to activate a door strike while the area is disarmed.

1. Enter in both left and right digits of address locations.

2. Valid entries are: 0-9.

**Note:** Also, "Access Control on Aux. Output" (Address 2418) and "Aux. Output Access Control Timeout" (Address 2402) must both be enabled.

Ambush Code	ADDRESS 0495	
	LEFT	RIGHT

[Default = blank (\*) blank (\*)]

**AMBUSH CODE:** Enter a 2-digit code used just prior to disarming and will activate an Ambush Condition, causing a SILENT report to be sent to the central station.

1. Enter in both left and right digits of address locations.

2. Valid entries are: 0-9.

**Note:** Also, "Enable Keypad Ambush" (Address 2440-2446), "Report on Ambush Alarm" (Address 1125, 1127, 1135 & 1137) and "Ambush Code" (Address 0900) must all be enabled.

Dealer Security Code	ADDRESS 0500-0502					
	0500		0501		0502	
	L	R	L	R	L	R

[Default = blank (\*) blank (\*) from address 0500-0502]

**DEALER SECURITY CODE:** Enter up to 6 digits to be used by the dealer to enter programming.

1. Enter in both left and right digits of address locations.

2. Valid entries are: 0-9.

**Note:** If left blank, the Master Security Code must then be used to enter programming.



# CS RECEIVER FORMAT OPTIONS (ADDRESS 0520, 0521, 0525, 0526, 0550, 0551, 0575 & 0576)

CS Receiver 1 Format	ADDRESS 0525	
	LEFT	RIGHT

CS Receiver 2 Format	ADDRESS 0550	
	LEFT	RIGHT

CS Receiver 3 Format	ADDRESS 0575	
	LEFT	RIGHT

Default for CS Receiver 1 Format depends on Easy Menu Question "RCVR FORMAT". [Default = •(blank) •(blank)] for CS Receivers 2 and 3 Formats.

DATA ENTRIES		CS RECEIVER FORMATS
LEFT	RIGHT	
blank (•)	blank (•)	Ademco Slow, Silent Knight Slow
blank (•)	1	Sescoa, Vertex, DCI, Franklin Fast
blank (•)	2	Radionics Fast
blank (•)	3	Silent Knight Fast
blank (•)	4	Radionics, DCI, Franklin Slow
blank (•)	5	Universal High Speed
blank (•)	8	Radionics BFSK
blank (•)	9	FBI 4/3/1
blank (•)	0	Radionics Modem 2
blank (•)	B	SIA
blank (•)	C	Ademco Point ID
blank (•)	D	Ademco Express
blank (•)	E	Pager
1	blank (•)	Radionics Modem IIe

**CS RECEIVER FORMATS:** Up to 3 CS Formats may be programmed.

1. Select the desired CS Receiver Format from the table shown.

2. Enter in the corresponding left and right digit address locations for each CS Receiver.

**NOTE:** Dark shaded data value box shows option not available.

Leading Digits for Pager Format (1st Digit)	ADDRESS 0520	
	LEFT	RIGHT
	blank (•)	

[Default = blank (•) blank (•)]







Leading Digits for Pager Format (2nd Digit)	ADDRESS 0521	
	LEFT	RIGHT
	blank (•)	

[Default = blank (•) blank (•)]

**LEADING DIGITS FOR PAGER FORMAT:** In Pager Format reporting, the message typically begins with "00". However, for some pager services, this will cause the Pager's Voice Mail feature to activate. This option allows you to program these digits to any number desired. Typical Pager report is "003 022 1234", where 3 is the Event, 22 is the zone, and 1234 is the Subscriber ID number. For example, if the Leading Digits are programmed as "98", the Pager report will now appear as "983 022 1234".

1. Enter in 1st and 2nd Leading Digits in right digit only (left digit is not used) as shown.

2. Valid entries are: 0-9.

CS RECEIVER 1 OPTIONS		LEFT DATA VALUES (CIRCLE 	ADDRESS 0526		RIGHT DATA VALUES (CIRCLE 	CS RECEIVER 1 OPTIONS	
Sum Check		1	LEFT DIGIT (SUM OF DATA VALUES)	RIGHT DIGIT (SUM OF DATA VALUES)	1	1400Hz Handshake/Kissoff *	
3/1 with Extended Restores		2			2	2300Hz Handshake/Kissoff *	
RESERVED		4			4	Enable Zone Number on Pulse Alarm	
RESERVED		8			8	Single Digit Only	
			[Default = blank (•) blank (•)]				
CS RECEIVER 2 OPTIONS		LEFT DATA VALUES (CIRCLE 	ADDRESS 0551		RIGHT DATA VALUES (CIRCLE 	CS RECEIVER 2 OPTIONS	
Sum Check		1	LEFT DIGIT (SUM OF DATA VALUES)	RIGHT DIGIT (SUM OF DATA VALUES)	1	1400Hz Handshake/Kissoff *	
3/1 with Extended Restores		2			2	2300Hz Handshake/Kissoff *	
RESERVED		4			4	Enable Zone Number on Pulse Alarm	
RESERVED		8			8	Single Digit Only	
			[Default = blank (•) blank (•)]				
CS RECEIVER 3 OPTIONS		LEFT DATA VALUES (CIRCLE 	ADDRESS 0576		RIGHT DATA VALUES (CIRCLE 	CS RECEIVER 3 OPTIONS	
Sum Check		1	LEFT DIGIT (SUM OF DATA VALUES)	RIGHT DIGIT (SUM OF DATA VALUES)	1	1400Hz Handshake/Kissoff *	
3/1 with Extended Restores		2			2	2300Hz Handshake/Kissoff *	
RESERVED		4			4	Enable Zone Number on Pulse Alarm	
RESERVED		8			8	Single Digit Only	
			[Default = blank (•) blank (•)]				

**CS RECEIVER OPTIONS:** Select options for any of the three CS Receivers.

1. Select the desired option by circling  the data values for each digit (left and right).

2. Add the data values (ex: 15=1+2+4+8) from the selected options.

3. Enter in address location (left and right digits).

**NOTE:** Dark shaded data value box shows option not available.

**NOTE:** \* If both are selected, 1400Hz has priority over 2300Hz.

## CS RECEIVER TELEPHONE NUMBERS (ADDRESS 0527-0546, 0552-0571, 0577-0596)

CS Receiver 1 Telephone Number (Digits 1-20)	ADDRESS 0527-0546 (RIGHT DIGITS 1-20)																				
	0527	0528	0529	0530	0531	0532	0533	0534	0535	0536	0537	0538	0539	0540	0541	0542	0543	0544	0545	0546	
	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

CS Receiver 2 Telephone Number (Digits 1-20)	ADDRESS 0552-0571 (RIGHT DIGITS 1-20)																				
	0552	0553	0554	0555	0556	0557	0558	0559	0560	0561	0562	0563	0564	0565	0566	0567	0568	0569	0570	0571	
	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

CS Receiver 3 Telephone Number (Digits 1-20)	ADDRESS 0577-0596 (RIGHT DIGITS 1-20)																				
	0577	0578	0579	0580	0581	0582	0583	0584	0585	0586	0587	0588	0589	0590	0591	0592	0593	0594	0595	0596	
	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Default for CS Receiver 1 Telephone Number depends on Easy Menu Question "CENTRAL PHONE #".

[Default = blank (\*)] across digits 1-20 for CS Receiver Telephone Numbers 2 and 3.

**CS RECEIVER TELEPHONE NUMBERS:** Enter telephone numbers for any of the three CS Receivers (Telco 1, 2 & 3).

1. Enter in right digit only (left digit is not used).

2. Enter up to 20 digits from left to right. **NOTE:** Leave trailing boxes blank (\*).

3. Valid entries are: 1-9, B = [\*] button, C = [#] button, D = 3 sec. pause, E = Wait for dial tone, F = ignore location

## DOWNLOAD/CALLBACK OPTIONS (ADDRESS 4089, 0600-0619, 0625-0647, 1022 & 1023)

No. Rings Before Pickup	ADDRESS 4089	
	LEFT	RIGHT
		blank (*)

[Default = blank (\*) F]

**NUMBER OF RINGS BEFORE PICKUP:** Enter the number of rings before automatic pickup by the control panel when downloading from a computer (see Glossary at the back for more information).

1. Enter in right digit only (left digit is not used).

2. Valid entries are: 3-15, 0 = 10, B = 11, C = 12, D = 13, E = 14, F = 15

**NOTE:** Default is 15 Rings. Dark shaded data shows option not available.

Callback Telephone Number 1 (Digits 1-20)	ADDRESS 0600-0619 (RIGHT DIGITS 1-20)																				
	0600	0601	0602	0603	0604	0605	0606	0607	0608	0609	0610	0611	0612	0613	0614	0615	0616	0617	0618	0619	
	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

[Default = blank (\*) for all digits 1-20]

Callback Telephone Number 2 (Digits 1-20)	ADDRESS 0625-0644 (RIGHT DIGITS 1-20)																				
	0625	0626	0627	0628	0629	0630	0631	0632	0633	0634	0635	0636	0637	0638	0639	0640	0641	0642	0643	0644	
	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

[Default = blank (\*) for all digits 1-20]

**CALLBACK TELEPHONE NUMBERS:** Enter telephone numbers to be used when downloading from a computer.

1. Enter in right digit only (left digit is not used).

2. Enter up to 20 digits from left to right. **NOTE:** Leave trailing boxes blank (\*).

3. Valid entries are: 0-9, B = [\*] button, C = [#] button, D = 3 sec. pause, E = Wait for dial tone, F = ignore location

Download Security Code	ADDRESS 0645-0647					
	0645		0646		0647	
	L	R	L	R	L	R

[Default = blank (\*) blank (\*)]

Callback Telephone No. Select	ADDRESS 1022	
	LEFT	RIGHT
		blank (*)

[Default = blank (\*) blank (\*)]

Auto Download ID No.	ADDRESS 1023	
	LEFT	RIGHT

Valid entries - 01-99

[Default = blank (\*) blank (\*)]

**DOWNLOAD SECURITY CODE:** Enter up to 6 digits to be used for remote access when downloading from a computer.

1. Enter in both left and right digits of address locations.

2. Valid entries are: 0-9.

**Note:** Download Security Code must match the code entered in the PCD3000 Software.

**CALLBACK TELEPHONE NO. SELECT:** Enter either "1" for Callback Telephone Number 1 or "2" for Callback Telephone Number 2.

1. Enter in right digit only (left digit is not used).

2. Valid entries are: 1 or 2.



# CS SUBSCRIBER ID NUMBERS (ADDRESS 0650-0787)

## CS TELCO 1 SUBSCRIBER OPENING/CLOSING ID NUMBERS

AREA 1				
ADDRESS 0650-0653 (RIGHT DIGITS 1-4)				
0650	0651	0652	0653	
R	R	R	R	

AREA 2				
ADDRESS 0654-0657 (RIGHT DIGITS 1-4)				
0654	0655	0656	0657	
R	R	R	R	

AREA 3				
ADDRESS 0658-0661 (RIGHT DIGITS 1-4)				
0658	0659	0660	0661	
R	R	R	R	

AREA 4				
ADDRESS 0662-0665 (RIGHT DIGITS 1-4)				
0662	0663	0664	0665	
R	R	R	R	

AREA 5				
ADDRESS 0666-0669 (RIGHT DIGITS 1-4)				
0666	0667	0668	0669	
R	R	R	R	

AREA 6				
ADDRESS 0670-0673 (RIGHT DIGITS 1-4)				
0670	0671	0672	0673	
R	R	R	R	

AREA 7				
ADDRESS 0674-0677 (RIGHT DIGITS 1-4)				
0674	0675	0676	0677	
R	R	R	R	

AREA 8				
ADDRESS 0678-0681 (RIGHT DIGITS 1-4)				
0678	0679	0680	0681	
R	R	R	R	

## CS TELCO 1 SUBSCRIBER EVENT ID NUMBERS

AREA 1				
ADDRESS 0682-0685 (RIGHT DIGITS 1-4)				
0682	0683	0684	0685	
R	R	R	R	

AREA 2				
ADDRESS 0686-0689 (RIGHT DIGITS 1-4)				
0686	0687	0688	0689	
R	R	R	R	

AREA 3				
ADDRESS 0690-0693 (RIGHT DIGITS 1-4)				
0690	0691	0692	0693	
R	R	R	R	

AREA 4				
ADDRESS 0694-0697 (RIGHT DIGITS 1-4)				
0694	0695	0696	0697	
R	R	R	R	

AREA 5				
ADDRESS 0698-0701 (RIGHT DIGITS 1-4)				
0698	0699	0700	0701	
R	R	R	R	

AREA 6				
ADDRESS 0702-0705 (RIGHT DIGITS 1-4)				
0702	0703	0704	0705	
R	R	R	R	

AREA 7				
ADDRESS 0706-0709 (RIGHT DIGITS 1-4)				
0706	0707	0708	0709	
R	R	R	R	

AREA 8				
ADDRESS 0710-0713 (RIGHT DIGITS 1-4)				
0710	0711	0712	0713	
R	R	R	R	

SYSTEM				
ADDRESS 0714-0717 (RIGHT DIGITS 1-4)				
0714	0715	0716	0717	
R	R	R	R	

## CS TELCO 2 SUBSCRIBER OPENING/CLOSING ID NUMBERS (BACKUP REPORTING)

AREA 1				
ADDRESS 0720-0723 (RIGHT DIGITS 1-4)				
0720	0721	0722	0723	
R	R	R	R	

AREA 2				
ADDRESS 0724-0727 (RIGHT DIGITS 1-4)				
0724	0725	0726	0727	
R	R	R	R	

AREA 3				
ADDRESS 0728-0731 (RIGHT DIGITS 1-4)				
0728	0729	0730	0731	
R	R	R	R	

AREA 4				
ADDRESS 0732-0735 (RIGHT DIGITS 1-4)				
0732	0733	0734	0735	
R	R	R	R	

AREA 5				
ADDRESS 0736-0739 (RIGHT DIGITS 1-4)				
0736	0737	0738	0739	
R	R	R	R	

AREA 6				
ADDRESS 0740-0743 (RIGHT DIGITS 1-4)				
0740	0741	0742	0743	
R	R	R	R	

AREA 7				
ADDRESS 0744-0747 (RIGHT DIGITS 1-4)				
0744	0745	0746	0747	
R	R	R	R	

AREA 8				
ADDRESS 0748-0751 (RIGHT DIGITS 1-4)				
0748	0749	0750	0751	
R	R	R	R	

## CS TELCO 2 SUBSCRIBER EVENT ID NUMBERS (BACKUP REPORTING)

AREA 1				
ADDRESS 0752-0755 (RIGHT DIGITS 1-4)				
0752	0753	0754	0755	
R	R	R	R	

AREA 2				
ADDRESS 0756-0759 (RIGHT DIGITS 1-4)				
0756	0757	0758	0759	
R	R	R	R	

AREA 3				
ADDRESS 0760-0763 (RIGHT DIGITS 1-4)				
0760	0761	0762	0763	
R	R	R	R	

AREA 4				
ADDRESS 0764-0767 (RIGHT DIGITS 1-4)				
0764	0765	0766	0767	
R	R	R	R	

AREA 5				
ADDRESS 0768-0771 (RIGHT DIGITS 1-4)				
0768	0769	0770	0771	
R	R	R	R	

AREA 6				
ADDRESS 0772-0775 (RIGHT DIGITS 1-4)				
0772	0773	0774	0775	
R	R	R	R	

AREA 7				
ADDRESS 0776-0779 (RIGHT DIGITS 1-4)				
0776	0777	0778	0779	
R	R	R	R	

AREA 8				
ADDRESS 0780-0783 (RIGHT DIGITS 1-4)				
0780	0781	0782	0783	
R	R	R	R	

SYSTEM				
ADDRESS 0784-0787 (RIGHT DIGITS 1-4)				
0784	0785	0786	0787	
R	R	R	R	

## CS SUBSCRIBER ID NUMBERS (ADDRESS 0790-0857)

### CS TELCO 3 SUBSCRIBER OPENING/CLOSING ID NUMBERS

AREA 1				AREA 2				AREA 3				AREA 4			
ADDRESS 0790-0793 (RIGHT DIGITS 1-4)				ADDRESS 0794-0797 (RIGHT DIGITS 1-4)				ADDRESS 0798-0801 (RIGHT DIGITS 1-4)				ADDRESS 0802-0805 (RIGHT DIGITS 1-4)			
0790	0791	0792	0793	0794	0795	0796	0797	0798	0799	0800	0801	0802	0803	0804	0805
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
AREA 5				AREA 6				AREA 7				AREA 8			
ADDRESS 0806-0809 (RIGHT DIGITS 1-4)				ADDRESS 0810-0813 (RIGHT DIGITS 1-4)				ADDRESS 0814-0817 (RIGHT DIGITS 1-4)				ADDRESS 0818-0821 (RIGHT DIGITS 1-4)			
0806	0807	0808	0809	0810	0811	0812	0813	0814	0815	0816	0817	0818	0819	0820	0821
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

### CS TELCO 3 SUBSCRIBER EVENT ID NUMBERS

AREA 1				AREA 2				AREA 3				AREA 4			
ADDRESS 0822-0825 (RIGHT DIGITS 1-4)				ADDRESS 0826-0829 (RIGHT DIGITS 1-4)				ADDRESS 0830-0833 (RIGHT DIGITS 1-4)				ADDRESS 0834-0837 (RIGHT DIGITS 1-4)			
0822	0823	0824	0825	0826	0827	0828	0829	0830	0831	0832	0833	0834	0835	0836	0837
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
AREA 5				AREA 6				AREA 7				AREA 8			
ADDRESS 0838-0841 (RIGHT DIGITS 1-4)				ADDRESS 0842-0845 (RIGHT DIGITS 1-4)				ADDRESS 0846-0849 (RIGHT DIGITS 1-4)				ADDRESS 0850-0853 (RIGHT DIGITS 1-4)			
0838	0839	0840	0841	0842	0843	0844	0845	0846	0847	0848	0849	0850	0851	0852	0853
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R



## CS REPORTING CODES (ADDRESS 0870-0904)

SYSTEM REPORTING CODES	ADDRESS 0870-0880		
	LEFT	ADDR	RIGHT
Test Timer		0870	
Alarm Supervisory		0871	
Bus Failure		0872	
Memory Failure		0873	
Panel Low Battery		0874	
Panel AC Failure		0875	
EZM Tamper		0876	
Sensor Watch		0877	
RESERVED	blank (*)	0878	blank (*)
RESERVED	blank (*)	0879	blank (*)
Telco Line Failure		0880	

SYSTEM REPORTING CODES	ADDRESS 0890-0897		
	LEFT	ADDR	RIGHT
Digital Dialer Test		0890	
GuardTour Fail		0891	blank (*)
RESERVED		0892	blank (*)
Service Message		0893	
Program Change		0894	
RF Receiver Trouble		0895	
RF Tamper		0896	
RF Trouble		0897	

[Default = blank (\*) blank (\*) from address 0870-0904]

KEYPAD REPORTING CODES	ADDRESS 0900-0904		
	LEFT	ADDR	RIGHT
Ambush		0900	
Panic		0901	
Fire		0902	
Auxiliary		0903	
Tamper		0904	

### CS REPORTING CODES:

1. Enter in corresponding address location (left and right digits).

2. Valid entries are: 1-9, 0 and B-F.

**NOTE:** Dark shaded data value box shows option not available.

**CAUTION:** For all 2-Digit Reporting Formats (see CS Receiver Format Options), use the following:


Reporting Code	ADDRESS Loc.	
	LEFT	RIGHT
	1	2

2nd Digit of Reporting Code

1st Digit of Reporting Code

Example: The 2-digit reporting code as shown is "21".

## CS AREA & SYSTEM REPORTING OPTIONS (ADDRESS 1024-1027)



### CS AREA & SYSTEM REPORTING OPTIONS:

1. Select the desired option by circling the data values for each digit (left and right).

2. Add the data values (ex: 15=1+2+4+8) from the selected options.

3. Enter in address location (left and right digits).

**NOTE:** Dark shaded data value box shows option not available.

**\* NOTE:** If neither TouchTone Dialing nor TouchTone w/Rotary Backup is selected, then system defaults automatically to Rotary Dialing. Leave blank (\*) to select Rotary Dialing.

# CS ZONE REPORTING CODES (ADDRESS 0910-1005)

ADDRESS 0910-0917							
ZONES REPORT CODE (CONTROL PANEL)							
ZONE 1	ZONE 2	ZONE 3	ZONE 4	ZONE 5	ZONE 6	ZONE 7	ZONE 8
0910	0911	0912	0913	0914	0915	0916	0917
L R	L R	L R	L R	L R	L R	L R	L R

ADDRESS 0918-0921			
ZONES REPORT CODE (GROUP 1)			
ZONE 9	ZONE 10	ZONE 11	ZONE 12
0918	0919	0920	0921
L R	L R	L R	L R

ADDRESS 0922-0925			
ZONES REPORT CODE (GROUP 2)			
ZONE 13	ZONE 14	ZONE 15	ZONE 16
0922	0923	0924	0925
L R	L R	L R	L R

ADDRESS 0926-0929			
ZONES REPORT CODE (GROUP 3)			
ZONE 17	ZONE 18	ZONE 19	ZONE 20
0926	0927	0928	0929
L R	L R	L R	L R

ADDRESS 0930-0933			
ZONES REPORT CODE (GROUP 4)			
ZONE 21	ZONE 22	ZONE 23	ZONE 24
0930	0931	0932	0933
L R	L R	L R	L R

ADDRESS 0934-0937			
ZONES REPORT CODE (GROUP 5)			
ZONE 25	ZONE 26	ZONE 27	ZONE 28
0934	0935	0936	0937
L R	L R	L R	L R

ADDRESS 0938-0941			
ZONES REPORT CODE (GROUP 6)			
ZONE 29	ZONE 30	ZONE 31	ZONE 32
0938	0939	0940	0941
L R	L R	L R	L R

ADDRESS 0942-0945			
ZONES REPORT CODE (GROUP 7)			
ZONE 33	ZONE 34	ZONE 35	ZONE 36
0942	0943	0944	0945
L R	L R	L R	L R

ADDRESS 0946-0949			
ZONES REPORT CODE (GROUP 8)			
ZONE 37	ZONE 38	ZONE 39	ZONE 40
0946	0947	0948	0949
L R	L R	L R	L R

ADDRESS 0950-0953			
ZONES REPORT CODE (GROUP 9)			
ZONE 41	ZONE 42	ZONE 43	ZONE 44
0950	0951	0952	0953
L R	L R	L R	L R

ADDRESS 0954-0957			
ZONES REPORT CODE (GROUP 10)			
ZONE 45	ZONE 46	ZONE 47	ZONE 48
0954	0955	0956	0957
L R	L R	L R	L R

ADDRESS 0958-0961			
ZONES REPORT CODE (GROUP 11)			
ZONE 49	ZONE 50	ZONE 51	ZONE 52
0958	0959	0960	0961
L R	L R	L R	L R

ADDRESS 0962-0965			
ZONES REPORT CODE (GROUP 12)			
ZONE 53	ZONE 54	ZONE 55	ZONE 56
0962	0963	0964	0965
L R	L R	L R	L R

ADDRESS 0966-0969			
ZONES REPORT CODE (GROUP 13)			
ZONE 57	ZONE 58	ZONE 59	ZONE 60
0966	0967	0968	0969
L R	L R	L R	L R

ADDRESS 0970-0973			
ZONES REPORT CODE (GROUP 14)			
ZONE 61	ZONE 62	ZONE 63	ZONE 64
0970	0971	0972	0973
L R	L R	L R	L R

ADDRESS 0974-0977			
ZONES REPORT CODE (GROUP 15)			
ZONE 65	ZONE 66	ZONE 67	ZONE 68
0974	0975	0976	0977
L R	L R	L R	L R

ADDRESS 0978-0981			
ZONES REPORT CODE (GROUP 16)			
ZONE 69	ZONE 70	ZONE 71	ZONE 72
0978	0979	0980	0981
L R	L R	L R	L R

ADDRESS 0982-0985			
ZONES REPORT CODE (GROUP 17)			
ZONE 73	ZONE 74	ZONE 75	ZONE 76
0982	0983	0984	0985
L R	L R	L R	L R

ADDRESS 0986-0989			
ZONES REPORT CODE (GROUP 18)			
ZONE 77	ZONE 78	ZONE 79	ZONE 80
0986	0987	0988	0989
L R	L R	L R	L R

ADDRESS 0990-0993			
ZONES REPORT CODE (GROUP 19)			
ZONE 81	ZONE 82	ZONE 83	ZONE 84
0990	0991	0992	0993
L R	L R	L R	L R

ADDRESS 0994-0997			
ZONES REPORT CODE (GROUP 20)			
ZONE 85	ZONE 86	ZONE 87	ZONE 88
0994	0995	0996	0997
L R	L R	L R	L R

ADDRESS 0998-1001			
ZONES REPORT CODE (GROUP 21)			
ZONE 89	ZONE 90	ZONE 91	ZONE 92
0998	0999	1000	1001
L R	L R	L R	L R

ADDRESS 1002-1005			
ZONES REPORT CODE (GROUP 22)			
ZONE 93	ZONE 94	ZONE 95	ZONE 96
1002	1003	1004	1005
L R	L R	L R	L R

Default for Group Zone Report Codes depends on Easy Menu Question "RCVR. FORMAT".

ZONE REPORT CODE OPTIONS	
DATA ENTRIES	
LEFT	RIGHT

**NOTE:** Zones 1-8 are included in the control panel and Zones 9-96 are EZM Zones. See Address 2600-2621 to enable "EZM Zone Groups".

DATA ENTRIES	
LEFT	MODEM CODE
1	Fire *
2	Panic
3	Burglary
4	Hold up
7	Gas Alarm
8	Heat Alarm
0	Auxiliary Alarm
B	24 Hour Auxiliary

**PULSE EVENT CODE** will be the first digit of the 2 digit reporting code. The second digit will be the second digit of the reporting zone. For example, for zone 9 (address 0918), if the right digit is "3", then the reporting code is "39". For example, for zone 15 (address 0924), if the right digit is "4", then the reporting code is "45".

**MODEM CODES** determine the zone types reported for the following formats: SIA and ADEMCO Point ID.

1. Select the desired Modem Code for each zone from the table shown.

## CS USER REPORTING CODES (ADDRESS 1030-1055)

User Opening Telco 1	LEFT DATA VALUES				ADDRESS 1031		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1030		RIGHT DATA VALUES			
	User 16	User 15	User 14	User 13	LEFT	RIGHT	User 12	User 11	User 10	User 9	User 8	User 7	User 6	User 5	LEFT	RIGHT	User 4	User 3	User 2	User 1
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Opening Telco 1	LEFT DATA VALUES				ADDRESS 1033		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1032		RIGHT DATA VALUES			
	User 32	User 31	User 30	User 29	LEFT	RIGHT	User 28	User 27	User 26	User 25	User 24	User 23	User 22	User 21	LEFT	RIGHT	User 20	User 19	User 18	User 17
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Opening Telco 1	LEFT DATA VALUES				ADDRESS 1035		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1034		RIGHT DATA VALUES			
	User 48	User 47	User 46	User 45	LEFT	RIGHT	User 44	User 43	User 42	User 41	User 40	User 39	User 38	User 37	LEFT	RIGHT	User 36	User 35	User 34	User 33
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Opening Telco 1	LEFT DATA VALUES				ADDRESS 1037		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1036		RIGHT DATA VALUES			
	User 64	User 63	User 62	User 61	LEFT	RIGHT	User 60	User 59	User 58	User 57	User 56	User 55	User 54	User 53	LEFT	RIGHT	User 52	User 51	User 50	User 49
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Opening Telco 1	LEFT DATA VALUES				ADDRESS 1039		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1038		RIGHT DATA VALUES			
	User 80	User 79	User 78	User 77	LEFT	RIGHT	User 76	User 75	User 74	User 73	User 72	User 71	User 70	User 69	LEFT	RIGHT	User 68	User 67	User 66	User 65
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Opening Telco 1	LEFT DATA VALUES				ADDRESS 1041		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1040		RIGHT DATA VALUES			
	User 96	User 95	User 94	User 93	LEFT	RIGHT	User 92	User 91	User 90	User 89	User 88	User 87	User 86	User 85	LEFT	RIGHT	User 84	User 83	User 82	User 81
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Opening Telco 1	ADDRESS 1042		RIGHT DATA VALUES				User 97 = Auto Arming/Disarming User 98 = Quickloader Arming/Disarming User 99 = Easy Arming (Opening not applicable) User 00 = Keyswitch Arming													
	LEFT	RIGHT	User 00	User 99	User 98	User 97														
	blank (+)		8	4	2	1														

**NOTE:** These opening events will report as the user number shown. Also, Keyfobs 1-16 (see Easy Menu Program Driven Mode) will report as Users 81-96, respectively.

User Closing Telco 1	LEFT DATA VALUES				ADDRESS 1044		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1043		RIGHT DATA VALUES			
	User 16	User 15	User 14	User 13	LEFT	RIGHT	User 12	User 11	User 10	User 9	User 8	User 7	User 6	User 5	LEFT	RIGHT	User 4	User 3	User 2	User 1
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Closing Telco 1	LEFT DATA VALUES				ADDRESS 1046		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1045		RIGHT DATA VALUES			
	User 32	User 31	User 30	User 29	LEFT	RIGHT	User 28	User 27	User 26	User 25	User 24	User 23	User 22	User 21	LEFT	RIGHT	User 20	User 19	User 18	User 17
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Closing Telco 1	LEFT DATA VALUES				ADDRESS 1048		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1047		RIGHT DATA VALUES			
	User 48	User 47	User 46	User 45	LEFT	RIGHT	User 44	User 43	User 42	User 41	User 40	User 39	User 38	User 37	LEFT	RIGHT	User 36	User 35	User 34	User 33
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Closing Telco 1	LEFT DATA VALUES				ADDRESS 1050		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1049		RIGHT DATA VALUES			
	User 64	User 63	User 62	User 61	LEFT	RIGHT	User 60	User 59	User 58	User 57	User 56	User 55	User 54	User 53	LEFT	RIGHT	User 52	User 51	User 50	User 49
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Closing Telco 1	LEFT DATA VALUES				ADDRESS 1052		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1051		RIGHT DATA VALUES			
	User 80	User 79	User 78	User 77	LEFT	RIGHT	User 76	User 75	User 74	User 73	User 72	User 71	User 70	User 69	LEFT	RIGHT	User 68	User 67	User 66	User 65
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Closing Telco 1	LEFT DATA VALUES				ADDRESS 1054		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1053		RIGHT DATA VALUES			
	User 96	User 95	User 94	User 93	LEFT	RIGHT	User 92	User 91	User 90	User 89	User 88	User 87	User 86	User 85	LEFT	RIGHT	User 84	User 83	User 82	User 81
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Closing Telco 1	ADDRESS 1055		RIGHT DATA VALUES				User 97 = Auto Arming/Disarming User 98 = Quickloader Arming/Disarming User 99 = Easy Arming (Opening not applicable) User 00 = Keyswitch Arming													
	LEFT	RIGHT	User 00	User 99	User 98	User 97														
	blank (+)		8	4	2	1														

**NOTE:** These opening events will report as the user number shown. Also, Keyfobs 1-16 (see Easy Menu Program Driven Mode) will report as Users 81-96, respectively.



# CS USER REPORTING CODES (ADDRESS 1056-1081)

User Opening Telco 3	LEFT DATA VALUES				ADDRESS 1057		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1056		RIGHT DATA VALUES			
	User 16	User 15	User 14	User 13	LEFT	RIGHT	User 12	User 11	User 10	User 9	User 8	User 7	User 6	User 5	LEFT	RIGHT	User 4	User 3	User 2	User 1
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Opening Telco 3	LEFT DATA VALUES				ADDRESS 1059		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1058		RIGHT DATA VALUES			
	User 32	User 31	User 30	User 29	LEFT	RIGHT	User 28	User 27	User 26	User 25	User 24	User 23	User 22	User 21	LEFT	RIGHT	User 20	User 19	User 18	User 17
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Opening Telco 3	LEFT DATA VALUES				ADDRESS 1061		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1060		RIGHT DATA VALUES			
	User 48	User 47	User 46	User 45	LEFT	RIGHT	User 44	User 43	User 42	User 41	User 40	User 39	User 38	User 37	LEFT	RIGHT	User 36	User 35	User 34	User 33
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Opening Telco 3	LEFT DATA VALUES				ADDRESS 1063		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1062		RIGHT DATA VALUES			
	User 64	User 63	User 62	User 61	LEFT	RIGHT	User 60	User 59	User 58	User 57	User 56	User 55	User 54	User 53	LEFT	RIGHT	User 52	User 51	User 50	User 49
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Opening Telco 3	LEFT DATA VALUES				ADDRESS 1065		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1064		RIGHT DATA VALUES			
	User 80	User 79	User 78	User 77	LEFT	RIGHT	User 76	User 75	User 74	User 73	User 72	User 71	User 70	User 69	LEFT	RIGHT	User 68	User 67	User 66	User 65
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Opening Telco 3	LEFT DATA VALUES				ADDRESS 1067		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1066		RIGHT DATA VALUES			
	User 96	User 95	User 94	User 93	LEFT	RIGHT	User 92	User 91	User 90	User 89	User 88	User 87	User 86	User 85	LEFT	RIGHT	User 84	User 83	User 82	User 81
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Opening Telco 3	ADDRESS 1068		RIGHT DATA VALUES				User 97 = Auto Arming/Disarming User 98 = Quickloader Arming/Disarming User 99 = Easy Arming (Opening not applicable) User 00 = Keyswitch Arming													
	LEFT	RIGHT	User 00	User 99	User 98	User 97														
	blank (+)		8	4	2	1														



**NOTE:** These opening events will report as the user number shown. Also, Keyfobs 1-16 (see Easy Menu Program Driven Mode) will report as Users 81-96, respectively.

User Closing Telco 3	LEFT DATA VALUES				ADDRESS 1070		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1069		RIGHT DATA VALUES			
	User 16	User 15	User 14	User 13	LEFT	RIGHT	User 12	User 11	User 10	User 9	User 8	User 7	User 6	User 5	LEFT	RIGHT	User 4	User 3	User 2	User 1
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Closing Telco 3	LEFT DATA VALUES				ADDRESS 1072		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1071		RIGHT DATA VALUES			
	User 32	User 31	User 30	User 29	LEFT	RIGHT	User 28	User 27	User 26	User 25	User 24	User 23	User 22	User 21	LEFT	RIGHT	User 20	User 19	User 18	User 17
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Closing Telco 3	LEFT DATA VALUES				ADDRESS 1074		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1073		RIGHT DATA VALUES			
	User 48	User 47	User 46	User 45	LEFT	RIGHT	User 44	User 43	User 42	User 41	User 40	User 39	User 38	User 37	LEFT	RIGHT	User 36	User 35	User 34	User 33
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Closing Telco 3	LEFT DATA VALUES				ADDRESS 1076		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1075		RIGHT DATA VALUES			
	User 64	User 63	User 62	User 61	LEFT	RIGHT	User 60	User 59	User 58	User 57	User 56	User 55	User 54	User 53	LEFT	RIGHT	User 52	User 51	User 50	User 49
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Closing Telco 3	LEFT DATA VALUES				ADDRESS 1078		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1077		RIGHT DATA VALUES			
	User 80	User 79	User 78	User 77	LEFT	RIGHT	User 76	User 75	User 74	User 73	User 72	User 71	User 70	User 69	LEFT	RIGHT	User 68	User 67	User 66	User 65
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Closing Telco 3	LEFT DATA VALUES				ADDRESS 1080		RIGHT DATA VALUES				LEFT DATA VALUES				ADDRESS 1079		RIGHT DATA VALUES			
	User 96	User 95	User 94	User 93	LEFT	RIGHT	User 92	User 91	User 90	User 89	User 88	User 87	User 86	User 85	LEFT	RIGHT	User 84	User 83	User 82	User 81
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1
User Closing Telco 3	ADDRESS 1081		RIGHT DATA VALUES				User 97 = Auto Arming/Disarming User 98 = Quickloader Arming/Disarming User 99 = Easy Arming (Opening not applicable) User 00 = Keyswitch Arming													
	LEFT	RIGHT	User 00	User 99	User 98	User 97														
	blank (+)		8	4	2	1														

**NOTE:** These opening events will report as the user number shown. Also, Keyfobs 1-16 (see Easy Menu Program Driven Mode) will report as Users 81-96, respectively.





# GLOBAL SYSTEM TROUBLE REPORTING OPTIONS (ADDRESS 1082-1116)



SYSTEM RESPONSE ACTIVATED BY GLOBAL EVENT/TROUBLE	GLOBAL SYSTEM EVENT/TROUBLE				ADDRESS 1082-1092			GLOBAL SYSTEM EVENT/TROUBLE			
	LEFT DATA VALUES (CIRCLE  )							RIGHT DATA VALUES (CIRCLE  )			
	SENSOR WATCH	EZM TAMPER	AC FAIL	LOW BATTERY	LEFT	ADDR	RIGHT	MEMORY FAILURE	COMM. BUS 1	ALARM SUPERV.	TEST TIMER
Burglary Alarm Output	8	4	2	1		1082		8	4	2	1
Pulsed Burg. Output	8	4	2	1		1083		8	4	2	1
Fire Output	8	4	2	1		1084		8	4	2	1
Reset Relay	8	4	2	1		1085		8	4	2	1
Auxiliary Relay	8	4	2	1		1086		8	4	2	1
Report Event Telco 1	8	4	2	1		1087		8	4	2	1
Report Restore Telco 1	8	4	2	1		1088		8	4	2	1
Report Event Telco 3	8	4	2	1		1091		8	4	2	1
Report Restore Telco 3	8	4	2	1		1092		8	4	2	1

See NOTE 

[Default = blank (•) blank (•) from address 1082-1092]

SYSTEM RESPONSE ACTIVATED BY GLOBAL EVENT/TROUBLE	GLOBAL SYSTEM EVENT/TROUBLE				ADDRESS 1094-1104			GLOBAL SYSTEM EVENT/TROUBLE			
	LEFT DATA VALUES (CIRCLE  )							RIGHT DATA VALUES (CIRCLE  )			
	RSRVD.	RSRVD.	RSRVD.	RSRVD.	LEFT	ADDR	RIGHT	Telemetry Failure	Telemetry Trouble	RSRVD.	TELCO FAIL
Burglary Alarm Output	8	4	2	1	blank (•)	1094		8	4	2	1
Pulsed Burg. Output	8	4	2	1	blank (•)	1095		8	4	2	1
Fire Output	8	4	2	1	blank (•)	1096		8	4	2	1
Reset Relay	8	4	2	1	blank (•)	1097		8	4	2	1
Auxiliary Relay	8	4	2	1	blank (•)	1098		8	4	2	1
Report Event Telco 1	8	4	2	1	blank (•)	1099		8	4	2	1
Report Restore Telco 1	8	4	2	1	blank (•)	1100		8	4	2	1
Report Event Telco 3	8	4	2	1	blank (•)	1103		8	4	2	1
Report Restore Telco 3	8	4	2	1	blank (•)	1104		8	4	2	1


[Default = blank (•) blank (•) from address 1094-1104]

SYSTEM RESPONSE ACTIVATED BY GLOBAL EVENT/TROUBLE	GLOBAL SYSTEM EVENT/TROUBLE				ADDRESS 1106-1116			GLOBAL SYSTEM EVENT/TROUBLE			
	LEFT DATA VALUES (CIRCLE  )							RIGHT DATA VALUES (CIRCLE  )			
	RF TROUBLE	RF TAMPER	RF RCVR.	PROGRAM CHANGE	LEFT	ADDR	RIGHT	SERVICE MESSAGE	RSRVD.	GUARD TOUR FAIL	Digital Dialer Test
Burglary Alarm Output	8	4	2	1		1106		8	4	2	1
Pulsed Burg. Output	8	4	2	1		1107		8	4	2	1
Fire Output	8	4	2	1		1108		8	4	2	1
Reset Relay	8	4	2	1		1109		8	4	2	1
Auxiliary Relay	8	4	2	1		1110		8	4	2	1
Report Event Telco 1	8	4	2	1		1111		8	4	2	1
Report Restore Telco 1	8	4	2	1	blank (•)	1112	blank (•)	8	4	2	1
Report Event Telco 3	8	4	2	1		1115		8	4	2	1
Report Restore Telco 3	8	4	2	1	blank (•)	1116	blank (•)	8	4	2	1

See NOTE 

[Default = blank (•) blank (•) from address 1106-1116]



 1. Select the desired option by circling  the data values for each digit (left and right).

 2. Add the data values (ex: 15=1+2+4+8) from the selected options.



 3. Enter in address location (left and right digits).

**NOTE:** Dark shaded data value box shows option not available.



# AREA SYSTEM TROUBLE REPORTING OPTIONS (ADDRESS 1120-1157)

AREA 1	SYSTEM RESPONSE ACTIVATED BY AREA 1 EVENT/TROUBLE	AREA 1 SYSTEM EVENT/TROUBLE				ADDRESS 1120-1127			AREA 1 SYSTEM EVENT/TROUBLE			
		LEFT DATA VALUES (CIRCLE  )							RIGHT DATA VALUES (CIRCLE  )			
		RSRVD.	FAIL TO CLOSE	FAIL TO OPEN	KEYPAD TAMPER	LEFT	ADDR	RIGHT	KEYPAD AUX.	KEYPAD FIRE	KEYPAD PANIC	AMBUSH
	Pulsed Burg. Output	8	4	2	1		1120		8	④	2	1
	Burglary Output	8	4	2	1		1121		⑧	4	②	1
	Fire Output	8	4	2	1		1122		8	4	2	1
	Reset Relay	8	4	2	1		1123		8	4	2	1
	Auxiliary Relay	8	4	2	1		1124		8	4	2	1
	Report Alarm Telco 1	8	4	2	1		1125		⑧	④	②	1
	Report Alarm Telco 3	8	4	2	1		1127		8	4	2	1



[Defaults as circled from address 1120-1127]

AREA 2	SYSTEM RESPONSE ACTIVATED BY AREA 2 EVENT/TROUBLE	AREA 2 SYSTEM EVENT/TROUBLE				ADDRESS 1130-1137			AREA 2 SYSTEM EVENT/TROUBLE			
		LEFT DATA VALUES (CIRCLE  )							RIGHT DATA VALUES (CIRCLE  )			
		RSRVD.	FAIL TO CLOSE	FAIL TO OPEN	KEYPAD TAMPER	LEFT	ADDR	RIGHT	KEYPAD AUX.	KEYPAD FIRE	KEYPAD PANIC	AMBUSH
	Pulsed Burg. Output	8	4	2	1		1130		8	4	2	1
	Burglary Output	8	4	2	1		1131		8	4	2	1
	Fire Output	8	4	2	1		1132		8	4	2	1
	Reset Relay	8	4	2	1		1133		8	4	2	1
	Auxiliary Relay	8	4	2	1		1134		8	4	2	1
Report Alarm Telco 1	8	4	2	1		1135		8	4	2	1	
Report Alarm Telco 3	8	4	2	1		1137		8	4	2	1	

[Default = blank (•) blank (•) from address 1130-1137]


AREA 3	SYSTEM RESPONSE ACTIVATED BY AREA 3 EVENT/TROUBLE	AREA 3 SYSTEM EVENT/TROUBLE				ADDRESS 1140-1147			AREA 3 SYSTEM EVENT/TROUBLE			
		LEFT DATA VALUES (CIRCLE  )							RIGHT DATA VALUES (CIRCLE  )			
		RSRVD.	FAIL TO CLOSE	FAIL TO OPEN	KEYPAD TAMPER	LEFT	ADDR	RIGHT	KEYPAD AUX.	KEYPAD FIRE	KEYPAD PANIC	AMBUSH
	Pulsed Burg. Output	8	4	2	1		1140		8	4	2	1
	Burglary Output	8	4	2	1		1141		8	4	2	1
	Fire Output	8	4	2	1		1142		8	4	2	1
	Reset Relay	8	4	2	1		1143		8	4	2	1
	Auxiliary Relay	8	4	2	1		1144		8	4	2	1
	Report Alarm Telco 1	8	4	2	1		1145		8	4	2	1
	Report Alarm Telco 3	8	4	2	1		1147		8	4	2	1

[Default = blank (•) blank (•) from address 1140-1147]

AREA 4	SYSTEM RESPONSE ACTIVATED BY AREA 4 EVENT/TROUBLE	AREA 4 SYSTEM EVENT/TROUBLE				ADDRESS 1150-1157			AREA 4 SYSTEM EVENT/TROUBLE			
		LEFT DATA VALUES (CIRCLE  )							RIGHT DATA VALUES (CIRCLE  )			
		RSRVD.	FAIL TO CLOSE	FAIL TO OPEN	KEYPAD TAMPER	LEFT	ADDR	RIGHT	KEYPAD AUX.	KEYPAD FIRE	KEYPAD PANIC	AMBUSH
	Pulsed Burg. Output	8	4	2	1		1150		8	4	2	1
	Burglary Output	8	4	2	1		1151		8	4	2	1
	Fire Output	8	4	2	1		1152		8	4	2	1
	Reset Relay	8	4	2	1		1153		8	4	2	1
	Auxiliary Relay	8	4	2	1		1154		8	4	2	1
	Report Alarm Telco 1	8	4	2	1		1155		8	4	2	1
	Report Alarm Telco 3	8	4	2	1		1157		8	4	2	1

[Default = blank (•) blank (•) from address 1150-1157]

 1. Select the desired option by circling  the data values for each digit (left and right).



 2. Add the data values (ex: 15=1+2+4+8) from the selected options.

 3. Enter in address location (left and right digits).

**NOTE:** Dark shaded data value box shows option not available.





# AREA SYSTEM TROUBLE REPORTING OPTIONS (ADDRESS 1160-1197)

AREA 5	SYSTEM RESPONSE ACTIVATED BY AREA 5 EVENT/TROUBLE	AREA 5 SYSTEM EVENT/TROUBLE				ADDRESS 1160-1167			AREA 5 SYSTEM EVENT/TROUBLE			
		LEFT DATA VALUES (CIRCLE  )							RIGHT DATA VALUES (CIRCLE  )			
		RSRVD.	FAIL TO CLOSE	FAIL TO OPEN	KEYPAD TAMPER	LEFT	ADDR	RIGHT	KEYPAD AUX.	KEYPAD FIRE	KEYPAD PANIC	AMBUSH
	Pulsed Burg. Output	8	4	2	1		1160		8	4	2	1
	Burglary Output	8	4	2	1		1161		8	4	2	1
	Fire Output	8	4	2	1		1162		8	4	2	1
	Reset Relay	8	4	2	1		1163		8	4	2	1
	Auxiliary Relay	8	4	2	1		1164		8	4	2	1
	Report Alarm Telco 1	8	4	2	1		1165		8	4	2	1
	Report Alarm Telco 3	8	4	2	1		1167		8	4	2	1



[Default = blank (•) blank (•) from address 1160-1167]

AREA 6	SYSTEM RESPONSE ACTIVATED BY AREA 6 EVENT/TROUBLE	AREA 6 SYSTEM EVENT/TROUBLE				ADDRESS 1170-1177			AREA 6 SYSTEM EVENT/TROUBLE			
		LEFT DATA VALUES (CIRCLE  )							RIGHT DATA VALUES (CIRCLE  )			
		RSRVD.	FAIL TO CLOSE	FAIL TO OPEN	KEYPAD TAMPER	LEFT	ADDR	RIGHT	KEYPAD AUX.	KEYPAD FIRE	KEYPAD PANIC	AMBUSH
	Pulsed Burg. Output	8	4	2	1		1170		8	4	2	1
	Burglary Output	8	4	2	1		1171		8	4	2	1
	Fire Output	8	4	2	1		1172		8	4	2	1
	Reset Relay	8	4	2	1		1173		8	4	2	1
	Auxiliary Relay	8	4	2	1		1174		8	4	2	1
	Report Alarm Telco 1	8	4	2	1		1175		8	4	2	1
	Report Alarm Telco 3	8	4	2	1		1177		8	4	2	1


[Default = blank (•) blank (•) from address 1170-1177]

AREA 7	SYSTEM RESPONSE ACTIVATED BY AREA 7 EVENT/TROUBLE	AREA 7 SYSTEM EVENT/TROUBLE				ADDRESS 1140-1147			AREA 7 SYSTEM EVENT/TROUBLE			
		LEFT DATA VALUES (CIRCLE  )							RIGHT DATA VALUES (CIRCLE  )			
		RSRVD.	FAIL TO CLOSE	FAIL TO OPEN	KEYPAD TAMPER	LEFT	ADDR	RIGHT	KEYPAD AUX.	KEYPAD FIRE	KEYPAD PANIC	AMBUSH
	Pulsed Burg. Output	8	4	2	1		1180		8	4	2	1
	Burglary Output	8	4	2	1		1181		8	4	2	1
	Fire Output	8	4	2	1		1182		8	4	2	1
	Reset Relay	8	4	2	1		1183		8	4	2	1
	Auxiliary Relay	8	4	2	1		1184		8	4	2	1
	Report Alarm Telco 1	8	4	2	1		1185		8	4	2	1
	Report Alarm Telco 3	8	4	2	1		1187		8	4	2	1





[Default = blank (•) blank (•) from address 1180-1187]

AREA 8	SYSTEM RESPONSE ACTIVATED BY AREA 8 EVENT/TROUBLE	AREA 8 SYSTEM EVENT/TROUBLE				ADDRESS 1190-1197			AREA 8 SYSTEM EVENT/TROUBLE			
		LEFT DATA VALUES (CIRCLE  )							RIGHT DATA VALUES (CIRCLE  )			
		RSRVD.	FAIL TO CLOSE	FAIL TO OPEN	KEYPAD TAMPER	LEFT	ADDR	RIGHT	KEYPAD AUX.	KEYPAD FIRE	KEYPAD PANIC	AMBUSH
	Pulsed Burg. Output	8	4	2	1		1190		8	4	2	1
	Burglary Output	8	4	2	1		1191		8	4	2	1
	Fire Output	8	4	2	1		1192		8	4	2	1
	Reset Relay	8	4	2	1		1193		8	4	2	1
	Auxiliary Relay	8	4	2	1		1194		8	4	2	1
	Report Alarm Telco 1	8	4	2	1		1195		8	4	2	1
	Report Alarm Telco 3	8	4	2	1		1197		8	4	2	1

[Default = blank (•) blank (•) from address 1190-1197]

1. Select the desired option by circling  the data values for each digit (left and right). 2. Add the data values (ex: 15=1+2+4+8) from the selected options. 3. Enter in address location (left and right digits). **NOTE:** Dark shaded data value box shows option not available.

# ZONE OPTIONS / ZONES 1-16 (ADDRESS 1200-1386)

ZONE OPTIONS	ZONES 13-16 LEFT DATA VALUES (CIRCLE  )				ADDRESS 1302-1386			ZONES 9-12 RIGHT DATA VALUES (CIRCLE  )				ZONES 5-8 LEFT DATA VALUES (CIRCLE  )				ADDRESS 1200-1286			ZONES 1-4 RIGHT DATA VALUES (CIRCLE  )			
	ZN16	ZN15	ZN14	ZN13	L	ADDR	R	ZN12	ZN11	ZN10	ZN9	ZN8	ZN7	ZN6	ZN5	L	ADDR	R	ZN4	ZN3	ZN2	ZN1
50ms Loop Response (A)	8	4	2	1	(+)		(+)	8	4	2	1	8	4	2	1		1200		8	4	2	1
20ms Loop Response (A)	8	4	2	1	(+)		(+)	8	4	2	1	8	4	2	1		1201		8	4	2	1
† Priority	8	4	2	1		1302		8	4	2	1	8	4	2	1		1202		8	4	2	1
Priority with Bypass	8	4	2	1		1303		8	4	2	1	8	4	2	1		1203		8	4	2	1
Auto-Bypass	8	4	2	1		1304		8	4	2	1	8	4	2	1		1204		8	4	2	1
† Selective Bypass	8	4	2	1		1305		8	4	2	1	8	4	2	1		1205		8	4	2	1
Keyswitch Arming	8	4	2	1		1306		8	4	2	1	8	4	2	1		1206		8	4	2	1
Auto-Bypass Re-entry	8	4	2	1		1307		8	4	2	1	8	4	2	1		1207		8	4	2	1
Pre-Alarm Warning	8	4	2	1		1308		8	4	2	1	8	4	2	1		1208		8	4	2	1
Never Arm	8	4	2	1		1309		8	4	2	1	8	4	2	1		1209		8	4	2	1
24-Hour Zone	8	4	2	1		1310		8	4	2	1	8	4	2	1		1210		8	4	2	1
† Burg. Alarm Output	8	4	2	1		1311		8	4	2	1	8	4	2	1		1211		8	4	2	1
† Pulsed Alarm Output	8	4	2	1		1312		8	4	2	1	8	4	2	1		1212		8	4	2	1
Fire Output (Lug E9)	8	4	2	1		1313		8	4	2	1	8	4	2	1		1213		8	4	2	1
Reset Relay	8	4	2	1		1314		8	4	2	1	8	4	2	1		1214		8	4	2	1
Auxiliary Relay	8	4	2	1		1315		8	4	2	1	8	4	2	1		1215		8	4	2	1
† Entry/Exit 1	8	4	2	1		1316		8	4	2	1	8	4	2	1		1216		8	4	2	1
† Entry/Exit 2	8	4	2	1		1317		8	4	2	1	8	4	2	1		1217		8	4	2	1
† Exit/Entry Follower	8	4	2	1		1318		8	4	2	1	8	4	2	1		1218		8	4	2	1
⊗ Auto Reset	8	4	2	1		1319		8	4	2	1	8	4	2	1		1219		8	4	2	1
⊗ Swinger Shutdown	8	4	2	1		1320		8	4	2	1	8	4	2	1		1220		8	4	2	1
† Chime	8	4	2	1		1321		8	4	2	1	8	4	2	1		1221		8	4	2	1
Abort Delay	8	4	2	1		1322		8	4	2	1	8	4	2	1		1222		8	4	2	1
Power-up Delay	8	4	2	1		1323		8	4	2	1	8	4	2	1		1223		8	4	2	1
Day Zone Open	8	4	2	1		1324		8	4	2	1	8	4	2	1		1224		8	4	2	1
Day Zone Short	8	4	2	1		1325		8	4	2	1	8	4	2	1		1225		8	4	2	1
Alarm on Day Zone	8	4	2	1		1326		8	4	2	1	8	4	2	1		1226		8	4	2	1
† Alarm Telco 1	8	4	2	1		1327		8	4	2	1	8	4	2	1		1227		8	4	2	1
Alarm Restore 1	8	4	2	1		1328		8	4	2	1	8	4	2	1		1228		8	4	2	1
Trouble Telco 1	8	4	2	1		1329		8	4	2	1	8	4	2	1		1229		8	4	2	1
Trouble Restore 1	8	4	2	1		1330		8	4	2	1	8	4	2	1		1230		8	4	2	1
Alarm Telco 3	8	4	2	1		1335		8	4	2	1	8	4	2	1		1235		8	4	2	1
Alarm Restore 3	8	4	2	1		1336		8	4	2	1	8	4	2	1		1236		8	4	2	1
Trouble Telco 3	8	4	2	1		1337		8	4	2	1	8	4	2	1		1237		8	4	2	1
Trouble Restore 3	8	4	2	1		1338		8	4	2	1	8	4	2	1		1238		8	4	2	1
No EOL Resistor	8	4	2	1		1339		8	4	2	1	8	4	2	1		1239		8	4	2	1
Sensor Watch	8	4	2	1		1340		8	4	2	1	8	4	2	1		1240		8	4	2	1
Trouble on Open	8	4	2	1		1341		8	4	2	1	8	4	2	1		1241		8	4	2	1
Trouble on Short	8	4	2	1		1342		8	4	2	1	8	4	2	1		1242		8	4	2	1
Trouble on Night Open	8	4	2	1		1343		8	4	2	1	8	4	2	1		1243		8	4	2	1
† Zone Area 1	8	4	2	1		1344		8	4	2	1	8	4	2	1		1244		8	4	2	1
† Zone Area 2	8	4	2	1		1345		8	4	2	1	8	4	2	1		1245		8	4	2	1
Zone Area 3	8	4	2	1		1346		8	4	2	1	8	4	2	1		1246		8	4	2	1
Zone Area 4	8	4	2	1		1347		8	4	2	1	8	4	2	1		1247		8	4	2	1
Zone Area 5	8	4	2	1		1348		8	4	2	1	8	4	2	1		1248		8	4	2	1
Zone Area 6	8	4	2	1		1349		8	4	2	1	8	4	2	1		1249		8	4	2	1
Zone Area 7	8	4	2	1		1350		8	4	2	1	8	4	2	1		1250		8	4	2	1
Zone Area 8	8	4	2	1		1351		8	4	2	1	8	4	2	1		1251		8	4	2	1
† 2-Wire Smoke Detectors (B)	8	4	2	1	(+)		(+)	8	4	2	1	8	4	2	1		1252		8	4	2	1
Bypass on Guard Tour	8	4	2	1		1353		8	4	2	1	8	4	2	1		1253		8	4	2	1
Zone ANDing Group 1	8	4	2	1		1354		8	4	2	1	8	4	2	1		1254		8	4	2	1
Zone ANDing Group 2	8	4	2	1		1355		8	4	2	1	8	4	2	1		1255		8	4	2	1
Zone ANDing Group 3	8	4	2	1		1356		8	4	2	1	8	4	2	1		1256		8	4	2	1
Zone ANDing Group 4	8	4	2	1		1357		8	4	2	1	8	4	2	1		1257		8	4	2	1
Zone ANDing Group 5	8	4	2	1		1358		8	4	2	1	8	4	2	1		1258		8	4	2	1
Zone ANDing Group 6	8	4	2	1		1359		8	4	2	1	8	4	2	1		1259		8	4	2	1
Zone ANDing Group 7	8	4	2	1		1360		8	4	2	1	8	4	2	1		1260		8	4	2	1
Zone ANDing Group 8	8	4	2	1		1361		8	4	2	1	8	4	2	1		1261		8	4	2	1
† Interior #1 Bypass	8	4	2	1		1362		8	4	2	1	8	4	2	1		1262		8	4	2	1
⊗ Interior #2 Bypass	8	4	2	1		1363		8	4	2	1	8	4	2	1		1263		8	4	2	1
Keypad Sounder on Alarm	8	4	2	1		1364		8	4	2	1	8	4	2	1		1264		8	4	2	1
† Fire (C)	8	4	2	1		1375		8	4	2	1	8	4	2	1		1275		8	4	2	1
† Fire Alarm Verification (C)	8	4	2	1		1376		8	4	2	1	8	4	2	1		1276		8	4	2	1
† Interior (STAY) Bypass	8	4	2	1		1384		8	4	2	1	8	4	2	1		1284		8	4	2	1
Chime 2	8	4	2	1		1386		8	4	2	1	8	4	2	1		1286		8	4	2	1

† When the Easy Program Menu is used, these features are enabled by default.

⊗ Do not program if "K Series" keypads (with "[STAY]" and "[AWAY]" buttons) are used in the system.





⊗ Disable Auto-Reset on non-fire zones for SIA CP-01 installations.


II In UL installations, all Fire Zones must also be programmed for "Pulsed Burg Output" and "fire Output Cadence" (Address 2422, bit zero).





# **ZONE OPTIONS / ZONES 17-32 (ADDRESS 1402-1586)**

	ZONE OPTIONS	ZONES 29-32 LEFT DATA VALUES				ADDRESS 1502-1586			ZONES 25-28 RIGHT DATA VALUES				ZONES 21-24 LEFT DATA VALUES				ADDRESS 1402-1486			ZONES 17-20 RIGHT DATA VALUES			
		(CIRCLE  )							(CIRCLE  )				(CIRCLE  )							(CIRCLE  )			
		ZN32	ZN31	ZN30	ZN29	L	ADDR	R	ZN28	ZN27	ZN26	ZN25	ZN24	ZN23	ZN22	ZN21	L	ADDR	R	ZN20	ZN19	ZN18	ZN17
⌘	Priority	8	4	2	1		1502		8	4	2	1	8	4	2	1		1402		8	4	2	1
	Priority with Bypass	8	4	2	1		1503		8	4	2	1	8	4	2	1		1403		8	4	2	1
	Auto-Bypass	8	4	2	1		1504		8	4	2	1	8	4	2	1		1404		8	4	2	1
⌘	Selective Bypass	8	4	2	1		1505		8	4	2	1	8	4	2	1		1405		8	4	2	1
	Keyswitch Arming	8	4	2	1		1506		8	4	2	1	8	4	2	1		1406		8	4	2	1
	Auto-Bypass Re-entry	8	4	2	1		1507		8	4	2	1	8	4	2	1		1407		8	4	2	1
⌘	Pre-Alarm Warning	8	4	2	1		1508		8	4	2	1	8	4	2	1		1408		8	4	2	1
	Never Arm	8	4	2	1		1509		8	4	2	1	8	4	2	1		1409		8	4	2	1
	24-Hour Zone	8	4	2	1		1510		8	4	2	1	8	4	2	1		1410		8	4	2	1
⌘	Burg. Alarm Output	8	4	2	1		1511		8	4	2	1	8	4	2	1		1411		8	4	2	1
	Pulsed Alarm Output	8	4	2	1		1512		8	4	2	1	8	4	2	1		1412		8	4	2	1
	Fire Output (Lug E9)	8	4	2	1		1513		8	4	2	1	8	4	2	1		1413		8	4	2	1
⌘	Reset Relay	8	4	2	1		1514		8	4	2	1	8	4	2	1		1414		8	4	2	1
	Auxiliary Relay	8	4	2	1		1515		8	4	2	1	8	4	2	1		1415		8	4	2	1
	Entry/Exit 1	8	4	2	1		1516		8	4	2	1	8	4	2	1		1416		8	4	2	1
⌘	Entry/Exit 2	8	4	2	1		1517		8	4	2	1	8	4	2	1		1417		8	4	2	1
	Exit/Entry Follower	8	4	2	1		1518		8	4	2	1	8	4	2	1		1418		8	4	2	1
	Auto Reset	8	4	2	1		1519		8	4	2	1	8	4	2	1		1419		8	4	2	1
⌘	Swinger Shutdown	8	4	2	1		1520		8	4	2	1	8	4	2	1		1420		8	4	2	1
	Chime	8	4	2	1		1521		8	4	2	1	8	4	2	1		1421		8	4	2	1
	Abort Delay	8	4	2	1		1522		8	4	2	1	8	4	2	1		1422		8	4	2	1
⌘	Power-up Delay	8	4	2	1		1523		8	4	2	1	8	4	2	1		1423		8	4	2	1
	Day Zone Open	8	4	2	1		1524		8	4	2	1	8	4	2	1		1424		8	4	2	1
	Day Zone Short	8	4	2	1		1525		8	4	2	1	8	4	2	1		1425		8	4	2	1
⌘	Alarm on Day Zone	8	4	2	1		1526		8	4	2	1	8	4	2	1		1426		8	4	2	1
	Alarm Telco 1	8	4	2	1		1527		8	4	2	1	8	4	2	1		1427		8	4	2	1
	Alarm Restore 1	8	4	2	1		1528		8	4	2	1	8	4	2	1		1428		8	4	2	1
⌘	Trouble Telco 1	8	4	2	1		1529		8	4	2	1	8	4	2	1		1429		8	4	2	1
	Trouble Restore 1	8	4	2	1		1530		8	4	2	1	8	4	2	1		1430		8	4	2	1
	Alarm Telco 3	8	4	2	1		1535		8	4	2	1	8	4	2	1		1435		8	4	2	1
⌘	Alarm Restore 3	8	4	2	1		1536		8	4	2	1	8	4	2	1		1436		8	4	2	1
	Trouble Telco 3	8	4	2	1		1537		8	4	2	1	8	4	2	1		1437		8	4	2	1
	Trouble Restore 3	8	4	2	1		1538		8	4	2	1	8	4	2	1		1438		8	4	2	1
⌘	No EOL Resistor	8	4	2	1		1539		8	4	2	1	8	4	2	1		1439		8	4	2	1
	Sensor Watch	8	4	2	1		1540		8	4	2	1	8	4	2	1		1440		8	4	2	1
	Trouble on Open	8	4	2	1		1541		8	4	2	1	8	4	2	1		1441		8	4	2	1
⌘	Trouble on Short	8	4	2	1		1542		8	4	2	1	8	4	2	1		1442		8	4	2	1
	Trouble on Night Open	8	4	2	1		1543		8	4	2	1	8	4	2	1		1443		8	4	2	1
	Zone Area 1	8	4	2	1		1544		8	4	2	1	8	4	2	1		1444		8	4	2	1
⌘	Zone Area 2	8	4	2	1		1545		8	4	2	1	8	4	2	1		1445		8	4	2	1
	Zone Area 3	8	4	2	1		1546		8	4	2	1	8	4	2	1		1446		8	4	2	1
	Zone Area 4	8	4	2	1		1547		8	4	2	1	8	4	2	1		1447		8	4	2	1
⌘	Zone Area 5	8	4	2	1		1548		8	4	2	1	8	4	2	1		1448		8	4	2	1
	Zone Area 6	8	4	2	1		1549		8	4	2	1	8	4	2	1		1449		8	4	2	1
	Zone Area 7	8	4	2	1		1550		8	4	2	1	8	4	2	1		1450		8	4	2	1
⌘	Zone Area 8	8	4	2	1		1551		8	4	2	1	8	4	2	1		1451		8	4	2	1
	Bypass on Guard Tour	8	4	2	1		1553		8	4	2	1	8	4	2	1		1453		8	4	2	1
	Zone ANDing Group 1	8	4	2	1		1554		8	4	2	1	8	4	2	1		1454		8	4	2	1
⌘	Zone ANDing Group 2	8	4	2	1		1555		8	4	2	1	8	4	2	1		1455		8	4	2	1
	Zone ANDing Group 3	8	4	2	1		1556		8	4	2	1	8	4	2	1		1456		8	4	2	1
	Zone ANDing Group 4	8	4	2	1		1557		8	4	2	1	8	4	2	1		1457		8	4	2	1
⌘	Zone ANDing Group 5	8	4	2	1		1558		8	4	2	1	8	4	2	1		1458		8	4	2	1
	Zone ANDing Group 6	8	4	2	1		1559		8	4	2	1	8	4	2	1		1459		8	4	2	1
	Zone ANDing Group 7	8	4	2	1		1560		8	4	2	1	8	4	2	1		1460		8	4	2	1
⌘	Zone ANDing Group 8	8	4	2	1		1561		8	4	2	1	8	4	2	1		1461		8	4	2	1
	Interior #1 Bypass	8	4	2	1		1562		8	4	2	1	8	4	2	1		1462		8	4	2	1
	Interior #2 Bypass	8	4	2	1		1563		8	4	2	1	8	4	2	1		1463		8	4	2	1
⌘	Keypad Sounder on Alarm	8	4	2	1		1564		8	4	2	1	8	4	2	1		1464		8	4	2	1
	Fire (C)	8	4	2	1		1575		8	4	2	1	8	4	2	1		1475		8	4	2	1
	Fire Alarm Verification (C)	8	4	2	1		1576		8	4	2	1	8	4	2	1		1476		8	4	2	1
⌘	Interior (STAY) Bypass	8	4	2	1		1584		8	4	2	1	8	4	2	1		1484		8	4	2	1
	Chime 2	8	4	2	1		1586		8	4	2	1	8	4	2	1		1486		8	4	2	1



✚ When the Easy Program Menu is used, these features are enabled by default.

✚ Do not program if "K Series" keypads (with "STAY" and "AWAY" buttons) are used in the system.

⚡ Disable Auto-Reset on non-fire zones for SIA CP-01 installations.

II In UL installations, all Fire Zones must also be programmed for "Pulsed Burg Output" and "fire Output Cadence" (Address 2422, bit zero).

See Zone Options on Page 46.







NAPCO Security Systems



GEM-P9600 Programming Instructions

# ZONE OPTIONS / ZONES 33-48 (ADDRESS 1602-1786)

ZONE OPTIONS	ZONES 45-48 LEFT DATA VALUES (CIRCLE  )				ADDRESS 1702-1786			ZONES 41-44 RIGHT DATA VALUES (CIRCLE  )				ZONES 37-40 LEFT DATA VALUES (CIRCLE  )				ADDRESS 1602-1686			ZONES 33-36 RIGHT DATA VALUES (CIRCLE  )			
	ZN48	ZN47	ZN46	ZN45	L	ADDR	R	ZN44	ZN43	ZN42	ZN41	ZN40	ZN39	ZN38	ZN37	L	ADDR	R	ZN36	ZN35	ZN34	ZN33
† Priority	8	4	2	1		1702		8	4	2	1	8	4	2	1		1602		8	4	2	1
Priority with Bypass	8	4	2	1		1703		8	4	2	1	8	4	2	1		1603		8	4	2	1
Auto-Bypass	8	4	2	1		1704		8	4	2	1	8	4	2	1		1604		8	4	2	1
† Selective Bypass	8	4	2	1		1705		8	4	2	1	8	4	2	1		1605		8	4	2	1
Keyswitch Arming	8	4	2	1		1706		8	4	2	1	8	4	2	1		1606		8	4	2	1
Auto-Bypass Re-entry	8	4	2	1		1707		8	4	2	1	8	4	2	1		1607		8	4	2	1
Pre-Alarm Warning	8	4	2	1		1708		8	4	2	1	8	4	2	1		1608		8	4	2	1
Never Arm	8	4	2	1		1709		8	4	2	1	8	4	2	1		1609		8	4	2	1
24-Hour Zone	8	4	2	1		1710		8	4	2	1	8	4	2	1		1610		8	4	2	1
† Burg. Alarm Output	8	4	2	1		1711		8	4	2	1	8	4	2	1		1611		8	4	2	1
† Pulsed Alarm Output	8	4	2	1		1712		8	4	2	1	8	4	2	1		1612		8	4	2	1
Fire Output (Lug E9)	8	4	2	1		1713		8	4	2	1	8	4	2	1		1613		8	4	2	1
Reset Relay	8	4	2	1		1714		8	4	2	1	8	4	2	1		1614		8	4	2	1
Auxiliary Relay	8	4	2	1		1715		8	4	2	1	8	4	2	1		1615		8	4	2	1
† Entry/Exit 1	8	4	2	1		1716		8	4	2	1	8	4	2	1		1616		8	4	2	1
Entry/Exit 2	8	4	2	1		1717		8	4	2	1	8	4	2	1		1617		8	4	2	1
† Exit/Entry Follower	8	4	2	1		1718		8	4	2	1	8	4	2	1		1618		8	4	2	1
† Auto Reset	8	4	2	1		1719		8	4	2	1	8	4	2	1		1619		8	4	2	1
† Swinger Shutdown	8	4	2	1		1720		8	4	2	1	8	4	2	1		1620		8	4	2	1
† Chime	8	4	2	1		1721		8	4	2	1	8	4	2	1		1621		8	4	2	1
Abort Delay	8	4	2	1		1722		8	4	2	1	8	4	2	1		1622		8	4	2	1
Power-up Delay	8	4	2	1		1723		8	4	2	1	8	4	2	1		1623		8	4	2	1
Day Zone Open	8	4	2	1		1724		8	4	2	1	8	4	2	1		1624		8	4	2	1
Day Zone Short	8	4	2	1		1725		8	4	2	1	8	4	2	1		1625		8	4	2	1
Alarm on Day Zone	8	4	2	1		1726		8	4	2	1	8	4	2	1		1626		8	4	2	1
† Alarm Telco 1	8	4	2	1		1727		8	4	2	1	8	4	2	1		1627		8	4	2	1
Alarm Restore 1	8	4	2	1		1728		8	4	2	1	8	4	2	1		1628		8	4	2	1
Trouble Telco 1	8	4	2	1		1729		8	4	2	1	8	4	2	1		1629		8	4	2	1
Trouble Restore 1	8	4	2	1		1730		8	4	2	1	8	4	2	1		1630		8	4	2	1
Alarm Telco 3	8	4	2	1		1735		8	4	2	1	8	4	2	1		1635		8	4	2	1
Alarm Restore 3	8	4	2	1		1736		8	4	2	1	8	4	2	1		1636		8	4	2	1
Trouble Telco 3	8	4	2	1		1737		8	4	2	1	8	4	2	1		1637		8	4	2	1
Trouble Restore 3	8	4	2	1		1738		8	4	2	1	8	4	2	1		1638		8	4	2	1
No EOL Resistor	8	4	2	1		1739		8	4	2	1	8	4	2	1		1639		8	4	2	1
Sensor Watch	8	4	2	1		1740		8	4	2	1	8	4	2	1		1640		8	4	2	1
Trouble on Open	8	4	2	1		1741		8	4	2	1	8	4	2	1		1641		8	4	2	1
Trouble on Short	8	4	2	1		1742		8	4	2	1	8	4	2	1		1642		8	4	2	1
Trouble on Night Open	8	4	2	1		1743		8	4	2	1	8	4	2	1		1643		8	4	2	1
† Zone Area 1	8	4	2	1		1744		8	4	2	1	8	4	2	1		1644		8	4	2	1
† Zone Area 2	8	4	2	1		1745		8	4	2	1	8	4	2	1		1645		8	4	2	1
Zone Area 3	8	4	2	1		1746		8	4	2	1	8	4	2	1		1646		8	4	2	1
Zone Area 4	8	4	2	1		1747		8	4	2	1	8	4	2	1		1647		8	4	2	1
Zone Area 5	8	4	2	1		1748		8	4	2	1	8	4	2	1		1648		8	4	2	1
Zone Area 6	8	4	2	1		1749		8	4	2	1	8	4	2	1		1649		8	4	2	1
Zone Area 7	8	4	2	1		1750		8	4	2	1	8	4	2	1		1650		8	4	2	1
Zone Area 8	8	4	2	1		1751		8	4	2	1	8	4	2	1		1651		8	4	2	1
Bypass on Guard Tour	8	4	2	1		1753		8	4	2	1	8	4	2	1		1653		8	4	2	1
Zone ANDing Group 1	8	4	2	1		1754		8	4	2	1	8	4	2	1		1654		8	4	2	1
Zone ANDing Group 2	8	4	2	1		1755		8	4	2	1	8	4	2	1		1655		8	4	2	1
Zone ANDing Group 3	8	4	2	1		1756		8	4	2	1	8	4	2	1		1656		8	4	2	1
Zone ANDing Group 4	8	4	2	1		1757		8	4	2	1	8	4	2	1		1657		8	4	2	1
Zone ANDing Group 5	8	4	2	1		1758		8	4	2	1	8	4	2	1		1658		8	4	2	1
Zone ANDing Group 6	8	4	2	1		1759		8	4	2	1	8	4	2	1		1659		8	4	2	1
Zone ANDing Group 7	8	4	2	1		1760		8	4	2	1	8	4	2	1		1660		8	4	2	1
Zone ANDing Group 8	8	4	2	1		1761		8	4	2	1	8	4	2	1		1661		8	4	2	1
† Interior #1 Bypass	8	4	2	1		1762		8	4	2	1	8	4	2	1		1662		8	4	2	1
† Interior #2 Bypass	8	4	2	1		1763		8	4	2	1	8	4	2	1		1663		8	4	2	1
† Keypad Sounder on Alarm	8	4	2	1		1764		8	4	2	1	8	4	2	1		1664		8	4	2	1
† Fire (C)	8	4	2	1		1775		8	4	2	1	8	4	2	1		1675		8	4	2	1
† Fire Alarm Verification (C)	8	4	2	1		1776		8	4	2	1	8	4	2	1		1676		8	4	2	1
† Interior (STAY) Bypass	8	4	2	1		1784		8	4	2	1	8	4	2	1		1684		8	4	2	1
Chime 2	8	4	2	1		1786		8	4	2	1	8	4	2	1		1686		8	4	2	1



† When the Easy Program Menu is used, these features are enabled by default.





‡ Do not program if "K Series" keypads (with "STAY" and "AWAY" buttons) are used in the system.


⌘ Disable Auto-Reset on non-fire zones for SIA CP-01 installations.

¶ In UL installations, all Fire Zones must also be programmed for "Pulsed Burg Output" and "fire Output Cadence" (Address 2422, bit zero).

See Zone Options on Page 46.

# ZONE OPTIONS / ZONES 49-64 (ADDRESS 1802-1986)

ZONE OPTIONS	ZONES 61-64 LEFT DATA VALUES				ADDRESS 1902-1986			ZONES 57-60 RIGHT DATA VALUES				ZONES 53-56 LEFT DATA VALUES				ADDRESS 1802-1886			ZONES 49-52 RIGHT DATA VALUES			
	(CIRCLE  )							(CIRCLE  )				(CIRCLE  )							(CIRCLE  )			
	ZN64	ZN63	ZN62	ZN61	L	ADDR	R	ZN60	ZN59	ZN58	ZN57	ZN56	ZN55	ZN54	ZN53	L	ADDR	R	ZN52	ZN51	ZN50	ZN49
✚ Priority	8	4	2	1		1902		8	4	2	1	8	4	2	1		1802		8	4	2	1
Priority with Bypass	8	4	2	1		1903		8	4	2	1	8	4	2	1		1803		8	4	2	1
Auto-Bypass	8	4	2	1		1904		8	4	2	1	8	4	2	1		1804		8	4	2	1
✚ Selective Bypass	8	4	2	1		1905		8	4	2	1	8	4	2	1		1805		8	4	2	1
✚ Keyswitch Arming	8	4	2	1		1906		8	4	2	1	8	4	2	1		1806		8	4	2	1
Auto-Bypass Re-entry	8	4	2	1		1907		8	4	2	1	8	4	2	1		1807		8	4	2	1
Pre-Alarm Warning	8	4	2	1		1908		8	4	2	1	8	4	2	1		1808		8	4	2	1
Never Arm	8	4	2	1		1909		8	4	2	1	8	4	2	1		1809		8	4	2	1
24-Hour Zone	8	4	2	1		1910		8	4	2	1	8	4	2	1		1810		8	4	2	1
✚ Burg. Alarm Output	8	4	2	1		1911		8	4	2	1	8	4	2	1		1811		8	4	2	1
✚ Pulsed Alarm Output	8	4	2	1		1912		8	4	2	1	8	4	2	1		1812		8	4	2	1
Fire Output (Lug E9)	8	4	2	1		1913		8	4	2	1	8	4	2	1		1813		8	4	2	1
Reset Relay	8	4	2	1		1914		8	4	2	1	8	4	2	1		1814		8	4	2	1
Auxiliary Relay	8	4	2	1		1915		8	4	2	1	8	4	2	1		1815		8	4	2	1
✚ Entry/Exit 1	8	4	2	1		1916		8	4	2	1	8	4	2	1		1816		8	4	2	1
Entry/Exit 2	8	4	2	1		1917		8	4	2	1	8	4	2	1		1817		8	4	2	1
✚ Exit/Entry Follower	8	4	2	1		1918		8	4	2	1	8	4	2	1		1818		8	4	2	1
✚✚ Auto Reset	8	4	2	1		1919		8	4	2	1	8	4	2	1		1819		8	4	2	1
✚✚ Swinger Shutdown	8	4	2	1		1920		8	4	2	1	8	4	2	1		1820		8	4	2	1
✚ Chime	8	4	2	1		1921		8	4	2	1	8	4	2	1		1821		8	4	2	1
Abort Delay	8	4	2	1		1922		8	4	2	1	8	4	2	1		1822		8	4	2	1
Power-up Delay	8	4	2	1		1923		8	4	2	1	8	4	2	1		1823		8	4	2	1
Day Zone Open	8	4	2	1		1924		8	4	2	1	8	4	2	1		1824		8	4	2	1
Day Zone Short	8	4	2	1		1925		8	4	2	1	8	4	2	1		1825		8	4	2	1
Alarm on Day Zone	8	4	2	1		1926		8	4	2	1	8	4	2	1		1826		8	4	2	1
✚ Alarm Telco 1	8	4	2	1		1927		8	4	2	1	8	4	2	1		1827		8	4	2	1
Alarm Restore 1	8	4	2	1		1928		8	4	2	1	8	4	2	1		1828		8	4	2	1
Trouble Telco 1	8	4	2	1		1929		8	4	2	1	8	4	2	1		1829		8	4	2	1
Trouble Restore 1	8	4	2	1		1930		8	4	2	1	8	4	2	1		1830		8	4	2	1
Alarm Telco 3	8	4	2	1		1935		8	4	2	1	8	4	2	1		1835		8	4	2	1
Alarm Restore 3	8	4	2	1		1936		8	4	2	1	8	4	2	1		1836		8	4	2	1
Trouble Telco 3	8	4	2	1		1937		8	4	2	1	8	4	2	1		1837		8	4	2	1
Trouble Restore 3	8	4	2	1		1938		8	4	2	1	8	4	2	1		1838		8	4	2	1
No EOL Resistor	8	4	2	1		1939		8	4	2	1	8	4	2	1		1839		8	4	2	1
Sensor Watch	8	4	2	1		1940		8	4	2	1	8	4	2	1		1840		8	4	2	1
Trouble on Open	8	4	2	1		1941		8	4	2	1	8	4	2	1		1841		8	4	2	1
Trouble on Short	8	4	2	1		1942		8	4	2	1	8	4	2	1		1842		8	4	2	1
Trouble on Night Open	8	4	2	1		1943		8	4	2	1	8	4	2	1		1843		8	4	2	1
✚ Zone Area 1	8	4	2	1		1944		8	4	2	1	8	4	2	1		1844		8	4	2	1
✚ Zone Area 2	8	4	2	1		1945		8	4	2	1	8	4	2	1		1845		8	4	2	1
Zone Area 3	8	4	2	1		1946		8	4	2	1	8	4	2	1		1846		8	4	2	1
Zone Area 4	8	4	2	1		1947		8	4	2	1	8	4	2	1		1847		8	4	2	1
Zone Area 5	8	4	2	1		1948		8	4	2	1	8	4	2	1		1848		8	4	2	1
Zone Area 6	8	4	2	1		1949		8	4	2	1	8	4	2	1		1849		8	4	2	1
Zone Area 7	8	4	2	1		1950		8	4	2	1	8	4	2	1		1850		8	4	2	1
Zone Area 8	8	4	2	1		1951		8	4	2	1	8	4	2	1		1851		8	4	2	1
Bypass on Guard Tour	8	4	2	1		1953		8	4	2	1	8	4	2	1		1853		8	4	2	1
Zone ANDing Group 1	8	4	2	1		1954		8	4	2	1	8	4	2	1		1854		8	4	2	1
Zone ANDing Group 2	8	4	2	1		1955		8	4	2	1	8	4	2	1		1855		8	4	2	1
Zone ANDing Group 3	8	4	2	1		1956		8	4	2	1	8	4	2	1		1856		8	4	2	1
Zone ANDing Group 4	8	4	2	1		1957		8	4	2	1	8	4	2	1		1857		8	4	2	1
Zone ANDing Group 5	8	4	2	1		1958		8	4	2	1	8	4	2	1		1858		8	4	2	1
Zone ANDing Group 6	8	4	2	1		1959		8	4	2	1	8	4	2	1		1859		8	4	2	1
Zone ANDing Group 7	8	4	2	1		1960		8	4	2	1	8	4	2	1		1860		8	4	2	1
Zone ANDing Group 8	8	4	2	1		1961		8	4	2	1	8	4	2	1		1861		8	4	2	1
✚ Interior #1 Bypass	8	4	2	1		1962		8	4	2	1	8	4	2	1		1862		8	4	2	1
✚ Interior #2 Bypass	8	4	2	1		1963		8	4	2	1	8	4	2	1		1863		8	4	2	1
Keypad Sounder on Alarm	8	4	2	1		1964		8	4	2	1	8	4	2	1		1864		8	4	2	1
✚ Fire (C)	8	4	2	1		1975		8	4	2	1	8	4	2	1		1875		8	4	2	1
✚ Fire Alarm Verification (C)	8	4	2	1		1976		8	4	2	1	8	4	2	1		1876		8	4	2	1
✚ Interior (STAY) Bypass	8	4	2	1		1984		8	4	2	1	8	4	2	1		1884		8	4	2	1
Chime 2	8	4	2	1		1986		8	4	2	1	8	4	2	1		1886		8	4	2	1



☞ When the Easy Program Menu is used, these features are enabled by default.

☞ Do not program if "K Series" keypads (with "STAY" and "AWAY" buttons) are used in the system.

☞ Disable Auto-Reset on non-fire zones for SIA CP-01 installations.

☞ In UL installations, all Fire Zones must also be programmed for "Pulsed Burg Output" and "fire Output Cadence" (Address 2422, bit zero).

See Zone Options on Page 46.







NAPCO Security Systems



GEMINI GEM-P9600 Programming Instructions

# ZONE OPTIONS / ZONES 65-80 (ADDRESS 2002-2186)

ZONE OPTIONS	ZONES 77-80 LEFT DATA VALUES (CIRCLE  )				ADDRESS 2102-2186			ZONES 73-76 RIGHT DATA VALUES (CIRCLE  )				ZONES 69-72 LEFT DATA VALUES (CIRCLE  )				ADDRESS 2002-2086			ZONES 65-68 RIGHT DATA VALUES (CIRCLE  )			
	ZN80	ZN79	ZN78	ZN77	L	ADDR	R	ZN76	ZN75	ZN74	ZN73	ZN72	ZN71	ZN70	ZN69	L	ADDR	R	ZN68	ZN67	ZN66	ZN65
† Priority	8	4	2	1		2102		8	4	2	1	8	4	2	1		2002		8	4	2	1
Priority with Bypass	8	4	2	1		2103		8	4	2	1	8	4	2	1		2003		8	4	2	1
Auto-Bypass	8	4	2	1		2104		8	4	2	1	8	4	2	1		2004		8	4	2	1
† Selective Bypass	8	4	2	1		2105		8	4	2	1	8	4	2	1		2005		8	4	2	1
Keyswitch Arming	8	4	2	1		2106		8	4	2	1	8	4	2	1		2006		8	4	2	1
Auto-Bypass Re-entry	8	4	2	1		2107		8	4	2	1	8	4	2	1		2007		8	4	2	1
Pre-Alarm Warning	8	4	2	1		2108		8	4	2	1	8	4	2	1		2008		8	4	2	1
Never Arm	8	4	2	1		2109		8	4	2	1	8	4	2	1		2009		8	4	2	1
24-Hour Zone	8	4	2	1		2110		8	4	2	1	8	4	2	1		2010		8	4	2	1
† Burg. Alarm Output	8	4	2	1		2111		8	4	2	1	8	4	2	1		2011		8	4	2	1
† Pulsed Alarm Output	8	4	2	1		2112		8	4	2	1	8	4	2	1		2012		8	4	2	1
Fire Output (Lug E9)	8	4	2	1		2113		8	4	2	1	8	4	2	1		2013		8	4	2	1
Reset Relay	8	4	2	1		2114		8	4	2	1	8	4	2	1		2014		8	4	2	1
Auxiliary Relay	8	4	2	1		2115		8	4	2	1	8	4	2	1		2015		8	4	2	1
† Entry/Exit 1	8	4	2	1		2116		8	4	2	1	8	4	2	1		2016		8	4	2	1
Entry/Exit 2	8	4	2	1		2117		8	4	2	1	8	4	2	1		2017		8	4	2	1
† Exit/Entry Follower	8	4	2	1		2118		8	4	2	1	8	4	2	1		2018		8	4	2	1
† Auto Reset	8	4	2	1		2119		8	4	2	1	8	4	2	1		2019		8	4	2	1
† Swinger Shutdown	8	4	2	1		2120		8	4	2	1	8	4	2	1		2020		8	4	2	1
† Chime	8	4	2	1		2121		8	4	2	1	8	4	2	1		2021		8	4	2	1
Abort Delay	8	4	2	1		2122		8	4	2	1	8	4	2	1		2022		8	4	2	1
Power-up Delay	8	4	2	1		2123		8	4	2	1	8	4	2	1		2023		8	4	2	1
Day Zone Open	8	4	2	1		2124		8	4	2	1	8	4	2	1		2024		8	4	2	1
Day Zone Short	8	4	2	1		2125		8	4	2	1	8	4	2	1		2025		8	4	2	1
Alarm on Day Zone	8	4	2	1		2126		8	4	2	1	8	4	2	1		2026		8	4	2	1
† Alarm Telco 1	8	4	2	1		2127		8	4	2	1	8	4	2	1		2027		8	4	2	1
Alarm Restore 1	8	4	2	1		2128		8	4	2	1	8	4	2	1		2028		8	4	2	1
Trouble Telco 1	8	4	2	1		2129		8	4	2	1	8	4	2	1		2029		8	4	2	1
Trouble Restore 1	8	4	2	1		2130		8	4	2	1	8	4	2	1		2030		8	4	2	1
Alarm Telco 3	8	4	2	1		2135		8	4	2	1	8	4	2	1		2035		8	4	2	1
Alarm Restore 3	8	4	2	1		2136		8	4	2	1	8	4	2	1		2036		8	4	2	1
Trouble Telco 3	8	4	2	1		2137		8	4	2	1	8	4	2	1		2037		8	4	2	1
Trouble Restore 3	8	4	2	1		2138		8	4	2	1	8	4	2	1		2038		8	4	2	1
No EOL Resistor	8	4	2	1		2139		8	4	2	1	8	4	2	1		2039		8	4	2	1
Sensor Watch	8	4	2	1		2140		8	4	2	1	8	4	2	1		2040		8	4	2	1
Trouble on Open	8	4	2	1		2141		8	4	2	1	8	4	2	1		2041		8	4	2	1
Trouble on Short	8	4	2	1		2142		8	4	2	1	8	4	2	1		2042		8	4	2	1
Trouble on Night Open	8	4	2	1		2143		8	4	2	1	8	4	2	1		2043		8	4	2	1
† Zone Area 1	8	4	2	1		2144		8	4	2	1	8	4	2	1		2044		8	4	2	1
† Zone Area 2	8	4	2	1		2145		8	4	2	1	8	4	2	1		2045		8	4	2	1
Zone Area 3	8	4	2	1		2146		8	4	2	1	8	4	2	1		2046		8	4	2	1
Zone Area 4	8	4	2	1		2147		8	4	2	1	8	4	2	1		2047		8	4	2	1
Zone Area 5	8	4	2	1		2148		8	4	2	1	8	4	2	1		2048		8	4	2	1
Zone Area 6	8	4	2	1		2149		8	4	2	1	8	4	2	1		2049		8	4	2	1
Zone Area 7	8	4	2	1		2150		8	4	2	1	8	4	2	1		2050		8	4	2	1
Zone Area 8	8	4	2	1		2151		8	4	2	1	8	4	2	1		2051		8	4	2	1
Bypass on Guard Tour	8	4	2	1		2153		8	4	2	1	8	4	2	1		2053		8	4	2	1
Zone ANDing Group 1	8	4	2	1		2154		8	4	2	1	8	4	2	1		2054		8	4	2	1
Zone ANDing Group 2	8	4	2	1		2155		8	4	2	1	8	4	2	1		2055		8	4	2	1
Zone ANDing Group 3	8	4	2	1		2156		8	4	2	1	8	4	2	1		2056		8	4	2	1
Zone ANDing Group 4	8	4	2	1		2157		8	4	2	1	8	4	2	1		2057		8	4	2	1
Zone ANDing Group 5	8	4	2	1		2158		8	4	2	1	8	4	2	1		2058		8	4	2	1
Zone ANDing Group 6	8	4	2	1		2159		8	4	2	1	8	4	2	1		2059		8	4	2	1
Zone ANDing Group 7	8	4	2	1		2160		8	4	2	1	8	4	2	1		2060		8	4	2	1
Zone ANDing Group 8	8	4	2	1		2161		8	4	2	1	8	4	2	1		2061		8	4	2	1
† Interior #1 Bypass	8	4	2	1		2162		8	4	2	1	8	4	2	1		2062		8	4	2	1
† Interior #2 Bypass	8	4	2	1		2163		8	4	2	1	8	4	2	1		2063		8	4	2	1
† Keypad Sounder on Alarm	8	4	2	1		2164		8	4	2	1	8	4	2	1		2064		8	4	2	1
† Fire (C)	8	4	2	1		2175		8	4	2	1	8	4	2	1		2075		8	4	2	1
† Fire Alarm Verification (C)	8	4	2	1		2176		8	4	2	1	8	4	2	1		2076		8	4	2	1
† Interior (STAY) Bypass	8	4	2	1		2184		8	4	2	1	8	4	2	1		2084		8	4	2	1
Chime 2	8	4	2	1		2186		8	4	2	1	8	4	2	1		2086		8	4	2	1



† When the Easy Program Menu is used, these features are enabled by default.





‡ Do not program if "K Series" keypads (with "STAY" and "AWAY" buttons) are used in the system.


⌘ Disable Auto-Reset on non-fire zones for SIA CP-01 installations.

¶ In UL installations, all Fire Zones must also be programmed for "Pulsed Burg Output" and "fire Output Cadence" (Address 2422, bit zero).

See Zone Options on Page 46.

# ZONE OPTIONS / ZONES 81-96 (ADDRESS 2202-2386)

ZONE OPTIONS	ZONES 93-96 LEFT DATA VALUES (CIRCLE  )				ADDRESS 2302-2376			ZONES 89-92 RIGHT DATA VALUES (CIRCLE  )				ZONES 85-88 LEFT DATA VALUES (CIRCLE  )				ADDRESS 2202-2276			ZONES 81-84 RIGHT DATA VALUES (CIRCLE  )			
	ZN96	ZN95	ZN94	ZN93	L	ADDR	R	ZN92	ZN91	ZN90	ZN89	ZN88	ZN87	ZN86	ZN85	L	ADDR	R	ZN84	ZN83	ZN82	ZN81
Priority	8	4	2	1		2302		8	4	2	1	8	4	2	1		2202		8	4	2	1
Priority with Bypass	8	4	2	1		2303		8	4	2	1	8	4	2	1		2203		8	4	2	1
Auto-Bypass	8	4	2	1		2304		8	4	2	1	8	4	2	1		2204		8	4	2	1
Selective Bypass	8	4	2	1		2305		8	4	2	1	8	4	2	1		2205		8	4	2	1
Keyswitch Arming	8	4	2	1		2306		8	4	2	1	8	4	2	1		2206		8	4	2	1
Auto-Bypass Re-entry	8	4	2	1		2307		8	4	2	1	8	4	2	1		2207		8	4	2	1
Pre-Alarm Warning	8	4	2	1		2308		8	4	2	1	8	4	2	1		2208		8	4	2	1
Never Arm	8	4	2	1		2309		8	4	2	1	8	4	2	1		2209		8	4	2	1
24-Hour Zone	8	4	2	1		2310		8	4	2	1	8	4	2	1		2210		8	4	2	1
Burg. Alarm Output	8	4	2	1		2311		8	4	2	1	8	4	2	1		2211		8	4	2	1
Pulsed Alarm Output	8	4	2	1		2312		8	4	2	1	8	4	2	1		2212		8	4	2	1
Fire Output (Lug E9)	8	4	2	1		2313		8	4	2	1	8	4	2	1		2213		8	4	2	1
Reset Relay	8	4	2	1		2314		8	4	2	1	8	4	2	1		2214		8	4	2	1
Auxiliary Relay	8	4	2	1		2315		8	4	2	1	8	4	2	1		2215		8	4	2	1
Entry/Exit 1	8	4	2	1		2316		8	4	2	1	8	4	2	1		2216		8	4	2	1
Entry/Exit 2	8	4	2	1		2317		8	4	2	1	8	4	2	1		2217		8	4	2	1
Exit/Entry Follower	8	4	2	1		2318		8	4	2	1	8	4	2	1		2218		8	4	2	1
Auto Reset	8	4	2	1		2319		8	4	2	1	8	4	2	1		2219		8	4	2	1
Swinger Shutdown	8	4	2	1		2320		8	4	2	1	8	4	2	1		2220		8	4	2	1
Chime	8	4	2	1		2321		8	4	2	1	8	4	2	1		2221		8	4	2	1
Abort Delay	8	4	2	1		2322		8	4	2	1	8	4	2	1		2222		8	4	2	1
Power-up Delay	8	4	2	1		2323		8	4	2	1	8	4	2	1		2223		8	4	2	1
Day Zone Open	8	4	2	1		2324		8	4	2	1	8	4	2	1		2224		8	4	2	1
Day Zone Short	8	4	2	1		2325		8	4	2	1	8	4	2	1		2225		8	4	2	1
Alarm on Day Zone	8	4	2	1		2326		8	4	2	1	8	4	2	1		2226		8	4	2	1
Alarm Telco 1	8	4	2	1		2327		8	4	2	1	8	4	2	1		2227		8	4	2	1
Alarm Restore 1	8	4	2	1		2328		8	4	2	1	8	4	2	1		2228		8	4	2	1
Trouble Telco 1	8	4	2	1		2329		8	4	2	1	8	4	2	1		2229		8	4	2	1
Trouble Restore 1	8	4	2	1		2330		8	4	2	1	8	4	2	1		2230		8	4	2	1
Alarm Telco 3	8	4	2	1		2335		8	4	2	1	8	4	2	1		2235		8	4	2	1
Alarm Restore 3	8	4	2	1		2336		8	4	2	1	8	4	2	1		2236		8	4	2	1
Trouble Telco 3	8	4	2	1		2337		8	4	2	1	8	4	2	1		2237		8	4	2	1
Trouble Restore 3	8	4	2	1		2338		8	4	2	1	8	4	2	1		2238		8	4	2	1
No EOL Resistor	8	4	2	1		2339		8	4	2	1	8	4	2	1		2239		8	4	2	1
Sensor Watch	8	4	2	1		2340		8	4	2	1	8	4	2	1		2240		8	4	2	1
Trouble on Open	8	4	2	1		2341		8	4	2	1	8	4	2	1		2241		8	4	2	1
Trouble on Short	8	4	2	1		2342		8	4	2	1	8	4	2	1		2242		8	4	2	1
Trouble on Night Open	8	4	2	1		2343		8	4	2	1	8	4	2	1		2243		8	4	2	1
Zone Area 1	8	4	2	1		2344		8	4	2	1	8	4	2	1		2244		8	4	2	1
Zone Area 2	8	4	2	1		2345		8	4	2	1	8	4	2	1		2245		8	4	2	1
Zone Area 3	8	4	2	1		2346		8	4	2	1	8	4	2	1		2246		8	4	2	1
Zone Area 4	8	4	2	1		2347		8	4	2	1	8	4	2	1		2247		8	4	2	1
Zone Area 5	8	4	2	1		2348		8	4	2	1	8	4	2	1		2248		8	4	2	1
Zone Area 6	8	4	2	1		2349		8	4	2	1	8	4	2	1		2249		8	4	2	1
Zone Area 7	8	4	2	1		2350		8	4	2	1	8	4	2	1		2250		8	4	2	1
Zone Area 8	8	4	2	1		2351		8	4	2	1	8	4	2	1		2251		8	4	2	1
Bypass on Guard Tour	8	4	2	1		2353		8	4	2	1	8	4	2	1		2253		8	4	2	1
Zone ANDing Group 1	8	4	2	1		2354		8	4	2	1	8	4	2	1		2254		8	4	2	1
Zone ANDing Group 2	8	4	2	1		2355		8	4	2	1	8	4	2	1		2255		8	4	2	1
Zone ANDing Group 3	8	4	2	1		2356		8	4	2	1	8	4	2	1		2256		8	4	2	1
Zone ANDing Group 4	8	4	2	1		2357		8	4	2	1	8	4	2	1		2257		8	4	2	1
Zone ANDing Group 5	8	4	2	1		2358		8	4	2	1	8	4	2	1		2258		8	4	2	1
Zone ANDing Group 6	8	4	2	1		2359		8	4	2	1	8	4	2	1		2259		8	4	2	1
Zone ANDing Group 7	8	4	2	1		2360		8	4	2	1	8	4	2	1		2260		8	4	2	1
Zone ANDing Group 8	8	4	2	1		2361		8	4	2	1	8	4	2	1		2261		8	4	2	1
Interior #1 Bypass	8	4	2	1		2362		8	4	2	1	8	4	2	1		2262		8	4	2	1
Interior #2 Bypass	8	4	2	1		2363		8	4	2	1	8	4	2	1		2263		8	4	2	1
Keypad Sounder on Alarm	8	4	2	1		2364		8	4	2	1	8	4	2	1		2264		8	4	2	1
Fire (C)	8	4	2	1		2375		8	4	2	1	8	4	2	1		2275		8	4	2	1
Fire Alarm Verification (C)	8	4	2	1		2376		8	4	2	1	8	4	2	1		2276		8	4	2	1
Interior (STAY) Bypass	8	4	2	1		2384		8	4	2	1	8	4	2	1		2284		8	4	2	1
Chime 2	8	4	2	1		2386		8	4	2	1	8	4	2	1		2286		8	4	2	1



† When the Easy Program Menu is used, these features are enabled by default.

‡ Do not program if "K Series" keypads (with "STAY" and "AWAY" buttons) are used in the system.

⌘ Disable Auto-Reset on non-fire zones for SIA CP-01 installations.

⌘ In UL installations, all Fire Zones must also be programmed for "Pulsed Burg Output" and "fire Output Cadence" (Address 2422, bit zero).

See Zone Options on Page 46.



NAPCO Security Systems



GEMINI GEM-P9600 Programming Instructions


# ZONE OPTIONS / ZONES 1-96 (ADDRESS 1200-2386)

1. **Select** the desired zone option.

2. **Enable** desired options for each zone by drawing a circle around its corresponding binary data value.

NOTE: No circle = feature disabled.

ZN04	ZN03	ZN02	ZN01
8	4	2	1



3. **Search table** below for data entry.

DIGIT VALUE	DATA ENTRY	DIGIT VALUE	DATA ENTRY
8 4 2 1	Blank (-)	8 4 2 1	8
8 4 2 1	1	8 4 2 1	9
8 4 2 1	2	8 4 2 1	0
8 4 2 1	3	8 4 2 1	B
8 4 2 1	4	8 4 2 1	C
8 4 2 1	5	8 4 2 1	D
8 4 2 1	6	8 4 2 1	E
8 4 2 1	7	8 4 2 1	F

4. **Enter data** in address locations (left and right digits).

L	ADDR	R
blank (-)	1200	1

NOTE: Dark shaded data value box shows option not available.

NOTE: See Direct Address Programming Example on page 22.

- NOTES:**
- (A) 50ms & 20 ms Loop Response only available for zones 1-8.
  - (B) 2-wire Smoke Detectors only available for zones 1-8.
  - (C) If Fire Alarm Verification is selected, then Fire must also be selected.

**DEFAULTS:** The zone options indicated are automatically set after exiting the Easy Menu Driven Mode.











- ✓ *Priority, Selective Bypass, Alarm Output, Auto Reset, Swinger Shutdown, Zone Area 1 and Zone Area 2* are enabled for the total number of zones entered in "AREA 1 # ZONES = 08" and "AREA 2 # ZONES = 00".
- ✓ *Alarm Telco 1* is enabled for the zones if [YES] is entered for "REPORT ALL ZONES TO CENTRAL ZONES? Y/N".
- ✓ *Entry/Exit 1 and Chime* are enabled for zone numbers entered in "EXIT / ENTRY ZONES".
- ✓ *Exit/Entry Follower and Interior Bypass* are enabled for zone numbers entered in "INTERIOR ZONES".
- ✓ *Fire, Pulse Alarm Output and Fire Verification* is enabled for the zone numbers entered in "FIRE ZONES".
- ✓ *2-Wire Smoke Detector* is enabled for zone numbers entered in "2 WIRE FIRE ZONES".

Note: See "Number of Zones & Keypads per Area" in Easy Menu Driven program Mode.

THIS PAGE INTENTIONALLY LEFT BLANK



# SYSTEM OPTIONS (ADDRESS 2415-2419)

SYSTEM OPTIONS	LEFT DATA VALUES (CIRCLE  )	ADDRESS 2415	RIGHT DATA VALUES (CIRCLE  )	SYSTEM OPTIONS
Disable Fire Reset (Area 5)	1	LEFT DIGIT (SUM OF DATA VALUES)	1	Disable Fire Reset (Area 1)
Disable Fire Reset (Area 6)	2	RIGHT DIGIT (SUM OF DATA VALUES)	2	Disable Fire Reset (Area 2)
Disable Fire Reset (Area 7)	4		4	Disable Fire Reset (Area 3)
Disable Fire Reset (Area 8)	8		8	Disable Fire Reset (Area 4)
		[Default = blank (•) blank (•)]		
SYSTEM OPTIONS	LEFT DATA VALUES (CIRCLE  )	ADDRESS 2416	RIGHT DATA VALUES (CIRCLE  )	SYSTEM OPTIONS
Enable Day Zone Watch (Area 5)	1	LEFT DIGIT (SUM OF DATA VALUES)	1	Enable Day Zone Watch (Area 1)
Enable Day Zone Watch (Area 6)	2	RIGHT DIGIT (SUM OF DATA VALUES)	2	Enable Day Zone Watch (Area 2)
Enable Day Zone Watch (Area 7)	4		4	Enable Day Zone Watch (Area 3)
Enable Day Zone Watch (Area 8)	8		8	Enable Day Zone Watch (Area 4)
		[Default = blank (•) blank (•)]		
SYSTEM OPTIONS	LEFT DATA VALUES (CIRCLE  )	ADDRESS 2417	RIGHT DATA VALUES (CIRCLE  )	SYSTEM OPTIONS
RESERVED	1	LEFT DIGIT (SUM OF DATA VALUES)	1	Opening Report only after Alarm Report
Lug E4 Armed Away Only	2	RIGHT DIGIT (SUM OF DATA VALUES)	2	Closing Report only on Cond. Closing (Auto-Byp.)
Disable Auto-Unbypass on Disarming	4		4	Include Sel./Grp. Bypass in Cond. Closing Status
Bypass Faulted Zones	8		8	Status Report (Auto-Byp. Zones on
		[Default = blank (•) blank (•)]		
SYSTEM OPTIONS	LEFT DATA VALUES (CIRCLE  )	ADDRESS 2418	RIGHT DATA VALUES (CIRCLE  )	SYSTEM OPTIONS
Access Control (Panel) on Aux. Output	1	LEFT DIGIT (SUM OF DATA VALUES)	1	Auto Bell Test on Arming
Enable Burg. Output Warning on Entry	2	RIGHT DIGIT (SUM OF DATA VALUES)	2	Auto Reset after Burg. Output Timeout
Enable Manager's Mode	4		4	Suppress "Bypass" Reminder when Armed
Start Exit Delay after Ringback	8		8	RESERVED
		[Default = blank (•) blank (•)]		
SYSTEM OPTIONS	LEFT DATA VALUES (CIRCLE  )	ADDRESS 2419	RIGHT DATA VALUES (CIRCLE  )	SYSTEM OPTIONS
Disable Function-Mode Download	1	LEFT DIGIT (SUM OF DATA VALUES)	1	Interior 1 Normally Bypassed*
Disable Callback Download	2	RIGHT DIGIT (SUM OF DATA VALUES)	2	Enable Exit-Delay Restart
Disable Answering-Machine Download	4		4	Reset Day Zone with Arm/Disarm Only
Disable Auto-Reset on Day Zone	8		8	Enable Local Alarm on First Zone "AND" Trip
		[Default = blank (•) blank (•)]		

1. Select the desired option by circling  the data values for each digit (left and right).

2. Add the data values (ex: 15=1+2+4+8) from the selected options.



3. Enter in address location (left and right digits).



**NOTE:** Dark shaded data value box shows option not available.



\*Do not enable on systems with "K Series" keypads.





# SYSTEM OPTIONS (ADDRESS 2420-2422, 3874 & 3879-3881)

SYSTEM OPTIONS	LEFT DATA VALUES (CIRCLE 	ADDRESS 2420		RIGHT DATA VALUES (CIRCLE 	SYSTEM OPTIONS
Disable Keypad Instant Button	1	LEFT DIGIT (SUM OF DATA VALUES)	RIGHT DIGIT (SUM OF DATA VALUES)	1	Disable System Trouble Audible at Keypad *
Enable Line-Fault Test	2			2	Chime on E4 Lug
Disable AC Fail Detection	4			4	Disable Code required for Func. Mode Lvl. 1
Telco Fail only when Armed	8			8	Disable Code required for Easy Bypass
		[Default = blank (•) blank (•)] *Not for UL Installations			


SYSTEM OPTIONS	LEFT DATA VALUES (CIRCLE 	ADDRESS 2421		RIGHT DATA VALUES (CIRCLE 	SYSTEM OPTIONS
Don't Clear Aux. Relay with Disarm	1	<div>LEFT DIGIT (SUM OF DATA VALUES)</div> <div>RIGHT DIGIT (SUM OF DATA VALUES)</div>	<div>[Default = blank (•) blank (•)]</div>	1	Automatic Interior Bypass
2nd Call Answering Machine Override	2			2	Veri-phone Zones trip Aux. Relay
Disable Auto Status	4			4	Veri-phone Zones Priority over Alarms
Veri-phone Zones trip Fire Output	8			8	Aux. Output Chirp on Keyfob Arm/Disarm

SYSTEM OPTIONS	LEFT DATA VALUES (CIRCLE 	ADDRESS 2422		RIGHT DATA VALUES (CIRCLE 	SYSTEM OPTIONS
Disable Area Entry Relays	1	LEFT DIGIT (SUM OF DATA VALUES)	RIGHT DIGIT (SUM OF DATA VALUES)	1	Fire Output Cadence <sup>§</sup>
Disable Entry Urgency Tone at Keypad	2			2	Wireless Smoke Low Battery Resound
Enable Bell Output on Keyfob Arming	4			4	Supervised Alarm Output
Enable Burg. Output on Telco Fail only when Armed	8			8	Enable Smoke Detector Dirty Trouble
		[Default = blank (•) blank (•)]			

<sup>§</sup>In Zone Options, Fire Zones, and only Fire Zones, must be programmed for pulse alarm output.

SYSTEM OPTIONS	LEFT DATA VALUES (CIRCLE  )	ADDRESS 3874		RIGHT DATA VALUES (CIRCLE  )	SYSTEM OPTIONS
Enable Set Time/Date	1	LEFT DIGIT (SUM OF DATA VALUES)	RIGHT DIGIT (SUM OF DATA VALUES)	1	Enable GEM-PRINT
RESERVED	2			2	Cancel Report to Telco 3
Enable Time/Date Display	4			4	Report Wireless Trouble to Telco 1
RESERVED	8			8	Report Wireless Trouble to Telco 3
		[Default = blank (•) blank (•)]			

 1. Select the desired option by circling  the data values for each digit (left and right).

 2. Add the data values (ex: 15=1+2+4+8) from the selected options.

 3. Enter in address location (left and right digits).



**NOTE:** Dark shaded data value box shows option not available.

## ALARM/TROUBLE REPORTING CODES (ADDRESS 3879-3881)

ALARM/TROUBLE REPORTING CODES	ADDRESS 3879-3881		
	LEFT	ADDR	RIGHT
Wireless Low Battery	blank (*)	3879	
Wireless Supervisory	blank (*)	3880	
Wireless Tamper	blank (*)	3881	

[Default = blank (\*) blank (\*) from address 3879-3881]

### ALARM/TROUBLE REPORTING CODES:

- Enter in corresponding address location (left and right digits).  
**NOTE:** Left digit is the first digit and right digit is the second digit in a two digit CS receiver format.
- Valid entries are: 1-9, 0 and B-F.  
**NOTE:** A is not permitted.
- To disable a code leave boxes blank (\*).
- Press  or  to save.

## SYSTEM OPTIONS (ADDRESS 3882-3901, 3903-3905 & 4084)


Telephone Number Dialing Prefix (Digits 1-20)	ADDRESS 3882-3901 (RIGHT DIGITS 1-20)																			
	3882	3883	3884	3885	3886	3887	3888	3889	3890	3891	3892	3893	3894	3895	3896	3897	3898	3899	3900	3901
	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Pager Format: Re-sends of First Report	ADDRESS 3903	
	LEFT	RIGHT

[Default = blank (\*) blank (\*)]


Pager Format: Maximum Pages per Session	ADDRESS 3904	
	LEFT	RIGHT




[Default = blank (\*) blank (\*)]


SYSTEM OPTIONS	LEFT DATA VALUES (CIRCLE  )
Digital Dialer Rpt Enter/ Exit Test Mode	1
Enable CP-01 Limits	2
Disable Call Waiting on First Attempt	4
Enable Ambush in User Assignment Code Type	8

ADDRESS 3905	
LEFT DIGIT (SUM OF DATA VALUES)	RIGHT DIGIT (SUM OF DATA VALUES)

[Default = blank (\*) blank (\*)]

RIGHT DATA VALUES (CIRCLE  )	SYSTEM OPTIONS
1	RESERVED
2	Exit Time Restart
4	Sound Alarm on Exit Error
8	Rpt Exit Err/Recent Close

- Select the desired option by circling  the data values for each digit (left and right).
  - Add the data values (ex: F=15=(1+2+4+8) from the selected options. See page 24).
  - Enter in address location (left and right digits).
- NOTE:** Dark shaded data value box shows option not available.
- Press  or  to save.

SYSTEM OPTIONS	LEFT DATA VALUES (CIRCLE  )
RESERVED	1
RESERVED	2
RESERVED	4
Disable Auto Dial Tone Detection	8

ADDRESS 4084	
LEFT DIGIT (SUM OF DATA VALUES)	RIGHT DIGIT (SUM OF DATA VALUES)
	blank (*)

[Default = blank (\*) blank (\*)]

**Note:** Right digit is RESERVED (not used). Enter data in left digit only.

## KEYPAD OPTIONS (ADDRESS 2425-2454)

Keypad 1 Type & Area Assignment	ADDRESS 2425	
	LEFT	RIGHT

[Default = blank (•)]

Keypad 5 Type & Area Assignment	ADDRESS 2429	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

Keypad 9 Type & Area Assignment	ADDRESS 2433	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

Keypad 13 Type & Area Assignment	ADDRESS 2437	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

Keypad 2 Type & Area Assignment	ADDRESS 2426	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

Keypad 6 Type & Area Assignment	ADDRESS 2430	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

Keypad 10 Type & Area Assignment	ADDRESS 2434	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

Keypad 14 Type & Area Assignment	ADDRESS 2438	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

Keypad 3 Type & Area Assignment	ADDRESS 2427	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

Keypad 7 Type & Area Assignment	ADDRESS 2431	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

Keypad 11 Type & Area Assignment	ADDRESS 2435	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

Keypad 15 Type & Area Assignment	ADDRESS 2439	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

Keypad 4 Type & Area Assignment	ADDRESS 2428	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

Keypad 8 Type & Area Assignment	ADDRESS 2432	
	LEFT	RIGHT

[Default = blank (•) blank (•)]


Keypad 12 Type & Area Assignment	ADDRESS 2436	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

**KEYPAD TYPE & AREA ASSIGNMENT:** Up to 15 keypads may be programmed, if they are connected.



**NOTE:** See Keypad Configuration Mode. By default from the factory, each keypad is configured as number 1.

 1. Select keypad type & area assignment for each keypad from the tables shown.

 2. Enter in corresponding right and left digit address locations above.

KEYPAD TYPE	
LEFT	OPTION
blank (•)	Burg Keypad
2	Wizard Keypad

KEYPAD AREA ASSIGNMENT	
RIGHT	OPTION
blank (•)	Not Used
1	Area 1
2	Area 2
3	Area 3
4	Area 4
5	Area 5
6	Area 6
7	Area 7
8	Area 8


KEYPAD NO.	KEYPAD OPTIONS				ADDRESS 2440-2454			KEYPAD OPTIONS			
	LEFT DATA VALUES (CIRCLE  )							RIGHT DATA VALUES (CIRCLE  )			
	TOUR STATION	PANEL ACCESS	EASY ARMING	AMBUSH	LEFT	ADDR	RIGHT	Rem. Acc. Only *	KEYPAD PANIC	KEYPAD AUXILIARY	KEYPAD FIRE
1	8	4	2	1		2440		8	④	②	①
2	8	4	2	1		2441		8	4	2	1
3	8	4	2	1		2442		8	4	2	1
4	8	4	2	1		2443		8	4	2	1
5	8	4	2	1		2444		8	4	2	1
6	8	4	2	1		2445		8	4	2	1
7	8	4	2	1		2446		8	4	2	1
8	8	4	2	1		2447		8	4	2	1
9	8	4	2	1		2448		8	4	2	1
10	8	4	2	1		2449		8	4	2	1
11	8	4	2	1		2450		8	4	2	1
12	8	4	2	1		2451		8	4	2	1
13	8	4	2	1		2452		8	4	2	1
14	8	4	2	1		2453		8	4	2	1
15	8	4	2	1		2454		8	4	2	1

[Default = blank (•) blank (7) for address 2440]

**KEYPAD OPTIONS:** Select options for any of the 15 keypads.



\* **Note:** For Remote Access Control only (no Arm/Disarm capability).

 1. Select the desired option by circling  the data values for each digit (left and right).

 2. Add the data values (ex: 15=1+2+4+8) from the selected options.



 3. Enter in address location (left and right digits). **NOTE:** Dark shaded data value box shows option not available.


# USER AREA OPTIONS (ADDRESS 2500-2595)

USER NO.	AREAS 5-8 LEFT DATA VALUES (CIRCLE  )				ADDRESS 2500-2547			AREAS 1-4 RIGHT DATA VALUES (CIRCLE  )			
	A8	A7	A6	A5	L	ADDR	R	A4	A3	A2	A1
1	8	4	2	1		2500		8	4	2	1
2	8	4	2	1		2501		8	4	2	1
3	8	4	2	1		2502		8	4	2	1
4	8	4	2	1		2503		8	4	2	1
5	8	4	2	1		2504		8	4	2	1
6	8	4	2	1		2505		8	4	2	1
7	8	4	2	1		2506		8	4	2	1
8	8	4	2	1		2507		8	4	2	1
9	8	4	2	1		2508		8	4	2	1
10	8	4	2	1		2509		8	4	2	1
11	8	4	2	1		2510		8	4	2	1
12	8	4	2	1		2511		8	4	2	1
13	8	4	2	1		2512		8	4	2	1
14	8	4	2	1		2513		8	4	2	1
15	8	4	2	1		2514		8	4	2	1
16	8	4	2	1		2515		8	4	2	1
17	8	4	2	1		2516		8	4	2	1
18	8	4	2	1		2517		8	4	2	1
19	8	4	2	1		2518		8	4	2	1
20	8	4	2	1		2519		8	4	2	1
21	8	4	2	1		2520		8	4	2	1
22	8	4	2	1		2521		8	4	2	1
23	8	4	2	1		2522		8	4	2	1
24	8	4	2	1		2523		8	4	2	1
25	8	4	2	1		2524		8	4	2	1
26	8	4	2	1		2525		8	4	2	1
27	8	4	2	1		2526		8	4	2	1
28	8	4	2	1		2527		8	4	2	1
29	8	4	2	1		2528		8	4	2	1
30	8	4	2	1		2529		8	4	2	1
31	8	4	2	1		2530		8	4	2	1
32	8	4	2	1		2531		8	4	2	1
33	8	4	2	1		2532		8	4	2	1
34	8	4	2	1		2533		8	4	2	1
35	8	4	2	1		2534		8	4	2	1
36	8	4	2	1		2535		8	4	2	1
37	8	4	2	1		2536		8	4	2	1
38	8	4	2	1		2537		8	4	2	1
39	8	4	2	1		2538		8	4	2	1
40	8	4	2	1		2539		8	4	2	1
41	8	4	2	1		2540		8	4	2	1
42	8	4	2	1		2541		8	4	2	1
43	8	4	2	1		2542		8	4	2	1
44	8	4	2	1		2543		8	4	2	1
45	8	4	2	1		2544		8	4	2	1
46	8	4	2	1		2545		8	4	2	1
47	8	4	2	1		2546		8	4	2	1
48	8	4	2	1		2547		8	4	2	1



[Default = blank (\*) blank (\*) from address 2500-2595]



USER NO.	AREAS 5-8 LEFT DATA VALUES (CIRCLE  )				ADDRESS 2548-2595			AREAS 1-4 RIGHT DATA VALUES (CIRCLE  )			
	A8	A7	A6	A5	L	ADDR	R	A4	A3	A2	A1
49	8	4	2	1		2548		8	4	2	1
50	8	4	2	1		2549		8	4	2	1
51	8	4	2	1		2550		8	4	2	1
52	8	4	2	1		2551		8	4	2	1
53	8	4	2	1		2552		8	4	2	1
54	8	4	2	1		2553		8	4	2	1
55	8	4	2	1		2554		8	4	2	1
56	8	4	2	1		2555		8	4	2	1
57	8	4	2	1		2556		8	4	2	1
58	8	4	2	1		2557		8	4	2	1
59	8	4	2	1		2558		8	4	2	1
60	8	4	2	1		2559		8	4	2	1
61	8	4	2	1		2560		8	4	2	1
62	8	4	2	1		2561		8	4	2	1
63	8	4	2	1		2562		8	4	2	1
64	8	4	2	1		2563		8	4	2	1
65	8	4	2	1		2564		8	4	2	1
66	8	4	2	1		2565		8	4	2	1
67	8	4	2	1		2566		8	4	2	1
68	8	4	2	1		2567		8	4	2	1
69	8	4	2	1		2568		8	4	2	1
70	8	4	2	1		2569		8	4	2	1
71	8	4	2	1		2570		8	4	2	1
72	8	4	2	1		2571		8	4	2	1
73	8	4	2	1		2572		8	4	2	1
74	8	4	2	1		2573		8	4	2	1
75	8	4	2	1		2574		8	4	2	1
76	8	4	2	1		2575		8	4	2	1
77	8	4	2	1		2576		8	4	2	1
78	8	4	2	1		2577		8	4	2	1
79	8	4	2	1		2578		8	4	2	1
80	8	4	2	1		2579		8	4	2	1
81	8	4	2	1		2580		8	4	2	1
82	8	4	2	1		2581		8	4	2	1
83	8	4	2	1		2582		8	4	2	1
84	8	4	2	1		2583		8	4	2	1
85	8	4	2	1		2584		8	4	2	1
86	8	4	2	1		2585		8	4	2	1
87	8	4	2	1		2586		8	4	2	1
88	8	4	2	1		2587		8	4	2	1
89	8	4	2	1		2588		8	4	2	1
90	8	4	2	1		2589		8	4	2	1
91	8	4	2	1		2590		8	4	2	1
92	8	4	2	1		2591		8	4	2	1
93	8	4	2	1		2592		8	4	2	1
94	8	4	2	1		2593		8	4	2	1
95	8	4	2	1		2594		8	4	2	1
96	8	4	2	1		2595		8	4	2	1



 1. **Select** the desired user number.

USER NO.
1
2
3
4
5



 2. **Enable** desired areas for each user by drawing a circle  around its corresponding binary data value.

NOTE: No circle = feature disabled.


A4	A3	A2	A1
8	4	2	1



Draw Circle

 3. **Search table** below for data entry.

DIGIT VALUE	DATA ENTRY	DIGIT VALUE	DATA ENTRY
8 4 2 1	Blank (*)	8 4 2 1	8
8 4 2 (1)	1	8 4 2 (1)	9
8 4 (2) 1	2	8 4 (2) 1	0
8 4 (2) (1)	3	8 4 (2) (1)	B
8 (4) 2 1	4	8 (4) 2 1	C
8 (4) 2 (1)	5	8 (4) 2 (1)	D
8 (4) (2) 1	6	8 (4) (2) 1	E
8 (4) (2) (1)	7	8 (4) (2) (1)	F

 4. **Enter data** in address locations (left and right digits).

L	ADDR	R
blank (*)	2500	1

## EZM GROUP OPTIONS (ADDRESS 2600-2621)

EZM Group 1	
ZONES 9-12	
ADDRESS 2600	
LEFT	RIGHT
blank (•)	

EZM Group 7	
ZONES 33-36	
ADDRESS 2606	
LEFT	RIGHT
blank (•)	

EZM Group 13	
ZONES 57-60	
ADDRESS 2612	
LEFT	RIGHT
blank (•)	

EZM Group 19	
ZONES 81-84	
ADDRESS 2618	
LEFT	RIGHT
blank (•)	

EZM Group 2	
ZONES 13-16	
ADDRESS 2601	
LEFT	RIGHT
blank (•)	

EZM Group 8	
ZONES 37-40	
ADDRESS 2607	
LEFT	RIGHT
blank (•)	

EZM Group 14	
ZONES 61-64	
ADDRESS 2613	
LEFT	RIGHT
blank (•)	

EZM Group 20	
ZONES 85-88	
ADDRESS 2619	
LEFT	RIGHT
blank (•)	

EZM Group 3	
ZONES 17-20	
ADDRESS 2602	
LEFT	RIGHT
blank (•)	

EZM Group 9	
ZONES 41-44	
ADDRESS 2608	
LEFT	RIGHT
blank (•)	

EZM Group 15	
ZONES 64-68	
ADDRESS 2614	
LEFT	RIGHT
blank (•)	

EZM Group 21	
ZONES 89-92	
ADDRESS 2620	
LEFT	RIGHT
blank (•)	

EZM Group 4	
ZONES 21-24	
ADDRESS 2603	
LEFT	RIGHT
blank (•)	

EZM Group 10	
ZONES 45-48	
ADDRESS 2609	
LEFT	RIGHT
blank (•)	

EZM Group 16	
ZONES 69-72	
ADDRESS 2615	
LEFT	RIGHT
blank (•)	

EZM Group 22	
ZONES 93-96	
ADDRESS 2621	
LEFT	RIGHT
blank (•)	

EZM Group 5	
ZONES 25-28	
ADDRESS 2604	
LEFT	RIGHT
blank (•)	

EZM Group 11	
ZONES 49-52	
ADDRESS 2610	
LEFT	RIGHT
blank (•)	

EZM Group 17	
ZONES 73-76	
ADDRESS 2616	
LEFT	RIGHT
blank (•)	

EZM Group 6	
ZONES 29-32	
ADDRESS 2605	
LEFT	RIGHT
blank (•)	

EZM Group 12	
ZONES 53-56	
ADDRESS 2611	
LEFT	RIGHT
blank (•)	

EZM Group 18	
ZONES 77-80	
ADDRESS 2617	
LEFT	RIGHT
blank (•)	

Default depends on Easy Menu Question  
 “## OF ZNS IN AREA1  
 and “## OF ZNS IN AREA2

. For example, If 96 zones are used, then all 22 groups will be automatically enabled. If only 8 zones are used, then groups 1-22 will be automatically disabled.

**NOTE:** Zones 1-8 are included in the control panel and Zones 9-96 (Groups 1-22) are EZM Zones (either Wireless or Hardwired).

EZM TYPE	
DATA ENTRIES RIGHT	OPTION
blank (•)	Not used (No EZM present)
1	4-Zone EZM

**EZM GROUP OPTIONS:** Up to 22 Groups of 4 Zones each may be programmed depending on the number of zones used and which EZM modules are connected. Each group represents 4 zones.

1. Select EZM type from the table shown.

2. Enter in corresponding address locations above (right digit only).

**NOTE:** Dark shaded data value box shows option not available.

EZM PGM TERMINAL CONTROL											
GROUP NO.	AREAS 5-8 LEFT DATA VALUES				ADDRESS 2622-2632			AREAS 1-4 RIGHT DATA VALUES			
	A8	A7	A6	A5	L	ADDR	R	A4	A3	A2	A1
1	8	4	2	1		2622		8	4	2	1
2	8	4	2	1		2623		8	4	2	1
3	8	4	2	1		2624		8	4	2	1
4	8	4	2	1		2625		8	4	2	1
5	8	4	2	1		2626		8	4	2	1
6	8	4	2	1		2627		8	4	2	1
7	8	4	2	1		2628		8	4	2	1
8	8	4	2	1		2629		8	4	2	1
9	8	4	2	1		2630		8	4	2	1
10	8	4	2	1		2631		8	4	2	1
11	8	4	2	1		2632		8	4	2	1

EZM PGM TERMINAL CONTROL											
GROUP NO.	AREAS 5-8 LEFT DATA VALUES				ADDRESS 2633-2643			AREAS 1-4 RIGHT DATA VALUES			
	A8	A7	A6	A5	L	ADDR	R	A4	A3	A2	A1
12	8	4	2	1		2633		8	4	2	1
13	8	4	2	1		2634		8	4	2	1
14	8	4	2	1		2635		8	4	2	1
15	8	4	2	1		2636		8	4	2	1
16	8	4	2	1		2637		8	4	2	1
17	8	4	2	1		2638		8	4	2	1
18	8	4	2	1		2639		8	4	2	1
19	8	4	2	1		2640		8	4	2	1
20	8	4	2	1		2641		8	4	2	1
21	8	4	2	1		2642		8	4	2	1
22	8	4	2	1		2643		8	4	2	1

[Default = blank (•) blank (•) from address 2622-2643]

**EZM PGM ARMED TERMINAL CONTROL:** For each zone group select the area(s) which, when armed, will activate the PGM Lug on the corresponding EZM modules. Each zone group corresponds to 4 zones. If 8-Zone EZMs are used each one is treated as TWO zone groups. **NOTE:** Lug goes ACTIVE (low) when ANY selected area is armed. When activated, the PGM Lug goes negative (to Ground).

1. Select the desired group number.



2. Enable desired options for each area by drawing a circle around its corresponding binary data value.

**NOTE:** No circle = feature disabled.

3. Enter data in corresponding left and right digit address locations above.




## AREA ARMING OPTIONS (ADDRESS 2650-2657)

PRIORITY AREA ARMING											
ARMING AREA	AREAS 5-8 LEFT DATA VALUES (CIRCLE  )				ADDRESS 2650-2657			AREAS 1-4 RIGHT DATA VALUES (CIRCLE  )			
	A8	A7	A6	A5	L	ADDR	R	A4	A3	A2	A1
AREA 1	8	4	2	1		2650		8	4	2	1
AREA 2	8	4	2	1		2651		8	4	2	1
AREA 3	8	4	2	1		2652		8	4	2	1
AREA 4	8	4	2	1		2653		8	4	2	1
AREA 5	8	4	2	1		2654		8	4	2	1
AREA 6	8	4	2	1		2655		8	4	2	1
AREA 7	8	4	2	1		2656		8	4	2	1
AREA 8	8	4	2	1		2657		8	4	2	1

[Default = blank (\*) blank (\*) from address 2650-2657]


### PRIORITY AREA ARMING:

1. Select the desired arming area.
2. Enable desired options for each priority area by drawing a circle  around its corresponding binary data value.
3. Enter data in corresponding left and right digit address locations above.


**NOTE:** No circle = feature disabled.

**NOTE:** Dark shaded data value box shows option not available.





## REMOTE ACCESS LOGGING (ADDRESS 3184)







**REMOTE ACCESS LOGGING:** Enable logging of every keypad access event.

1. Select the desired option by circling  the data values for each digit (left and right).
2. Add the data values (ex: 15=1+2+4+8) from the selected options.
3. Enter in address location (left and right digits).





## AREA OUTPUT CONTROL OPTIONS (ADDRESS 2700-2739)

	DISARMING AREA 1 TURNS OFF AREA OUTPUT												DISARMING AREA 2 TURNS OFF AREA OUTPUT											
OUTPUT SILENCED (TURNED OFF)	AREAS 5-8 LEFT DATA VALUES (CIRCLE 				ADDRESS 2700-2732			AREAS 1-4 RIGHT DATA VALUES (CIRCLE 				AREAS 5-8 LEFT DATA VALUES (CIRCLE 				ADDRESS 2701-2733			AREAS 1-4 RIGHT DATA VALUES (CIRCLE 					
	A8	A7	A6	A5	L	ADDR	R	A4	A3	A2	A1	A8	A7	A6	A5	L	ADDR	R	A4	A3	A2	A1		
Burglary Output	8	4	2	1		2700		8	4	2	①	8	4	2	1		2701		8	4	2	1		
Pulsed Burg. Output	8	4	2	1		2708		8	4	2	①	8	4	2	1		2709		8	4	2	1		
Fire Output	8	4	2	1		2716		8	4	2	1	8	4	2	1		2717		8	4	2	1		
Reset Relay	8	4	2	1		2724		8	4	2	1	8	4	2	1		2725		8	4	2	1		
Auxiliary Relay	8	4	2	1		2732		8	4	2	1	8	4	2	1		2733		8	4	2	1		





[Default = 2700 (•1) 2708 (•1) ]

	DISARMING AREA 3 TURNS OFF AREA OUTPUT											DISARMING AREA 4 TURNS OFF AREA OUTPUT										
OUTPUT SILENCED (TURNED OFF)	AREAS 5-8 LEFT DATA VALUES				ADDRESS 2702-2734			AREAS 1-4 RIGHT DATA VALUES				AREAS 5-8 LEFT DATA VALUES				ADDRESS 2703-2735			AREAS 1-4 RIGHT DATA VALUES			
	(CIRCLE 							(CIRCLE 				(CIRCLE 							(CIRCLE 			
	A8	A7	A6	A5	L	ADDR	R	A4	A3	A2	A1	A8	A7	A6	A5	L	ADDR	R	A4	A3	A2	A1
Burglary Output	8	4	2	1		2702		8	4	2	1	8	4	2	1		2703		8	4	2	1
Pulsed Burg. Output	8	4	2	1		2710		8	4	2	1	8	4	2	1		2711		8	4	2	1
Fire Output	8	4	2	1		2718		8	4	2	1	8	4	2	1		2719		8	4	2	1
Reset Relay	8	4	2	1		2726		8	4	2	1	8	4	2	1		2727		8	4	2	1
Auxiliary Relay	8	4	2	1		2734		8	4	2	1	8	4	2	1		2735		8	4	2	1

[Default = blank (•) blank (•) from address 2702-2735]

	DISARMING AREA 5 TURNS OFF AREA OUTPUT											DISARMING AREA 6 TURNS OFF AREA OUTPUT										
OUTPUT SILENCED (TURNED OFF)	AREAS 5-8 LEFT DATA VALUES (CIRCLE 				ADDRESS 2704-2736			AREAS 1-4 RIGHT DATA VALUES (CIRCLE 				AREAS 5-8 LEFT DATA VALUES (CIRCLE 				ADDRESS 2705-2737			AREAS 1-4 RIGHT DATA VALUES (CIRCLE 			
	A8	A7	A6	A5	L	ADDR	R	A4	A3	A2	A1	A8	A7	A6	A5	L	ADDR	R	A4	A3	A2	A1
Burglary Output	8	4	2	1		2704		8	4	2	1	8	4	2	1		2705		8	4	2	1
Pulsed Burg. Output	8	4	2	1		2712		8	4	2	1	8	4	2	1		2713		8	4	2	1
Fire Output	8	4	2	1		2720		8	4	2	1	8	4	2	1		2721		8	4	2	1
Reset Relay	8	4	2	1		2728		8	4	2	1	8	4	2	1		2729		8	4	2	1
Auxiliary Relay	8	4	2	1		2736		8	4	2	1	8	4	2	1		2737		8	4	2	1

[Default = blank (•) blank (•) from address 2704-2737]

	DISARMING AREA 7 TURNS OFF AREA OUTPUT											DISARMING AREA 8 TURNS OFF AREA OUTPUT										
OUTPUT SILENCED (TURNED OFF)	AREAS 5-8 LEFT DATA VALUES (CIRCLE 				ADDRESS 2706-2738			AREAS 1-4 RIGHT DATA VALUES (CIRCLE 				AREAS 5-8 LEFT DATA VALUES (CIRCLE 				ADDRESS 2707-2739			AREAS 1-4 RIGHT DATA VALUES (CIRCLE 			
	A8	A7	A6	A5	L	ADDR	R	A4	A3	A2	A1	A8	A7	A6	A5	L	ADDR	R	A4	A3	A2	A1
Burglary Output	8	4	2	1		2706		8	4	2	1	8	4	2	1		2707		8	4	2	1
Pulsed Burg. Output	8	4	2	1		2714		8	4	2	1	8	4	2	1		2715		8	4	2	1
Fire Output	8	4	2	1		2722		8	4	2	1	8	4	2	1		2723		8	4	2	1
Reset Relay	8	4	2	1		2730		8	4	2	1	8	4	2	1		2731		8	4	2	1
Auxiliary Relay	8	4	2	1		2738		8	4	2	1	8	4	2	1		2739		8	4	2	1

[Default = blank (•) blank (•) from address 2706-2739]

**AREA OUTPUT TURNS OFF UPON DISARM:** Select options for any of the 5 Outputs per area when disarming a particular area.

1. Select the desired option by circling  the data values for left and right digits.

2. Add the data values (ex: 15=1+2+4+8) from the selected options.

3. Enter in right digit address location.

# RF RECEIVERS & SUPERVISORY TIMER OPTIONS (ADDRESS 3776 & 3760-3775)

Number of RF Receivers	ADDRESS 3776	
	LEFT	RIGHT
	blank (*)	

Default for Number of Receivers depends on Easy Menu Question for RF Transmitters.

DATA ENTRIES		RF Receiver(s)
RIGHT	blank (*)	
1		1
2		2
3		3
4		4

**RF RECEIVERS:** Up to 4 RF Receivers may be programmed.  
**NOTE:** This adds wireless capability to the system, increasing up to 96 the number of zones.

1. Select the number of receivers from the table shown.

2. Enter in corresponding right digit address location shown (left digit is not used).

RF SUPERVISORY TIMER	RF TRANSMITTER	ADDRESS 3760-3767		
		LEFT	ADDR	RIGHT
Type 0	Window/Door, 2 Pt.		3760	
Type 1	Window/Door, 2 Pt.		3761	
Type 2	Window/Door, 2 Pt.		3762	
Type 3	Window/Door, 2 Pt.		3763	
Type 4	Window/Door, 4 Pt.		3764	
Type 5	PIR		3765	
Type 6	PIR		3766	
Type 7	Smoke Detector		3767	

[Default = blank (\*) 8 from address 3760-3767 (80 minutes)]

RF SUPERVISORY TIMER	RF TRANSMITTER	ADDRESS 3768-3775		
		LEFT	ADDR	RIGHT
Type 8	Smoke Detector		3768	
Type 9	Keyfob		3769	
Type A	Dual Tech.		3770	
Type B	Keyfob		3771	
Type C	Window/Door, 4 Pt.		3772	
Type D	PIR		3773	
Type E	Smoke Detector		3774	
Type F	Napco Glass Break		3775	

[Default = blank (\*) 8 from address 3768-3775 (80 minutes)]

RF SUPERVISORY TIMERS		
DATA ENTRIES		DELAY
LEFT	RIGHT	
blank (*)	blank (*)	0 min.
blank (*)	1	10 min.
blank (*)	2	20 min.
blank (*)	3	30 min.
blank (*)	4	40 min.
blank (*)	5	50 min.
blank (*)	6	60 min.
blank (*)	7	70 min.
blank (*)	8	80 min.
blank (*)	9	90 min.
blank (*)	0	100 min.
blank (*)	B	110 min.
blank (*)	C	120 min.
blank (*)	D	130 min.
blank (*)	E	140 min.
blank (*)	F	150 min.
1	blank (*)	160 min.
1	1	170 min.
1	2	180 min.
1	3	190 min.
1	4	200 min.
1	5	210 min.
1	6	220 min.
1	7	230 min.
1	8	240 min.
1	9	250 min.
1	0	260 min.
1	B	270 min.
1	C	280 min.
1	D	290 min.
1	E	300 min.
1	F	310 min.
2	blank (*)	320 min.
2	1	330 min.
2	2	340 min.
2	3	350 min.
2	4	360 min.
2	5	370 min.

RF SUPERVISORY TIMERS		
DATA ENTRIES		DELAY
LEFT	RIGHT	
2	6	380 min.
2	7	390 min.
2	8	400 min.
2	9	410 min.
2	0	420 min.
2	B	430 min.
2	C	440 min.
2	D	450 min.
2	E	460 min.
2	F	470 min.
3	blank (*)	480 min.
3	1	490 min.
3	2	500 min.
3	3	510 min.
3	4	520 min.
3	5	530 min.
3	6	540 min.
3	7	550 min.
3	8	560 min.
3	9	570 min.
3	0	580 min.
3	B	590 min.
3	C	600 min.
3	D	610 min.
3	E	620 min.
3	F	630 min.
4	blank (*)	640 min.
4	1	650 min.
4	2	660 min.
4	3	670 min.
4	4	680 min.
4	5	690 min.
4	6	700 min.
F	F	2550 min. = 42 Hr., 30 min.

**RF SUPERVISORY TIMERS:** RF Supervisory Timers may be programmed for each type of transmitter used. A transmitter will send a transmission every time it is tripped, when there is NO activity, the transmitter sends a status transmission about once an hour. If the receiver does NOT receive ANY signal (a trip or a status) from a transmitter in the time specified for transmitter type, a system trouble "E-04-NN" will be displayed at the keypad.

1. Select timer delay from the table shown. Timers are programmed in increments of 10 minutes each. Valid entries are (\*)8-FF (80 minutes-2550 min) (2550 minutes = 42 hr,30 min).

**WARNING:** Timers have uncertainty of +/-30 minutes.

2. Enter in corresponding address locations above (left and right digits).

3. For a desired timer not listed do the following:

$$\begin{array}{r}
 \textcircled{6} \text{ Quotient} \longrightarrow \text{Left Digit} \\
 16 \overline{) 100} \\
 \underline{-96} \\
 \textcircled{4} \text{ Remainder} \longrightarrow \text{Right Digit}
 \end{array}$$

A. Choose a desired timer (intervals of 10),  
ex: 1440 min. (24 Hours)

B. Divide it by 10, ex: 1440/10 = 144

C. Divide it by 16

**NOTE:** These timers apply only to Supervised RF Transmitters (see RF Transmitters in Easy Menu Driven Mode Programming).





**EXTERNAL RELAY CONTROL / RELAYS 1-39 (ADDRESS 3778-3816 & 2800-2955)**

ADDRESS 3778 & 2800-2803 (RELAY/entry 1)									
3778	2800	2801	2802	2803					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3781 & 2812-2815 (RELAY/entry 4)									
3781	2812	2813	2814	2815					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3784 & 2824-2827 (RELAY/entry 7)									
3784	2824	2825	2826	2827					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3787 & 2836-2839 (RELAY/entry 10)									
3787	2836	2837	2838	2839					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3790 & 2848-2851 (RELAY/entry 13)									
3790	2848	2849	2850	2851					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3793 & 2860-2863 (RELAY/entry 16)									
3793	2860	2861	2862	2863					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3796 & 2872-2875 (RELAY/entry 19)									
3796	2872	2873	2874	2875					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3799 & 2884-2887 (RELAY/entry 22)									
3799	2884	2885	2886	2887					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3802 & 2896-2899 (RELAY/entry 25)									
3802	2896	2897	2898	2899					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3805 & 2908-2911 (RELAY/entry 28)									
3805	2908	2909	2910	2911					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3808 & 2920-2923 (RELAY/entry 31)									
3808	2920	2921	2922	2923					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3811 & 2932-2935 (RELAY/entry 34)									
3811	2932	2933	2934	2935					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3814 & 2944-2947 (RELAY/entry 37)									
3814	2944	2945	2946	2947					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3779 & 2804-2807 (RELAY/entry 2)									
3779	2804	2805	2806	2807					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3782 & 2816-2819 (RELAY/entry 5)									
3782	2816	2817	2818	2819					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3785 & 2828-2831 (RELAY/entry 8)									
3785	2828	2829	2830	2831					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3788 & 2840-2843 (RELAY entry 11)									
3788	2840	2841	2842	2843					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3791 & 2852-2855 (RELAY/entry 14)									
3791	2852	2853	2854	2855					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3794 & 2864-2867 (RELAY/entry 17)									
3794	2864	2865	2866	2867					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3797 & 2876-2879 (RELAY/entry 20)									
3797	2876	2877	2878	2879					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3800 & 2888-2891 (RELAY/entry 23)									
3800	2888	2889	2890	2891					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3803 & 2900-2903 (RELAY/entry 26)									
3803	2900	2901	2902	2903					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3794 & 2864-2867 (RELAY/entry 29)									
3806	2912	2913	2914	2915					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3809 & 2924-2927 (RELAY/entry 32)									
3809	2924	2925	2926	2927					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3812 & 2936-2939 (RELAY/entry 35)									
3812	2936	2937	2938	2939					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3815 & 2948-2951 (RELAY/entry 38)									
3815	2948	2949	2950	2951					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3780 & 2808-2811 (RELAY/entry 3)									
3780	2808	2809	2810	2811					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3783 & 2820-2823 (RELAY/entry 6)									
3783	2820	2821	2822	2823					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3786 & 2832-2835 (RELAY/entry 9)									
3786	2832	2833	2834	2835					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3789 & 2844-2847 (RELAY/entry 12)									
3789	2844	2845	2846	2847					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3792 & 2856-2859 (RELAY/entry 15)									
3792	2856	2857	2858	2859					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3795 & 2868-2871 (RELAY/entry 18)									
3795	2868	2869	2870	2871					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3798 & 2880-2883 (RELAY/entry 21)									
3798	2880	2881	2882	2883					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3801 & 2892-2895 (RELAY/entry 24)									
3801	2892	2893	2894	2895					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3804 & 2904-2907 (RELAY/entry 27)									
3804	2904	2905	2906	2907					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3807 & 2916-2919 (RELAY/entry 30)									
3807	2916	2917	2918	2919					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3810 & 2928-2931 (RELAY/entry 33)									
3810	2928	2929	2930	2931					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3813 & 2940-2943 (RELAY/entry 36)				
---	--	--	--	--

# EXTERNAL RELAY CONTROL / RELAYS 40-78 (ADDRESS 3817-3855 & 2856-3111)

## EXTERNAL RELAY CONTROL

ADDRESS 3778 & 2956-2959 (RELAY/entry 40)									
3817	2956	2957	2958	2959					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3820 & 2968-2971 (RELAY/entry 43)									
3820	2968	2969	2970	2971					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3823 & 2980-2983 (RELAY/entry 46)									
3823	2980	2981	2982	2983					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3826 & 2992-2995 (RELAY/entry 49)									
3826	2992	2993	2994	2995					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3829 & 3004-3007 (RELAY/entry 52)									
3829	3004	3005	3006	3007					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3832 & 3016-3019 (RELAY/entry 55)									
3832	3016	3017	3018	3019					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3835 & 3028-3031 (RELAY/entry 58)									
3835	3028	3029	3030	3031					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3838 & 3040-3043 (RELAY/entry 61)									
3838	3040	3041	3042	3043					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3841 & 3052-3055 (RELAY/entry 64)									
3841	3052	3053	3054	3055					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3844 & 3064-3067 (RELAY/entry 67)									
3844	3064	3065	3066	3067					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3847 & 3076-3079 (RELAY/entry 70)									
3847	3076	3077	3078	3079					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3850 & 3088-3091 (RELAY/entry 73)									
3850	3088	3089	3090	3091					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3853 & 3100-3103 (RELAY/entry 76)									
3853	3100	3101	3102	3103					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3818 & 2960-2963 (RELAY/entry 41)									
3818	2960	2961	2962	2963					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3821 & 2972-2975 (RELAY/entry 44)									
3821	2972	2973	2974	2975					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3824 & 2984-2987 (RELAY/entry 47)									
3824	2984	2985	2986	2987					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3827 & 2996-2999 (RELAY EVENT 50)									
3827	2996	2997	2998	2999					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3830 & 3008-3011 (RELAY/entry 53)									
3830	3008	3009	3010	3011					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3833 & 3020-3023 (RELAY/entry 56)									
3833	3020	3021	3022	3023					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3836 & 3032-3035 (RELAY/entry 59)									
3836	3032	3033	3034	3035					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3839 & 3044-3047 (RELAY/entry 62)									
3839	3044	3045	3046	3047					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3842 & 3056-3059 (RELAY/entry 65)									
3842	3056	3057	3058	3059					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3845 & 3068-3071 (RELAY/entry 68)									
3845	3068	3069	3070	3071					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3848 & 3080-3083 (RELAY/entry 71)									
3848	3080	3081	3082	3083					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3851 & 3092-3095 (RELAY/entry 74)									
3851	3092	3093	3094	3095					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3854 & 3104-3107 (RELAY/entry 77)									
3854	3104	3105	3106	3107					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3819 & 2964-2967 (RELAY/entry 42)									
3819	2964	2965	2966	2967					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3822 & 2976-2979 (RELAY/entry 45)									
3822	2976	2977	2978	2979					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3825 & 2988-2991 (RELAY/entry 48)									
3825	2988	2989	2990	2991					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3828 & 3000-3003 (RELAY/entry 51)									
3828	3000	3001	3002	3003					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3831 & 3012-3015 (RELAY/entry 54)									
3831	3012	3013	3014	3015					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3834 & 3024-3027 (RELAY/entry 57)									
3834	3024	3025	3026	3027					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3798 & 3036-3039 (RELAY/entry 60)									
3798	3036	3037	3038	3039					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3840 & 3048-3051 (RELAY/entry 63)									
3840	3048	3049	3050	3051					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3843 & 3060-3063 (RELAY/entry 66)									
3843	3060	3061	3062	3063					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3846 & 3072-3075 (RELAY/entry 69)									
3846	3072	3073	3074	3075					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3849 & 3084-3087 (RELAY/entry 72)									
3849		3084		3085		3086		3087	
L	R	L	R	L	R	L	R	L	R

# EXTERNAL RELAY CONTROL / RELAYS 79-96 (ADDRESS 3856-3873 & 3112-3183)

ADDRESS 3856 & 3112-3115 (RELAY/entry 79)									
3856	3112	3113	3114	3115					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3859 & 3124-3127 (RELAY/entry 82)									
3859	3124	3125	3126	3127					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3862 & 3136-3139 (RELAY/entry 85)									
3862	3136	3137	3138	3139					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3865 & 3148-3151 (RELAY/entry 88)									
3865	3148	3149	3150	3151					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3868 & 3160-3163 (RELAY/entry 91)									
3868	3160	3161	3162	3163					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3871 & 3172-3175 (RELAY/entry 94)									
3871	3172	3173	3174	3175					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3857 & 3116-3119 (RELAY/entry 80)									
3857	3116	3117	3118	3119					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3860 & 3128-3131 (RELAY/entry 83)									
3860	3128	3129	3130	3131					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3863 & 3140-3143 (RELAY/entry 86)									
3863	3140	3141	3142	3143					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3866 & 3152-3155 (RELAY entry 89)									
3866	3152	3153	3154	3155					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3869 & 3164-3167 (RELAY/entry 92)									
3869	3164	3165	3166	3167					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3872 & 3176-3179 (RELAY/entry 95)									
3872	3176	3177	3178	3179					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3858 & 3120-3123 (RELAY/entry 81)									
3858	3120	3121	3122	3123					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3861 & 3132-3135 (RELAY/entry 84)									
3861	3132	3133	3134	3135					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3864 & 3144-3147 (RELAY/entry 87)									
3864	3144	3145	3146	3147					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3867 & 3156-3159 (RELAY/entry 90)									
3867	3156	3157	3158	3159					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3870 & 3168-3171 (RELAY/entry 93)									
3870	3168	3169	3170	3171					
L	R	L	R	L	R	L	R	L	R

ADDRESS 3873 & 3180-3183 (RELAY/entry 96)									
3873	3180	3181	3182	3183					
L	R	L	R	L	R	L	R	L	R

[Default = blank (•) blank (•) from address 3778-3873 & 2800-3183]

To program, follow the 5 steps below:

**STEP 1: RELAY # OPTIONS:** Each relay/entry can be assigned to any of the 96 available external relays from Relay Module RM3008. Multiple entries can drive the same External Relay.

☞ Select the relay number from **Table 1** (shown on next page); enter in corresponding left and right digit address locations.

**Note:** Entries 01-96 correspond to relays 1 through 96. If entries are zero, zero (00), then relay number is identical to the relay/entry address table number, in the selected address table(s) above.

**STEP 2: AREA OPTIONS:** Each relay/entry can be assigned to Area 1-8 or all areas.

☞ Select the area from **Table 2** (shown on next page); enter in corresponding left and right digit address locations.

**STEP 3: TIMEOUTS:** Each relay event can be assigned a timeout depending on Alarm Type option.

☞ If Alarm Type (see next page) is selected for timeout in minutes or seconds, select the timeout from **Table 3** (shown on next page) in minutes or seconds and enter in corresponding address location (left digit and right digits). To choose seconds or minutes, see step 5A below. 254 is maximum entry.

**STEP 4: EVENT ID CODES:** Each relay event can be assigned any of the available event IDs from the table.

☞ Select 2-digit Event ID from **Table 4** (see page 59); enter in corresponding address locations (left and right digit).


**STEP 5: RELAY EVENT CONDITION OPTIONS:** Each relay event can be assigned an alarm type; and an activation condition; also, select a timeout type for each.

☞ 5A. Select Alarm Type and Timeout Type from **Table 5A** (see page 60); enter in corresponding address location (left digit).

**NOTE:** Select Timeout from Step 3.

☞ 5B. Select Activation from **Table 5B** (see page 60); enter in corresponding address location (right digit).

RELAY EVENT OPTIONS									
RELAY #	AREA	Timeout	Event ID	COND.					
L	R	L	R	L	R	L	R	L	R



Continued

RELAY EVENT OPTIONS				
RELAY # See Table 1 below	AREA See Table 2 below	TIMEOUT See Table 3 below	EVENT ID See Table 4 on page 59	COND. See Tables 5A & 5B on page 60

TABLE 1 RELAY MAPPING		
DATA ENTRIES		RELAY #
LEFT	RIGHT	
blank (*)	blank (*)	None *
blank (*)	1	1
blank (*)	2	2
blank (*)	3	3
blank (*)	4	4
blank (*)	5	5
blank (*)	6	6
blank (*)	7	7
blank (*)	8	8
blank (*)	9	9
blank (*)	0	10
blank (*)	B	11
blank (*)	C	12
blank (*)	D	13
blank (*)	E	14
blank (*)	F	15
1	blank (*)	16
1	1	17
1	2	18
1	3	19
1	4	20
1	5	21
1	6	22
1	7	23
1	8	24
1	9	25
1	0	26
1	B	27
1	C	28
1	D	29
1	E	30
1	F	31
2	blank (*)	32
2	1	33
2	2	34
2	3	35
2	4	36
2	5	37
2	6	38
2	7	39
2	8	40
2	9	41
2	0	42
2	B	43
2	C	44
2	D	45
2	E	46
2	F	47
6	blank (*)	96

\* Note: [blank (\*) blank (\*)] option affects the relay with the same entry number. All other options affect the relay number specified. Ex: Suppose Relay/Entry 1 is mapped to External Relay 1 and Relay/Entry 2 is mapped to External Relay 24. The data entries are as follows: Address 3778 = [blank (\*) blank (\*)] and Address 3779 = [1C].

For a desired relay not listed:  
A. Choose a desired relay, ex: 60  
B. Divide it by 16

$$\begin{array}{r} 16 \overline{) 60} \\ \underline{-48} \\ 12 \end{array}$$
 ③ Quotient → Left Digit  
 ④ Remainder → Right Digit

Areas 1-4

TABLE 2 (AREAS 1-4) AREAS CONTROLLING RELAY SHUTOFF ON DISARM				
RIGHT DATA ENTRY	AREA 4	AREA 3	AREA 2	AREA 1
blank (*)	NONE			
1	Y			
2		Y		
3	Y	Y		
4			Y	
5	Y		Y	
6		Y	Y	
7	Y	Y	Y	
8				Y
9	Y			Y
0		Y		Y
B	Y	Y		Y
C			Y	Y
D	Y		Y	Y
E		Y	Y	Y
F	Y	Y	Y	Y

Note: "Y" indicates option is enabled.

Areas 5-8

TABLE 2 (AREAS 5-8) AREAS CONTROLLING RELAY SHUTOFF ON DISARM				
LEFT DATA ENTRY	AREA 8	AREA 7	AREA 6	AREA 5
blank (*)	NONE			
1	Y			
2		Y		
3	Y	Y		
4			Y	
5	Y		Y	
6		Y	Y	
7	Y	Y	Y	
8				Y
9	Y			Y
0		Y		Y
B	Y	Y		Y
C			Y	Y
D	Y		Y	Y
E		Y	Y	Y
F	Y	Y	Y	Y

Note: "Y" indicates option is enabled.

TABLE 3 TIMEOUTS (Alarm Type is selected for Timeout Type in min. or sec.)		
DATA ENTRIES		TIMEOUT
LEFT	RIGHT	
blank (*)	blank (*)	0 min./sec.
blank (*)	1	1 min./sec.
blank (*)	2	2 min./sec.
blank (*)	3	3 min./sec.
blank (*)	4	4 min./sec.
blank (*)	5	5 min./sec.
blank (*)	6	6 min./sec.
blank (*)	7	7 min./sec.
blank (*)	8	8 min./sec.
blank (*)	9	9 min./sec.
blank (*)	0	10 min./sec.
blank (*)	B	11 min./sec.
blank (*)	C	12 min./sec.
blank (*)	D	13 min./sec.
blank (*)	E	14 min./sec.
blank (*)	F	15 min./sec.
1	blank (*)	16 min./sec.
1	1	17 min./sec.
1	2	18 min./sec.
1	3	19 min./sec.
1	4	20 min./sec.
1	5	21 min./sec.
1	6	11 min./sec.
1	7	12 min./sec.
1	8	13 min./sec.
1	9	14 min./sec.
1	0	15 min./sec.
1	B	16 min./sec.
1	C	17 min./sec.
1	D	18 min./sec.
F	F	255 min./sec.

For a desired delay/timeout not listed:  
A. Choose a desired delay/timeout, ex: 20 min.  
B. Divide it by 16

$$\begin{array}{r} 16 \overline{) 20} \\ \underline{-16} \\ 4 \end{array}$$
 ① Quotient → Left Digit  
 ② Remainder → Right Digit

Continued



**STEP 4: EVENT ID CODES:** Each relay event can be assigned any of the available event IDs from the table.


 Select 2-digit Event ID from **Table 4** (below); enter in corresponding address locations (left and right digit).

TABLE 4		
EVENT ID CODES		
DATA ENTRIES		OPTION
LEFT	RIGHT	
blank (+)	blank (+)	Area 1 Arm/Disarm
blank (+)	1	Area 2 Arm/Disarm
blank (+)	2	Area 3 Arm/Disarm
blank (+)	3	Area 4 Arm/Disarm
blank (+)	4	Area 5 Arm/Disarm
blank (+)	5	Area 6 Arm/Disarm
blank (+)	6	Area 7 Arm/Disarm
blank (+)	7	Area 8 Arm/Disarm
blank (+)	8	Zone 1
blank (+)	9	Zone 2
blank (+)	0	Zone 3
blank (+)	B	Zone 4
blank (+)	C	Zone 5
blank (+)	D	Zone 6
blank (+)	E	Zone 7
blank (+)	F	Zone 8
1	blank (+)	Zone 9
1	1	Zone 10
1	2	Zone 11
1	3	Zone 12
1	4	Zone 13
1	5	Zone 14
1	6	Zone 15
1	7	Zone 16
1	8	Zone 17
1	9	Zone 18
1	0	Zone 19
1	B	Zone 20
1	C	Zone 21
1	D	Zone 22
1	E	Zone 23
1	F	Zone 24
2	blank (+)	Zone 25
2	1	Zone 26
2	2	Zone 27
2	3	Zone 28
2	4	Zone 29
2	5	Zone 30
2	6	Zone 31
2	7	Zone 32
2	8	Zone 33
2	9	Zone 34
2	0	Zone 35
2	B	Zone 36
2	C	Zone 37
2	D	Zone 38
2	E	Zone 39
2	F	Zone 40
3	blank (+)	Zone 41
3	1	Zone 42
3	2	Zone 43
3	3	Zone 44
3	4	Zone 45
3	5	Zone 46
3	6	Zone 47
3	7	Zone 48
3	8	Zone 49
3	9	Zone 50
3	0	Zone 51
3	B	Zone 52
3	C	Zone 53
3	D	Zone 54
3	E	Zone 55
3	F	Zone 56
4	blank (+)	Zone 57
4	1	Zone 58
4	2	Zone 59
4	3	Zone 60

4	4	Zone 61
4	5	Zone 62
4	6	Zone 63
4	7	Zone 64
4	8	Zone 65
4	9	Zone 66
4	0	Zone 67
4	B	Zone 68
4	C	Zone 69
4	D	Zone 70
4	E	Zone 71
4	F	Zone 72
5	blank (+)	Zone 73
5	1	Zone 74
5	2	Zone 75
5	3	Zone 76
5	4	Zone 77
5	5	Zone 78
5	6	Zone 79
5	7	Zone 80
5	8	Zone 81
5	9	Zone 82
5	0	Zone 83
5	B	Zone 84
5	C	Zone 85
5	D	Zone 86
5	E	Zone 87
5	F	Zone 88
6	blank (+)	Zone 89
6	1	Zone 90
6	2	Zone 91
6	3	Zone 92
6	4	Zone 93
6	5	Zone 94
6	6	Zone 95
6	7	Zone 96
6	8	Area 1 Keypad Ambush
6	9	Area 1 Keypad Panic
6	0	Area 1 Keypad Fire
6	B	Area 1 Keypad Medical
6	C	Keypad Tamper
6	D	Area 1 Fail to Open
6	E	Area 1 Fail to Close
7	blank (+)	Area 2 Keypad Ambush
7	1	Area 2 Keypad Panic
7	2	Area 2 Keypad Fire
7	3	Area 2 Keypad Medical
7	5	Area 2 Fail to Open
7	6	Area 2 Fail to Close
7	8	Area 3 Keypad Ambush
7	9	Area 3 Keypad Panic
7	0	Area 3 Keypad Fire
7	B	Area 3 Keypad Medical
7	D	Area 3 Fail to Open
7	E	Area 3 Fail to Close
8	blank (+)	Area 4 Keypad Ambush
8	1	Area 4 Keypad Panic
8	2	Area 4 Keypad Fire
8	3	Area 4 Keypad Medical
8	5	Area 4 Fail to Open
8	6	Area 4 Fail to Close
8	8	Area 5 Keypad Ambush
8	9	Area 5 Keypad Panic
8	0	Area 5 Keypad Fire
8	B	Area 5 Keypad Medical
8	D	Area 5 Fail to Open
8	E	Area 5 Fail to Close
9	blank (+)	Area 6 Keypad Ambush
9	1	Area 6 Keypad Panic
9	2	Area 6 Keypad Fire
9	3	Area 6 Keypad Medical
9	5	Area 6 Fail to Open
9	6	Area 6 Fail to Close
9	8	Area 7 Keypad Ambush
9	9	Area 7 Keypad Panic

9	0	Area 7 Keypad Fire
9	B	Area 7 Keypad Medical
9	D	Area 7 Fail to Open
9	E	Area 7 Fail to Close
0	blank (+)	Area 8 Keypad Ambush
0	1	Area 8 Keypad Panic
0	2	Area 8 Keypad Fire
0	3	Area 8 Keypad Medical
0	5	Area 8 Fail to Open
0	6	Area 8 Fail to Close
0	8	Test Timer
0	0	Bus Fail
0	B	Guarded RAM Fail
0	C	Low Battery
0	D	AC Fail
0	E	EZM Tamper
0	F	Sensor Watch
B	blank (+)	Telco Fault
B	8	Digital Dialer Test
B	9	Guard-Tour Fail
B	B	Service Message
B	C	Program Change
B	D	RF Receiver Trouble
B	E	Transmitter Tamper
B	F	Transmitter Trouble
D	blank (+)	Keypad Fail
D	1	EZM Fail
D	2	Quickloader Device Control
D	3	System Shutdown
D	4	Quickloader Keypad Reset
D	5	General System Alarm
D	8	Area 1 General System Alarm
D	9	Area 2 General System Alarm
D	0	Area 3 General System Alarm
D	B	Area 4 General System Alarm
D	C	Area 5 General System Alarm
D	D	Area 6 General System Alarm
D	E	Area 7 General System Alarm
D	F	Area 8 General System Alarm
F	blank (+)	Relay Group 1
F	1	Relay Group 2
F	2	Relay Group 3
F	3	Relay Group 4
F	4	Relay Group 5
F	5	Relay Group 6
F	6	Relay Group 7
F	7	Relay Group 8
F	8	Area 1 Entry Delay
F	9	Area 2 Entry Delay
F	0	Area 3 Entry Delay
F	B	Area 4 Entry Delay
F	C	Area 5 Entry Delay
F	D	Area 6 Entry Delay
F	E	Area 7 Entry Delay
F	F	Area 8 Entry Delay

**NOTE:** Keypad Tamper must be enabled in UL installations using jumper option on keypad.

*Continued*



**STEP 5: RELAY EVENT CONDITION OPTIONS:** Each relay event can be assigned an alarm type; and an activation condition; also, select a timeout type for each.

5A. Select Alarm Type and Timeout Type from **Table 5A** (below); enter in corresponding address location (left digit). **NOTE:** Select Timeout from Step 2.

5B. Select Activation from from **Table 5B** (below); enter in corresponding address location (right digit).

TABLE 5A		
RELAY EVENT		
ALARM TYPE OPTIONS		
LEFT DATA ENTRIES	ALARM TYPE	TIMEOUT TYPE
blank (*)	Burglary	Minutes
1	Fire	Minutes
4	Day Zone	Minutes
8	Burglary	Seconds
9	Fire	Seconds
C	Day Zone	Seconds

TABLE 5B	
RELAY EVENT	
ACTIVATION CONDITIONS	
RIGHT DATA ENTRIES	OPTIONS
1	Alarm
2	Restore
3	Trouble
4	Trouble Restore
5	Follows Open Zone
6	Follows Shorted Zone

## NUMBER OF RELAY BOARD MODULES (ADDRESS 3777)

Number of Relay Board Modules	ADDRESS 3777	
	LEFT	RIGHT
	blank (*)	

[Default = blank (\*) blank (\*)]

DATA ENTRIES	Relay Board Module(s)
RIGHT	
blank (*)	None
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	10
B	11
C	12

**RELAY BOARD MODULES:** Up to 12 External Relay Board Modules (RM3008) may be programmed.

1. Select the number of relay modules from the table shown.

2. Enter in corresponding right digit address location shown (left digit is not used).

## SYSTEM RESET OPTIONS (ADDRESS 4091-4093)

4091 XX

GEM-RP1CAe2 Keypad

### ***Clear Dealer Program (Erases Dealer Program)***

**WARNING**

This erases the dealer program. Use this feature to start a customized default program.

4091XX

Access address 4091, then press the  button. Data entry is not allowed.

**NOTE:** Enter Easy Menu Driven Program Mode to program system again.

4093 XX

GEM-RP1CAe2 Keypad

### ***Cold Start (Erases Entire Program)***

**WARNING**

This erases the entire program (codes, schedules, foreign language configuration, etc), leaving the panel as it came right out of the box.

4093XX

Access address 4093, then press the  button. Data entry is not allowed.



**NOTE:** Some features (schedules, language configuration) can only be re-programmed with the Downloading Software.

# USER PROGRAM MODE





## PRELIMINARY INFORMATION



The User Program Mode is covered in detail in the operating instructions for the keypad in use.




- ☞ Only Keypad #1 may be used for programming, however this keypad may be located in any area.
- ☞ The Program Mode cannot be accessed while the communicator is transmitting except during the first three minutes after power-up.
- ☞ After entering codes or data, press the save  button. *Data will not be stored into memory unless this button is pressed.*
- ☞ If the keypad is in the Program Mode and no activity is detected for longer than 4 minutes, a steady tone will sound.
- ☞ Press the  button to silence the sounder and exit the User Program Mode.

**NOTE:** For ease of programming, it is recommended that a GEM-RP1CAe2 or GEM-K1CA be used as Keypad #1. (A new GEM-RP1CAe2/GEM-K1CA is automatically configured as Keypad #1). See Keypad Configuration Mode and WI777 for more information.

If a GEM-K2AS or GEM-RP2ASe2 keypad is used, configure address jumpers as Keypad #1 (see page 64, "Configuring the Keypads"). Use the  or  button to manually scroll the display at the end of each programming line.

## ACCESSING USER PROGRAM MODE


1. Press  

↙ New Panel (Default User Code = 123) ↘  
Existing Panel (Any Code with User Program Option Enabled)
2. Press  Until "TURNON PROG Y/N" (GEM-RP2ASe2/GEM-K2AS) or "77" (GEM-RP3DGTL/GEM-K3DGTL or GEM-RP4RFC/GEM-K4RF) appears on the LCD screen.
3. Press  To Enter User Program Mode.
4. Press  To Exit User Program Mode when finished.



## USER CODES

GEM-K2AS Keypad




(Direct Entry)

### To Program User Codes

1. Enter 2-digit User Number (01-32) directly using number buttons (0-9).
2. Press the **MENU** button.
3. Enter Code (1-6 digits) directly using number buttons (0-9).
4. Press the **ENTER** button to save each code.


**NOTE:** Press **\*** **0** button to clear character at cursor.

To continue press **STAY** or **AWAY** button.




### Programming User Codes with GEM-K2AS Keypad


GEM-K3DGTL Keypad



User Program Mode



User Number




User Code (Direct Entry)

### To Program User Codes

1. Enter 2-digit User Number (01-32) directly using number buttons (0-9).
2. Press the **MENU** button.
3. Enter Code (1-6 digits) directly using number buttons (0-9).
4. Press the **ENTER** button to save each code.

**NOTE:** Press **\*** **0** button to clear character at cursor.

To continue press **STAY** or **AWAY** button.



### Programming User Codes with GEM-K3DGTL Keypad

GEM-K4RF Keypad



User Program Mode



User Number




User Code (Direct Entry)

### To Program User Codes

1. Enter 2-digit User Number (01-32) directly using number buttons (0-9).
2. Press the **MENU** button.
3. Enter Code (1-6 digits) directly using number buttons (0-9).
4. Press the **ENTER** button to save each code.

**NOTE:** Press **\*** **0** button to clear character at cursor.

To continue press **STAY** or **AWAY** button.



### Programming User Codes with GEM-K4RF Keypad

# KEYPAD CONFIGURATION MODE



This section will focus on configuring the GEM-RP2ASe2/GEM-K2AS, GEM-RP3DGTL/GEM-K3DGTL, GEM-RP4RFC/GEM-K4RF, and GEM-RP4C/GEM-K4 series Keypads. If there is more than one keypad in the system, only Keypad No. 1 may be used for programming. For ease of programming, it is recommended that a GEM-RP1CAe2 or a GEM-K1CA be selected as Keypad #1 (see WI777 for Programming Instructions).

## KEYPAD INSTALLATION

Each keypad must be assigned an address number (1–15) and each requires its own configuration procedure (see CONFIGURING THE KEYPADS, which follows, and DIRECT ADDRESS KEYPAD AREA OPTIONS). At least 1 keypad must be used; only 1 is required for a single-area Commercial Burglary installation. **Note:** The **GEM-RP2ASe2/GEM-K2AS** keypads are utility LCD keypads combining several preset LCD words with a limited message line. Due to space constraints, available messages are abbreviated and will scroll automatically.

## CONFIGURING THE KEYPADS

### *Configuring the GEM-RP2ASe2/GEM-K2AS, GEM-RP3DGTL/GEM-K3DGTL, GEM-RP4RFC/GEM-K4RF and GEM-RP4C/GEM-K4 Keypads*

Up to 15 GEM-RP2ASe2/GEM-K2AS, GEM-RP3DGTL/GEM-K3DGTL, GEM-RP4RFC/GEM-K4RF and/or GEM-RP4C/GEM-K4 series keypads may be connected to the panel (Keypads 1–15). Each must be configured for a keypad address. In addition, the keypad may be configured to disable (a) touchpad backlight; (b) LCD backlight; and (c) entry sounder. Keypads are configured by the proper selection of jumpers. Refer to the label on the circuit board insulation paper for jumper locations and a summary of settings.

#### KEYPAD ADDRESS

If more than one keypad is installed:

- ☞ Each must be assigned a unique address (that is, no two keypads may be numbered alike).
- ☞ Keypads must be addressed consecutively (that is, missing numbers are not permitted).
- ☞ Only Keypad No. 1 may be used for programming. (However, for ease of programming, it is recommended that a GEM-RP1CAe2/ GEM-K1CA be selected as Keypad #1).

Assign the keypad address number by selecting Jumpers J1–3 in accordance with the table at right.

KEYPAD NUMBER	KEYPAD ADDRESS SETTING			PARK
	1	2	3	
1	OFF or ON*	OFF	OFF	STORE SPARE JUMPER AT THIS POSITION
2	OFF	ON	OFF	
3	ON	ON	OFF	
4	OFF	OFF	OFF	
5	ON	OFF	ON	
6	OFF	ON	ON	
7	ON	ON	ON	

**\*Notes:** (1) Keypads are shipped from the factory *without* jumpers installed and as such are automatically configured as Keypad No. 1. (2) Only one keypad in the system may be configured as Keypad No. 1, otherwise none will function.

#### TOUCHPAD BACK LIGHT

Cut Jumper A to disable touch pad backlighting to conserve 11mA standby current.

#### LCD BACKLIGHT

Cut Jumper B to disable LCD backlighting.

#### DISABLE SOUNDER

Cut Jumper C to disable the sounder. (Do not disable in UL applications).

**ALPHABETICAL INDEX**

20ms Loop Response (A) .....	40
24 Hour Zones in Area 1	
Easy Program Menu .....	7, 15
24-Hour Zone	
(Zone Option) .....	40-45
2nd Call Answering Machine Override, Address 2421 .....	49
2-Wire Fire Zones in Area 1	
Easy Program Menu .....	6, 14
2-Wire Smoke Detectors (B)	
(Zone Option) .....	40-45
50 mS Loop Response Zones	
Easy Program Menu .....	7, 15
50ms Loop Response (A) .....	40

**A**

Abort Delay	
(Zone Option) .....	40-45
ABORT DELAY, Address 2406 .....	27
AC Fail Report Delay, Address 2408 .....	27
Access Control (Panel) on Aux. Output, Address 2418 .....	48
Access Direct Address Program Mode .....	23, 24
ACCESSING DEALER PROGRAM MODE .....	5
ACCESSING DIRECT ADDRESS PROGRAM MODE .....	22
ACCESSING USER PROGRAM MODE .....	64
Alarm on Day Zone	
(Zone Option) .....	40-45
Alarm Restore 1	
(Zone Option) .....	40-45
Alarm Restore 3	
(Zone Option) .....	40-45
Alarm Telco 1	
(Zone Option) .....	40-45
Alarm Telco 3	
(Zone Option) .....	40-45
ALARM/TROUBLE REPORTING CODES, Address	
0860-0862 .....	32
ALARM/TROUBLE REPORTING CODES, ADDRESS	
3879-3881 .....	50
Ambush Code, Address 0495 .....	28
AREA ARMING OPTIONS, ADDRESS 2650-2657 .....	54
AREA OUTPUT CONTROL OPTIONS, ADDRESS	
2700-2739 .....	55
Area SYSTEM TROUBLE reporting OPTIONS,	
ADDRESS 1120-1157 .....	38
Area SYSTEM TROUBLE reporting OPTIONS,	
ADDRESS 1160-1197 .....	39
Auto Bell Test on Arming, Address 2418 .....	48
Auto Bypass Re-entry Zones	
Easy Program Menu .....	7, 16
Auto Disarm Rearm Delay, Address 4083 .....	28
Auto Download ID No., Address 1023 .....	30
Auto Reset	
(Zone Option) .....	40-45
Auto Reset after Burg. Output Timeout, Address 2418 .....	48
Auto-Bypass	
(Zone Option) .....	40-45
Auto-Bypass Re-entry	
(Zone Option) .....	40-45
Automatic Interior Bypass, Address 2421 .....	49
Aux Output Activated on Alarm Zones	

Easy Program Menu .....	7, 15
Aux. Output Access Control Timeout, Address 2402 .....	27
Aux. Output Chirp on Keyfob Arm/Disarm, Address 2421 .....	49
Aux. Output Timeout, Address 2401 .....	28
Auxiliary Relay	
(Zone Option) .....	40-45

**B**

Backup Report on Telco 2, Address 1027 .....	33
Burg. Alarm Output	
(Zone Option) .....	40-45
Burg. Alarm Output Timeout, Address 2403 .....	28
Bypass Faulted Zones, Address 2417 .....	48
Bypass on Guard Tour	
(Zone Option) .....	40-45

**C**

Callback Method	
Overview .....	4
Callback Telephone No. Select, Address 1022 .....	30
Cancel Next Test Timer on any Report, Address 1027 .....	33
Cancel Report to Telco 3, Address 3874 .....	49
Central Station Receiver 1 Account Number	
Easy Program Menu .....	9, 17
Central Station Receiver 1 Format	
Easy Program Menu .....	9, 17
Central Station Receiver 1 Telephone Number	
Easy Program Menu .....	8, 17
CHANGES FROM PREVIOUS EDITION .....	2
CHANGING OR CANCELING A CODE	
Easy Program Menu .....	11, 19
Chime	
(Zone Option) .....	40-45
Chime 2	
(Zone Option) .....	40-45
Chime 2 Zones in Area 1	
Easy Program Menu .....	7, 15
Chime on E4 Lug, Address 2420 .....	49
CHIME TIMEOUT, Address 2407 .....	27
Chime Zones in Area 1	
Easy Program Menu .....	7, 15
Clear Dealer Program .....	63
Easy Program Menu .....	13, 21
CLEAR PROGRAM	
Easy Program Menu .....	13, 21
Closing Report only on Cond. Closing (Auto-Byp.),	
Address 2417 .....	48
Cold Start .....	63
Easy Program Menu .....	13, 21
CONFIGURING THE KEYPADS .....	66
Conventions Used in this Manual .....	25
CS AREA & SYSTEM REPORTING OPTIONS,	
ADDRESS 1024-1027 .....	33
CS Receiver 1 Format, Address 0525 .....	29
CS RECEIVER 1 OPTIONS, Address 0526 .....	29
CS Receiver 2 Format, Address 0550 .....	29
CS RECEIVER 2 OPTIONS, Address 0551 .....	29
CS Receiver 3 Format, Address 0575 .....	29
CS RECEIVER 3 OPTIONS, Address 0576 .....	29



# ALPHABETICAL INDEX (CONT'D)

CS RECEIVER FORMAT OPTIONS, ADDRESS	
0520, 0521, 0525, 0526, 0550, 0551, 0575 & 0576	29
CS RECEIVER TELEPHONE NUMBERS, ADDRESS	
0527-0546, 0552-0571, 0577-0596	30
CS REPORTING CODES, ADDRESS 0859-0907	32
CS REPORTING CODES, ADDRESS 0870-0904	33
CS SUBSCRIBER ID NUMBERS, ADDRESS 0650-	
0787	31
CS SUBSCRIBER ID NUMBERS, ADDRESS 0790-	
0857	32
CS SYSTEM REPORT OPTIONS, Address 1027	33
CS TELCO 1 SUBSCRIBER EVENT ID NUMBERS	31
CS TELCO 1 SUBSCRIBER OPENING/CLOSING ID	
NUMBERS	31
CS TELCO 2 SUBSCRIBER EVENT ID NUMBERS	
(BACKUP REPORTING)	31
CS TELCO 2 SUBSCRIBER OPENING/CLOSING ID	
NUMBERS (BACKUP REPORTING)	31
CS Telco 3 Report Delay, Address 3902	27
CS TELCO 3 SUBSCRIBER EVENT ID NUMBERS	32
CS TELCO 3 SUBSCRIBER OPENING/CLOSING ID	
NUMBERS	32
CS USER REPORTING CODES, ADDRESS 1030-	
1055	35
CS USER REPORTING CODES, ADDRESS 1056-	
1081	36
CS zone REPORTING CODES, ADDRESS 0910-1005	34
CUSTOMIZING A DEFAULT PROGRAM	5

## D

Day Zone Open	
(Zone Option)	40-45
Day Zone Short	
(Zone Option)	40-45
Dealer Code	
Easy Program Menu	13, 21
DEALER PROGRAM	
Overview	5
Dealer Security Code, Address 0500-0502	28
Digital Dialer Rpt Enter/Exit Test Mode, Address 3905	50
Direct Address Program Mode	
Overview	4
DIRECT ADDRESS PROGRAM MODE	22
DIRECT ADDRESS PROGRAM MODE KEYPAD	
COMMANDS	23
Disable AC Fail Detection, Address 2420	49
Disable Answering-Machine Download, Address 2419	48
Disable Area Entry Relays, Address 2422	49
Disable Auto Dial Tone Detection, Address 4084	50
Disable Auto Status, Address 2421	49
Disable Auto-Reset on Day Zone, Address 2419	48
Disable Auto-Unbypass on Disarming, Address 2417	48
Disable Call Waiting on First Attempt, Address 3905	50
Disable Callback Download, Address 2419	48
DISABLE CLOSING REPORTS, Address 1025	33
Disable Code required for Easy Bypass, Address 2420	49
Disable Code required for Func. Mode Lvl. 1, Address	
2420	49

Disable Entry Urgency Tone at Keypad, Address 2422	49
Disable Fire Reset (Areas 1-8), Address 2415	48
Disable Function-Mode Download, Address 2419	48
Disable Keypad Instant Button, Address 2420	49
DISABLE OPENING REPORTS, Address 1024	33
DISABLE Sounder	
CONFIGURING	66
Disable System Trouble Audible at Keypad, Address	
2420	49
Disable Wait for Handshake, Address 1027	33
Disable Wait for Silence, Address 1027	33
Don't Clear Aux. Relay with Disarm, Address 2421	49
Download Security Code, Address 0645-0647	30
DOWNLOAD/CALLBACK OPTIONS, ADDRESS	
4089, 0600-0619, 0625-0647, 1022 & 1023	30
Downloading From a Computer	4

## E

EASY MENU DRIVEN PROGRAM MODE	5
Easy Programming of Auto download ID #'s	
Easy Program Menu	9
Easy Programming of PC Preset Callback Numbers	
Easy Program Menu	9
Enable Ambush in User Assignment Code Type,	
Address 3905	50
Enable Bell Output on Keyfob Arming, Address 2422	49
Enable Burg Output Chirp on KeyFob?	
Easy Program Menu	8, 16
Enable Burg. Output on Telco Fail only when Armed,	
Address 2422	49
Enable Burg. Output Warning on Entry, Address 2418	48
Enable CP-01 Limits, Address 3905	50
Enable Day Zone Watch (Areas 1-8), Address 2416	48
Enable Exit-Delay Restart, Address 2419	48
Enable GEM-PRINT, Address 3874	49
Enable Line-Fault Test, Address 2420	49
Enable Local Alarm on First Zone "AND" Trip,	
Address 2419	48
Enable Manager's Mode, Address 2418	48
Enable No EOLR Zones	
Easy Program Menu	8, 16
Enable Set Time/Date, Address 3874	49
Enable SIA CP-01 Features?	
Easy Program Menu	8, 16
Enable Smoke Detector Dirty Trouble, Address 2422	49
Enable Telco Line Fault Test?	
Easy Program Menu	8, 16
Enable Time/Date Display, Address 3874	49
Enter Date	
Easy Program Menu	13
Enter Time	
Easy Program Menu	13
Enter User Codes	
Easy Program Menu	10, 18
ENTRY DELAY 1, Address 0001	27
ENTRY DELAY 2, Address 0002	27
Entry/Exit 1	
(Zone Option)	40-45



**ALPHABETICAL INDEX (CONT'D)**

Entry/Exit 2	
(Zone Option) .....	40–45
Erasing Dealer Program .....	63
Easy Program Menu .....	13, 21
Erasing Entire Program .....	63
Easy Program Menu .....	13, 21
EXIT DEALER PROGRAM MODE	
Easy Program Menu .....	13, 21
Exit Delay, Address 0000 .....	27
Exit Time Restart, Address 3905 .....	50
Exit/Entry Follower	
(Zone Option) .....	40–45
Exit/Entry Zones in Area 1	
Easy Program Menu .....	6, 14
Exit/Entry2 Zones in Area 1	
Easy Program Menu .....	7, 15
EXTERNAL RELAY CONTROL / relays 1-39,	
ADDRESS 3778-3816 & 2800-2955 .....	57–62
EXTERNAL RELAY CONTROL / relays 40-78,	
ADDRESS 3817-3855 & 2856-3111 .....	57–62
EXTERNAL RELAY CONTROL / RELAYS 79-96,	
ADDRESS 3856-3873 & 3112-3183 .....	57–62
EZM group OPTIONS, ADDRESS 2600-2621 .....	53
EZM PGM ARMED TERMINAL CONTROL .....	53

**F**

Fire (C)	
(Zone Option) .....	40–45
Fire Alarm Verification (C)	
(Zone Option) .....	40–45
Fire Output (Lug E9)	
(Zone Option) .....	40–45
Fire Output Cadence, Address 2422 .....	49
Fire Output Timeout, Address 2405 .....	28
Fire Zones in Area 1	
Easy Program Menu .....	6, 14
Function Mode	
Overview .....	4

**G**

GEM-P9600 WIRING DIAGRAM .....	76
General Programming Steps .....	25
GLOBAL SYSTEM TROUBLE REPORTING	
OPTIONS, ADDRESS 1082-1116 .....	37

**H**

Handshake for Local Telemetry, Address 1027 .....	33
---	----

**I**

Include Sel./Grp. Bypass in Cond. Closing Status,	
Address 2417 .....	48
Interior #1 Bypass	
(Zone Option) .....	40–45
Interior #2 Bypass	
(Zone Option) .....	40–45

Interior (STAY) Bypass	
(Zone Option) .....	40–45
Interior 1 Normally Bypassed, Address 2419 .....	48
Interior Zones in Area 1	
Easy Program Menu .....	6, 15

**K**

Key Fob Transmitters as Arm/Disarm & Control	
Devices	
Easy Program Menu .....	12, 20
Key Fob Transmitters as Zone Input Devices	
Easy Program Menu .....	13, 21
KEY FOB ZONE ASSIGNMENT	
Easy Program Menu .....	12, 20
Keypad Address	
CONFIGURING .....	66
KEYPAD ADDRESS PROGRAM MODE DISPLAY .....	23
KEYPAD CONFIGURATION MODE .....	66
Keypad Easy Program Menu .....	6, 14
KEYPAD INSTALLATION .....	66
KEYPAD OPTIONS, ADDRESS 2425-2454 .....	51
KEYPAD PROGRAMMING OVERVIEW .....	22
Keypad Sounder on Alarm	
(Zone Option) .....	40–45
Keypad Sounder On Alarm Zones	
Easy Program Menu .....	7, 16
KEYPAD SYSTEM CODES, ADDRESS 0490, 0495 &	
0500 .....	28
KEYPAD TYPE & AREA ASSIGNMENT .....	51
Keyswitch Arming	
(Zone Option) .....	40–45

**L**

LCD Backlight	
CONFIGURING .....	66
Leading Digits for Pager Format (1st Digit), Address	
0520 .....	29
Leading Digits for Pager Format (2nd Digit), Address	
0521 .....	29
Local Downloading	
Overview .....	4
Local or Central Station Reporting System	
Easy Program Menu .....	6, 14
Lug E4 Armed Away Only, Address 2417 .....	48

**M**

MODEM CODES .....	34
-------------------	----

**N**

Never Arm	
(Zone Option) .....	40–45
NEW PANELS .....	5
No EOL Resistor	
(Zone Option) .....	40–45
No. Rings Before Pickup, Address 4089 .....	30



# ALPHABETICAL INDEX (CONT'D)

Number of Keypads in Area 1	
Easy Program Menu.....	8, 16
Number of Keypads in Area 2	
Easy Program Menu.....	8, 16
NUMBER OF RELAY BOARD MODULES,	
ADDRESS 3777 .....	62

## O

Opening Report only after Alarm Report, Address 2417 .....	48
OPENING/CLOSING REPORTING CODES, Address	
0864-0907 .....	32

## P

Pager Format: Maximum Pages per Session, Address	
3904 .....	50
Pager Format: Re-sends of First Report, Address 3903 .....	50
Panel Access Code, Address 0490-0492 .....	28
Power-up Delay	
(Zone Option) .....	40-45
Pre-Alarm Warning	
(Zone Option) .....	40-45
Priority	
(Zone Option) .....	40-45
PRIORITY AREA ARMING: .....	54
Priority with Bypass	
(Zone Option) .....	40-45
Pulse Alarm Output Timeout, Address 2404 .....	28
PULSE EVENT CODE .....	34
Pulsed Alarm Output	
(Zone Option) .....	40-45

## Q

Quick Method	
Easy Program Menu.....	12, 20

## R

remote access logging, ADDRESS 3184 .....	54
Remote Downloading	
Overview .....	4
Report Cancel Window, Address 4082 .....	28
Report Wireless Trouble to Telco 1, Address 3874 .....	49
Report Wireless Trouble to Telco 3, Address 3874 .....	49
Reset Day Zone with Arm/Disarm Only, Address 2419 .....	48
RESET OPTIONS, ADDRESS 4091-4093 .....	63
Reset Output Timeout, Address 2400 .....	28
Reset Relay	
(Zone Option) .....	40-45
RF RECEIVERS & SUPERVISORY TIMER	
OPTIONS, ADDRESS 3776 & 3760-3775 .....	56
RF SUPERVISORY TIMERS .....	56
RF Transmitter Points	
Easy Program Menu.....	12, 20
Rpt Exit Err/Recent Close, Address 3905 .....	50

## S

Selective Bypass	
(Zone Option) .....	40-45
Sensor Watch	
(Zone Option) .....	40-45
Sensor Watch Delay, Address 4088 .....	27
Sensor Watch Zones	
Easy Program Menu.....	7, 15
Sound Alarm on Exit Error, Address 3905 .....	50
Start Exit Delay after Ringback, Address 2418 .....	48
Status Report (Auto-Byp. Zones on Clos.), Address	
2417 .....	48
Supervised Alarm Output, Address 2422 .....	49
Suppress "Bypass" Reminder when Armed, Address	
2418 .....	48
Swinger Shutdown	
(Zone Option) .....	40-45
SYSTEM DELAYS & TIMEOUTS, ADDRESS 0000-	
0002, 2402, 2406, 2414 & 3902 .....	27
SYSTEM DELAYS & TIMEOUTS, ADDRESS 2400,	
2401, 2403-2405, 4082 & 4083 .....	28
SYSTEM DELAYS & TIMEOUTS, ADDRESS 2407,	
2408 & 4088 .....	27
SYSTEM OPTIONS, ADDRESS 2415-2419 .....	48
SYSTEM OPTIONS, ADDRESS 2420-2422, 3874 &	
3879-3881 .....	49
SYSTEM OPTIONS, ADDRESS 3882-3901, 3903-	
3905 & 4084 .....	50
SYSTEM PROGRAMMING OPTIONS .....	4
SYSTEM RESET OPTIONS, ADDRESS 4091-4093 .....	63

## T

TABLE OF CONTENTS .....	3
Telco Fail only when Armed, Address 2420 .....	49
Telephone Line Test Delay, Address 2414 .....	27
Total Number of Zones in Area 1	
Easy Program Menu.....	6, 14
Total Number of Zones in Area 2	
Easy Program Menu.....	6, 14
TouchPad Back light	
CONFIGURING .....	66
TouchTone Dialing Only, Address 1027 .....	33
TouchTone Dialing w/Rotary Backup, Address 1027 .....	33
Transmit "402" Opening/Closing Code, Address 1027 .....	33
Trouble on Night Open	
(Zone Option) .....	40-45
Trouble on Open	
(Zone Option) .....	40-45
Trouble on Short	
(Zone Option) .....	40-45
Trouble Restore 1	
(Zone Option) .....	40-45
Trouble Restore 3	
(Zone Option) .....	40-45
Trouble Telco 1	
(Zone Option) .....	40-45



# ALPHABETICAL INDEX (CONT'D)

Trouble Telco 3 (Zone Option) .....	40-45
--	-------

## U

USER AREA OPTIONS, ADDRESS 2500-2595 .....	52
USER Codes (Programming).....	65
User Program Mode Overview.....	4
USER PROGRAM MODE.....	64

## V

Veri-phone Zones Priority over Alarms, Address 2421 .....	49
Veri-phone Zones trip Aux. Relay, Address 2421.....	49
Veri-phone Zones trip Fire Output, Address 2421 .....	49

## W

Wireless Smoke Low Battery Resound, Address 2422 .....	49
WIRING DIAGRAM.....	76

## Z

Zone ANDing Group 1-8 (Zone Option) .....	40-45
Zone Area 1-8 (Zone Option) .....	40-45
ZONE DESCRIPTIONS Easy Program Menu .....	13, 21
ZONE OPTIONS / ZONES 1-16, ADDRESS 1200-1386.....	40
ZONE OPTIONS / ZONES 17-32, ADDRESS 1402- 1586 .....	41
ZONE OPTIONS / ZONES 1-96, ADDRESS 1200-2386.....	46
ZONE OPTIONS / ZONES 33-48, ADDRESS 1602- 1786 .....	42
ZONE OPTIONS / ZONES 49-64, ADDRESS 1802- 1986 .....	43
ZONE OPTIONS / ZONES 65-80, ADDRESS 2002- 2186 .....	44
ZONE OPTIONS / ZONES 81-96, ADDRESS 2202- 2386 .....	45

# ADDRESS NUMBER LOCATION INDEX

0000	EXIT DELAY	27
0000-0002	SYSTEM DELAYS & TIMEOUTS	27
0001	ENTRY DELAY 1	27
0002	ENTRY DELAY 2	27
0490	KEYPAD SYSTEM CODES	28
0490-0492	PANEL ACCESS CODE	28
0495	AMBUSH CODE	28
0495	KEYPAD SYSTEM CODES	28
0500	KEYPAD SYSTEM CODES	28
0500-0502	DEALER SECURITY CODE	28
0520	CS RECEIVER FORMAT OPTIONS	29
0520	LEADING DIGITS FOR PAGER FORMAT (1ST DIGIT)	29
0521	CS RECEIVER FORMAT OPTIONS	29
0521	LEADING DIGITS FOR PAGER FORMAT (2ND DIGIT)	29
0525	CS RECEIVER 1 FORMAT	29
0525	CS RECEIVER FORMAT OPTIONS	29
0526	CS RECEIVER 1 OPTIONS	29
0526	CS RECEIVER FORMAT OPTIONS	29
0527-0546	CS RECEIVER TELEPHONE NUMBERS	30
0550	CS RECEIVER 2 FORMAT	29
0550	CS RECEIVER FORMAT OPTIONS	29
0551	CS RECEIVER 2 OPTIONS	29
0551	CS RECEIVER FORMAT OPTIONS	29
0552-0571	CS RECEIVER TELEPHONE NUMBERS	30
0575	CS RECEIVER 3 FORMAT	29
0575	CS RECEIVER FORMAT OPTIONS	29
0576	CS RECEIVER 3 OPTIONS	29
0576	CS RECEIVER FORMAT OPTIONS	29
0577-0596	CS RECEIVER TELEPHONE NUMBERS	30
0600-0619	DOWNLOAD/CALLBACK OPTIONS	30
0625-0647	DOWNLOAD/CALLBACK OPTIONS	30
0645-0647	DOWNLOAD SECURITY CODE	30
0650-0787	CS SUBSCRIBER ID NUMBERS	31
0790-0857	CS SUBSCRIBER ID NUMBERS	32
0859-0907	CS REPORTING CODES	32
0860-0862	ALARM/TROUBLE REPORTING CODES	32
0864-0907	OPENING/CLOSING REPORTING CODES	32
0870-0904	CS REPORTING CODES	33
0910-1005	CS ZONE REPORTING CODES	34
1022	CALLBACK TELEPHONE NO. SELECT	30
1022 & 1023	DOWNLOAD/CALLBACK OPTIONS	30
1023	AUTO DOWNLOAD ID NO.	30
1024	DISABLE OPENING REPORTS	33
1024-1027	CS AREA & SYSTEM REPORTING OPTIONS	33
1025	DISABLE CLOSING REPORTS	33
1027	BACKUP REPORT ON TELCO 2	33
1027	CANCEL NEXT TEST TIMER ON ANY REPORT	33
1027	CS SYSTEM REPORT OPTIONS	33
1027	DISABLE WAIT FOR HANDSHAKE	33
1027	DISABLE WAIT FOR SILENCE	33
1027	HANDSHAKE FOR LOCAL TELEMTRY	33
1027	TOUCHTONE DIALING ONLY	33
1027	TOUCHTONE DIALING W/ROTARY BACKUP	33
1027	TRANSMIT "402" OPENING/CLOSING CODE	33
1030-1055	CS USER REPORTING CODES	35



**ADDRESS NUMBER LOCATION INDEX (CONT'D)**

1056-1081	CS USER REPORTING CODES	36
1082-1116	GLOBAL SYSTEM TROUBLE REPORTING OPTIONS	37
1120-1157	AREA SYSTEM TROUBLE REPORTING OPTIONS	38
1160-1197	AREA SYSTEM TROUBLE REPORTING OPTIONS	39
1200-1386	ZONE OPTIONS / ZONES 1-16	40
1200-2386	ZONE OPTIONS / ZONES 1-96	46
1402-1586	ZONE OPTIONS / ZONES 17-32	41
1602-1786	ZONE OPTIONS / ZONES 33-48	42
1802-1986	ZONE OPTIONS / ZONES 49-64	43
2002-2186	ZONE OPTIONS / ZONES 65-80	44
2202-2386	ZONE OPTIONS / ZONES 81-96	45
2400	RESET OUTPUT TIMEOUT	28
2400	SYSTEM DELAYS & TIMEOUTS	28
2401	AUX. OUTPUT TIMEOUT	28
2401	SYSTEM DELAYS & TIMEOUTS	28
2402	AUX. OUTPUT ACCESS CONTROL TIMEOUT	27
2402	SYSTEM DELAYS & TIMEOUTS	27
2403	BURG. ALARM OUTPUT TIMEOUT	28
2403-2405	SYSTEM DELAYS & TIMEOUTS	28
2404	PULSE ALARM OUTPUT TIMEOUT	28
2405	FIRE OUTPUT TIMEOUT	28
2406	ABORT DELAY	27
2406	SYSTEM DELAYS & TIMEOUTS	27
2407	CHIME TIMEOUT	27
2407	SYSTEM DELAYS & TIMEOUTS	27
2408	AC FAIL REPORT DELAY	27
2408	SYSTEM DELAYS & TIMEOUTS	27
2414	SYSTEM DELAYS & TIMEOUTS	27
2414	TELEPHONE LINE TEST DELAY	27
2415	DISABLE FIRE RESET (AREAS 1-8)	48
2415-2419	SYSTEM OPTIONS	48
2416	ENABLE DAY ZONE WATCH (AREAS 1-8)	48
2417	BYPASS FAULTED ZONES	48
2417	CLOSING REPORT ONLY ON COND. CLOSING (AUTO-BYP.)	48
2417	DISABLE AUTO-UNBYPASS ON DISARMING	48
2417	INCLUDE SEL./GRP. BYPASS IN COND. CLOSING STATUS	48
2417	LUG E4 ARMED AWAY ONLY	48
2417	OPENING REPORT ONLY AFTER ALARM REPORT	48
2417	STATUS REPORT (AUTO-BYP. ZONES ON CLOS.)	48
2418	ACCESS CONTROL (PANEL) ON AUX. OUTPUT	48
2418	AUTO BELL TEST ON ARMING	48
2418	AUTO RESET AFTER BURG. OUTPUT TIMEOUT	48
2418	ENABLE BURG. OUTPUT WARNING ON ENTRY	48
2418	ENABLE MANAGER'S MODE	48
2418	START EXIT DELAY AFTER RINGBACK	48
2418	SUPPRESS "BYPASS" REMINDER WHEN ARMED	48
2419	DISABLE ANSWERING-MACHINE DOWNLOAD	48
2419	DISABLE AUTO-RESET ON DAY ZONE	48
2419	DISABLE CALLBACK DOWNLOAD	48
2419	DISABLE FUNCTION-MODE DOWNLOAD	48
2419	ENABLE EXIT-DELAY RESTART	48
2419	ENABLE LOCAL ALARM ON FIRST ZONE "AND" TRIP	48
2419	INTERIOR 1 NORMALLY BYPASSED	48
2419	RESET DAY ZONE WITH ARM/DISARM ONLY	48
2420	CHIME ON E4 LUG	49
2420	DISABLE AC FAIL DETECTION	49
2420	DISABLE CODE REQUIRED FOR EASY BYPASS	49

# ADDRESS NUMBER LOCATION INDEX (CONT'D)

2420	DISABLE CODE REQUIRED FOR FUNC. MODE LVL. 1	49
2420	DISABLE KEYPAD INSTANT BUTTON	49
2420	DISABLE SYSTEM TROUBLE AUDIBLE AT KEYPAD	49
2420	ENABLE LINE-FAULT TEST	49
2420	TELCO FAIL ONLY WHEN ARMED	49
2420-2422	SYSTEM OPTIONS	49
2421	2ND CALL ANSWERING MACHINE OVERRIDE	49
2421	AUTOMATIC INTERIOR BYPASS	49
2421	AUX. OUTPUT CHIRP ON KEYFOB ARM/DISARM	49
2421	DISABLE AUTO STATUS	49
2421	DON'T CLEAR AUX. RELAY WITH DISARM	49
2421	VERI-PHONE ZONES PRIORITY OVER ALARMS	49
2421	VERI-PHONE ZONES TRIP AUX. RELAY	49
2421	VERI-PHONE ZONES TRIP FIRE OUTPUT	49
2422	DISABLE AREA ENTRY RELAYS	49
2422	DISABLE ENTRY URGENCY TONE AT KEYPAD	49
2422	ENABLE BELL OUTPUT ON KEYFOB ARMING	49
2422	ENABLE BURG. OUTPUT ON TELCO FAIL ONLY WHEN ARMED	49
2422	ENABLE SMOKE DETECTOR DIRTY TROUBLE	49
2422	FIRE OUTPUT CADENCE	49
2422	SUPERVISED ALARM OUTPUT	49
2422	WIRELESS SMOKE LOW BATTERY RESOUND	49
2425-2454	KEYPAD OPTIONS	51
2500-2595	USER AREA OPTIONS	52
2600-2621	EZM GROUP OPTIONS	53
2650-2657	AREA ARMING OPTIONS	54
2700-2739	AREA OUTPUT CONTROL OPTIONS	55
2800-2955	EXTERNAL RELAY CONTROL / RELAYS 1-39	57-62
2856-3111	EXTERNAL RELAY CONTROL / RELAYS 40-78	57-62
3112-3183	EXTERNAL RELAY CONTROL / RELAYS 79-96	57-62
3184	REMOTE ACCESS LOGGING	54
3760-3775	RF RECEIVERS & SUPERVISORY TIMER OPTIONS	56
3776	RF RECEIVERS & SUPERVISORY TIMER OPTIONS	56
3777	NUMBER OF RELAY BOARD MODULES	62
3778-3816	EXTERNAL RELAY CONTROL / RELAYS 1-39	57-62
3817-3855	EXTERNAL RELAY CONTROL / RELAYS 40-78	57-62
3856-3873	EXTERNAL RELAY CONTROL / RELAYS 79-96	57-62
3874	CANCEL REPORT TO TELCO 3	49
3874	ENABLE GEM-PRINT	49
3874	ENABLE SET TIME/DATE	49
3874	ENABLE TIME/DATE DISPLAY	49
3874	REPORT WIRELESS TROUBLE TO TELCO 1	49
3874	REPORT WIRELESS TROUBLE TO TELCO 3	49
3874	SYSTEM OPTIONS	49
3879-3881	ALARM/TROUBLE REPORTING CODES	50
3879-3881	SYSTEM OPTIONS	49
3882-3901	SYSTEM OPTIONS	50
3902	CS TELCO 3 REPORT DELAY	27
3902	SYSTEM DELAYS & TIMEOUTS	27
3903	PAGER FORMAT: RE-SENDS OF FIRST REPORT	50
3903-3905	SYSTEM OPTIONS	50
3904	PAGER FORMAT: MAXIMUM PAGES PER SESSION	50
3905	DIGITAL DIALER RPT ENTER/EXIT TEST MODE	50
3905	DISABLE CALL WAITING ON FIRST ATTEMPT	50
3905	ENABLE AMBUSH IN USER ASSIGNMENT CODE TYPE	50



**ADDRESS NUMBER LOCATION INDEX (CONT'D)**

3905	ENABLE CP-01 LIMITS	50
3905	EXIT TIME RESTART	50
3905	RPT EXIT ERR/RECENT CLOSE	50
3905	SOUND ALARM ON EXIT ERROR	50
4082	REPORT CANCEL WINDOW	28
4082	SYSTEM DELAYS & TIMEOUTS	28
4083	AUTO DISARM REARM DELAY	28
4083	SYSTEM DELAYS & TIMEOUTS	28
4084	DISABLE AUTO DIAL TONE DETECTION	50
4084	SYSTEM OPTIONS	50
4088	SENSOR WATCH DELAY	27
4088	SYSTEM DELAYS & TIMEOUTS	27
4089	DOWNLOAD/CALLBACK OPTIONS	30
4089	NO. RINGS BEFORE PICKUP	30
4091-4093	SYSTEM RESET OPTIONS	63

