

D6600



Security Systems

EN | Operation and Installation Guide
Receiver/Gateway

BOSCH

Trademarks

Microsoft[®], Windows[®], Windows NT[®] are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Contents

1.0	Introduction	5	10.1.5	Message is Received	18
1.1	Documentation Conventions	6	10.1.6	How Call Groups Work	18
2.0	Emergency Procedures	6	10.1.7	Buzzer Operation	18
3.0	Card Functions and Locations	7	10.1.8	Reporting Devices: Primary and Secondary	18
3.1	Front Panel	7	10.2	Normal Operation Mode	19
3.2	Line Cards and Modules	7	10.3	Operating in Manual Mode	19
3.3	Rear View	8	10.4	Keypad Menu Operation	19
4.0	D6600 Specific Cards	9	10.4.1	Log In	19
4.1	D6640/D6641 Line Cards and D6645 Line Terminator Card	9	10.4.2	Using the Keypad	20
4.1.1	D6640/D6641 LED Descriptions	9	10.4.3	Event Buffer Display	20
4.1.2	Card Installation	10	10.4.4	Current System Trouble Display	20
4.1.3	Telephone Line Monitoring Voltage	11	10.4.5	Software Version Display	20
4.2	D6610 CPU Card and D6615 CPU Terminator Card	11	10.4.6	Keypad Functions	20
4.2.1	D6610 CPU Card Connection	11	10.4.7	Skip Current Automation Event	21
4.2.2	D6615 CPU Terminator Card	11	10.4.8	Line Test	21
4.2.3	Card Removal and Replacement	12	10.4.9	Clear Pending Events	21
5.0	Power Supply Modules	12	10.5	Busy Seconds (Line Busy) Reports	22
6.0	Printer Specifications	12	10.6	Two-Way Audio	22
7.0	Installation	12	10.6.1	Enhancements and Changes	23
7.1	All Installations	12	10.6.2	Two-Way Audio Modes of Operation	23
7.2	UL Installations	12	11.0	Network Communications	24
7.3	Burglar Alarm Applications	12	12.0	No Data Received Reports	25
7.4	Fire Alarm Applications	13	12.1	Description	25
7.5	Installation Check List	13	12.2	No Data Received	25
7.6	Rack Mount Instructions	13	12.3	Data Error	25
7.7	Powering Down the Receiver	13	12.4	Wrong Data	25
8.0	Standby Power	13	13.0	Using the Central Station Automation System with the D6600	26
8.1	Connecting External Batteries	14	14.0	Central Station Tips	27
8.1.1	Minimum Standby Battery Chart	14	14.1	Back-up Receiver	27
8.1.2	Minimum Standby UPS Power	14	14.2	Computer Interface	27
9.0	Input and Output Ports	15	14.3	D6200 Programming Software	27
9.1	UPS Monitoring through CPU Programmable Input Ports	15	14.4	Telephone Lines	27
9.1.1	Input Default Connection Configuration	15	14.4.1	Emergency Ringers	27
9.1.2	Input Reverse Connection Configuration	15	14.4.2	Rotary Lines	27
9.2	Automation Link Monitoring (COM3) through CPU Programmable Output Ports	16	14.5	Proper Ground	27
10.0	D6600 Operation	16	14.6	Radio Frequency Interference	27
10.1	Process Flow	16	14.7	Test Communicator	27
10.1.1	Event Database	16	15.0	Troubleshooting Guide	28
10.1.2	Receiver Handshake and Kiss-Off	17	16.0	Specifications	31
10.1.3	Message Verification	18	17.0	Service Information	32
10.1.4	Handshake Tone Compatibility	18			

Figures

Figure 1:	D6600 Communications Receiver/Gateway (front view)	7
Figure 2:	D6600 Communications Receiver/Gateway (rear view)	8
Figure 3:	Receiver Card Placement.....	8
Figure 4:	D6640/D6641 Line Card	9
Figure 5:	D6645 Line Terminator Card.....	9
Figure 6:	D6640/D6641 LED Descriptions	9
Figure 7:	Removing the top cover of the D6600 ...	10
Figure 8:	Inserting the D6645 Line Terminator Card	10
Figure 9:	Securing the D6645 Line Terminator Card	10
Figure 10:	D6615 CPU Terminator Card.....	11
Figure 11:	Location of D6600 Battery Connector....	12
Figure 12:	D6600 Back Panel Showing Input/Output Ports.....	15
Figure 13:	Input Wiring for Reverse Configuration.....	15
Figure 14:	D6600 NetCom System Connection Diagram - C900TTL-E and Any Control Panel	24
Figure 15:	D6600 NetCom System Connection Diagram - D9133TTL-E and Bosch Control Panels	25
Figure 16:	NO DATA RECEIVED Message.....	25
Figure 17:	D6600 System – Direct Connect.....	26
Figure 18:	D6600 System – Standard/Network Automation	26

Tables

Table 1:	D6600 Supported Communication Formats	5
Table 2:	Battery Supervision.....	7
Table 3:	System Trouble	7
Table 4:	D6600 Line Cards and Modules.....	7
Table 5:	Battery Voltage Display	14
Table 6:	Calculating Standby Capacity Required by UL	14
Table 7:	Minimum Standby Battery Chart	14
Table 8:	Terminator Card Configuration.....	16
Table 9:	Testing Communication Links	21
Table 10:	Hardware Troubleshooting Guide.....	28
Table 11:	D6600 Specifications	31

1.0 Introduction

The D6600 Communications Receiver/Gateways offers several unique features:

- Modular construction with plug-in circuit boards for quick, easy service
- Open structure PC platform for future development
- Programmable formatting for receiving data from most major brands of digital communicators
- Easy and inexpensive updating, using modular cards and software downloads
- Superior digital signal processing to reduce noise and signal loss
- User interface module with LED indicators
- Front panel keypad
- Alphanumeric liquid crystal display (LCD)

The D6600 metal enclosure contains several modular cards:

- D6610 Central Processing Unit (CPU) Card
- D6615 CPU Terminator Card
- D6630 AC/DC Power Supply Module
- D6631 DC/DC Power Supply Module
- D6640 or D6641 Telephone Line Card that supports four telephone line interfaces
- D6645 Telephone Line Terminator Card

Up to seven additional telephone line cards along with seven additional line terminator cards can be installed in the D6600 to expand the receiver's capacity to 32 receiving lines.

The D6600 is compatible with major communication formats.

Table 1: D6600 Supported Communication Formats

Acron Super Fast	Scancom 4-16-1, 5-16-1, 6-16-1
Ademco 4-1 Express	Scancom 4-24-1, 5-24-1, 6-24-1
Ademco 4-2 Express	Series FSK
Ademco Contact-ID	Series DTMF
Ademco High Speed, 4-8-1	SIA
ADT SIA	Silent Knight FSK0
Caller ID	Silent Knight FSK1
CFSK	Silent Knight FSK2
Common Formats	Silent Knight FSK80 D6500 mode
DNIS/ANI	Telim
DSC 4-3	Text Message
FBI Super Fast	Varitech FSK 4-1
ITI	Varitech FSK 4-2
RB2000	VONK
Sescoa Super Speed	X-SIA Text

Use a printer to permanently record date, time, group number or transmission format and line number, account number, receiver number, and event by area, zone, and point. The printer tape and the D6600 LCD display show other receiver status messages such as software revision levels of the CPU Card.

Program the D6600 using the front panel keypad or the COM4 port with the D6200 Programming Software package.

NetCom refers to the D6600 with the optional D6680 Network Adapter. It supports data network communications including an account database capacity of up to 3200 accounts with the optional D6201 Security Key. Refer to *Section 11.0 Network Communications* on page 24 for more detailed information.

The D6600 works with the following Bosch Control Panels (referred to throughout this manual as "Bosch Control Panels"):

- D9412G
- D7412G
- D7212G
- D9412
- D7412
- D7212
- D9112

1.1 Documentation Conventions



Important Notes - Information for successful operation and programming. Also tips and shortcuts can be included here.



Caution - These caution the operator that physical damage to the program or equipment might occur.



Warning - These warn of the possibility of physical damage to the operator.

2.0 Emergency Procedures

Section 17.0 Service Information on page 32 of this guide contains a *Service Information* form. Keep this form current and accessible to central station personnel at all times in case of emergency.

If your D6600 Receiver becomes inoperable or experiences trouble receiving signals:

1. Notify your supervisor.
2. Refer to *Section 15.0 Troubleshooting Guide* on page 28.
3. Contact Bosch Security Systems 24-Hour Technical Support at (888) 886-6189 for assistance if you have a receiver spares package and need to replace a circuit card or module.



The AC/DC Power Supply Module and DC/DC Power Supply Module are not field serviceable. Contact Bosch Security Systems for service.



Disconnect power to the receiver before removing the CPU or CPU terminator card.


Before Calling 24-Hour Technical Support

1. Have this guide nearby and opened to *Section 15.0 Troubleshooting Guide* on page 28.
2. Have your spares package, the D6200 Programming Software, and the *D6600 Program Entry Guide* (P/N: 4998122702) nearby.
3. Know the location of the telephone line jacks for the receiver.
4. Know the telephone numbers to the receiver's telephone line cards.
5. Know the exact nature of the problem you are experiencing such as reports received, LEDs lit, Operator Alert Buzzer sounded.
6. Have the *Service Information form* nearby (page 32).

3.0 Card Functions and Locations

3.1 Front Panel

Figure 1: D6600 Communications Receiver/Gateway (front view)



- 1 - **LCD** - Shows up to 80 characters of information (two lines of up to 40 characters each)
- 2 - **Keypad** - The D6600 has a 20-button keypad for easy user interface.

Table 2 shows the state of the D6600's Power LED using AC or battery power.

Table 2: Battery Supervision

	Present		Power LED Status		
	AC	Battery	Green		Clear
			Solid	Blinking	
On	X	X			
	X				
		X			
Off	X	X			
	X				
		X			

Table 3: System Trouble

	System Trouble LED Status	
	Solid Red	Clear
No System Trouble		
Any System Trouble*		

* Refer to *Appendix B: D6600 Internal Messages* in the *D6600 Computer Interface Manual* (P/N: 4998122703). The following items cause system trouble. Depending on the supervision setting, the items indicated by ** might or might not cause system trouble.

Battery Missing**	External Printing Error**
UPS AC Fail	Line Fault**
Battery Bad**	COM# Error**
UPS Battery Low	Line Card Trouble**
AC Fail	COM3 Trouble**
System Temperature High	

3.2 Line Cards and Modules


Table 4: D6600 Line Cards and Modules

Name	Model	Description
Telephone line card	D6640	Up to eight line cards can be installed in one D6600 Receiver, for up to 32 telephone line connections.
Telephone line card	D6641	Functions like the D6640. Includes improved Public Switched Telephone Network (PSTN) processing, additional memory for future enhancements, and single firmware upgrade package.
CPU card	D6610	The D6600 uses one CPU card. The CPU card takes the incoming information from the line card and routes the information to an automation port, the LCD on the front of the receiver, and an external printer.
Power supply modules	D6630 and D6631	The power supply modules regulate the power used by the D6600. These are not field serviceable.
Telephone line terminator card	D6645	Located behind the line card, the telephone line terminator card isolates and protects the line card against outside voltage surges that might come over the telephone line. Each line card must have a line terminator card.
CPU terminator card	D6615	Located behind the CPU card, the CPU terminator card provides the D6600 with two serial ports (COM3 and COM4), a parallel port (parallel printer), and a general I/O port (I/O). The serial ports can be used for computer automation, PC connection for programming, or NetCom connection with a D6680.

3.3 Rear View

The D6600 has input and output pin connector sockets for up to eight line cards, network option (if installed), and one CPU card. It also has slots for connecting these cards to their corresponding terminator cards.


Figure 2: D6600 Communications Receiver/Gateway (rear view)



- | | |
|---|--------------------------------|
| 1 - Blank plate and location of installed D6672 Serial COM1 Expansion Kit | 3 - Card slot covers |
| 2 - D6615 CPU Terminator Card | 4 - D6645 Line Terminator Card |

3.4 Internal View

Figure 3: Receiver Card Placement




- | | |
|---|--|
| 1 - D6645 or D6645INTL Telephone Line Terminator Card | 5 - D6610 CPU Card |
| 2 - Back plate | 6 - D6631 DC/DC Power Supply (not serviceable) |
| 3 - D6615 CPU Terminator Card | 7 - Card guides |
| 4 - D6630 AC/DC Power Supply (not serviceable) | 8 - D6640/D6641 Telephone Line Card |
| | 9 - Direction of receiver front |

4.0 D6600 Specific Cards


4.1 D6640/D6641 Line Cards and D6645 Line Terminator Card

Figure 4: D6640/D6641 Line Card



- 1 - 48-pin connection to D6645 Line Termination Card
- 2 - 40-pin connection to D6600 Back Plate
- 3 - LEDs (refer to Figure 6)

Figure 5: D6645 Line Terminator Card




- 1 - 48-pin connection to D6640/D6641 Line Card
- 2 - Alignment Guide - Stabilizes the connection and acts as a guide for connecting the terminator card to the line card.
- 3 - Telco Line Jacks - Standard telephone lines connect to the RJ11C jacks.

4.1.1 D6640/D6641 LED Descriptions

The LED is active until the system acknowledges the entire transmission and the telephone line is ready to receive signals

Figure 6: D6640/D6641 LED Descriptions



- 1 - Flashes green when an incoming call rings.
- 2 - Glows green when the receiver is online with an incoming call.
- 3 - Glows red when the line card detects a line fault condition.
- 4 - LED is off and ready to receive signals or is disabled in the software.

4.1.2 Card Installation



Power down the receiver when removing, replacing, or installing telephone line cards or telephone line terminator cards (refer to *Section 7.7 Powering Down the Receiver* on page 13).




Discharge static electricity from your body by touching the receiver's internal frame (unpainted section) before handling any circuit card.

Installing Telephone Line Terminator Cards


1. Remove the rear slot cover (*Item 3, Figure 2* on page 8).
One telephone line terminator card is installed in the receiver when shipped from the factory.
2. Insert a terminator card in the slot next to the installed telephone line terminator cards.

Figure 7: Removing the top cover of the D6600



3. To replace a failed terminator card, remove the six screws (*Item 1, Figure 7*). Hold the top metal cover of the D6600 and lift it off (*Item 2, Figure 7*).
4. Remove the defective card.
5. Insert the new card in the same slot by aligning the top and bottom of the terminator card with the card guides in the enclosure.


Figure 8: Inserting the D6645 Line Terminator Card



- | | |
|-------------------------|-------------------------------|
| 1 - Alignment slot | 3- D6645 Line Terminator card |
| 2 - Alignment guide tab | 4 - D6600 Back plate |

6. Slide the card into the enclosure so the alignment guide (*Item 2, Figure 8*) tab on the back of the terminator card (*Item 3*) inserts into the alignment slot (*Item 1*) in the back of the D6600's back plate (*Item 4*) circuit board.

Figure 9: Securing the D6645 Line Terminator Card



- | |
|-------------------------------------|
| 1 - D6645 Line Terminator Card |
| 2 - Bracket screws (top and bottom) |
| 3 - Empty slot |
| 4 - D6600 |

7. Mount the terminator card (*Item 1, Figure 9* on page 10) in an empty slot (*Item 3, Figure 9*) of the receiver cabinet (*Item 4, Figure 9*) by securing the bracket screws at the top and bottom (*Item 2, Figure 9*) of the terminator card to the mounting rails at the top and bottom edges of the cabinet. Ensure the screws are tight.
8. Repeat this process for all additional terminator cards.



Do not install spare line cards and do not connect line cards to the spare terminator cards.

9. Connect appropriate telephone line cords to the telephone line jack on the terminator cards.

Installing Telephone Line Cards

1. Install the telephone line terminator card(s) (refer to *Installing Telephone Line Terminator Cards* on page 10).
2. Open the display door on the receiver.
One telephone line card is installed in the receiver when shipped from the factory.
3. Slide a line card into the slot next to the installed line card.
4. Remove the appropriate snap-in covers from the front of the panel.
5. Close the front panel.
6. Program the line card if necessary.

When the line card is initialized (as indicated by a printer report), the settings in the line card programming section automatically load into the card.

7. Connect telephone lines to the line card

4.1.3 Telephone Line Monitoring Voltage

The receiver continuously monitors the telephone line voltage. Normal operating voltage ranges from 1.8 VDC to 2.5 VDC. Any voltage above 2.5 VDC causes the line to appear good (restoral) and an indication appears if any voltage is below 1.8 VDC.


4.2 D6610 CPU Card and D6615 CPU Terminator Card

4.2.1 D6610 CPU Card Connection

The CPU card connects to the user interface on the front of the D6600 using a 50-pin ribbon cable socket.

4.2.2 D6615 CPU Terminator Card

Figure 10: D6615 CPU Terminator Card



- 1 - Alignment Guide - Stabilizes the connection and acts as a guide for connecting the terminator card to the CPU card.
- 2 - COM3 Automation Computer Port - An auxiliary RS-232 port for connecting to a computer terminal or an automation computer for SIA/6500 Mode Automation Format reporting use a null-modem cable to connect to a computer.
- 3 - COM4 RS-232 Port - Connection to a computer running the D6200 programming software.*
- 4 - Parallel Printer Port

* Use a null-modem cable to connect directly to the computer. You can also connect this port to a D6680 for communicating over a network.

4.2.3 Card Removal and Replacement



Power down the D6600 before removing, replacing, or installing the CPU card (D6610) or CPU terminator card (D6615).

Removing the CPU Card

1. Power down the receiver (refer to *Section 7.7 Powering Down the Receiver* on page 13).
2. Carefully grasp the plastic grip on the CPU card. Slide it 2 in. to 3 in. (50 mm to 75 mm) out of the enclosure.
3. Unplug the 50-pin ribbon cable connecting the user interface card to the CPU card. Be careful not to bend the board when disconnecting this cable. Grasp the plastic plug connected to the CPU board at the end of the cable and gently pull it away from the circuit board.
4. Pull the CPU card straight out of the card guide.

Replacing the CPU Card

1. Power down the receiver (refer to *Section 7.7 Powering Down the Receiver* on page 13).
2. Remove the defective CPU card from the enclosure.
3. Align the top and bottom of the CPU card with the card guides. Slide the card into the enclosure, leaving 2 to 3 in. (50 mm to 75 mm) out to connect the ribbon cable.
4. Connect the ribbon cable to the CPU card. Orient the cable so the red stripe is up and slide the card the remaining distance into the enclosure.
5. Power-up the receiver.

5.0 Power Supply Modules



The AC/DC (D6630) and DC/DC (D6631) Power Supply Modules are not field serviceable.

Contact the National Repair Center at (800) 289-0096, extension 4220 for repair or replacement.

6.0 Printer Specifications

Parallel printer connection: Use the DB25 port on the back of the D6600 rear panel to connect to a standard parallel text printer.

Models: Safecom SC9002 [Star 300] requires 3.25 in. (82.6 mm) wide paper.

7.0 Installation

7.1 All Installations

Install the D6600 Communications Receiver/Gateway according to the National Electrical Code (NEC), NFPA 70, the National Fire Alarm Code, NFPA 72, and the local Authority Having Jurisdiction (AHJ).

7.2 UL Installations



UL Standard 827 requires that any central station listed for NFPA 72, Central Station Protective Signaling, UL Central Station Burglary or Police Station Connect Service must have a redundant receiver on the premises to use if the primary receiver malfunctions.

UL Standard 827 also states that you must be able to switch from one receiver to a standby receiver within 30 sec, and repair the faulty receiver and return it to service within 30 min.


NFPA 72 requires that if more than eight telephone lines are used, the receiving equipment must be completely duplicated so switchover can be accomplished in 30 sec (per NFPA 72-1996 4-5.3.2.2.1.1).

7.3 Burglar Alarm Applications

Install the D6600 Receiver according to UL Standard 827 for Central Station Burglar Alarm Systems. Use in a central station that has backup AC power (per UL 827) to supervise certificated accounts.

Terminals for connection of external batteries are on the rear of the receiver (*Figure 11*).

Figure 11: Location of D6600 Battery Connector



Receivers are not shown to scale.

7.4 Fire Alarm Applications

The D6600 Receiver can be used for Central Station Protective Signaling when it is installed and used in compliance with NFPA 72 and ANSI/NFPA 70. Installation limits for digital alarm communicator receivers (DACR) are under the local AHJ.

7.5 Installation Check List

1. Check each receiver card to see that they are correctly positioned in the card guides at the top and bottom of the enclosure. Also confirm connections did not loosen during shipment.
2. Ensure the earth ground is connected and grounded through the AC inlet.
3. If you are installing additional line cards, install the terminator cards now.
4. After installing additional line terminator cards, install the line cards (refer to *Section 4.1.2 Card Installation* on page 10).
5. You might also want to install the line terminator card(s) from your spares package(s). If there is a malfunction, you can quickly switch over to the replacement card (refer to *Section 4.1.2 Card Installation* on page 10).



You can install spare line terminator cards. Do not install spare line cards.

6. Connect four or six conductor telephone cord(s) to the RJ11C jack(s) of the desired telephone line(s). Plug the other end of the modular telephone cord(s) into the telephone jack on the appropriate line terminator card(s).
7. Plug the AC cord into a correctly wired 120 VAC, 60 Hz or 220 VAC, 50 Hz outlet (standard AC outlet).
8. Plug the AC transformer into the correctly wired wall receptacle that matches the voltage of the transformer.



Ensure a switch does not control the outlet.

9. Turn the D6600 power switch on.
10. Set the calendar and clock to the correct date and time and program the necessary options.
11. Ensure that communication formats are correct by having communicators send test reports to each line connected to the receiver.

7.6 Rack Mount Instructions

Rack mounting hardware is included with the D6600. When mounted in a rack, plug the D6600's AC cord into an outlet inside the rack only if the outlet is wired according to Article 760 of the NEC. Rack mounting is required (per NFPA 72, 1-5.2.5.2) to meet the mechanical protection requirement when using the type of AC cord provided with the D6600. It is also required that a UL Listed rack for fire protective service be provided when used in UL Listed central stations.



Do not connect the D6600 to an outlet controlled by a switch.



Install a shelf or bracket at the back of the rack to support the D6600. The front mounting ears cannot support the full weight of the D6600.

7.7 Powering Down the Receiver

1. Remove battery power.
2. Turn off the AC power on the D6600.
3. Unplug the AC cord from the outlet.



Do not try to restart the D6600 with a fully discharged battery. Reconnect after power up. To prevent deep battery discharge, use a D135A Low Battery Cutoff Module. Refer to the *D135A Installation Guide* (P/N: 74-06499-000) for more information.



If programmable Output 1 or 2 is activated by automation failure, Output 1 or 2 cannot be cleared by pressing [ACKNOWLEDGE].

8.0 Standby Power

During a loss of AC power, the receiver automatically switches to standby power. External batteries or an uninterruptible power supply (UPS) provides standby power. As long as there is adequate standby power, the receiver's operation is not interrupted, even if the power loss occurs during signal processing. When power supervision is enabled and a loss of AC power occurs, the primary reporting devices (such as printers and computers) show AC FAIL and the D6600's power indicator starts blinking. When AC power restores, the power indicator stops blinking and reporting devices show AC RESTORE.

8.1 Connecting External Batteries



Do not connect an external battery charger to the D6600.

Use the terminal on the rear panel to connect an external DC power source. During AC power outages, the external DC source supplies power to the receiver. Use a 12 VDC lead-acid battery for external back-up power.

Only use approved stationary standby batteries for UL applications. Battery wiring must run from the receiver through the UL Listed rack, exit the rack through a conduit connection, and terminate at a UL Listed battery enclosure suitable for the size and number of batteries used for UL applications.

Table 5: Battery Voltage Display

Battery Voltage	Display (during AC power outage)	Display (if battery missing when AC power restores)
11.5 V above	Battery OK	
11.5 V to 10.2 V	Battery Low	
Below 10.2 V	Battery Bad	Battery Missing

Table 6 shows the calculations for the standby capacity required by UL when using the D6600.

Table 6: Calculating Standby Capacity Required by UL

Device	Qty	Battery Standby Current	Total Battery Standby Current	UPS Standby Current	Total UPS Standby Current
D6600 Base with one D6640/ D6641 installed	1	800 mA	800 mA	350 mA	350 mA
D6640/ D6641 Line Cards (up to 8)		210 mA/each		35 mA/each	
D6672 COM1 Adapter		10 mA		2 mA	
		Total:		Total:	

8.1.1 Minimum Standby Battery Chart

Table 7 shows the derated battery divided by the hours.

Derated battery = Battery Ah - 20% Storage

8.1.2 Minimum Standby UPS Power


Total UPS current x 120 (voltage) x desired hours of standby + 20% (storage) = Minimum UPS required in watts.

Table 7: Minimum Standby Battery Chart

Rechargeable Battery Size	Maximum Standby for 4 hr
7 Ah	1400 mA
8 Ah	1600 mA
10 Ah	2000 mA
12 Ah	2400 mA
18 Ah	3440 mA

9.0 Input and Output Ports

Figure 12: D6600 Back Panel Showing Input/Output Ports



- | | |
|------------|-------------|
| 1 - #1 | 4 - Outputs |
| 2 - #2 | 5 - Ground |
| 3 - Inputs | |

9.1 UPS Monitoring through CPU Programmable Input Ports

Use the CPU programmable input port to connect the external UPS to the D6600 for power monitoring. Connect the monitoring port from the UPS to matching pins on the D6600 CPU Programmable Input/Output port (Figure 12). Wiring must run from the receiver through the UL Listed rack, exit the rack through a conduit connection, and terminate at the external UPS for UL applications. Set up the D6600 from **Menu 2.2.27 CPU Programmable Input 1** for Input 1; **Menu 2.2.28 CPU Programmable Input 2** for Input 2. Refer to the *D6600 Program Entry Guide* (P/N: 4998122702) for more information.

9.1.1 Input Default Connection Configuration

- The I/O ports work with dry contact outputs.
- The open circuit input voltage on the input measures between 9 V and 12 V.
- UPS Battery OK (restore) – contacts closed
- UPS Battery Low input – contacts open

You can apply other output sources to the input wiring as long as you follow these guidelines:

- The maximum input voltage allowed without causing damage to the input is 24 VDC.
- For UPS “Battery OK” (restore), the input range must be between 0 V and 1 V.
- For UPS “Battery Low,” the input range must be between 3 V and 24 V.




Because the input state is undefined in the voltage range, input voltages between 1 V and 3 V can cause abnormal results. This might cause unexpected results such as toggling between “Battery Low” and “Battery OK.”

9.1.2 Input Reverse Connection Configuration

If the input must be the opposite polarity for correct operation, place an external transistor circuit between the UPS output signal and the D6600 I/O input (Figure 13).

Figure 13: Input Wiring for Reverse Configuration



- | |
|--|
| 1 - From UPS Battery OK signal 5 to 24 V |
| 2 - 22 k to 39 k |
| 3 - Battery Low signal 0 to 0.6V |
| 4 - To I/O input |
| 5 - Any general purpose NPN transistor |

Follow these guidelines for correct operation:

- The maximum input voltage allowed without damaging the input is 24 V.
- UPS Battery OK (restore) input range from the UPS operates between 5 V and 24 V.
- UPS Battery Low input range operates between 0 V and 0.5 V



Operating the input as an analog input between 0.5 V and 5 V might cause abnormal results. This input state is not defined and might change expected results



Reverse configuration is not for use in UL Listed applications.

9.2 Automation Link Monitoring (COM3) through CPU Programmable Output Ports

The output connections on the I/O port have an open collector transistor output that can activate an external sounder or light if the automation system fails.



Configure external devices using the specifications listed in *Table 8*. Outputs are not verified by UL.

Table 8: Terminator Card Configuration

Radionics D6615 CPU Terminator Card	Bosch D6615 CPU Terminator Card
Solid state output provides a current sink to common (-)	Solid State output provides a current sink to common (-)
Maximum load is 20 mA	Maximum load is 75 mA
Vsat @ 1 mA = 0.5 VDC	Vsat @ 10 mA = 0.5 VDC
Vsat @ 10 mA = 3.0 VDC	Vsat @ 25 mA = 1.0 VDC
Maximum voltage = 30 VDC	Vsat @ 50 mA = 2.5 VDC
	Maximum voltage = 30 VDC

10.0 D6600 Operation

10.1 Process Flow

10.1.1 Event Database

The Event Database stores all trouble conditions and alarm messages that occur in the D6600. The maximum number of events stored in the database is 20000. If the automation system is not functioning, the D6600 does the following:

- When receiving over telephone lines, the D6600 stops answering and acknowledging calls at 19500.
- When receiving over a network, the D6600 stops acknowledging incoming events at 19000 because the communication is much faster.

These limits provide a warning before the database becomes full.

Under normal operation, when the database reaches capacity, the receiver drops the oldest event in the database. This is typically known as First In, First Out (FIFO).

When using the D6600 keypad, an authorized user can view these messages through the menu. To enter the Event Database:

04/06/2004 14:25:00

1. Enter Password: _
2. Enter password.
Enter Password: ****
3. 1 EVENT DATABASE
Welcome Manager...



















Sort and Display Events by Time/Date

To view individual events in the Event Database on the D6600 LCD.

1. 1 EVENT DATABASE
Welcome Manager...
2. 1.1 Display Sort by Time/Date
3. 1.1 Display Sort by Time/Date
Input Event Buffer No# [1..20000]:
4. Enter the desired event number (from 1 to 20000).
 Msg#0001 - (TOTAL 1 LINE)
01/01 00:01 L00 SYSTEM RESET
5. See the expanded message if the stored event has multiple lines of text.
 Selects another message
 When the last message in the database is reached,
Total 0008 alarms
***** NO MORE MESSAGE *****
6. repeatedly
04/06/2004 14:25:00

Display Current System Troubles

To review a log of trouble conditions that occurred:


1.   
2.   
3.   
4.    = the most recent trouble condition message. The total number is in brackets.
5.    Scroll back through the trouble conditions
6.    repeatedly

Saving the Event Database as a File


You can receive the event database from the D6600 and save it as a file to the Host PC. If there is a problem, Bosch Security Systems Technical Support can use this file to help troubleshoot the problem.


Use the D6200 software to download the event database and save it to the Host PC:


1.  

 The default User ID is 6200 and the default password is 6200.

2.  




3. 



In this example the path is **C:\Program Files\D6200** and the name of the file is **D6600.04-22-2003.13_27_01.ebf**.

The number immediately following D6600 in the file name is the date the file is created.

 Bosch Security Systems Technical Support can only read the proprietary format of the database file.

4.  

10.1.2 Receiver Handshake and Kiss-Off

The telephone line dialed by the communicator connects to a line card in the D6600. The line card detects ringing voltage, answers the incoming call, and sends a programmed series of handshake tones. The communicator detects the expected handshake and transmits its message. The receiver sends the kiss-off after the receiver receives and understands the communicator's message.

Program the receiver for up to eight handshake attempts, using any combination of the available handshake tones.

With Handshake Optimization enabled, the D6600 can send the appropriate Handshake Tone (associated with the Caller ID number in the Caller ID database) to the control panel or a Dialed Number Identification Service (DNIS) database can be created to optimize the handshake outputs and other line card parameters.



The D6600 can only use only one database (DNIS or Caller ID) at a time.

10.1.3 Message Verification

The D6600 Receiver checks each message for errors. If the receiver receives the data correctly, it sends the kiss-off acknowledgment tone to the communicator. The communicator hangs up and returns the subscriber's telephone line to normal.

If the data is not correct, the receiver withholds the kiss-off tone and prints an error message (refer to *Section 12.0 No Data Received Reports* on page 25) causing the communicator to retransmit the information. If the receiver still does not receive the data correctly after the communicator's set number of retransmissions, the communicator hangs up. The communicator restarts the signal process and attempts to transmit another message. The communicator repeats this process until the receiver receives the kiss-off tone or until the maximum number of dialing attempts is depleted.

10.1.4 Handshake Tone Compatibility

When the D6600 Receiver answers an incoming line, it waits for a programmed time before transmitting the handshake tone(s).



Some communicators wait approximately 30 sec for the proper handshake tone. Others hang up immediately if they hear an improper handshake tone. Others have a very short handshake wait time.

To eliminate waiting through a sequence of handshake tones, program the line card so the first handshake tone transmitted is compatible with existing equipment.

The D6600 can receive incoming signals while transmitting handshakes.

10.1.5 Message is Received

The receiver can process messages from all 32 telephone lines simultaneously. The messages print and appear one by one, as the previous message clears from the display.

Many control panels can transmit multiple messages in the same telephone call. Program the receiver to print all multiple message transmissions as a group, or print each message on arrival. Refer to *Report Grouping* in the *D6600 Program Entry Guide* (P/N: 4998122702) for more information.

As the receiver receives each message and checks the accuracy, it sends the kiss-off tone so the communicator can hang up. This allows the receiver to process new incoming calls on the line. As reporting devices (such as printers, computers) become available to receive additional signals, the D6600 retrieves the stored messages from memory and sends the messages to the reporting devices.

10.1.6 How Call Groups Work

The D6600 Receiver allows each line to report and print as part of a call group. The receiver assigns telephone lines, which operate in rotary, to the same call group. A call group can include any combination of incoming lines, regardless of the physical location of the line card in the receiver or the geographical location of the accounts that report to the various lines in the group. When the receiver assigns a line to a call group, the group number (such as G01) can identify all reports on that line, with the exception of telephone line or line card trouble reports. If the receiver does not assign a line to a group, the line number (such as L01) identifies all reports. Refer to the *D6600 Program Entry Guide* (P/N: 4998122702) for more details on call groups.

10.1.7 Buzzer Operation

In the Manual Mode, an Operator Alert Buzzer sounds when a message is received until you press [ACKNOWLEDGE]. The buzzer operation is programmable and can be disabled when the receiver is programmed for the Automatic Mode.

10.1.8 Reporting Devices: Primary and Secondary

A reporting device is any device that can print or display messages from the D6600 Receiver. This includes the central station automation computer or an external printer. You can enable the external printer and designate it as the primary or secondary device. The automation computer is always a primary device unless disabled. Primary reporting devices receive all reports generated by the D6600. Secondary reporting devices only receive input from the D6600 when all primary devices fail.



UL 1981 allows the receiver to suppress printing during normal automation system operation if the printer starts printing upon automation system failure.

If the receiver is in the Automatic Mode and all of the primary reporting devices (such as printers and computers) fail, the receiver re-routes the messages to the secondary reporting device(s). If the receiver programs no secondary reporting devices or if all secondary reporting devices fail, the D6600 automatically switches to Manual Mode. When the receiver restores automation to normal operation, the D6600 returns to the Automatic Mode if the user manually acknowledges the last buffered signal.

10.2 Normal Operation Mode

In Normal Operation Mode, the D6600 Receiver sends messages immediately or in blocks to reporting devices (such as printers and computers) as soon as the devices are ready to receive the information. Signals do not remain visible in the display. If all reporting devices fail, the D6600 reverts to Manual Mode until a device returns to service. Normally, the D6600 sounds the Operator Alert Buzzer for new events received when the automation link fails.

Typical Alarm Receiving Sequence

1. An alarm occurs on Zone 3 at subscriber location 456. The user programs Account 456 to report to Line 01 and does not assign Line 01 to report to a call group.
2. The OL LED glows green when the receiver answers the call and receives data.
3. The primary reporting device(s) (such as external printer or automation computer) activates.

If the external printer is a primary reporting device and Line 01 is not assigned to Group Reporting, it prints:

```
11/11 14:10 L01 ACCT 456 ALARM ZN 3
```

If Line 01 is assigned to Group 1 Reporting, the receiver's external printer prints:

```
11/11 14:10 G01 ACCT 456 ALARM ZN 3
```

4. Line 01 hangs up

10.3 Operating in Manual Mode















If all reporting devices (such as printers and computers) fail, the D6600 reverts to Manual Mode until a device returns to service.

When the D6600 receives signals while in Manual Mode:

The Operator Alert Buzzer sounds.






1.  Shuts off the operator alert buzzer

Compare the display to the printout to confirm you correctly read the data.

2.   
3.  Sends the message to a connected printer
4.  
5.  Sends the message to a connected printer
6.  
7.  Sends the message to a connected printer
8. Repeat until the reporting device(s) records all outstanding messages and the display clears.
9.    

10.4 Keypad Menu Operation

10.4.1 Log In

1.  
 2. Enter password. 
 - Enter Password: **** 
-  D6600 default password: 6600

3. 

```
1 EVENT DATABASE
Welcome Manager...
```

10.4.2 Using the Keypad

 **D6600**

Scrolls up or down to the appropriate menu.

 **D6600**

 **D6600**

Enters a particular menu.

Continue making changes to options until all changes are complete.

 **D6600**

Accepts the change.

 **D6600**

Cancels the change and returns to previous menu.

The new data takes affect upon exiting the menu.

10.4.3 Event Buffer Display

 **D6600**

Shows event buffer contents in the order the events are received.

 **D6600**

If multiple lines of text are received,

```
TOTAL LINES 10
```

 **D6600**

Views the remaining lines of each message.

 **D6600**

Continues to browse the events in the buffer.


 **D6600**

 **D6600**

Exits this menu.

Refer to *Section 10.1.1 Event Database* on page 16 for more information.

10.4.4 Current System Trouble Display

D6600
 SYSTEM TROUBLE

System troubles in the buffer.

```
1 EVENT DATABASE
```

 **D6600**

```
1.1 Display Sort by Time/Date
Input Event Buffer No# [1..20000]:
```

 **D6600**

```
1.2 Display Current System Troubles
```

 **D6600** **D6100**
MENU

```
Current System Trouble[05]
L02 PHONE LINE FAULT
```

 **D6600**


Browse the system troubles in the buffer.

 **D6600**

 **D6600**

Cancels this menu

As you correct system troubles, the receiver removes them from this list.

D6600
 SYSTEM TROUBLE

No more system troubles remain

Refer to *Section 15.0 Troubleshooting Guide* on page 28 for more information.

10.4.5 Software Version Display

```
5 SOFTWARE VERSIONS
```

Shows the current software versions of the CPU and each line card.

10.4.6 Keypad Functions

Use this option to test the communication links to the automation firmware and printer.


```
04/06/2004 14:25:00
```

1.  **D6600**

```
Enter Password: _
```

2. Enter password.



```
Enter Password: ****
```

 **D6600** default password: 6600.

3.  **D6600**

```
Welcome Manager...
```

```
Select the Function# [1..99]: _
```

4. 
5. 

Printer	
Automation	DD/DDsTT:TTsL08sACCTs888sss [TES T] sZNsss8 D6500 h1rr8ssssssss888s [sss8t Mode SIA Mode <header> [NVX]

10.4.7 Skip Current Automation Event

Use this option to skip the current Automation event.


04/06/2004 14:25:00

1. 

Enter Password: _

2. Enter password.

Enter Password: ****

 D6600 default password: 6600

3. 

Welcome Manager...

Select the Function# [1..99]: _

4. 

5. 

10.4.8 Line Test

Use this option to test the line operation.


04/06/2004 14:25:00

1. 

Enter Password: _

2. Enter password.

Enter Password: ****

 D6600 default password: 6600

3. 

Welcome Manager...

Select the Function# [1..99]: _

4. 

Test Line Work Status
Select the Function# [1..99]: 3_

5. 

Test Line Work Status
Select the Function# [1..99]: 3_

D6600:
Test Line Work Status
Input Line [1..32]: _

6. 

 to 

Selects the line to test.

7. 

The line disconnects, the receiver sends the handshakes, and the line reconnects.

10.4.9 Clear Pending Events

Use this option to clear all pending events.


04/06/2004 14:25:00


1. 

Enter Password: _


2. Enter password.

Enter Password: ****



 D6600 default password: 6600

3. 

Welcome Manager...

Select the Function# [1..99]: _
4. 

Clear All Pending Events
Select the Function# [1..99]: 4_

Clear All Pending Events
Sure? 0/1 - No/Yes: _
5.  Cancels the function and does not delete all pending events.
 Clears all pending events.

10.5 Busy Seconds (Line Busy) Reports

The D6600 Receiver software monitors and reports when a call group of receiver lines cannot receive signals. The receiver cannot process signals if its incoming telephone lines are in trouble, if other communicators have the line tied up, or if the line card is inoperative. The receiver interprets these conditions as busy time.

The amount of busy time accumulated during a 10 min period is the basis for a Busy Seconds Reports. The 10 min busy period begins when all lines in a call group become busy, or when a non-programmed single line for a call group becomes busy. The D6600 totals the accumulated busy time and prints the Busy Seconds Report after the 10 min period ends. After at least 60 sec (10%) of busy time, the receiver generates a report. The D6600 reports up to 100% busy time.


Program the Busy Seconds Reports option to **No** if Busy Seconds Reports are not wanted for all lines. Setting the Line Sniff option to 2 disables reports for individual lines.



Set Busy Seconds Reports to Yes for UL Listed central stations.

UL inspectors might investigate the amount of time the digital receiver lines cannot receive signals. Ensure lines are available to process emergency signals on a timely basis. Excessive Line Busy Reports can indicate it is necessary to install additional lines in rotary with your primary receiver lines.

Assign each line to a call group. For the group to start accumulating busy time, all lines in the call group must be online, in trouble, or without an operating line card.



Although it is not mandatory, not assigning a line to a call group, or when there is only one line in the group, 1 min of busy time during a 10 min period results in a Busy Seconds Report.

If you do not assign a line to a call group, displays and printer reports identify the line number instead of the Group number. A Line Busy Report shows and prints:

```
11/11 06:20 L01 BUSY SECONDS 23% RCVR01
```

10.6 Two-Way Audio

When using the D6600 for Two-Way Audio (TWA) verification, use the Flash or Hold option according to the central station Private Branch Exchange (PBX) system, taking the D6600 off line in a short period. If a PBX is not used, connect a regular telephone in parallel with the incoming telephone line. Once the D6600 is in Two-Way Audio Mode, the operator can pick up the telephone and undertake the two way audio operation. Return the telephone to the receiver after the two-way audio operation finishes.

The D6600 verifies the first digit of the account code range 0 to F programmed in the Account Digits option for the following communication formats:

- Pulse (3 or 4 digit account code)
- DTMF
- BFSK
- Modem II/IIIa²
- SIA

If the received account code is two-way audio enabled, the line card goes into Two-Way Audio Mode.

Program a non-zero number in the Two-way Audio Duration option. This option affects all formats, and the control panels cannot control the two-way audio duration over the D6600.

If the qualifying criteria apply, the D6600 sends a signal to the automation firmware indicating the physical line is in Two-Way Audio Mode. The line remains off-hook for the time programmed in minutes in the Two-Way Audio Duration option.

or

When the flash option is set for 1 to 20 (100 ms to 2 sec), the CPU first sends the two-way audio signal to automation firmware. Then the line is flashed (quickly disconnected and reconnected) for the programmed flash duration. It remains off-hook for another 5 sec then hangs up.

or

When the Hold option is set for 1 to 99 sec the line card remains off-hook for the programmed hold after sending the audio event signal to the automation firmware, allowing the firmware controlled PBX to pick up the line. Then it hangs up.

10.6.1 Enhancements and Changes

- Setting TWA by the selected Alarm Code allows one or multiple Alarm Codes to be selected. TWA works with 10 to 40 baud Pulse formats, DTMF 4/1, 4/2, 4/3 and Contact ID formats
- Setting TWA by the selected zone number allows the selection of one or multiple zone numbers. TWA works with 10 to 40 baud formats and DTMF 4/1, 4/2 and 4/3 formats.



The zone number is the last digit of events that activates the TWA function.

- TWA by combined conditions include account number, alarm code, and zone number
- Supports TWA auto-entered by more events and in various protocols, including Contact ID Event Code 606, and SIA control blocks.

When the line card is in Two-Way Audio Mode, it only goes on-hook when the operator presses [CAN], or the automation firmware issues a Stop Listening Command !Knn<CR>, where nn is the physical line number.



The maximum on-line time during two audio sessions is disabled.

The line card listen in duration settings overrides any control panel listen in duration settings.

When pressing [CAN] during the two-way audio session, the receiver prompts the operator to enter the line number for stopping the two-way audio. Ensure the D6600 is not in Menu Mode during this operation.

The OL/LF LED flashes green during the audio session.

The D6600 prints the audio status on the printer with the physical line number and sends the audio status to the automation firmware with the physical line number.

The D6600 decodes the first digit of the account number to determine when to start two-way audio operation. If the first digit of the account number matches the selection, two-way audio activates.

10.6.2 Two-Way Audio Modes of Operation

- **Transfer:** D6600 transfers the incoming line to another line; a flash operation occurs at the end of the alarm signal. The receiver dials the line programmed at Transfer Phone Number (refer to *Menu Items 3.1.4.18 Flash [x 100ms]* and *3.1.4.19 Transfer Phone Number* in the *D6600 Program Entry Guide* [P/N: 4998122702]).
- **Hold:** The D6600 remains off-hook as programmed so another device can take over the line before hold time expires. Refer to *Menu Item 3.1.4.20 Hold* in the *D6600 Program Entry Guide* (P/N: 4998122702) to program.
- **Duration:** The D6600 remains off-hook as programmed or until terminated by a Stop command. Connect a regular telephone in parallel with the incoming telephone line. Refer to *Menu Item 3.1.4.1 Duration* in the *D6600 Program Entry Guide* (P/N: 4998122702) to program.




The D6600 can only perform one of these operations at a time. If there is more than one, the sequence is Transfer, Hold, and Duration.

11.0 Network Communications

The D6600 Central Station Communications Receiver/Gateway NetCom system supports data network communications. NetCom allows the D6600 Receiver to connect to Ethernet networks, and process messages both to and from most networks in user datagram protocol (UDP) or internet protocol (IP). Use a COM4 or a COM1 connection from the D6600 Receiver to connect to the network adapter. Central station automation software, through a local-area network (LAN) or wide-area network (WAN), receive reports from alarm control panels from the PSTN, or other data networks. The automation software also monitors the control panel status and connection over the network. Update or upgrade the D6600 through the network connection. Use the D6200 software to remote program the D6600. Refer to the following documents about network communications and their installation requirements.


- *NetCom System Guide* (P/N: 4998122712)
- *D9133TTL-E Installation Guide* (P/N: 4998122717)
- *C900TTL-E Installation Guide* (P/N: 4998122718)
- *DX4020 Installation Guide* (P/N: 49522)
- *D6680 Network Adapter Installation Guide* (P/N: 4998138732)
- *DeviceInstaller Operation and Installation Guide* (P/N: 4998138688)

Figure 14: D6600 NetCom System Connection Diagram - C900TTL-E and Any Control Panel



- 1 Any manufacturer's control panel
- 2 C900TTL-E Dialer Capture Module
- 3 Host PC running D6200 Programming Administrative Software
- 4 Ethernet hub
- 5 D6680 Network Adapter
- 6 D6600 Central Station Receiver (CSR)
- 7 Connection - Control panel telco jack to C900TTL-E jack
- 8 Connection - C900TTL-E Ethernet jack to Ethernet hub
- 9 Connection - Host PC network interface card (NIC) to Ethernet hub
- 10 Connection - Ethernet hub to D6680
- 11 Connection - Ethernet hub to second D6680
- 12 Connection - D6680 to D6600 COM4 port
- 13 Connection - Second D6680 to D6600 COM 1 port (optional)

Figure 15: D6600 NetCom System Connection Diagram - D9133TTL-E and Bosch Control Panels



- 1 Bosch Control Panels
- 2 D9133TTL-E or DX4020 Network Interface Module
- 3 Host PC running D6200 Programming Administrative Software
- 4 Ethernet hub
- 5 D6680 Network Adapter
- 6 D6600 Receiver
- 7 Connection – Control panel serial device interface (SDI) bus to D9133TTL-E or DX4020 SDI Terminals
- 8 Connection – D9133TTL-E or DX4020 Ethernet port to Ethernet hub
- 9 Connection – Ethernet hub to Host PC NIC
- 10 Connection – Ethernet hub to D6680
- 11 Connection – Ethernet hub to second D6680
- 12 Connection – D6680 to D6600 COM4 port
- 13 Connection – Second D6680 to D6600 COM1 port (optional)

12.0 No Data Received Reports

12.1 Description

If a message is garbled (incorrect checksum or inconsistent message rounds) due to a noisy telephone line or other difficulty, the receiver withholds the kiss-off tone. This causes the control panel to retransmit the same message up to four times.

12.2 No Data Received

The D6600 generates the message shown in *Figure 16* if one or more of the following occur:

- Telephone line noise causes the data to be unrecognized.
- A control panel sends the data in a format not recognized by the D6600.
- A control panel transmitted nothing.

Figure 16: NO DATA RECEIVED Message

```
10/13 09:28 L01 NO DATA RECEIVED
```

12.3 Data Error

Data Error is a function of PSTN. It is an error condition when the D6600 receives partial data, appears on the D6600 LCD, and sends the error to a connected printer.

This occurs when telephone line noise causes data to be unrecognizable.

12.4 Wrong Data

Wrong Data is a function of the CPU where the PSTN software sends an invalid signal to the CPU. It only sends output to the LCD and any connected printer.

13.0 Using the Central Station Automation System with the D6600


If using a D6600, connect a central station automation system computer to the COM3 port (automation computer port) on the D6615 CPU Terminator Card with a null-modem cable. Refer to the *D6600 Computer Interface Manual* (P/N: 4998122703) for additional information.

Standard automation reporting usually sends RS-232 serial data from the D6600's COM3 port to a COM port of a separate automation PC (refer to *COM3 Automation Configuration* in the *D6600 Program Entry Guide* [P/N: 4998122702]). With no additional programming required at the D6600 Receiver, you can use the same serial communication across a network connection by using D6680 Network Adapter modules at both ends of the automation communication path. The D6600 still sends the standard serial data, but the D6680 Network Adapter modules communicate with each other, convert the data back to the standard RS-232 that the automation computer can interpret, and transmit that data back over the network.




Some messages might go unacknowledged (NACK) due to increased network activities. This forces NetCom to resend these messages. Refer to the *D6600 NetCom System Guide* (P/N: 4998122712) for complete details on network communications and programming.

Figure 17: D6600 System – Direct Connect



- 1 Host PC
- 2 D6600 Receiver
- 3 Connection - Host PC COM1 Port to D6600 COM3 Port

Figure 18: D6600 System – Standard/Network Automation



- 1 - Automation PC
- 2 - Connection - PC COM1 to D6680
- 3 - D6680
- 4 - Connection - D6680 to hub
- 5 - Hub
- 6 - Second D6680
- 7 - Connection - D6680 to D6600 COM4
- 8 - D6600 Receiver
- 9 - Connection - Host PC Network Interface Card to Hub

NOTE:

For automation packages with network capabilities : The packet format received from the D6600 is the same as for RS-232 reporting, except an internet protocol (IP) and user datagram protocol (UDP) header is stamped on the packet as the data transmitted by either standard IP or UDP structure over the network. Automation software can easily support the network communication by calling Socket functions, both provided in Windows and UNIX. Using the built-in IP connections (or sockets) available in Windows and Unix.

14.0 Central Station Tips

14.1 Back-up Receiver

Spare circuit boards and receivers should be available at the central station. Keep a spare kit on hand. UL Listed central stations monitoring burglary or fire alarms must have a spare receiver available for activation within 30 sec.

14.2 Computer Interface



Keep spare cards for all receiver components.

Keep a spare CPU terminator card in the central station.

14.3 D6200 Programming Software



Keep D6200 Programming Software in the central station at all times.

14.4 Telephone Lines

14.4.1 Emergency Ringers

Extension ringers for incoming receiver telephone lines are available from telephone equipment supply companies. They ring briefly to indicate an incoming call. If they continue to ring, your receiver is out-of-service. The ringer has a volume control, but in a high traffic central station, you might prefer to use beehive lights instead of ringers.

14.4.2 Rotary Lines



Use rotary receiver lines (hunt groups) to prevent delay in alarm signals during periods of busy central station traffic.

Rotary lines are also important for providing alternate paths when a line is out of service. To use this feature have your dispatcher dial the out-of-service line and leave the calling telephone off the hook. This creates a busy signal on the line to all incoming communicators. The communicators automatically switch to an unused line. The telephone company provides rotary service when ordered.



UL and Factory Mutual central station service standards require constant monitoring of telephone lines.

14.5 Proper Ground

Connect the receivers to an **earth ground**, not a chassis or electrical ground. Measure the resistance of the receiver ground to another ground. If the meter reads above 2 Ω , check your receiver ground against a third ground. If the difference is still greater than 2 Ω , ground your receiver to a different earth ground. Cold water pipes or a grounding rod usually make a good earth ground. The grounding wire should be heavy copper with as short and straight a run as possible. Avoid sharp bends in the ground wire because a large power surge might arc across the bend.

The terminator cards and their connection to the receiver cabinet provide the ground source for the receiver's circuit boards. Firmly tighten all the screws used to secure the terminator cards to the back of the receiver cabinet.



If the mounting bracket screws are not tight, the receiver's operation can be erratic. A short circuit or foreign voltage induced into the system can cause the receiver to fail.

Put an anti-static mat in front of the receiver to prevent electrostatic discharge from the operator to the equipment.

14.6 Radio Frequency Interference

The D6600 Receiver is microprocessor based. All microprocessors are susceptible to radio frequency interference (RFI), especially at the 480 MHz and 950 MHz bandwidths used by walkie-talkies. Never operate a walkie-talkie near a receiver.

14.7 Test Communicator

Periodically check your receiver and its telephone lines by using a digital communicator triggered by an interval timer. If you have more than one data line, use a communicator for each line or use a multiple number communicator.

15.0 Troubleshooting Guide

The D6600 consists of several plug-in assemblies that you can easily replace in the field (components and controls on individual assemblies are shown starting in *Section 3.0 Card Functions and Locations* on page 7).



Do not attempt to repair individual assemblies. Return any failed assemblies to Bosch Security Systems for testing and repair. Use this Troubleshooting Guide to identify failed modular components.

Table 10: Hardware Troubleshooting Guide



Problem	Symptom	Solution
Line Card OL/LF LED steadily glows red.	Telephone line, telephone connecting cord, line card, or telco terminator is defective.	<ul style="list-style-type: none"> Pull the line card out of the receiver, and re-insert it to ensure the card is properly connected. Swap the connecting cord with a telephone line that operates. If the original OL/LF LED remains a steady red, the problem is with a plug-in card. Replace the line card with a spare. If the OL/LF LED for the new card is a steady red, change the line terminator card. If the OL/LF LED on the original troubled card goes out and the OL/LF indicator on the previously untroubled card lights when you swap connecting cords, the trouble is with the telephone line. Replace the telco line connecting cord. <div style="border: 1px solid black; padding: 5px; margin-top: 10px;">  If the OL/LF LED is still on, the trouble might be in the telephone line. Report the trouble to the telephone company. </div>
	<p>Take immediate action if a telephone line is out of order and is the first line in a rotary or hunt group. Have the telephone company busy the defective line at the telephone exchange.</p> <p>If emergency service is not available, call the troubled line and leave the calling handset off the hook. Do not hang up. Incoming alarm signals see a busy signal and rotor (hunt) to another line in the hunt group. This procedure does not work for Wide Area Telephone Service (WATS) lines.</p>	
Menus cannot be accessed.	<ul style="list-style-type: none"> Incorrect password Defective keypad panel Defective CPU card 	<ul style="list-style-type: none"> Default password is "6600." Ensure a secure connection of ribbon cable between CPU and front panel.
Printer works but no display.	<ul style="list-style-type: none"> Defective or loose cable between the CPU card and display panel or user interface card Defective user interface card Defective CPU 	<ul style="list-style-type: none"> Ensure a secure connection of ribbon cable between CPU and front panel. Swap CPU Card to confirm it is the problem.

Table 10: Hardware Troubleshooting Guide (continued)


Problem	Symptom	Solution
Operator alert buzzer cannot be silenced.	<ul style="list-style-type: none"> System stalled Defective [Acknowledge] key Defective user interface card 	<ul style="list-style-type: none"> Check watchdog LED on the inside of the door behind the keypad. LED must flash for a running system. A solid light does not indicate a running system. Reset power cycle of the D6600 if stalled. Order replacement part P6603. Return the D6600 for repair.
D6200 cannot connect to the D6600.	D6200 serial connection is defective, missing, or incorrect serial cable.	<ul style="list-style-type: none"> Ensure the cable between the PC and the D6600 is null-modem. Also ensure the cable is not damaged. Inspect all pins on the D6600, PC, and serial cable. Ensure the null-modem cable is connected to the correct COM port of the PC (as per the D6200 COM setting; COM1 through COM8). COM settings do not match. In the D6200, under the Settings Menu, select COM SETTINGS. Confirm all settings match the configuration of the D6600 Host Programming Parameters (Menu Item 4.5 Parameters). On the D6600, ensure Menu Item 4.5.9 RS-232 Direct Access Permission is set to 1. If upgrading software, ensure Menu Item 4.5.7 Software Programming Enable (on the D6600) is set to 1. <div style="border: 1px solid black; padding: 5px; margin-top: 10px;">  If Software Programming Enable is set to zero (0), communication between the D6200 and the D6600 is successful but file upgrades fail. </div> <ul style="list-style-type: none"> If using COM4 through a direct connection, Menu Item 6.1.5 COM4 Network Adapter must be set to 0. If using COM1 through a direct connection, Menu Item 6.2.5 COM1 Network Adapter must be set to 0. Port conflicts with other applications on the host PC. Reboot the PC and restart the D6200 with no other applications running. Defective CPU terminator card. Defective CPU card. Defective PC COM port.

Table 10: Hardware Troubleshooting Guide (continued)

Problem	Symptom	Solution
D6200 cannot connect to the D6600 through a network connection.	D6200 network connection is defective, missing, or has incorrect network cable.	<ul style="list-style-type: none"> • Ensure the Ethernet connection light on the network interface module for the PC running D6200 Software is on. This indicates a good network connection. • Ensure the Ethernet connection light on the D6680 for the PC running D6200 Software is on. This indicates a good network connection. • If using the D6600's COM4 to connect to the D6680, ensure Menu Item 6.1.4 COM4 Network Adapter in the D6600 is set to 1. • If using the D6600's COM1 to connect to the D6680, ensure Menu Item 6.2.5 COM1 Network Adapter in the D6600 is set to 1.
D6200 cannot connect to the D6600 through a network connection.	D6200 network connection is defective, missing, or has incorrect network cable.	<ul style="list-style-type: none"> • If communicating within the same LAN, the IP address of the PC running the D6200 software must be entered into the D6600 Menu Items 6.4.1 IP Address 1, 6.4.2 IP Address 2, or 6.4.3 IP Address 3. • If communicating over a WAN, the external IP address of the LAN with the PC running the D6200 software must be entered into the D6600's Menu Items 6.4.1 IP Address 1, 6.4.2 IP Address 2, or 6.4.3 IP Address 3. • Ensure Menu Item 6.4.5 Network Programming Enable in the D6600 is set to 1. • Ensure that the D6200 programming software is set up for TCP/IP network connection (select Administration → Connection Settings). <ul style="list-style-type: none"> – If communicating on the same LAN, ensure the IP address of the D6680 is entered correctly. – If communicating over a WAN, ensure the external IP address of the LAN with the D6680 is entered. – Both port numbers match (valid ports are from 2001 to 9998). • If encryption is enabled on the D6200, <ul style="list-style-type: none"> – it must also be enabled on the D6680. – the 16-byte key must be the same in the D6680 and the D6200 software.
D6200 cannot connect to the D6600 through a network connection.	D6200 network connection is defective, missing, or has incorrect network cable.	<ul style="list-style-type: none"> • If communicating over a WAN, the firewalls of the LANs must be configured correctly. For example, the D6680 resides on one LAN while the D6200 software resides in another LAN. A WAN connects them both but the firewalls at either LAN need to allow TCP and UDP packets through. • Firewalls must allow your selected ports to pass through. • Contact your IT administrator.

16.0 Specifications

Table 11: D6600 Specifications			
Dimensions (H x W x D)	D6600	Rack mount	7.0 in. x 19.0 in. x 19.5 in. (18 cm x 48.3 cm x 49.5 cm)
		Standalone	7.0 in. x 17.75 in. x 19.5 in. (18 cm x 45.0 cm x 49.5 cm)
Weight	D6600	8.7 kg (19 lb)	
Cabinet Finish	Aluminum, dark gray, semi-gloss enamel.		
Power Input	AC Nominal Operating Range		120 V or 230 V
	AC Maximum Operating Range		100 VAC to 120 VAC, 220 VAC to 230 VAC, 50/60 Hz 2.5 A maximum
Current Required	D6600 with one line card installed	Required battery current	800 mA
		Required UPS AC standby current	350 mA
	For each additional line card or terminal card pair	Required additional battery current	210 mA
		Required additional UPS AC standby current	35 mA
	For network communications card	Required additional battery current	10 mA
Required additional UPS AC standby current		10 mA	
Standby Power	Use a UPS with the D6600. The receiver includes an external battery connection and battery harness. Use 12 V rechargeable sealed lead-acid batteries. A 4-hour minimum standby power supply (UPS or battery) is required for UL Certification (refer to <i>Section 8.1 Connecting External Batteries</i> on page 14 for battery size).		
Telephone Connections	RJ11C modular jacks, with 26 AWG or larger wire diameter.		
FCC Registration	<p>ESVUSA-25328-AL-N</p> <p>The D6600 Receiver is Federal Communications Commission (FCC) registered under Part No. 68 using the RJ11C Interconnect that can be ordered from your local telephone company.</p> <p>Notice: This equipment was tested and found to comply with the limits for a Class "A" digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy, and if not installed according to the instruction manual, might cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user must correct the interference at his or her own expense.</p>		
Ringer Equivalence	0.4 B		
Display	Screen size: (H x W)	0.7 in. x 6.0 in. (1.8 cm x 15.2 cm) dot matrix LCD (5 x 7 dots per character). Shows two separate lines of 40-characters each.	
	LED	LED display section indicates receiver status and power.	
Inputs and Outputs	<ul style="list-style-type: none"> One RS-232 interface port COM3 (middle connector on the CPU terminator card) for connection to an automation computer. One RS-232 interface port COM4 (upper connector of CPU terminator card) for connection to an external serial printer, a PC, a modem, or a network. One parallel printer port for connection to a parallel printer Two programmable inputs on the D6610 CPU I/O wire harness included) Two programmable outputs on the D6610 CPU I/O wire harness included) Optional: One RS-232 interface port (COM1) for the Network Communications expansion option. 		
Listings and Approvals	<ul style="list-style-type: none"> UL Central Station Fire (864) UL Central Station Burglary (1610) UL Police Station Connect (365) FCC Part 15 Radiated/Conducted Emissions FCC Part 68 Telecom ULC Industry Canada <ul style="list-style-type: none"> Austel Approved CE Approved <ul style="list-style-type: none"> - CTR-21 - EN60950 Safety - EN55022 Radiated/Conducted Emissions NIST AES Certification 		

17.0 Service Information

(EMERGENCY DATA SHEET)

In a central station emergency, use this information to contact the necessary people and enable Bosch Security Systems Customer Service Personnel to help you with your emergency. Have your supervisor provide you with the following information:

Supervisor's Name:	_____
Emergency Telephone #:	_____
Telephone Co. Repair Service Telephone #:	_____
Contact:	_____
Power & Light Co. Repair Service Telephone #:	_____
Contact:	_____



Bosch Security Systems Customer Service: (800) 289-0096 (press [6] for Technical Support) or
 Technical Support: (888) 886-6189

When calling for emergency central station service, please tell the operator "Receiver Problem."

Receiver Software Version # CPU: _____ Line: _____ D6200: _____

Incoming Receiver Telephone Line Numbers:	Line 1:	_____	Line 17:	_____
	Line 2:	_____	Line 18:	_____
	Line 3:	_____	Line 19:	_____
	Line 4:	_____	Line 20:	_____
	Line 5:	_____	Line 21:	_____
	Line 6:	_____	Line 22:	_____
	Line 7:	_____	Line 23:	_____
	Line 8:	_____	Line 24:	_____
	Line 9:	_____	Line 25:	_____
	Line 10:	_____	Line 26:	_____
	Line 11:	_____	Line 27:	_____
	Line 12:	_____	Line 28:	_____
	Line 13:	_____	Line 29:	_____
	Line 14:	_____	Line 30:	_____
	Line 15:	_____	Line 31:	_____
	Line 16:	_____	Line 32:	_____

Are Lines in Rotary? Yes: _____ No: _____

Type of WATS Lines? Local: _____ Statewide: _____ National: _____
 Other: _____

Location of Receiver Spares Package: _____

Location of Receiver Ground Wire Connection: _____

Location of AC Power for Receiver: _____

Location of Telephone Line Jacks: _____


Receiver Connected to Computer System?: Yes: _____ No: _____

Automation System Manufacturer: _____

Notes

Notes

Notes



Bosch Security Systems
130 Perinton Parkway
Fairport, NY 14450-9199
Customer Service: (800) 289-0096
Technical Support: (888) 886-6189

© 2005 Bosch Security Systems
4998122704E



BOSCH