

D1256/D1257

Fire Command Center/ Fire Alarm Annunciator

Installation Instructions



Radionics[®]

1.0 Introduction..... 5

1.1 Before You Begin 5

1.2 Type Styles Used Here..... 5
Tips, Notes, Cautions and Warnings..... 5

1.3 Organization and Layout 6

2.0 Overview 7

2.1 D1256/D1257 Differences..... 7

2.1.1 D1256 7

2.1.2 D1257 7

2.2 Description..... 7

2.2.1 Display 8

2.2.2 Audible Tones..... 8

2.2.3 Switch Settings 8

3.0 Installation..... 9

3.1 Mounting the D1256 and D1257 9

3.1.1 Mounting Locations 9

3.2 Wiring the D1256 and D1257 9

3.3 Programming the Control/Communicator 10

3.3.1 Command Center Assignments..... 10

3.3.2 Area Text 10

3.3.3 Custom Function..... 10

CF 128 – ALARM SILENCE ? 10

CF 129 – TROUBLE SILENCE ? 11

CF 130 – DETECTOR RESET ? 11

CF 131 – ANNUNCIATOR RESET ? 11

3.3.4 Menu/Function List 11

Menu Item and Function 12

CC Address # 12

3.3.5 Passcode Worksheet..... 12

Passcode..... 12

3.3.6 User Interface 13

Command Center Functions..... 15

Appendix A: Specifications 16

Contents

Figures

Figure 1: D1256/D1257 Internal Arrangement	7
Figure 2: Example 1 – Area Text.....	10
Figure 3: Example 2 – Custom Function.....	10
Figure 4: Example 3 – Menu/Function List.....	11
Figure 5: Example 4 – Passcode Worksheet	12
Figure 6: Example 5 – User Interface for D7212B, D9112B, and D9124 (that use the D9112LTB).....	13
Figure 7: Example 6 – User Interface for D7212, D7412, D9112, D9412, and D9124 (that uses the D9112LTB-EX)	14
Figure 8: Example 6 Continued – User Interface for D7212, D7412, D9112, D9412, and D9124 (that uses the D9112LTB-EX).....	15

Tables

Table 1: D1256/D1257 Installation Instructions organization.....	6
Table 2: Switch Address Settings	8
Table 3: Wiring Connections	9
Table 4: Menu/Function List Description.....	12

1.0 Introduction

1.1 Before You Begin

Before installing the D1256 or D1257, you should be familiar with the Operation and Installation manual and Program Entry Guide for the control/communicator you are using. When using the D1256 or D1257 with the D9112B, the software must be Revision 2.1 or higher.

1.2 Type Styles Used Here

We use special type styles to help you identify the objects that we are describing in this guide.

ITALICIZED text with a border represents the prompt that you will see in the D5200 Programmer's display.

Bold text usually indicates selections that you may use while programming your panel. It may also indicate an important fact that you should note.

Bold Italicized text represents a prompt when used in a description.

Italicized text references you to another section of the manual, or to a different manual. We also use Italicized text to symbolize names for records that you will create.

Courier Text shows what may be printed on the Display or internal printer. [CAPITALIZED TEXT] in brackets shows what is displayed at the command center. Capitalization may also be used for emphasis.

Tips, Notes, Cautions and Warnings

Throughout this document helpful tips and notes will be presented concerning the entire application and/or programming the unit. They will be set off as follows:



Application Tip:

Helpful shortcuts or reminders in using the unit.



Application Note:

This box will contain notes and clarifications of different aspects of the application.



Programming Notes:

Notes and clarifications specific to programming the unit are covered here.



Programming Tip:

This box presents helpful shortcuts or reminders in programming the unit.



Important Notes

These notes should be heeded for successful operation and programming.



Warning!

Warning of the possibility of physical damage to the operator, program and/or equipment.

Introduction

**Caution**

These caution the operator that physical damage to the program and/or equipment may occur.

1.3 Organization and Layout

These installation instructions consists of 3 chapters and an appendix. The table below provides a brief description of each section.

Chapter 1	<u>Introduction</u> This is the chapter you are reading.
Chapter 2	<u>Overview</u> Description of the different parts of the D1256 & D1257.
Chapter 3	<u>Installation</u> Procedures on how to mount and wire the D1256 & D1257 plus procedures on programming the Control/Communicator.
Appendix A	<u>Specifications</u> Power and optimum operating conditions requirements

Table 1: D1256/D1257 Installation Instructions organization

2.0 Overview

2.1 D1256/D1257 Differences

2.1.1 D1256

The **D1256 Fire Command Center** is a four-wire serial device used with the following Radionics Control/Communicators:

- **D7212B**
- **D7212**
- **D9112**
- **D9124 (that uses the D9112LTB), and**
- **D9112B**
- **D7412**
- **D9412**
- **D9124 (that uses the D9112LTB-EX)**

Each panel listed here supervise up to eight command centers. You can connect a total of 32 command centers to the system. The number of supervised command centers, number of areas, and the available power affect the total number of command centers you can connect to the system.

The D1256 provides annunciation as well as system control.

Four function keys on the D1256 provide quick execution of alarm silencing, trouble silencing, annunciator display reset, and sensor reset functions.

2.1.2 D1257

The **D1257 Fire Alarm Annunciator** is also a four-wire serial device used with the following Radionics Control/Communicators:

- **D7212B**
- **D7212**
- **D9112**
- **D9124 (that uses the D9112LTB), and**
- **D9112B**
- **D7412**
- **D9412**
- **D9124 (that uses the D9112LTB-EX)**

Each panel listed here supervise up to eight command centers. You can connect a total of 32 command centers to the system. The number of supervised command centers, number of areas, and the available power affect the total number of command centers you can connect to the system.

The D1257 provides remote annunciation without system control capability. It is well suited for use in locations where the public may have access to it.

Two keys on the D1257 allow the user to step forward or backward through a list of system events.

2.2 Description




Figure 1: D1256/D1257 Internal Arrangement

D1256/D1257

Overview

2.2.1 Display

Both the D1256 and D1257 feature a 16-character English language display, with custom programmable text. The custom text is provided through programming the control/communicator. See Figure 1: D1256/D1257 Internal Arrangement.

Both display the latest status conditions of the fire system using words, numbers, and symbols. When an alarm occurs, it is displayed until the user acknowledges the event at a command center. When a series of events affecting the system occur, each event displays in order of its priority.

2.2.2 Audible Tones

Both the D1256 and D1257 have a built-in speaker that produces several distinct warning tones. The speaker volume can be changed by adjusting the potentiometer. See Figure 1: D1256/D1257 Internal Arrangement. Turn the potentiometer clockwise to increase and counterclockwise to decrease the volume. You cannot connect external annunciation devices to the annunciators.

The following signals are silenced by pressing the correct key at the D1256 Fire Command Center.

- **Fire Signal** – When the system is in alarm, the annunciators emit a pulsed, high pitched "bell" tone.
- **Invalid Key Buzz** – When an invalid key, or sequence of keys, is pressed, the annunciators emit a flat buzz tone.
- **Keypad Encoding Tone** – Emits a muted beep tone as each key is pressed to indicate that the entry has been accepted. To disable this feature, see *Setting the DIP Switches*.
- **Trouble Buzzer** – When a trouble event occurs, such as a service alert, the annunciators emit a two tone warble until you press the "Trouble Silence" button on the D1256.

2.2.3 Switch Settings

A six-position switch located under the D1256 and D1257 cover allows you to select the address of each annunciator and silence the keypad encoding tones. See Figure 1: D1256/D1257 Internal Arrangement.

To access the switches:

1. Remove the front cover.
2. Using a small flat-bladed screwdriver, gently push in the two bottom tabs of the enclosure cover.
3. As the tabs are pushed in, lift the cover away from the base.
4. Set the switches as follows:

Address #	Switch					
	1	2	3	4	5	6
Address #1	ON	ON	ON	ON	ENCODING TONE ON/OFF	ON
Address #2	OFF	ON	ON	ON		ON
Address #3	ON	OFF	ON	ON		ON
Address #4	OFF	OFF	ON	ON		ON
Address #5	ON	ON	OFF	ON		ON
Address #6	OFF	ON	OFF	ON		ON
Address #7	ON	OFF	OFF	ON		ON
Address #8	OFF	OFF	OFF	ON		ON

Table 2: Switch Address Settings

3.0 Installation

3.1 Mounting the D1256 and D1257

The annunciators are low profile, surface-mounted units molded in durable red plastic. They can be mounted using the following optional packages:

- D56 Command Center Keypad Conduit Box (Protected surface or flush mount)
- D54B Command Center Flushmount Kit (Brass)
- D54C Command Center Flushmount Kit (Stainless Steel)

3.1.1 Mounting Locations

Do not mount annunciators in a location where they are exposed to direct sunlight. Direct sunlight can interfere with the display screen's visibility and damage internal components. Do not mount the annunciators in wet or moist locations.

3.2 Wiring the D1256 and D1257

A four-wire flying lead (See Figure 1: D1256/D1257 Internal Arrangement, Wiring Harness Connector) is required for the data and power connections between the annunciators and the control/communicator. The annunciators come with a wiring harness consisting of four color-coded flying leads with a female four-pin connector plug at one end.

To wire the D1256 and D1257:

1. Power down the control/communicator.
2. Connect the flying leads of the wiring harness (provided) to the wiring terminals on the panel.

D1256/D1257 Harness	Connecting an additional Annunciator to the D9100 carrier module (a part within the D9124)	Connecting to a compatible panel (see section 2.1.1 D1256)
12 VDC (red) to	12 VDC (terminal 1)	terminal 32
Data In (yellow) to	Data Out (terminal 3)	terminal 31
Data Out (green) to	Data In (terminal 4)	terminal 30
COMMON (black) to	COMMON (terminal 2)	terminal 29

Table 3: Wiring Connections

3. Using a small flat-bladed screwdriver, gently push in the two bottom tabs of the enclosure cover.
4. As the tabs are pushed back, lift the cover away from the base.
5. Set the switches as shown in Table 2: Switch Address Settings on page 8.
6. Turn the command center over and plug in the wiring connector through the opening in the back of the enclosure base.
7. Mount the annunciator's base to the wall. Secure it in place using the three mounting holes inside the enclosure base.
8. Replace the cover. Align and insert the top two tabs of the enclosure cover into the top two tab slots of the enclosure base.
9. Hold the top edges of the enclosure cover and base in position.
10. Push the tabs inward and press the enclosure and cover until the cover snaps into place.

D1256/D1257

Installation

3.3 Programming the Control/Communicator

The **Command Center**, **User Interface**, **Command Menu** (for D7212B, D9112B) or **Function List** (D7212, D7412, D9112, D9412), **and Passcode Worksheet** sections of the control/communicator program determine the annunciator displays and functions available from the D1256. Key points to consider are described below.

3.3.1 Command Center Assignments

1. **Command Center Text.** The D1256 can be used on any one of the eight (8) addresses in the control panel. The following sections (3.3.2 to 3.3.4) describes programming for one D1256 assigned to Command Center #1.
2. **Supervised.** Certain local jurisdictions may require that fire system annunciators be supervised. If this is a requirement in your area, set supervision to YES for the addresses that use fire alarm annunciators.
3. **Scope.** The D1256 is designed to acknowledge fire alarms and troubles, not burglar alarms and troubles. Set the scope to include fire areas only.
4. **Area.** Program the area number of the fire area(s) as normal.

3.3.2 Area Text

	Area 1	Area 2
Area # is On	P R E S S A L A R M S I L	-----
Area # Not Ready	C H E C K F I R E S Y S	-----
Area # is Off	* F I R E S Y S T E M *	-----
Area # Acct is On	-----	-----

Figure 2: Example 1 – Area Text

1. **Area # is On - PRESS ALARM SIL.** Fire area should remain in the OFF state at all times. If the authority level is not programmed correctly, the fire alarm area will become armed and the PRESS ALARM SIL display will show on the fire alarm annunciator. Pressing the ALARM SILENCE key will both silence any alarm(s) and disarm the area. This will cause the fire alarm annunciator to again display the normal * FIRE SYSTEM * display.
2. **Area # Not Ready - CHECK FIRE SYS.** Most fire alarm areas will consist of all 24-hour points and therefore the Area # Not Ready display will not be used. If a controlled point type is used for some type of fire supervision device, and the device becomes off-normal, the CHECK FIRE SYS message will appear on the fire command center.
3. **Area # is Off - * FIRE SYSTEM *.** This is the normal idle text for the fire alarm annunciator.
4. **Area # Acct is On - -----.** The Area # Acct is On text is not used in the system.

3.3.3 Custom Function

	Text	
CF 128	A L A R M S I L E N C E	1 2 5 6 0 0 E -----
CF 129	C H E C K F I R E S Y S	A 4 C C -----
CF 130	D E T E C T O R R E S E T	A 4 7 -----
CF 131	A N N U N C A T O R R E S E T	1 2 5 6 0 0 C -----

Figure 3: Example 2 – Custom Function

These items must be programmed as indicated in the *Custom Functions* section of *Command Center* to make the D1256 function keys operational. The passcode 125600 has been chosen for the following examples, although any passcode may be used.

CF 128 – ALARM SILENCE ?

Key Stroke: 125600E. This custom function will be programmed as the first Menu item. It will be executed when the ALARM SILENCE key is pressed on the D1256. The key stroke entry of 125600E will be seen by the control panel as a valid passcode entry in the area having the authority level to silence a ringing fire bell in the area. The "E" at the end of the string represents the ENTER key on the command center

CF 129 – TROUBLE SILENCE ?

Key Stroke: A4CC. This custom function will be programmed as the second item in the Menu and will be executed whenever the TROUBLE SILENCE key is pressed on the D1256. This entry is equivalent to the execution of a Command 4 at the D1256.

CF 130 – DETECTOR RESET ?

Key Stroke: A47. This custom function will be programmed as the third Menu item and will be executed when the DETECTOR RESET key is pressed on the D1256. This entry is equivalent to the execution of a Command 47 at the D1256.

CF 131 – ANNUNCIATOR RESET ?

Key Stroke: 125600C. This custom function will be programmed as the fourth command menu item and will be executed when the ANNUNCIATOR RESET key is pressed. The effect of this function is to clear the "View Memory" buffer. It does not clear the event out the event log contained with the panel.

3.3.4 Menu/Function List

Menu/Function List

Menu Item	Function	CC Address 1	CC Address 2	CC Address 3	CC Address 4	CC Address 5	CC Address 6	CC Address 7	CC Address 8
1	1 2 8	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No
2	1 2 9	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No
3	1 3 0	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No
4	1 3 1	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No
5	- - 9	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No
6	- 1 0	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No
7	- 1 2	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No
8	- 2 1	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No
9	- 2 9	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No
10	- 3 2	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No
11	- - -	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No

Figure 4: Example 3 – Menu/Function List

The D7212B, D9112B and the D9124 (that uses the D9112LTB) Program Record Sheet references this section as the Menu List. However, the D7212, D7412, D9112, D9412, and the D9124 (that uses the D9112LTB-EX) Program Record Sheet references this section as the Function List.

D1256/D1257

Installation

Menu Item and Function

Radionics recommends that you program the first ten menu items as indicated below. The first four menu items must be programmed as indicated below for the D1256 to function properly. The first four keys on the D1256 annunciator execute the first four menu items turned on at the command center address. Menu items five through ten are optional features that you may or may not want to program into the D1256 system. Menu items five through ten are explained in the *Fire System User's Guide* (P/N 71-06991-000) as optional features. See the User's Guide for further explanation of these items. Programming of items five through ten are optional.

Menu Item	Function	Description
1	128	ALARM SILENCE_ _?
2	129	TROUBLE SILENCE ?
3	130	DETECTOR RESET ?
4	131	ANNUNCIATOR RESET
5	9	VIEW _ MEMORY _ ?
6	10	VIEW PT STATUS _ ?
7	12	FIRE_ TEST_ ?
8	21	VIEW LOG _ ?
9	29	REMOTE PROGRAM ?
10	32	DISPLAY _ REV ?

Table 4: Menu/Function List Description

CC Address

Program command center addresses to YES for the first four menu items and the optionally program menu items five through ten as YES.

3.3.5 Passcode Worksheet

Passcode Worksheet

User Flag	User	Passcode	User Window	Area Auth								User Name
				1	2	4	5	6	7	8		
000	00	— — — — —	— —	15	15	15	15	15	15	15	15	_____
001	01	1 2 5 6 0 0	— —	14	—	—	—	—	—	—	—	_____

Figure 5: Example 4 – Passcode Worksheet

Passcode

A special passcode must be programmed as a valid passcode for the system to work. This passcode is used in custom functions 128 and 131. Any user number may be used to establish this mandatory valid passcode. It must additionally be created as a valid passcode in the area the D1256 is assigned to. Radionics recommends using authority level 14 in conjunction with the passcode you choose (see Authority Level Selections).

3.3.6 User Interface

User Interface

Cmd Center Function				Authority Level Selections														
Blank = Disabled / E = Enable / P = Passcode				Blank = Disabled / E = Enable														
#	Function	Command	E/P	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	Disarm		P															
2	Master Arm	CMD 1																
3	Mstr Arm Inst	CMD 11																
4	Perim Inst	CMD 2																
5	Perim Delay	CMD 3																
6	Watch Mode	CMD 6																E
7	Perim Partial	CMD 8																
8	View Area Stat																	E
9	View Event Mem	CMD 40	E															E
10	View Pt Status		E															E
11	Walk Test	CMD 44																E
12	Fire Test	CMD 58	E															E
13	Send Report	CMD 41/42																E
14	Not Used																	
15	Chg Display	CMD 49	E															E
16	Chg Time/Date	CMD 45																E
17	Chg Passcode	CMD 55																E
18	Add Passcode	CMD 56																
19	Del Passcode	CMD 53																E
20	Extend Close	CMD 51																E
21	View Log																	E
22	Print Log																	E
23	User Cmd 7	CMD 7																E
24	User Cmd 9	CMD 9																E
25	Bypass a Pt	CMD 0																
26	Unbypas a Pt	CMD 00																E
27	Reset Sensors	CMD 47	E															E
28	Relay Control	CMD 54																E
29	Remote Program	CMD 43	E															E
30	Move to Area	CMD 50																E
31	Not Used																	
32	Display Rev	CMD 59	E															E
33	Service Walk																	E
34	Default Text	CMD 57																E
35	Change Skeds	CMD 52																E
	Force Arm		P															
	Area O/C		P															
	Restricted O/C		P															
	Perimeter O/C		P															
	Send Duress		P															
	Passcode Arm		P															
	Passcode Disarm		P															E

Figure 6: Example 5 – User Interface for D7212B, D9112B, and D9124 (that use the D9112LTB)

D1256/D1257

Installation

User Interface

#	Functions*	Command	E/P	Authority Levels															
				1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	
1	Disarm ?		P	E	E	E	E	E											
2	Master Arm Delay ?	CMD 1																	
3	Master Arm Instant?	CMD 11																	
4	Perimeter Instant ?	CMD 2																	
5	Perimeter Delay ?	CMD 3																	
6	Watch Mode ?	CMD 6																	E
7	Perimeter Part ?	CMD 8																	
8	View Area Status ?																		E
9	View Memory ?	CMD 40	E																E
10	View Pt Status ?		E																E
11	Walk Test ?	CMD 44																	E
12	Fire Test ?	CMD 58	E																E
13	Send Report ?	CMD 41/42																	E
14	** Door Control ?	CMD 46																	E
	** Cycle Door ?																		E
	** Unlock Door ?																		E
	** Secure Door ?																		E
37	** Access Control Level?																		E
15	Change Display ?	CMD 49	E																E
16	Change Time/Date ?	CMD 45																	E
17	Change Passcode ?	CMD 55																	E
18	Add User ?	CMD 56																	E
19	Del User ?	CMD 53																	E
20	Extend Close ?	CMD 51																	E
21	View Log ?		E																E
22	Print Log ?																		E
23	User Command 7 ?	CMD 7																	E
24	User Command 9 ?	CMD 9																	E
25	Bypass a Point ?	CMD 0																	E
26	Unbypass a Point ?	CMD 00																	E
27	Reset Sensors ?	CMD 47	E																E
28	Change Relays ?	CMD 54																	E
29	Remote Program ?	CMD 43	E																E
30	Move To Area ?	CMD 50																	E
32	Display Rev ?	CMD 59	E																E
33	Service Walk ?																		E
34	Default Text ?	CMD 57																	E
35	Change Skeds ?	CMD 52																	E
#	Custom Functions																		
128	Custom Function 128		E																
129	Custom Function 129		E																
130	Custom Function 130		E																
131	Custom Function 131		E																
132	Custom Function 132		E																
133	Custom Function 133		E																
134	Custom Function 134		E																
135	Custom Function 135		E																
136	Custom Function 136		E																
137	Custom Function 137		E																

* Command Center Function Authority Level Options: Blank = Disabled, E = Enabled. A boldface **P** indicates that this command center function is invisible in the [CMD Ctr functions] menu of the D5200 Programmer. ** **D9412 only.**

TABLE CONTINUED ON NEXT PAGE

Figure 7: Example 6 – User Interface for D7212, D7412, D9112, D9412, and D9124 (that uses the D9112LTB-EX)

User Interface

#	Custom Functions*	Authority Levels															
		E/P	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
138	Custom Function 138	E															
139	Custom Function 139	E															
140	Custom Function 140	E															
141	Custom Function 141	E															
142	Custom Function 142	E															
143	Custom Function 143	E															
Report Levels																	
	Force Arm ?	P	E	E	E	E	E	E									
	Area O/C ?	P															
	Restricted O/C ?	P															
	Perimeter O/C ?	P															
	Send Duress ?	P	E	E	E	E	E	E	E	E	E	E	E	E	E	E	E
	Passcode Arm ?	P	E	E	E	E	E	E									
	Passcode Disarm ?	P	E	E	E	E	E										E
** Access Levels**																	
	** Access Level ?	E	M	M	P	P	P	D									
	** Disarm Level ?	E	I	D	D	D	D										

* Command Center Function Authority Level Options: Blank = Disabled, E = Enabled. A boldface P or E indicates that this command center function is invisible in the [CMD Ctr functions] menu of the D5200 Programmer.

** D9412 only.

** Access Authority Level Options:

Access Level?	M = Any Armed State, P = Perimeter Armed, D = Disarmed, Blank = No Access
Disarm Level?	I = Disarm to Perimeter Instant, D = Disarm All, Blank = No Disarm Rights

Figure 8: Example 6 Continued – User Interface for D7212, D7412, D9112, D9412, and D9124 (that uses the D9112LTB-EX)

Command Center Functions

The following command center function must be turned on to enable the DETECTOR RESET key.

- #27 Reset Sensors

It is suggested that the items below be included in the menu.

- #9 View Event Memory
- #10 View Point Status
- #12 Fire Test
- #21 View Log
- #29 Remote Program
- #32 Display Rev

Note: For D7212B and D9112B Control/Communicators, it is important to enable each of these items with an "E" and not a "P." If any of the above items are enabled with a "P" then a custom function must also be established to execute the menu item from the command center. This custom function would include the appropriate embedded passcode to let the system function. For example, if View Event Memory were to be passcode protected and the chosen passcode was 125600, the macro string would be A40125600E. Consideration should be given to passcode protecting the command center function in combined burglary/fire applications.

Note 2: For D7212, D7412, D9112 and D9412 Control Communicators, embedding passcodes inside Custom Functions is not allowed. Therefore, any command used in Custom Function, should not be passcode protected.

D1256/D1257

Installation



Further customization may be required if the D1256 is located in an unsecured area, or if D1255 Command Centers are installed in the system. The factory loaded program for the D9124 makes these functions available without requiring a passcode entry.

If for example, the D1256 that is connected to a D7212B or D9112B1 is located in a secure area, but the D1255 Command Centers are also installed, you may want to restrict command center functions by requiring a passcode in Cmd Center Function.

Note: The following paragraph applies only to the D7212B, D9112B and D9124 (that uses a D9112LTB) Control/Communicators. See Note 2 for information regarding the D7212, D7412, D9112, D9412, and the D9124 (that uses a D9112LTB-EX).

Once restricted, a passcode with an appropriate authority level must be entered in *Custom Key Strokes* along with the key strokes to make the function keys operational.

Finally, in the *Menu/Function List*, you would show the function numbers for the *Custom Functions* controlling the function keys ONLY at D1256 addresses in secured areas.

Function numbers for standard *User Interface* command center functions can be programmed in the *Menu Function List* for D1256 and D1255 addresses. Remember to enable functions only as appropriate for the command center at the address. The D1256 does not have numeric keys, so it can not be used to access functions that require a passcode.

Appendix A: Specifications

Power:	Nominal 12 VDC supplied by the Control/Communicator
Current Required:	Idle: 104 mA Maximum: 206 mA, with annunciator lighted and warning tone on.
Wiring:	Four-wire supplies Data In, Data Out, + 12VDC, and Common. Maximum data loop resistance is 10 Ω .
Dimensions:	Base: 4.6 x 8.2" (11.6 x 20.7 cm) (HxW) Cover: 4.3 x 8.12 x 0.816" (10.9 x 20.6 x 2.1 cm) (HxWxD)
Color:	Fire engine red
Display:	16 character vacuum fluorescent display. Each character is a 14-segment unit. Soft blue color.
Operating Temperature:	32° to 122°F (0° to 50°C)
Relative Humidity:	5 to 85% @ 86°F (30°C)