



Model IFP-100 Basic Operating Instructions

These Instructions must be framed and displayed next to the IFP-100 panel in accordance with NFPA 72 fire code for Local Protected Fire Alarm Systems. Test the system in accordance to NFPA 72,

Operation	Task to Perform
Silence Alarms and Troubles	Press SILENCE then enter a code if prompted. Silence LED will light.
Reset Alarms	Press RESET then enter a code if prompted.
Acknowledge Alarms and Troubles	Press ACK then enter a code if prompted. When the Alarm or Trouble is acknowledged an A will appear in the annunciator display as shown Below. <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <pre> TROUBLE: SMOKE-ION MODULE_33 POINT_1 [Z001] [M33:001] MISSING 1 OF 1 </pre> <p style="text-align: right;">Acknowledge Mark →</p> </div>
View Alarms, Supervisories, and Troubles	For each type of condition press the ∇ or \triangle button associated for Alarms, Supervisories, or Troubles.
Conduct a Fire Drill	Press the DRILL button enter a code if prompted. or 1. Press ENTER to access Main Menu. 2. Then press 1 to select System Tests. 3. Enter code if prompted, then press 1 to select Fire Drill. 4. Press ENTER to start the fire drill. 5. Press ENTER to end the fire drill.
View a Points Status	1. Press ENTER to access Main Menu. 2. Then press 2 to select Point Functions. 3. Enter code if prompted, then press 2 to select Point Status. 4. Select the module the device is located on by using the ∇ or \triangle . Then press ENTER . 5. Enter the point number.
Check Detector Sensitivity	1. Follow steps 1 through 5 for viewing a point status. 2. Press \triangleright to view detector sensitivity.
Set Time and Date	1. Press ENTER to access Main Menu. 2. Then press 4 to select Set Time & Date. Enter a code if prompted 3. Make changes in the fields on the screen as necessary. 4. Press ENTER if you wish to keep the changes. 5. Press ENTER to set the entered time and date.
Enable / Disable a Point	1. Press ENTER to access Main Menu. 2. Then press 2 to select Point Functions. 3. Enter code if prompted, then press 1 to select Disable / Enable Pt. 4. Select the module the point is located on by using the ∇ or \triangle . Then press ENTER . 5. Enter the point number.
View Event History	1. Press ENTER to access Main Menu. 2. Press 3 to select Event History. 3. Press the ∇ or \triangle to view events in the history buffer.
For Service call:	

Cut Along the Dotted Line