




466-1512-01 Rev D
December 2002

GE Interlogix

**Part Numbers:
60-792-01-95R
60-734-01**



Concord Security System

(Software Version 2.6)

Installation Instructions

FCC Notices

FCC Part 15 Information to the User

Changes or modifications not expressly approved by Interlogix Inc. can void the user's authority to operate the equipment.

FCC Part 15 Class B

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the affected equipment and the panel receiver to separate outlets, on different branch circuits.
- Consult the dealer or an experienced radio/TV technician for help.

ACTA Part 68


This equipment complies with Part 68 of the FCC Rules. Located on this equipment is a label that contains, among other information, the FCC registration number and the ringer equivalence number (REN) for this equipment. If requested, this information must be provided to the telephone company.

FCC Part 68 Registration No. B4ZUSA-25644-AL-E

The REN is used to determine the maximum number of devices that may be connected to your telephone line. Excessive RENs on a telephone line may result in devices not ringing in response to an incoming call. In most areas, the sum of all device RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company. For products approved after July 23, 2001, the REN for this product is part of the product identifier that has the format US:AAAEQ##TXXXX. The digits represented by ## are the REN without a decimal point (e.g., 03 is a REN of 0.3). For earlier products, the REN is separately shown on the label.

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements as adopted by ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compliant modular jack that is also compliant. See the Installation Instructions for details.

Alarm dialing equipment must be able to seize the telephone line and place a call in an emergency situation. It must be able to do this even if other equipment (telephone, answering system, computer modem, etc.) already has the telephone line in use. To do so, alarm dialing equipment must be connected to a properly installed RJ31X jack that is electrically in series and ahead of all other equipment attached to the same telephone line. Proper installation is depicted in the following diagram. If you have any questions concerning these instructions, consult your local telephone company or a qualified installer about installing an RJ31X jack and alarm dialing equipment for you.



If this equipment causes harm to the telephone network, the telephone company may temporarily disconnect your service. If possible, you will be notified in advance. When advance notice is not practical, you will be notified as soon as possible. You will also be advised of your right to file a complaint with the FCC.

The telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the operation of the equipment. You will be given advance notice in order to maintain uninterrupted service.

If you experience trouble with this equipment, please contact the company that installed the equipment for service and/or repair information. The telephone company may ask you to disconnect this equipment from the network until the problem has been corrected or you are sure that the equipment is not malfunctioning.

This equipment may not be used on coin service provided by the telephone company. Connection to party lines is subject to state tariffs.



GE Interlogix

Contents

About This Manual 1

Special Installation Requirements	1
UL Listed Installations	1
Central Station Reporting	2
UL Canada Listed Installations	2
California State Fire Marshall Listed Installations	3

Planning the Installation 3

Standard Panel	3
SuperBus 2000 Touchpads	3
SuperBus 2000 RF Receivers	4
Power Line Carrier Card	4
Phone Supervision Card	4
Supervised Wireless Siren	4
SuperBus 2000 Phone Interface/Voice Module	4
SnapCards	4
SuperBus 2000 8Z Input Module (HIM)	4
SuperBus 2000 4-Relay Output Module (HOM)	4
Interrogator 200 Audio Verification Module	4
SuperBus 2000 Cellular Backup Module	4
SuperBus 2000 Energy Saver Module (ESM)	5
SuperBus 2000 Automation Module	5
SuperBus 2000 Wireless Gateway Module	5

Installing the System 5

Determine the Panel Location	5
Total System Power and Wire Length Guidelines	6
Mounting the Panel	8

Identify Panel Components 9

Installing Antennas	9
Connecting the Panel to Earth Ground	10
Installing the Optional Power Line Carrier Card (60-755)	10
Installing the Optional Phone Supervision Card (60-789)	10
Installing Optional SnapCards	11
Connecting Detection Devices to Panel Zone Inputs	11
Connecting Intrusion Detection Devices	11
Connecting 2-Wire Smoke Detectors	11
Connecting 4-Wire Smoke Detectors	12
Connecting Speakers	12
15-Watt Speaker (13-060)	13
Hardwire Interior Speaker (60-528)	13
Connecting Piezo Sirens	14
Exterior Sirens	14
Interior Sirens	14

Installing Supervised Wireless Sirens (60-736-95)	14
Connecting an Interrogator 200 Audio Verification Module (60-677)	15
Connecting Alphanumeric and Fixed Display Touchpads	16
Installing SuperBus 2000 Modules	16
SuperBus 2000 RF Receiver (60-764-01-95R-16Z/32Z/MAX)	17
SuperBus 2000 Phone Interface/Voice Module (60-777-01)	17
SuperBus 2000 Energy Saver Module (60-620-01)	18
SuperBus 2000 8Z Input Module (60-774)	19
SuperBus 2000 4-Relay Output Module (60-770)	19
SuperBus 2000 Cellular Backup Module	19
SuperBus 2000 Automation Module	20
SuperBus 2000 Wireless Gateway Module (60-861)	20
Setting Device Address on SuperBus 2000 Devices	21
Installing an RJ-31X Phone Jack (13-081)	21
Connecting the Phone Line to the Panel with a DB-8 Cord	21
Connecting the AC Power Transformer	22
Powering Up the Panel	22

Programming the Panel

22

Entering Program Mode	22
Touchpad Button Programming Functions	23
Moving Through Program Mode Tiers and Menus	23
Programming Tier 1 Menu Items	24
Programming Tier 2 Menu Items	25
Using Shortcut Numbers	25
Security Menu	26
Phones Menu	29
Phone Options Menu	32
Timers Menu	36
Light Control Menu	38
Touchpad Options Menu	38
Reporting Menu	39
Siren Options Menu	44
Sensors Menu	45
Audio Verification Menu	47
Accessory Modules Menu	49
Onboard Options Menu	52
Exiting Programming Mode	53
Entering User Programming Mode	53
Time and Date Menu	54
User Codes Menu	54
Options Menu	56
Set Up Schedules Menu	57
Attach Schedules to Events Menu	58
Attach Lights to Sensors Menu	59
System Version Menu	60
Downloader Programming	60
ToolBox Downloader Programming	60

Testing the System

60

Basic System Commands	60
Testing Zones/Sensors	61
If a Wireless Sensor Does Not Test	61
Testing Phone Communication	62
Testing Central Station/Pager Communication	62
Testing Outputs and Sirens	63
Testing Light Control	63
Testing the Energy Saver Module (ESM)	63
Changing Fixed Display LCD Touchpad Chime and Trouble Beep Tones	64
Adjusting Touchpad Display Contrast	64
Testing Audio Verification Module (AVM) Communication	64
Testing Cellular Backup Communication	64
<i>Troubleshooting</i>	66
<i>Appendix A: System Planning Worksheets</i>	72
<i>Appendix B: Reference Tables</i>	79
<i>Appendix C: Settings</i>	88
<i>Specifications</i>	93
<i>System Wiring Notes</i>	94

About This Manual

This manual provides information for planning, installing, programming, and testing this security system. When necessary, this manual refers you to other documentation included with compatible peripherals.

Planning sheets are included for you to record hardware layout and software programming settings.

About the User's Guide

The *User's Guide* (466-1513-01) contains user worksheets that should be filled out during the installation and programming of the system. With two partition systems, a *User's Manual* for each partition is suggested.

Special Installation Requirements

This security system can be used as a fire warning system, an intrusion alarm system, an emergency notification system, or any combination of the three.

Some installations may require configurations dictated by city/state codes, insurance, or Underwriter's Laboratories (UL). This section describes the various component and configuration listings.

UL Listed Installations

This section describes the requirements for UL Listed installations.

Basic System

- Control Panel (60-734-01 Hybrid or 60-792-01-95R Integrated)
- Backup Battery 12V 4 AH (60-681) or 12V 7 AH (60-680)
- SuperBus[®] 2000 Fixed Display Touchpad (60-820), 2x16 LCD Touchpad (60-746-01), 2x20 LCD Touchpad (60-803), or 2x20 VFD Touchpad (60-804)
- Standard Class II 24 VAC, 30 VA Power Transformer (60-761), Class II 24 VAC, 30 VA Line Carrier Power Transformer (60-762), or Standard Class II 24 VAC, 50 VA Power Transformer (60-778), Class II 24 VAC, 50 VA Line Carrier Power Transformer (60-779)
- Interior Speaker Siren (60-528), Exterior Speaker Siren (13-060), Slim Line Hardwire Interior Siren (60-483-01) or Hardwire Exterior Siren (13-046)

Basic system may also include a SuperBus 2000 RF Receiver (60-764-01-95R-16Z) or (60-764-01-95R-32Z) or (60-764-01-95R-MAX).

Household Burglary Alarm System Unit (UL 1023)

Basic system, plus:

- Hardwire Magnetic Contact (13-068 or 13-071) or Wireless Learn Mode Door/Window Sensor (60-362)
- Immediate Trouble Beeps set to on
- UL 98 Options set to on
- Receiver Failure set to on (if wireless devices are used)
- Siren Verify set to on
- Exit Delay set to 60 seconds
- Quick Exit set to off
- Exit Extension set to off
- Siren Timeout set to 4 minutes or more
- Entry Delay set to 45 seconds or less
- AC Failure set to on
- RF TX Timeout set to 24 hours (if system includes a built in or SuperBus 2000 RF Receiver and wireless smoke sensors)

Household Fire Warning System (UL 985)

Basic system, plus:

- Hardwire Smoke Detector: *System Sensor models* 2100D, 2100TD, 2100S, 2100TS, 2400, or 2400TH learned into sensor group 26 or *Sentrol (ESL) models* 429AT, 521B or 521BXT learned into sensor group 26
- Wireless Smoke Sensor 60-506-319.5 or 60-838-95 learned into sensor group 26

- Immediate Trouble Beeps set to on
- UL 98 Options set to on
- Receiver Failure set to on (if wireless devices are used)
- Siren Verify set to on
- AC Failure set to on
- RF TX Timeout set to 4 hours (if system includes a built in or SuperBus 2000 RF Receiver and wireless smoke sensors)

UL 1023 & 985 24-Hour Backup

For 24-hour backup, the total current draw for all connected devices is limited to 90 mA (during normal standby conditions) using a 4.0 AH battery, or 190 mA (during normal standby conditions) using a 7.0 AH battery.

Commercial Burglary Alarm System Unit (Grade C UL 1610)

Basic system using Control Panel 60-801-01 plus:

- Hardwire Magnetic Contact (13-068 or 13-071) or Wireless Learn Mode Door/Window Sensor (60-499)
- SAW PIR Sensor (60-639-95R), Crystal PIR Sensor (60-703-95R), or DS924i PIR Sensor (60-511-01-95)
- Immediate Trouble Beeps set to on
- UL 98 Options set to on (see page 44)
- Receiver Failure set to on (if wireless devices are used)
- RF TX Timeout set to 4 hours
- 24-Hour Tamper set to on
- System Tamper set to on
- Auto Phone Test set to on
- Phone Test Freq. set to 1
- Next Phone Test set to 1
- Siren Verify set to on
- AC Failure set to on

UL 1610 24-Hour Backup

- Same as UL 1023 & 985

UL 1635 Digital Alarm Communicator System

- Same as UL 1023 & 985

Central Station Reporting

The panel has been tested with the following central station receivers using SIA and Contact ID reporting formats:

- CS-5000 Central Station Receiver
- Sur-Gard Central Station Receiver with models SG-DRL2A and SG-CPM2

UL Canada Listed Installations

This section describes the requirements for CUL (UL Canada) Listed installations.

Canadian Standards CSA Certified Accessories

Residential Burglary Alarm System Unit (ULC-S309)

Basic system as described for “UL Listed Installations” plus:

- Hardwire Magnetic Contact (13-068 or 13-071) or Wireless Learn Mode Door/Window Sensor (60-362)

Residential Fire Warning System Control Unit (ULC-S545-M89)

Basic system as described for “UL Listed Installations” plus:

- Hardwire Smoke Detector: *System Sensor models* 2100D, 2100TD, 2100S, 2100TS, 2400, 2400TH learned into Sensor Group 26, or *Sentrol (ESL) models* 429AT, 521B, or 521BXT learned into sensor group 26

Note

For 24-hour backup, external power drain is limited to 90 mA (during normal standby condition) using a 4.0 AH battery, or 190 mA continuous using a 7.0 AH battery.

- Wireless Smoke Sensor 60-506-319.5 or 60-838-95 learned into sensor group 26
- Immediate Trouble Beeps set to on
- RF TX **Timeout** set to 4 hours (if system includes SuperBus 2000 RF Receiver and wireless smoke sensors)

California State Fire Marshall Listed Installations

Same as Household Fire Warning System (UL 985), plus:

- SMOKE VERIFY must be set to off

Planning the Installation

This section describes system capabilities to help you get familiar with the system. “Appendix A” provides planning sheets with tables that let you record the hardware and programming configuration of the system. Fill in all necessary information ahead of time to help prepare for system installation.

When planning the installation, keep in mind that the panel has the following capabilities (dependent upon devices used):

- Up to 16 SuperBus 2000 Devices (maximum of 4 RF receivers)
- Up to 76 wireless or hardwired zones

Standard Panel

The following describe the basic panel (out-of-box) hardware capabilities.

- **Power:** Input for an AC step-down, plug-in style transformer.
- **Auxiliary Power Output:** Output that supplies 8.5 to 13.5 VDC with up to 1 amp (with panel powered by 30 VA transformer) or 2 amps (with panel powered by 50 VA transformer) for bus devices and hardwired detectors, such as smoke and motion detectors.
- **Bus A and B:** Input and output that provides communication between bus devices and the panel.
- **Siren Driver:** Output that can drive an 8-ohm load and provides intrusion and fire alarm sounds for partition 1.
- **2 Onboard Outputs:** Open-collector outputs that can be set up to activate other signalling devices, based on system events.
- **Microphone Input:** Input used for 2-way audio when used in conjunction with the Interrogator 200 Audio Verification Module.
- **8 Supervised Hardwire Zones:** Inputs for various hardwired detectors. Zone 8 can be set up in programming to accept 2-wire smoke detectors.
- **Built-In SuperBus 2000 Receiver (60-792-01-95R only):** Allows use of up to 16 or 32 319.5 MHz. crystal and/or SAW Learn Mode wireless sensors and touchpads. Also allows supervision of Supervised Wireless Sirens.
- **Phone Line Connection:** Allows panel to communicate with central monitoring station and/or pagers.

SuperBus 2000 Touchpads

The following describes the different touchpads that can be used for system programming and operation.

- **SuperBus 2000 Fixed Display Touchpad:** Provides operation control and user-programming access (*not installer/dealer programming*). Displays system messages and indicates system status.
- **SuperBus 2000 2x16 LCD Touchpad:** Provides complete system programming and operation control. Displays system messages that prompt users for information when needed and indicates system status.
- **SuperBus 2000 2x20 LCD Touchpad:** Provides complete system programming and operation control. Large display shows system messages that prompt users for information when needed and indicates system status.
- **SuperBus 2000 2x20 VFD Touchpad:** Provides complete system programming and operation control. Large fluorescent display shows system messages that prompt users for information when needed and indicates system status.

SuperBus 2000 RF Receivers

These receivers expand system wireless zone capacity by 16, 32, or the maximum zones allowed by the panel. The receivers are compatible with all 319.5 MHz. crystal and SAW Learn Mode wireless sensors, touchpads, and Supervised Wireless Sirens. You may connect up to 4 receivers to the panel.

Power Line Carrier Card

Adding this card (which requires that the panel be powered using a Power Line Carrier Transformer) adds the following capabilities to the system:

- Allows the use of Supervised Wireless Sirens.
- Allows the use of X-10 Powerhouse Lamp Modules for light control and light activation during alarms.

Phone Supervision Card

Adding this card allows the panel to check for the correct phone line voltage (partition 1 only), upon dialing the central station/pager number. The panel can also be programmed to check the phone line voltage automatically.

Supervised Wireless Siren

Supervised Wireless Sirens plug into any standard electrical outlet and produce status and alarm sounds. The panel sends signals to the siren through the Power Line Carrier Card and Line Carrier Power Transformer, through the AC electrical wiring.

The siren has a built-in transmitter that is used for supervising with the panel. With the siren transmitter learned into panel memory (panels with receivers), the siren can notify the panel if it is unplugged, stops receiving panel signals, or has a low backup battery.

SuperBus 2000 Phone Interface/Voice Module

This module allows system access and control using touch-tone telephones, on- or off-site. The module includes an output for a speaker that sounds system status and alarm voice messages.

SnapCards

The following SnapCards expand the system as described:

- **8Z Input SnapCard:** Provides eight additional hardwire zone inputs, of which two are dedicated for using two wire smoke detectors.
- **4 Output SnapCard:** Provides four form C relay outputs that can be set up to activate other signalling devices, based on system events, schedules, or direct control.
- **4Z Input/2 Output Combo SnapCard:** Provides three hardwire zone inputs, one two wire smoke detector loop, and two outputs that can be set up to activate other signalling devices, based on system events, schedules, or direct control.

SuperBus 2000 8Z Input Module (HIM)

Provides eight additional hardwire zone inputs.

SuperBus 2000 4-Relay Output Module (HOM)

Provides four form C relay outputs that can be set up to activate other signalling devices, based on system events.

Interrogator 200 Audio Verification Module

Adding this module allows central station operators to listen-in and talk to occupants on the premises to verify the emergency when an alarm report is received.

SuperBus 2000 Cellular Backup Module

Provides central station communication (cellular transmission) a backup to regular phone line(s).

SuperBus 2000 Energy Saver Module (ESM)

Provides a money-saving and convenient way to monitor and control temperatures. The ESM uses low- and high-temperature limits to save energy by overriding the existing HVAC thermostat. When the ESM is on, temperature limits determine when the heat or air-conditioning turns on. When the ESM is off, the HVAC thermostat controls heat and air-conditioning.

SuperBus 2000 Automation Module

Provides a connection to a compatible home automation device.

SuperBus 2000 Wireless Gateway Module

Allows users to control and monitor the status of their system from the alarm.com internet website. A wireless data transceiver on the module provides the link to a wireless 2-way paging network for website access.

Installing the System

This section describes how to install the system control panel. Before starting the installation, plan your system layout and programming using the worksheets provided in Appendix A.

Installing the system consists of the following:

- Determining the Panel Location
- Determining Total System Power and Wire Length Guidelines
- Mounting the Panel
- Identifying Panel Main Components
- Installing the Optional Power Line Carrier Card
- Installing Optional SnapCards
- Connecting Detection Devices to Panel Zone Inputs
- Connecting Speakers
- Connecting Piezo Sirens
- Connecting an Interrogator 200 Audio Verification Module
- Connecting Alphanumeric and Fixed Display Touchpads
- Installing SuperBus 2000 Modules
- Installing an RJ-31X Phone Jack
- Connecting the Phone Line to the Panel with a DB-8 Cord
- Connecting the AC Power Transformer
- Powering Up the Panel

Note

(A) Class 2, Class 3, and power-limited fire alarm circuits must be installed using FPL, FPLR, FPLP, or substitute cable permitted by the National Electrical Code ANSI/NFPA 70. Wire that extends beyond the cable jacket must be separated from all other conductors by a minimum of 1/4-inch or by a nonconductive barrier.

OR

(B) Class 2, Class 3, and power-limited fire alarm circuit conductors must be installed as Class 1 or higher circuits.

Determine the Panel Location

Before permanently mounting the panel, determine panel location using the following guidelines:

- Centrally locate the panel with relation to detection devices whenever possible, to help reduce wire run lengths and labor.
- Locate the panel where the temperature will not exceed 120°F (49°C) or fall below 32°F (0°C).
- Avoid running wires parallel with electrical wiring or fixtures such as fluorescent lighting, to prevent wire runs from picking up electrical noise.
- Mount the panel at a comfortable working height (about 45 to 55 inches from the floor to the bottom of the panel, as shown in Figure 1).




Figure 1. Determining Panel Location

- Leave space to the left and right of the panel for wiring, phone jack, and mounting optional modules.
- For wireless panels or hardwire panels that include a SuperBus 2000 RF Receiver, allow at least 9 inches above the panel cabinet for antennas.
- Allow at least 24 inches in front of the panel to open the panel door.

Total System Power and Wire Length Guidelines

Power

The panel can supply up to 1 amp (1,000 mA) when powered by the 24 VAC, 30 VA transformer or up to 2 amps (2,000 mA) when powered by the 24 VAC, 50 VA transformer for system devices.

Wire Length

The total system wire length allowed can vary depending on devices powered by the panel, the wire length between devices and the panel, and the combined wire length of all devices.

Table 1 describes the maximum wire length allowed between compatible devices and the panel, including the maximum current draw of each device.

Table 1: Maximum Device Wire Length and Current Draw

Device	Max. Wire Length to Panel	Max. mA Draw
SuperBus 2000 2x16 LCD Alphanumeric Touchpad	22 ga.—300 ft. 18 ga.—750 ft.	90 mA
SuperBus 2000 2x20 LCD Alphanumeric Touchpad	22 ga.—250 ft. 18 ga.—600 ft.	120 mA
SuperBus 2000 2x20 VFD Alphanumeric Touchpad	22 ga.—250 ft. 18 ga.—600 ft.	120 mA
SuperBus 2000 Fixed Display Touchpad	22 ga.—300 ft. 18 ga.—700 ft.	65 mA
SuperBus 2000 RF Receiver	22 ga.—1,100 ft. 18 ga.—2,800 ft.	30 mA
SuperBus 2000 Phone Interface/Voice Module	22 ga.—40 ft. 18 ga.—120 ft.	600 mA
Power Line Carrier Card	N/A	110 mA
4 Input/2 Output SnapCard	N/A	185 mA*
8Z Hardwire Zone Expander SnapCard	N/A	230 mA*
4 Output SnapCard	N/A	130 mA*

Table 1: Maximum Device Wire Length and Current Draw (Continued)

Device	Max. Wire Length to Panel	Max. mA Draw
SuperBus 2000 8Z Input Module	22 ga.—1,800 ft. 18 ga.—4,000 ft.	35 mA
SuperBus 2000 4-Relay Output Module	22 ga.—350 ft. 18 ga.—900 ft.	180 mA
SuperBus 2000 Energy Saver Module	22 ga.—1,600 ft. 18 ga.—4,000 ft.	20 mA
SuperBus 2000 Cellular Backup Module	Standard Power: 22 ga.—15 ft. 18 ga.—40 ft.	1600 mA
	High Power 22 ga.—10 ft. 18 ga.—30 ft.	1900 mA
SuperBus 2000 Automation Module	22 ga.—1,500 ft. 18 ga.—4,000 ft.	35 mA
SuperBus 2000 Wireless Gateway Module	22 ga.—40 ft. 18 ga.—90 ft.	1600 mA
Interrogator 200	22 ga.—3,200 ft. 18 ga.—4,500 ft.	10 mA
Interrogator AVM	22 ga.—110 ft. 18 ga.—260 ft.	300 mA
*Maximum current draw for the SnapCards does not include the load which may be applied to their auxiliary DC supply.		

Table 2 describes the total system wire lengths allowed when installing systems using unshielded or shielded cable.

Table 2: Total System Wire Length Allowed

Wire Type	Total System Wire
18-gauge, unshielded	4,500 ft.
18-gauge, shielded	3,000 ft.
22-gauge, unshielded	3,500 ft.
22-gauge, shielded	2,200 ft.

Table 3 describes the minimum current draw of each device when the panel is operating only from the backup battery. For 24-hour backup, the total current draw of all SnapCards connected to the panel and devices connected to +12V BUS (panel terminal 4) is limited to 90 mA (during normal standby condition) using a 4.0 AH battery, or 190 mA (during normal standby condition) using a 7.0 AH battery.

Table 3: Minimum Device Current Draw

Device	Min. mA Draw
SuperBus 2000 2x16 LCD Alphanumeric Touchpad	15 mA
SuperBus 2000 2x20 LCD Alphanumeric Touchpad	15 mA
SuperBus 2000 2x20 VFD Alphanumeric Touchpad	15 mA
SuperBus 2000 Fixed Display Touchpad	11 mA
SuperBus 2000 RF Receiver	27 mA
SuperBus 2000 Phone Interface/Voice Module	25 mA
Power Line Carrier Card	N/A
4 Input/2 Output SnapCard	20 mA
8Z Hardwire Zone Expander SnapCard	38 mA
4 Output SnapCard	1 mA
SuperBus 2000 8Z Input Module	18 mA
SuperBus 2000 4-Relay Output Module	12 mA
SuperBus 2000 Energy Saver Module	20 mA

Table 3: Minimum Device Current Draw

Device	Min. mA Draw
SuperBus 2000 Cellular Backup Module	90 mA
SuperBus 2000 Automation Module	30 mA
SuperBus 2000 Wireless Gateway Module	55 mA
Interrogator 200	10 mA
Interrogator AVM	45 mA

After determining panel location, run all necessary wires to that location using the guidelines in Table 4.

Table 4: Wire Requirements

Device	Wire Requirements
AC Power Transformer	2-conductor, 18-gauge, 25 feet max
Earth Ground	Single conductor, 16-gauge solid, 25 feet max
Telephone (RJ-31X)	4-conductor
Detection Devices	2- or 4-conductor, 18- to 22-gauge, 300-ohms max loop resistance including device
Speakers	2-conductor, 22-gauge, 175 feet max 2-conductor, 18-gauge, 440 feet max
SuperBus 2000 Devices	4-conductor, 22- or 18-gauge
Interrogator 200 AVM Power and Microphone	4-conductor, 22-gauge, shielded
2-Wire Smoke Detectors	2-conductor, 22-gauge, 330 feet max 2-conductor, 18-gauge, 830 feet max (based on 10-ohms max loop resistance plus a 2k-ohm, end-of-line resistor)

Mounting the Panel

Use the following procedure to mount the panel to the wall or wall studs.



Make sure you are free of static electricity whenever you work on the panel with the cover open. To discharge any static, first touch the metal panel chassis, then stay in contact with the chassis when touching the circuit board. Using an approved grounding strap is recommended.

Caution

➤ **To mount the panel:**

1. Open the panel door and remove the necessary wiring knockouts (see Figure 2). Be careful not to damage the circuit board.
2. Feed all wires through wiring knockouts and place the panel in position against the wall.
3. Level the panel and mark the top and bottom mounting holes (see Figure 2).
4. Install anchors where studs are not present.
5. Partially insert screws into the two top mounting hole locations, then hang the panel on the two screws.
6. Recheck for level, insert the two lower screws, and tighten all four mounting screws.




Figure 2. Mounting the Panel

Identify Panel Components

Before installing devices and making wiring connections, familiarize yourself with the main panel components. Figure 3 shows the main component locations for the hardwire circuit board and Figure 4 shows the main component locations for the combination hardwire/wireless circuit board.




Figure 3. Hardwire and Combination Hardwire/Wireless Circuit Board Main Components

Installing Antennas

Install the antennas (included with panel) into the inside terminal of each antenna terminal block on the combination hardwire/wireless panel (see Figure 4).




Figure 4. Installing the Antennas

Note

For best results, it is recommended that you crimp a spade lug on the wire end at the panel and secure the lug under the circuit board screw as shown in Figure 5.

Connecting the Panel to Earth Ground

For maximum protection from lightning strikes and transients, connect the lower-left circuit board screw to earth ground as shown in Figure 5. Use 16-gauge, solid copper wire from an earth grounded cold water pipe clamp to the panel.




Figure 5. Connecting the Panel to Earth Ground

Note

The lower header has two jumpers installed from the factory that must be removed before installing the Power Line Carrier Card. Leave these jumpers in place if you are not installing a Power Line Carrier Card.

Installing the Optional Power Line Carrier Card (60-755)

The Power Line Carrier card lets you add Supervised Wireless Sirens for alarm and status sounds and X-10 Lamp Modules for controlling lights.

Install the card on the header pins as shown in Figure 6. No wiring or programming is necessary.




Figure 6. Installing the Power Line Carrier Card

Installing the Optional Phone Supervision Card (60-789)

The Phone Supervision Card allows the panel to check the phone line voltage (partition 1 only), upon dialing the central station/pager number. The panel can also be programmed to check the phone line voltage automatically (see “Line Fail Delay”)

Install the card on the header pins as shown in Figure 7.




Figure 7. Installing the Phone Supervision Card

Installing Optional SnapCards

The SnapCard Header on the right side of the panel allows for the installation of one SnapCard. Install the desired SnapCard onto the panel SnapCard Header and secure it in place with two screws, included with the card (see Figure 8).

Connect all necessary input/output wiring using the *Installation Instructions* included with the card.




Figure 8. Installing a SnapCard into the Panel Expansion Connector

Note

The panel comes with factory programmed onboard hardwire zones. Install 2k-ohm, end of line (EOL) resistors on all unused factory programmed onboard hardwire zones. If you don't want to install EOL resistors, delete any unused zones from memory. See Table 8 for onboard hardwire zone factory programming.

Connecting Detection Devices to Panel Zone Inputs

Zone inputs 1 through 8 are supervised using included 2k-ohm, end-of-line resistors at the last device on each circuit. All eight zones accept either normally open (N/O) or normally closed (N/C) detection devices.

Connecting Intrusion Detection Devices

Figure 9 shows the typical wiring for N/C and N/O door/window intrusion detection.

Figure 10 shows the typical wiring for a Detection Systems model DS922 (part no. 13-082) motion detector. The minimum available panel voltage for hardwired PIR motion detectors is 8.5 VDC (9.5 VDC for UL listed installations).

Note

When using 2-wire smoke detectors on zone 8, the Two-Wire Smoke setting (in program mode) must be turned on **before** entering the LEARN SENSORS menu. See ONBOARD OPTIONS—INPUTS in the section "Programming the Panel" for complete details.




Figure 9. Connecting N/C and N/O Intrusion Detection Circuits to the Panel




Figure 10. Connecting a Motion Detector to the Panel

Connecting 2-Wire Smoke Detectors

Zone input 8 can be set up (in program mode) to accept the following 12 VDC, 2-wire smoke detectors:

- System Sensor models 2100D, 2100TD, 2100S, 2100TS, 2400, 2400TH
- ESL models 429AT, 521B, 521BXT—(models 521B and 521BXT require the following dip switch settings: 1-on, 2-off)



Caution

Use only the 2-wire smoke detector models described above. Alarm signals from other detectors may not be processed correctly if the panel has lost AC power and is operating only from the backup battery.

When set up for 2-wire smoke detectors, zone 8 can handle up to 10 smoke detectors with 120 uA maximum idle current per detector. Maximum total loop current allowed in an alarm condition is 100 mA. Connect one or more, 2-wire smoke detectors to the panel as shown in Figure 11.

Note

The Two-Wire Smoke setting (in program mode) must be off when using 4-wire smoke detectors. See ONBOARD OPTIONS—INPUTS in the section “Programming the Panel” for complete details.




Figure 11. Connecting 2-Wire Smoke Detectors to the Panel




Figure 12. Connecting 4-Wire Smoke Detectors to Panel Power and Zone 8 Input

Connecting 4-Wire Smoke Detectors

Zone input 8 can be used with 4-wire smoke detectors that latch and remain in the alarm state until power is removed, then restored to the detector. The panel provides this power interruption from terminal 23 (2-wire smoke power +), provided that zone 8 is learned into sensor group 26 (fire).

Note

Zone 8 must be learned into sensor group 26 (fire) for connected smoke detectors to reset after canceling a fire alarm.

Table 5 describes the minimum available panel power. Use only 4-wire smoke detectors that operate at these power limits. Connect up to five Sentrol (ESL) model 449AT (part no. 13-360) smoke detectors to panel power and zone 8 input as shown in Figure 12.

Table 5: Panel Minimum Available Power

Min. Voltage/Max. Current Available
8.3 VDC, up to 30 mA total (combined alarm) current
8.1 VDC, up to 40 mA total (combined alarm) current
7.7 VDC, up to 60 mA total (combined alarm) current
7.4 VDC, up to 80 mA total (combined alarm) current

Connecting Speakers

The panel provides one siren driver output for intrusion (steady), fire (temporal 3), and auxiliary (on-off-on-off) alarm sounds. This output trips only for partition 1 alarms.

The output can drive a single 8-ohm speaker or multiple speaker circuit of 8-ohms or higher (as shown in the following speaker wiring diagrams). Compatible speakers are described under “Connecting Piezo Sirens”.



Caution

To avoid disabling the panel speaker output, do not make speaker connections with the panel powered up.

15-Watt Speaker (13-060)

For exterior siren applications. Connect the speaker to the panel as shown in Figure 13.

Hardwire Interior Speaker (60-528)

For interior siren applications. Connect the speaker to the panel as shown in Figure 14.



Caution

Connect only the large speaker to the panel terminals 7 and 8 as shown. The smaller speaker cannot handle to output of terminals 7 and 8. To avoid damaging the speaker, the smaller speaker should not be connected to terminals 7 and 8.

Connect two units to the panel terminals with speakers in series (16-ohms), as shown in Figure 15.




Figure 13. Connecting Speakers to the Panel




Figure 14. Connecting the Hardwire Interior Speaker with Dual Speakers to the Panel




Figure 15. Connecting Two Hardwire Interior Speakers w/Dual Speaker Units to Panel Terminals

Connecting Piezo Sirens

Output 1

Onboard output 1 (OUT 1—terminal 9) is an open-collector (switched path-to-ground), programmable output that can handle a maximum of 200 mA current sink. The default setting (01614) activates the output 15 seconds after a police or fire alarm condition occurs. This allows you to connect a piezo siren without changing the output configuration number in programming. This output is typically used for exterior siren application.

Output 2

Onboard output 2 (OUT 2—terminal 10) is an open-collector (switched path-to-ground), programmable output that can handle a maximum of 200 mA current sink. The default setting (01710) activates the output for status and alarm tones, allowing for a piezo siren connection without changing the output configuration number. It is typically used for interior siren application.

For more information on output configuration numbers, see “Onboard Options Menu”.

Exterior Sirens

Hardwire Exterior Siren (13-046)

Connect the siren to panel as shown in Figure 16.

Interior Sirens

Interior Piezo Siren (30-006)

Connect the piezo siren to the panel terminals with a 2k-ohm resistor, as shown in Figure 17.

Note

Piezo siren connections to terminal 10 require a 2k resistor that can be located at the panel, since it does not supervise the circuit. If using an external power supply instead of panel terminal 4, the supply voltage must be limited to 9.5 VDC maximum and the negative side of the power supply must be connected to panel ground (terminal 3).




Figure 16. Connecting the Hardwire Exterior Siren to the Panel




Figure 17. Connecting an Interior Piezo Siren

Note

The volume switch settings inside the siren do not affect the siren output.

Slim Line Hardwire Interior Siren (60-483-01)

Connect the siren to the panel as shown in Figure 18.




Figure 18. Connecting the Slim Line Hardwire Interior Siren to the Panel

Installing Supervised Wireless Sirens (60-736-95)

Supervised Wireless Sirens (SWS) plug directly into electrical outlets and are not wired to the panel. The panel (when powered by a line carrier power transformer) sends alarm and status messages to the siren, along the building AC wiring.

Note

Power Line Carrier Card must be installed for Supervised Wireless Sirens to work.

For supervised operation, the siren has a built-in transmitter that, when learned into panel memory, transmits to the panel receiver if the siren has a low battery or other trouble condition.

Before plugging in Supervised Wireless Sirens, the panel must be powered up and partition House Codes and the SWS Supervision Code set (in program mode) to the desired settings.

The following procedures describe the basic steps for installing Supervised Wireless Sirens. For complete installation details, refer to the *Supervised Wireless Siren Installation Instructions*, included with each siren.

Note

Regardless of supervised or unsupervised siren installation, you must follow the order of installation as described to avoid learning the wrong (or undesired) House Code and SWS Supervision Code into siren memory.

Note

Hardwire Concord™ panels must have a SuperBus 2000 RF Receiver installed for supervised wireless siren operation.

Note

When installing Supervised Wireless Sirens for supervised operation, be sure to program sensor text that clearly identifies each siren. For example, HALLWAY SIREN or BASEMENT SIREN. This can help both you and your customer locate a specific siren if a problem occurs.

➤ **For unsupervised wireless siren installations:**

1. Power up the panel (see “Powering Up the Panel”).
2. Enter program mode and set the partition House Code to the desired setting (see the *LIGHT CONTROL* menu in the section “Programming the Panel”).
3. Exit program mode.
4. Install the siren backup battery.
5. Plug the siren into an electrical outlet.
6. Press the STATUS button on any working touchpad. The siren should beep once and the siren LED should flash 5 times, indicating it has learned the partition House Code.
7. If the siren doesn’t beep or the LED doesn’t flash, reset the house code on the siren by pressing and holding its button for 20 seconds. The siren will beep three times when the memory has been cleared. Repeat step 6.

➤ **For supervised wireless siren installations:**

1. Power up the panel (see “Powering Up the Panel”).
2. Install the siren backup battery.
3. Clear the siren memory by pressing and holding the siren button for 20 seconds. The siren will beep three times when the memory has been cleared.
4. Enter program mode and set the partition House Code to the desired setting (see the *LIGHT CONTROL* menu in the section “Programming the Panel”).
5. Proceed to the *SIREN OPTIONS* menu and set the SWS Supervision Code to the desired setting.
6. Proceed to the *LEARN SENSORS* menu and select the desired partition, sensor group 33, and the desired sensor number.
7. When the touchpad display shows *TRIP SENSOR nn*, plug the siren into an electrical outlet. The siren should beep once and the siren LED should flash 10 times, indicating the panel learned the siren transmitter ID and that the siren learned both the partition House Code and SWS Supervision Code.
8. Exit program mode.

Connecting an Interrogator 200 Audio Verification Module (60-677)

Connect the Interrogator 200 Audio Verification Module (AVM) to the panel terminals as shown in Figure 19. Partition 1 use only.



Caution

If a speaker is already connected to panel terminals 7 and 8, the Interrogator 200 speaker must be hooked up in series with that speaker to provide a 16-ohm load. Hooking up speakers in parallel to panel terminals 7 and 8 creates a 4-ohm load that can cause permanent damage to the panel.




Figure 19. Connecting an Interrogator 200 AVM to the Panel

Connecting Alphanumeric and Fixed Display Touchpads

Alphanumeric and Fixed Display touchpads use the same color-coded wire scheme. Connect the touchpads to the panel power output and bus terminals as shown in Figure 20.




Figure 20. Connecting Touchpads to the Panel




Figure 21. Support Standoff

Installing SuperBus 2000 Modules

SuperBus 2000 modules can be installed inside the panel cabinet or away from the panel. Use the following guidelines when installing modules inside the panel cabinet:

- Up to 16 bus modules can be connected to the panel. (15 modules for the RF panel since receiver counts as 1.)
- Up to 3 of the SuperBus 2000 modules listed in Table 1 can be mounted inside the cabinet.
- The panel includes two support standoffs you install to secure module backplates to the panel (see Figure 22).
- Install the standoffs at the locations shown in Figure 22.
- The cabinet has built-in mounting clips on the top and sides that module backplates slide onto for mounting (see Figure 22).

Note

Even if you don't plan to mount modules inside the cabinet, install the support standoffs for future use and to avoid losing them.

- One SuperBus 2000 RF Receiver can be installed inside the cabinet, but it must be mounted on the right-hand side to accommodate the antennas (see Figure 22). Additional receivers must be installed outside the cabinet.




Figure 22. Installing the Support Standoffs and Mounting SuperBus 2000 Modules Inside the Cabinet (RF Receiver Shown)

SuperBus 2000 RF Receiver (60-764-01-95R-16Z/32Z/MAX)

1. Mount the receiver inside the cabinet enclosure as shown in Figure 22.
2. Connect the receiver to the panel as shown in Figure 23.

SuperBus 2000 Phone Interface/Voice Module (60-777-01)

The Phone Interface/Voice Module includes two backplates for mounting the module inside the control panel cabinet. The module can also be mounted outside of the control panel using an optional plastic housing (part no. 60-800). Refer to the *SuperBus 2000 Phone Interface/Voice Module Installation Instructions* included with each module, for complete mounting instructions.

The module requires panel power and bus connections, phone line connection through panel terminals and DB-8 cord (from an RJ-31X jack), and speaker connection through panel terminals.

Wiring—Power

Connect the module to the panel power and bus terminals as shown in Figure 24.

Note
In UL Listed installations, the Phone Interface/Voice Module is for supplementary use only.




Figure 23. Connecting the SuperBus 2000 RF Receiver to the Panel Terminals




Figure 24. Connecting the Phone Interface/Voice Module to the Panel Power and Bus Terminals

Wiring—Phone Line

For partition 1, connect the phone line to the module through the panel terminals and DB-8 cord (from an RJ-31X jack) as shown in Figure 25. For partition 2 phone connection, see the SuperBus 2000 Phone Interface/Voice Module Installation Instructions.

Note
For RJ-31X connections, see "Installing an RJ-31X Phone Jack (13-081)." f




Figure 25. Connecting a Phone Line to the Module

Note

To prevent status voice messages from being broadcast outside, do not connect exterior speakers to Phone Interface/Voice module terminals 6 and 7.

Wiring—Speaker (Status Voice Messages Only)

Connect an interior speaker to the Phone Interface/Voice module terminals as shown in Figure 26. When connected as shown, the speaker only produces status voice messages. In an alarm situation the speaker will announce voice status messages.

Wiring—Speaker (Status and Alarm Messages)

Make the following connection only if the Phone Interface/Voice module is being installed in Partition 1 and alarm sounds are desired from the speaker connected to the terminals as shown in Figure 27. In an alarm situation, the speaker will alternate between alarm siren tones and voice status messages.




Figure 26. Status Messages Only




Figure 27. Status and Alarm Messages

SuperBus 2000 Energy Saver Module (60-620-01)

Connect the Energy Saver Module to the panel and premises thermostat as shown in Figure 28.




Figure 28. Connecting the Energy Saver Module

SuperBus 2000 8Z Input Module (60-774)

Connect the SuperBus 2000 8Z Input Module to the panel as shown in Figure 29.

Connect all necessary input wiring using the *Installation Instructions* included with module.

SuperBus 2000 4-Relay Output Module (60-770)

Connect the SuperBus 2000 4-Relay Output Module to the panel as shown in Figure 30.

Connect all necessary output wiring using the *Installation Instructions* included with the module.




Figure 29. Connecting the 8Z Input Module to the Panel




Figure 30. Connecting the 4-Relay Output Module to the Panel

SuperBus 2000 Cellular Backup Module

Connect the SuperBus 2000 Cellular Backup Module to the panel as shown in Figure 31.




Figure 31. Connecting the Cellular Backup Module to the Panel

SuperBus 2000 Automation Module (60-783-02)

Connect the SuperBus 2000 Automation Module to the panel as shown in Figure 32.




Figure 32. Connecting the SuperBus to the Panel

SuperBus 2000 Wireless Gateway Module (60-861)

Connect the SuperBus 2000 Wireless Gateway Module to the panel as shown in Figure 33.




Figure 33. Connecting the Wireless Gateway Module to the Panel

Setting Device Address on SuperBus 2000 Devices

When the panel is powered up it automatically assigns device addresses and unit numbers to SuperBus 2000 devices, enabling the panel and module to communicate.

Installing an RJ-31X Phone Jack (13-081)

Use the following guidelines when installing an RJ-31X phone jack for system control by phone and central station monitoring.

- Locate the RJ-31X jack (CA-38A in Canada) no further than five feet from the panel.
- The panel must be connected to a standard analog (loop-start) phone line, that provides 48 volts DC (on-hook or idle) which increases to 89 to 105 volts DC (ring voltage).
- For full line seizure, install an RJ-31X phone jack on the premises phone line so the panel is ahead of all phones and other devices on the line. This allows the panel to take control of the phone line when an alarm occurs, even if the phone is in use or off-hook.
- If an analog line is not available, contact a telecommunications specialist and request an analog line off the phone switch (PBX mainframe) or a 1FB (standard business line).

➤ To connect a phone line to the panel using an RJ-31X/CA-38A jack:

1. Run a 4-conductor cable from the TELCO protector block to the jack location (see A in Figure 34).
2. Connect one end of the cable to the jack (see B in Figure 34).
3. At the TELCO protector block, remove the premises phone lines from the block and splice them to the black and white (or yellow) wires of the 4-conductor cable (see C in Figure 34).
4. Connect the green and red wires from the 4-conductor cable to the TIP (+) and RING (-) posts on the block (see D in Figure 34).
5. Check the phones on the premises for dial tone and the ability to dial out and make phone calls. If phones do not work correctly, check all wiring and correct where necessary. Proceed to the “Troubleshooting” section of this manual if problems persist.

Connecting the Phone Line to the Panel with a DB-8 Cord

After installing the RJ-31X jack, you are ready to connect the phone line to the panel. A DB-8 cord (not included) uses a plug at one end for connecting to the RJ-31X module and flying leads on the other end for panel terminal connections.

➤ To connect the DB-8 cord to the panel terminals and RJ-31X jack:

1. Connect the green, brown, gray, and red flying leads from the DB-8 cord to panel terminals 24, 25, 26, and 27 (see Figure 35).
2. Insert the DB-8 cord’s plug into the RJ-31X (see Figure 35).
3. Check the phones on the premises for dial tone and the ability to dial out and make phone calls. If phones do not work correctly, check all wiring and correct where necessary. Proceed to the “Troubleshooting” section of this manual if problems persist.




Figure 34. Installing an RJ-31X Phone Jack




Figure 35. Connecting the DB-8 Cord to the Panel Terminals and RJ-31X Jack

Note

The panel cannot be used on a digital or PBX phone line. These systems are designed for digital type devices only, operating anywhere from 5 volts DC and up. The panel uses an analog modem and does not have a digital converter, adapter, or interface to operate through such systems.

Note

Connecting the panel to an analog line off the phone switch places the panel ahead of the phone system, preventing panel access from phones on the premises. However, the panel can still be accessed from off-site phones.

Connecting the AC Power Transformer

The panel must be powered by a plug-in stepdown transformer that supplies 24 VAC, 30 VA (60-761) or 24 VAC, 50 VA (60-778).

For systems that include a Power Line Carrier card and Supervised Wireless Sirens, or X-10 Lamp Modules, the panel must be powered with the Line Carrier Power Transformer that supplies 24 VAC, 30 VA (60-762) or 24 VAC, 50 VA (60-779). Connect the power transformer to the panel as shown in Figure 36.



Caution

Do not plug in the power transformer at this time. The panel must be powered up using the sequence of steps described in the next section, “Powering Up the Panel.”




Figure 36. Connecting a Power Transformer to the Panel Terminals




Figure 37. Connecting the Backup Battery to the Panel

Powering Up the Panel

After connecting and wiring all devices to the panel, you are ready to apply AC and backup battery power to the panel.

➤ To power up the panel:

1. Connect the red and black battery leads (included with panel) to the lugs located on the panel (see Figure 37).
2. Connect the other ends of the battery leads to the battery terminals (see Figure 37).
3. Plug the transformer into an outlet that is not controlled by a switch. Alphanumeric touchpads display *********, then *SCANNING BUS DEVICES*, and finally a date and time display.
4. To permanently mount the transformer, unplug it and remove the existing screw securing the AC outlet cover.

Note

If alphanumeric touchpads don't display anything, immediately unplug the transformer and disconnect the backup battery. Refer to the “Troubleshooting” section.



Warning

Use extreme caution when securing the transformer to a metal outlet cover. You could receive a serious shock if a metal outlet cover drops down onto the prongs of the plug while you are securing the transformer and cover to the outlet box.

5. Hold the outlet cover in place and plug the transformer into the lower receptacle.
6. Use the screw supplied with the transformer to secure the transformer to the outlet cover.

Programming the Panel

For on-site system programming, an alphanumeric touchpad is required.

Entering Program Mode

Entering program mode is done using an installer/dealer code (default = 4321). The system can be put into program mode only when the system is disarmed.

Note

If the system is powered up after the programming touchpad is connected or if a bus command scan is executed, the programming touchpad will be "learned" into the system and must later be manually deleted.

➤ **To enter program mode:**

1. Make sure the system is disarmed in all partitions.
2. Press 8 + 4321 + 0 + 0. The display shows *SYSTEM PROGRAMMING*.

➤ **To enter programming mode using a programming touchpad:**

1. Connect the red, black, green, and white wires from the Programming Touchpad Cable (60-791) to the power and bus wires on an alphanumeric touchpad, matching the wire colors on each.
2. Make sure the system is powered up and disarmed.
3. Connect the plug on the cable onto the panel programming touchpad header (see Figure 38).
4. Press 8 + 4321 + 0 + 2. The touchpad sounds one short beep. Press * and verify that the display shows *SERVICE TOUCHPAD ACTIVE*.
5. Press 8 + 4321 + 0 + 0 and the display shows *SYSTEM PROGRAMMING*.
6. After programming is completed, simply disconnect the touchpad from the panel header.




Figure 38. Connecting a Programming Touchpad

Touchpad Button Programming Functions

In program mode, touchpad buttons let you navigate to all installer programming menus for configuring the system. Table 6 describes the touchpad button functions in program mode.

Table 6: Touchpad Button Functions

Button	Programming Function
#	Selects menu item or data entry.
*	Deselects menu item or data entry (if pressed before #).
A & B	Scroll through available options at the current menu tier. Also scroll through sensor text options during sensor text programming.
C	Enters pauses when programming phone numbers.
D	Deletes certain programmed settings.
0 thru 9	Enter numeric values wherever needed.
1 & 2	Select off (1) or on (2) wherever needed.
1 thru 6	Press and hold to enter alphabetical characters A thru F for account numbers.
7 & 9	Press and hold to enter * (7) or # (9) for phone numbers.

Moving Through Program Mode Tiers and Menus

There are two basic tiers of programming menus. Tier 1 menus are accessible immediately after entering program mode (see Figure 39).




Figure 39. Tier 1 Program Menus

Arrows pointing right represent pressing B to advance forward through the menus. Pressing A moves through the menus in reverse.

The arrow below the *SYSTEM PROGRAMMING* menu represents pressing # to advance to tier 2 programming menus. Only when *SYSTEM PROGRAMMING* is displayed can you advance to tier 2 menus (see Figure 40).




Figure 40. Tier 2 Program Menus

Again, arrows pointing right represent pressing B to advance forward through the menus. Pressing A moves through the menus in reverse.

Arrows below each menu represent pressing # to advance to those settings that pertain to that menu. Only when a specific menu is displayed can you advance to those settings. For example, from the *SENSORS* menu pressing # gives you access to learning sensors, programming sensor text, deleting sensors, and viewing/editing sensor programming. Settings in tier 2 menu can also be accessed by entering shortcut numbers. See the section, “Programming Tier 2 Menu Items” for complete details.

Programming Tier 1 Menu Items

This section guides you through programming tier 1 menu items as they appear in sequence. The exact order you follow will depend on whether you’re installing a new system or changing programming in an existing system.

Demo Kit Mode (System Programming)

(Default = off) This setting determines whether the panel is used for a standard installation (off) or as a demo kit (on). When the Demo Kit option is on, only sensors learned into groups 01 and 03, duress code use, and phone test (8 + System Master Code + 2) will be reported. Turning on this feature and performing a memory clear changes the following settings:

- Partition 1 Master Code = 1000
- Partition 2 Master Code = 2000
- User Code 00 = 1001 (partition 1 code—can also be used to jump to partition 2)
- User Code 01 = 1002 (partition 1 code—can also be used to bypass sensors)
- User Code 02 = 2001 (partition 2 code—can also be used for remote or off-site access)
- User Code 03 = 2002 (partition 2 code—can also be used to perform system tests)

- User Code 04 = 1122 (partition 1 code—can also be used to jump to partition 2, for remote or off-site access, and system tests)
- User Code 05 = 1122 (partition 2 code—can also be used to jump to partition 1, for remote or off-site access, bypassing sensors, and system tests)
- Partition 1 House Code = 255 (P)
- Partition 2 House Code = 254 (O)
- Zone 1 (hardwire input 1) = Group 10, Front Door
- Zone 2 (hardwire input 2) = Group 13, Bedroom Window
- Zone 3 (hardwire input 3) = Group 17, Living Room Motion Sensor
- Zone 4 (hardwire input 4) = Group 1, Panic
- Zone 5 (wireless, keychain touchpad, ID F00201) = Group 01, (no text)
- Zone 6 (wireless, DWS, ID A00206) = Group 13, Kitchen Window
- COMM FAILURE = off Demo Kit = on
- AVM code = 1212
- Entry Delay = 8 sec
- Exit Delay = 8 sec
- Extended Delay = 1 minute
- Siren Timeout = 2 minutes

➤ **To turn Demo Kit Mode off or on:**

1. With the display showing *DEMO KIT MODE OFF/ON (current setting)*, press 1 (off) or 2 (on), then press #.
2. The display flashes the entered setting, then stops after pressing # and displays *DEMO KIT MODE OFF/ON (new setting)*.

Partition 1 Copy (System Programming)

(Default = none) After programming all settings pertaining to partition 1, you can make an exact copy to use for partition 2. This helps reduce programming time when the system is set up for two partitions. If there are certain settings that are unique to partition 2, simply advance to the appropriate menu and make the necessary changes.

➤ **To Copy Partition 1:**

- ◆ With the display showing *PARTITION 1 COPY*, press # + installer CODE + #. The display flashes, then stops after pressing # and shows *DONE*.

Clear Memory (System Programming)

Clearing memory deletes all existing programming information (except the Dealer Code).

➤ **To Clear Panel Memory:**

1. With the system in program mode, press A or B until the display shows *CLEAR MEMORY*.
2. Press # and the display shows *ENTER CODE TO CLEAR MEMORY*.
3. Enter the 4-digit installer or dealer code (if programmed) + #. After about five seconds, the system restarts and the panel scans the bus to learn all bus devices.

If the system doesn't respond as described, repeat step 3.

Programming Tier 2 Menu Items

This section guides you through programming tier 2 menu items as they appear in sequence. Figure 39 shows the menus available on tier 2.

Each menu on tier 2 represents a group of settings related to the menu name. Some tier 2 menus break down into settings that affect the whole system (global) or a specific partition.

Using Shortcut Numbers

To go directly to a setting in tier 2, you can enter the shortcut number for that setting. Shortcut numbers in this manual appear in parenthesis (), under the setting name (see Figure 41).

Note
Clearing the memory will erase onboard hardwire zone factory programming.




Figure 41. Menu Item Heading

Shortcut numbers can be used from any setting location within tier 2.

- **To advance to tier 2 program menus:**
 - ◆ With the system in program mode and the display showing *SYSTEM PROGRAMMING*, press # once. The display should show *SECURITY*.

Security Menu

The *SECURITY* menu lets you choose whether security settings affect the whole system (global) or a specific partition.

- **To access global or partition security menu items:**
 1. With the display showing *SECURITY*, press #. The display should show *GLOBAL*.
 2. Press # again to advance to global settings, or press A or B to display *PARTITION n*, then press # to advance to selected partition 1 or 2 settings.

The following describes how to program the security settings that appear under *GLOBAL*.

Downloader Code (Security-Global) (0000)

(Default = 12345) The 5-digit downloader code is used in conjunction with downloader programming. The downloader operator must have the panel account number and downloader code in order to perform any programming.

- **To program a Downloader Code:**
 - ◆ With the display showing *DOWNLOADER CODE nnnnn (current code)*, enter the desired 5-digit code. The display flashes the entered code. Press # and the display shows the new code.

Installer Code (Security-Global) (0001)

(Default = 4321) The 4-digit installer code is used for entering program mode and changing system settings. If a dealer code is programmed, only those settings not associated with phone numbers can be changed.

- **To program an Installer Code:**
 - ◆ With the display showing *INSTALLER CODE nnnn (current code)*, enter the desired 4-digit code. The display flashes the entered code. Press # and the display shows the new code.

Dealer Code (Security-Global) (0002)

(Default = none) The 4-digit dealer code is used to prevent unauthorized persons from changing the programmed central station phone numbers. When this feature is enabled, central station phone numbers cannot be changed (unless you enter the program mode by using the dealer code). All *other* system settings are still accessible by entering the program mode with the installer code.

- **To program a Dealer Code:**
 - ◆ With the display showing *DEALER CODE *****, enter the desired 4-digit code. The display flashes the entered code. Press # and the display shows the new code.
- **To delete a Dealer Code:**
 - ◆ With the display showing *DEALER CODE nnnn (current code)*, press D. The display shows *DEALER CODE *****.

Access Code Lock (Security—Global) (0003)

(Default = on) This setting determines whether or not the panel will include Access Codes when sending user information to the automation module. When this option is on, it means the Access Codes are not sent.

Note
The Downloader Code cannot be deleted or cleared from panel memory. To change the Downloader Code to its default setting, enter 12345.

Note
The Installer Code cannot be deleted or cleared from panel memory. To change the Installer Code to its default setting, enter 4321.

Note
The Dealer Code cannot be deleted by clearing panel memory.

- **To turn Access Code Lock off or on:**
- ◆ With the display showing *ACCESS CODE LOCK ON/OFF*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

The following sections describe the security settings that appear under *PARTITION 1* and *2*.

Account Number (Security—Partition 1-2)
(*partition 1: 0010, partition 2: 0020*)

(Default = 00000) The account number is used as panel (or customer) identification for the central monitoring station. The panel sends the account number every time it reports to the central station. Account numbers must be 1 to 10 characters long.

Alpha characters A–F can be assigned to the account number by pressing and holding buttons 1–6 respectively, until the character appears.

- **To program an Account Number:**
- ◆ With the display showing *ACCOUNT NUMBER nnnnn (current number)*, enter the desired account number. The display flashes the entered number. Press # and the display shows the new number.

Quick Arm (Security—Partition 1-2)
(*partition 1: 0011, partition 2: 0021*)

(Default = off) Quick Arm allows system arming without using an access code. When Quick Arm is on, the system arming level can be increased from Level 1-OFF to LEVEL 2-STAY, from Level 1-OFF to LEVEL 3-AWAY, or from Level 2-STAY to LEVEL 3-AWAY, without entering an access code.

A valid access code is still required to decrease the arming level or disarm the system.

- **To turn Quick Arm off or on:**
- ◆ With the display showing *QUICK ARM OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Quick Exit (Security—Partition 1-2)
(*partition 1: 0012, partition 2: 0022*)

(Default = on) This setting determines whether or not users can open and close a standard entry/exit door without causing an alarm (while the system is armed).

This feature would be useful if the user wants to go out to get the morning paper while the system is armed. This feature also allows the user to leave the armed premises without having to disarm and re-arm the system.

When Quick Exit is on, pressing D on a touchpad (while the system is armed) starts a 2-minute timer that allows one standard entry/exit door (sensor groups 10 and 19 only) to be activated once (opened, then closed).

When this feature is turned off, the system must be disarmed before any protected door is opened.

- **To turn Quick Exit off or on:**
- ◆ With the display showing *QUICK EXIT OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Exit Extension (Security—Partition 1-2)
(*partition 1: 0013, partition 2: 0023*)

(Default = on) This setting determines whether or not the user can re-enter and exit again through an entry or exit delay door (without disarming and re-arming the system). This helps prevent exit faults and false alarms by allowing users to re-enter the premises for a forgotten item.

When Exit Extension is on, the panel restarts the exit delay timer if the user re-enters the premises through a standard delay door before the standard exit delay time expires.

When this feature is off, the exit delay timer does not restart if the user re-enters the premises, forcing the user to disarm the system to avoid setting off an accidental alarm.

- **To turn Exit Extension off or on:**
- ◆ With the display showing *EXIT EXTENSION OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Note
For UL Listed installations, this feature must be set to off.

**Auto Stay Arming (Security—Partition 1-2)
(partition 1: 0014, partition 2: 0024)**

(Default = on) This setting determines whether or not the system automatically arms to STAY (level 2) if the user arms the system to AWAY (level 3) without exiting the premises. This can help prevent accidental alarms by deactivating interior motion sensors during occupied arming periods.

When this feature is on and the system is armed to AWAY, touchpads (and other status sounders) emit one exit delay beep every four seconds, then one every second during the last 10 seconds. If the exit delay time expires with no standard delay sensor activation, the system automatically arms to STAY.

➤ **To turn Auto Stay Arming off or on:**

- ◆ With the display showing *AUTO STAY ARMING OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

**Keyswitch Sensor (Security—Partition 1-2)
(partition 1: 0015, partition 2: 0025)**

(Default= none) This feature lets users arm and disarm the system using either a keyswitch wired to a hardwire zone input or a wireless door/window sensor.

For example, if sensor 1 is designated as the keyswitch sensor and the system is disarmed, then tripping sensor 1 could arm the system to AWAY. If the system is armed to STAY or AWAY, then tripping the sensor could disarm the system (depending on keyswitch style).

The panel reports opening, closing, and force armed reports (if turned on) to the central monitoring station.

➤ **To assign a Keyswitch Sensor:**

- ◆ With the display showing *KEYSWITCH SENSOR m (current sensor number)*, enter the desired sensor number (01–76). The display flashes the entered sensor number. Press # and the display shows the new number.

➤ **To delete a Keyswitch Sensor:**

- ◆ With the display showing *KEYSWITCH SENSOR m (current sensor number)*, press D to erase the keyswitch sensor attribute.

**Keyswitch Style (Security—Partition 1-2)
(partition 1: 0016, partition 2: 0026)**

(Default = transition) This feature allows users to select how they want the system to behave when armed/disarmed by a keyswitch sensor. The choices are as follows:

Transition: If keyswitch style is set to transition and the keyswitch sensor is tripped (opened) when the system is disarmed (level 1), the panel will automatically arm to AWAY (level 3). If the sensor is tripped (opened) when the system is armed to AWAY (level 3) or STAY (level 2), the panel will automatically disarm.

State: If keyswitch style is set to state, when the keyswitch sensor is tripped (opened) the panel arms to AWAY (level 3). If the sensor is restored (closed) the panel disarms.

Opening, closing, and force arming reports (if turned on) are reported to the central station for both keyswitch styles.

➤ **To assign a Keyswitch Style:**

- ◆ With the display showing *KEYSWITCH STYLE TRANSITION/STATE (current setting)*, press 1 for Transition or 2 for State. The display flashes the entered setting. Press # and the display shows the new setting.

**Duress Code (Security—Partition 1-2)
(partition 1: 0017, partition 2: 0027)**

(Default = none) The duress code is a unique 4-digit access code that allows users to operate the system and, at the same time, instructs the panel to send a silent alarm report to the central station.

Do not use a duress code unless it is absolutely necessary. Using duress codes often results in false alarms due to code entry errors. If a duress code is absolutely necessary, use it with an audio verification module (AVM) to reduce false alarms and accidental dispatches.

Note

Arming the system to "AWAY with No Delay" overrides the Auto Stay Arming feature.

Note

It is recommended that keyswitch sensors are learned into group 28.

Note

A bypassed keyswitch sensor cannot arm or disarm the system.

During an audible alarm, keyswitch sensors can disarm the system (which sends a cancel report to the central monitoring station), but cannot arm the system. The system can be armed only after the siren timeout expires.

Keyswitch sensors test the same as any other sensor and do not arm or disarm the system during a sensor test.

Note

To use this feature, the *Duress Option* setting under the reporting—partition 1 (2) menu must be turned on.

- **To program a Duress Code:**
 - ◆ With the display showing *DURESS CODE *****, enter the desired 4-digit duress code. The display flashes the entered setting. Press # and the display shows the new code.
- **To delete a Duress Code:**
 - ◆ With the display showing *DURESS CODE nnnn (current code)*, press D. The display shows *DURESS CODE *****.

Phones Menu

The *PHONES* menu lets you set up central station reporting for the system. The following describes how to program the settings that appear under *CS PHONE 1-3*.

**Phone Number (Phones—CS Phone 1-3)
(cs phone 1: 0100, cs phone 2: 0110, cs phone 3: 0120)**

(Default = none) This setting is used for programming the central station receiver phone number. Phone numbers can be 1 to 24 digits long, including pauses or * and # characters.

To enter pauses, press C.

To enter *, press and hold 7 for about two seconds.

To enter #, press and hold 9 for about two seconds.

- **To program a Central Station Phone Number:**
 - ◆ With the display showing *PHONE NUMBER _ (or current number)*, enter the desired phone number. The display flashes the entered number. Press # and the display shows the new number.
- **To delete a Central Station Phone Number:**
 - ◆ With the display showing *PHONE NUMBER (current number)*, press D. The display shows *PHONE NUMBER _*.

**High Level Rpts (Phones—CS Phone 1-3)
(cs phone 1: 0101, cs phone 2: 0111, cs phone 3: 0121)**

(Defaults: CS Phone 1 = on, CS Phone 2 and 3 = off) When this setting is on, the following conditions report to the central station:

- Fire, Police, Auxiliary, and Duress alarms
 - No Activity
 - Receiver Failure (or jam)
 - Tamper conditions, including Zone Tamper and System Tamper (40 incorrect key presses or touchpad supervisory)
 - Entering or exiting Sensor Test mode
 - Phone Test
- **To turn High-Level Reports off or on:**
 - ◆ With the display showing *HIGH LEVEL RPTS OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

**Low Level Rpts (Phones—CS Phone 1-3)
(cs phone 1: 0102, cs phone 2: 0112, cs phone 3: 0122)**

(Defaults: CS Phone 1 = on, CS Phone 2 and 3 = off) When this setting is on, the following non-alarm conditions report to the central station:

- Force Armed
 - Hardwire Zone Trouble (open or short)
 - Supervisory (wireless devices)
 - Low Battery (wireless devices)
 - Phone Test
 - Other non-alarm related conditions
- **To turn Low-Level Reports off or on:**
 - ◆ With the display showing *LOW LEVEL RPTS OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Note

The *PHONE NUMBER* menus are not accessible if a Dealer Code is programmed and the Installer Code is used to enter installer programming mode. To access these menus when a Dealer Code is programmed, you must enter installer programming mode using the Dealer Code.

Call-waiting services should be disabled to prevent interrupting panel communication to the central monitoring station. To program a dialing prefix that disables call-waiting, see the *Call Wait Cancel* setting under the menu *PHONE OPTIONS—GLOBAL*.

Exception Rpts (Phones—CS Phone 1-3)
(cs phone 1: 0103, cs phone 2: 0113, cs phone 3: 0123)

(Default = off) When this setting is on, the panel reports to the central station if the system is not armed or disarmed at the specified schedule times.

➤ **To turn Exception Reports off or on:**

- ◆ With the display showing *EXCEPTION RPTS OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Open/Close Rpts (Phones—CS Phone 1-3)
(cs phone 1: 0104, cs phone 2: 0114, cs phone 3: 0124)

(Default = off) This setting determines whether opening and closing reports are sent to the central station. When turned on, the panel sends a closing report when the system is armed and an opening report when the system is disarmed.

➤ **To turn Opening/Closing Reports off or on:**

- ◆ With the display showing *OPEN/CLOSE RPTS OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Backup (Phones—CS Phone 1-3)
(cs phone 1: 0105, cs phone 2: 0115, cs phone 3: 0125)

(Defaults: CS Phone 1 = on, CS Phone 2 and 3 = off) This setting determines whether or not the panel uses another programmed central station phone number for reporting if attempts with the first number are unsuccessful.

When Back Up is off, the panel will make up to eight attempts to deliver a report with the programmed phone number.

When Back Up is set to on, the panel makes up to 16 attempts to deliver the report, alternating between the programmed phone number and the backup phone number.

CS PHONE 1 is backed up by CS PHONE 2.
CS PHONE 2 is backed up by CS PHONE 1.
CS PHONE 3 is backed up by CS PHONE 1.

➤ **To turn Backup off or on:**

- ◆ With the display showing *BACK UP OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

SIA/CID Reporting (Phones—CS Phone 1-3)
(cs phone 1: 0106, cs phone 2: 0116, cs phone 3: 0126)

(Default = CID) This setting determines whether the panel uses the SIA or CID (Contact ID) reporting format for central station communication.

➤ **To select SIA or CID reporting:**

- ◆ With the display showing *REPORTING FORMAT SIA/CID (current setting)*, press 1 (for SIA) or 2 (for CID). The display flashes the entered setting. Press # and the display shows the new setting.

Cellular Backup (Phones—CS Phone 1-3)
(cs phone 1: 0107, cs phone 2: 0117, cs phone 3: 0127)

(Defaults: CS Phone 1=on, CS Phone 2 and 3=off) This setting determines whether the panel uses cellular communication for reporting if attempts using a landline are unsuccessful.

➤ **To turn Cellular Backup off or on:**

- ◆ With the display showing *CELLULAR BACKUP*, press 1 (for off) or 2 (for on). The display flashes the entered setting. Press # and the display shows the new setting.

The following describes how to program the phone settings that appear under *PAGER PHONE 1-5*.

Phone Number (Phones—Pager Phone 1-5)
(pager 1: 0130, pager 2: 0140, pager 3: 0150, pager 4: 0160, pager 5: 0170)

(Default = none) This setting is used for programming a phone number that communicates to a pager. Phone numbers can be 1 to 24 digits long and include pauses, a skylink number, and 7-digit PIN number.

Note

To use this feature, the Opening Reports and Closing Reports settings under the REPORTING menu must be turned on for that partition.

Note

Call-waiting services should be disabled to prevent interrupting panel communication to the pager(s). To program a dialing prefix that disables call-waiting, see the Call Wait Cancel setting under the menu PHONE OPTIONS—GLOBAL.

To enter pauses, press C.

To enter *, press and hold 7 for about two seconds.

To enter #, press and hold 9 for about two seconds.

➤ **To program a Pager Phone Number:**

- ◆ With the display showing *PHONE NUMBER _ (or current number)*, enter the desired pager phone number. The display flashes the entered number. Press # and the display shows the new setting.

➤ **To delete a Pager Phone Number:**

- ◆ With the display showing *PHONE NUMBER (current number)*, press D. The display shows *PHONE NUMBER _*.

High Level Rpts (Phones—Pager Phone 1-5)

(pager 1: 0131, pager 2: 0141, pager 3: 0151, pager 4: 0161, pager 5: 0171)

(Default = on) This setting determines whether the following alarm conditions report to a pager:

- Fire, Police, Auxiliary, and Duress alarms
- No Activity
- Receiver Failure (or jam)
- Tamper conditions, including Zone Tamper and System Tamper (40 incorrect key presses or touchpad supervisory)
- Entering or exiting Sensor Test mode
- Phone Test

➤ **To turn High-Level Reports off or on:**

- ◆ With the display showing *HIGH LEVEL RPTS OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Low Level Rpts (Phones—Pager Phone 1-5)

(pager 1: 0132, pager 2: 0142, pager 3: 0152, pager 4: 0162, pager 5: 0172)

(Default = off) This setting determines whether the following non-alarm conditions report to a pager:

- Force Armed
- Hardwire Zone Trouble (open or short)
- Supervisory (wireless devices)
- Low Battery (wireless devices)
- Phone Test
- Other non-alarm related conditions

➤ **To turn Low-Level Reports off or on:**

- ◆ With the display showing *LOW LEVEL RPTS OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Exception Rpts (Phones—Pager Phone 1-5)

(pager 1: 0133, pager 2: 0143, pager 3: 0153, pager 4: 0163, pager 5: 0173)

(Default = off) This setting determines whether the panel reports to a pager if the system is not armed or disarmed at the specified schedule times, if open/close reports are turned on.

➤ **To turn Exception Reports off or on:**

- ◆ With the display showing *EXCEPTION RPTS OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Open/Close Rpts (Phones—Pager Phone 1-5)

(pager 1: 0134, pager 2: 0144, pager 3: 0154, pager 4: 0164, pager 5: 0174)

(Default = off) This setting determines whether opening and closing reports are sent to a pager. When turned on, the panel sends a closing report when the system is armed and an opening report when the system is disarmed.

➤ **To turn Opening/Closing Reports off or on:**

- ◆ With the display showing *OPEN/CLOSE RPTS OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Note

To use this feature, the opening reports and closing reports settings under the REPORTING menu must be turned on for that partition.

Latchkey Reports (Phones—Pager Phone 1-5)
(**pager 1: 0135, pager 2: 0145, pager 3: 0155, pager 4: 0165, pager 5: 0175**)

(Default = on) This setting determines whether the panel reports to a pager when the system is armed or disarmed, according to latchkey time scheduling.

➤ **To turn Latchkey reports off or on:**

- ◆ With the display showing *LATCHKEY RPTS OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Streamlining (Phones—Pager Phone 1-5)
(**pager 1: 0136, pager 2: 0146, pager 3: 0156, pager 4: 0166, pager 5: 0176**)

(Default = on) This setting determines whether the panel includes (off) or excludes (on) the account number when reporting to a pager.

➤ **To turn Streamlining off or on:**

- ◆ With the display showing *STREAMLINING OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Ptn Assignment (Phones—Pager Phone 1-5)
(**pager 1: 0137, pager 2: 0147, pager 3: 0157, pager 4: 0167, pager 5: 0177**)

(Default = 1) This setting determines the partition that reports to a pager. Both partitions can be assigned to report to a single pager.

➤ **To set up Partition Assignments for pager reporting:**

- ◆ With the display showing *PTN ASSIGNMENT 1/2/12 (current setting)*, press 1 or 2 to select partition 1 or 2 (press 1 and 2 to select both partition 1 and 2). The display flashes the entered setting. Press # and the display shows the new setting.

The following describes how to program the phone settings that appear under *DOWNLOADER PHONE*.

Phone Number (Phones—Downloader Phone)
(**0180**)

(Default = none) Use this setting to enter the phone number of an off-site computer that can be used to program the panel through the phone line. Phone numbers can be 1 to 24 digits long, including pauses or * and # characters.

To enter pauses, press C.

To enter *, press and hold 7 for about two seconds.

To enter #, press and hold 9 for about two seconds.

➤ **To program a downloader phone number:**

- ◆ With the display showing *PHONE NUMBER (current number)*, enter the desired phone number. The display flashes the entered number. Press # and the display shows the new setting.

➤ **To delete a downloader phone number:**

- ◆ With the display showing *PHONE NUMBER (current number)*, press D to erase the number. The display shows *PHONE NUMBER_*.

Phone Options Menu

The *PHONE OPTIONS* menu lets you set up system phone access and communications that affect the whole system (global) or a specific partition.

The following describe how to program the phone option settings that appear under *GLOBAL*.

Phone Test (Phone Options—Global)
(**02000**)

(Default = on) This setting determines if the user can, at any time, test the communication from the panel to the central station or a pager by entering 8 + CODE + 2 (# + 8 + CODE + 2 from a touch-tone phone).

➤ **To turn the Phone Test setting off or on:**

- ◆ With the display showing *PHONE TEST OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Note

Call-waiting services should be disabled to prevent interrupting panel communication to the downloader. To program a dialing prefix that disables call-waiting, see the Call Wait Cancel setting under the menu *PHONE OPTIONS—GLOBAL*.

Auto Phone Test (Phone Options—Global) (02001)

Note

For U.L. Commercial Listed installations (UL 1610), this feature must be on.

(Default = off) This setting determines if the panel sends a phone test automatically to the central station or a pager on a predetermined schedule. (Refer to the “Phone Test Freq.” and “Next Phone Test” settings found under *TIMERS—GLOBAL*).

➤ **To turn Automatic Phone Test off or on:**

- ◆ With the display showing *AUTO PHONE TEST OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Auto Test Reset (Phone Options—Global) (02002)

(Default = on) This setting determines whether or not the Auto Phone Test interval is reset after any successful report to the central monitoring station. (Refer to the “Phone Test Freq.” and “Next Phone Test” settings found under *TIMERS—GLOBAL*).

When this feature is on, the panel considers any successful report to the central monitoring station to be a successful phone test. Thus, any panel report resets the Next Phone Test setting to the Phone Test Freq. value. The panel only conducts an Auto Phone Test if no other reports have been made during the Phone Test Freq. time period.

When this feature is off, an Auto Phone Test is always conducted according to the schedule of the Phone Test Freq. setting, even if the panel makes other reports to the central monitoring station during that time period.

➤ **To turn Auto Test Reset off or on:**

- ◆ With the display showing *AUTO TEST RESET OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Comm Failure (Phone Options—Global) (02003)

(Default = on) This setting determines whether the panel activates trouble beeps to alert users on the premises that communication to the central station failed. Failure notification occurs after the third unsuccessful reporting attempt to the central station/pager.

If a Phone Supervision Card (60-789) is installed, failure notification can occur immediately if inadequate phone line voltage is detected upon the initial dialing attempt.

➤ **To turn Communication Failure notification off or on:**

- ◆ With the display showing *COMM FAILURE OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

DTMF Dialing (Phone Options—Global) (02004)

(Default = on) This setting determines whether the panel uses DTMF tones (on) or pulse (off) for dialing programmed phone numbers.

➤ **To turn DTMF Dialing off or on:**

- ◆ With the display showing *DTMF DIALING OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Dialer Abort (Phone Options—Global) (02005)

(Default = on) This setting determines whether or not the user can stop a panel before it sends a false alarm to the central station.

When this feature is on, alarm reports from sensors in groups 00–20, 34, and 35 can be aborted. To abort the dialing attempt, the user must enter 1 + user code within the Dialer Abort Delay time setting (defaulted to 30 sec). Cancel and restoral reports from these sensor groups are aborted at the same time. The following reports can also be aborted.

- System Alarm Tamper/Cancel
- No Activity Alarm/Cancel
- Touchpad Police and Auxiliary Panic/Cancel
- Recent Closing and Two Trip Error

➤ **To turn Dialer Abort off or on:**

- ◆ With the display showing *DIALER ABORT OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Note

Fire alarm reports to the central station cannot be aborted.

**Dial Abort Delay (Phone Options—Global)
(02006)**

(Default = 30 sec) This setting determines how much time the user has to abort a panel report.

- **To change the Dial Abort Delay:**
- ◆ With the display showing *DIAL ABORT DELAY nn SECS (current setting)*, enter the desired time (15–120s). The display flashes the entered setting. Press # and the display shows the new setting.

**Cancel Message (Phone Options—Global)
(02007)**

Default = on) This setting determines whether or not the panel displays a cancel message after the user disarms the system to clear an alarm condition.

- **To turn Cancel Message off or on:**
- ◆ With the display showing *CANCEL MESSAGE OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

**Pager Delay (Phone Options—Global)
(02008)**

(Default = 15 sec) This setting determines how long a report is delayed to a pager, after the panel dials the pager number.

- **To set the Pager Delay time:**
- ◆ With the display showing *PAGER DELAY nn SECS (current setting)*, enter a delay time (0–30). The display flashes the entered setting. Press # and the display shows the new setting.

**Call Wait Cancel (Phone Options—Global)
(02009)**

(Default = none) This feature lets you set up a dialing prefix to disable the call waiting feature before the panel makes its first dialing attempt to any programmed central monitoring station or downloader phone number. The prefix can be up to eight digits.

To enter pauses, press C.

To enter *, press and hold 7 for one second.

To enter #, press and hold 9 for one second.

- **To set up Call Wait Cancel:**
- ◆ With the display showing *CALL WAIT CANCEL __ (or current setting)*, enter the desired prefix. The display flashes the entered setting. Press # and the display shows the new setting.
- **To delete the Call Wait Cancel prefix:**
- ◆ With the display showing *CALL WAIT CANCEL __ (or current setting)*, press D.

**Dial Tone Detect (Phone Options—Global)
(02010)**

(Default = on) When this setting is on, the panel begins dialing as soon as it detects a dial tone. When this feature is off, the panel begins dialing a few seconds after seizing the phone line.

- **To set up Dial Tone Detect:**
- ◆ With the display showing *DIAL TONE DETECT OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

The following sections describe the phone option settings that appear under *PARTITION 1-2*.

A Phone Interface/Voice module must be installed for the system to use the settings under *PHONE OPTIONS—PARTITION 1-2*.

**Local Phone Control (Phone Options—Partition 1-2)
(partition 1: 0210, partition 2: 0220)**

(Default = on) When this feature is on, the panel can be accessed from a phone on the premises.

- **To set up Local Phone Control:**
- ◆ With the display showing *LOCAL PHONE CTRL OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Note
The Pager Delay time should not be set below 5 seconds, unless absolutely necessary.

Note
There is no Dial Tone Detect on the last dialing attempt.

Remote Access (Phone Options—Partition 1-2)
(partition 1: 0211, partition 2: 0221)

(Default = on) When this setting is on, the panel can be accessed from an off-site phone.

➤ **To turn Remote Access off or on:**

- ◆ With the display showing *REMOTE ACCESS OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Ring/Hang/Ring (Phone Options—Partition 1-2)
(partition 1: 0212, partition 2: 0222)

(Default = on) This setting determines how the panel picks up (seizes) the phone line. Select “on” if an answering machine shares the phone line with the panel. Select “off” if there is no answering machine sharing the phone line with the panel.

When this feature is on, the person who is calling the panel must use the following procedure:

1. Listen for one or two full rings.
2. Hang up.
3. Call the premises again within the next 10–40 seconds. The system answers after the first ring.

When this feature is off, the system answers after 12 full rings.

➤ **To turn Ring/Hang/Ring access off or on:**

- ◆ With the display showing *RING/HANG/RING OFF/ON (current setting)*, press 1 (off) or 2 (on). The display begins flashing the entered selection. Press # and the display shows the new setting.

Line Fail Delay (Phone Options—Partition 1 only)
(partition 1: 0213)

(Default = none) This setting determines the amount of time the partition 1 phone line voltage must be absent before the panel indicates a phone failure trouble condition. If a delay is *not* programmed (default), the panel will not monitor the phone line voltage.

➤ **To set the Line Fail Delay time:**

1. With partition 1 selected, press A or B until the display shows *LINE FAIL DELAY nn SECS (current setting)*.
2. Enter the desired time value (10–240 seconds). The display flashes the entered setting. Press # and the display shows the new setting.

➤ **To delete the Line Fail Delay time:**

1. With partition 1 selected, press A or B until the display shows *LINE FAIL DELAY nn SECS (current setting)*.
2. Press D to delete the current line fail delay time.

Toll Saver (Phone Options—Partition 1-2)
(partition 1: 0214, partition 2: 0224)

(Default = on) This setting determines whether the panel answers a phone call on the eighth ring (on) or twelfth ring (off) when a trouble condition exists.

➤ **To turn Toll Saver off or on:**

1. With the desired partition selected, press A or B until the display shows *TOLL SAVER OFF/ON (current setting)*.
2. Press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Phone Panic (Phone Options—Partition 1-2)
(partition 1: 0215, partition 2: 0225)

(Default = off) This setting determines whether or not a police panic alarm can be activated from a touch-tone phone. When this feature is on, pressing # + ***** from a touch-tone phone on the premises causes a panic alarm.

➤ **To turn Phone Panic off or on:**

1. With the desired partition selected, press A or B until the display shows *PHONE PANIC OFF/ON (current setting)*.
2. Press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Note
The Remote Access setting must be turned on for this feature to work.

Note
Line Fail Delay is not available for partition 2 at this time.

A Phone Supervision Card must be installed to use this feature.

**Phone Access Key (Phone Options—Partition 1-2)
(partition 1: 0216, partition 2: 0226)**

(Default = #) This setting determines which touch-tone phone button is used for system access and control.

If the Local Phone Control feature is enabled, the user can pick up the phone and press # (within 5 seconds) to access the security system. The panel seizes the phone line and waits for the user to enter system commands. Phone access can be changed from # to * (see the following note).

➤ **To change the Phone Access Key:**

1. With the desired partition selected, press A or B until the display shows *PHONE ACCESS KEY #/* (current setting)*.
2. Press 1 (for *) or 2 (for #). The display flashes the entered setting. Press # and the display shows the new setting.

Timers Menu

The *TIMERS* menu lets you set up the various system feature times that affect the whole system (global) or a specific partition.

The following describes how to program the timer settings that appear under *GLOBAL*.

**Supervisory Time (Timers—Global)
(0300)**

(Default is set randomly between 01:00 and 04:00) This setting determines what time of day the panel sends supervisory, low battery, or auto phone test reports to the central station.

➤ **To set the Supervisory Time:**

- ◆ With the display showing *SUPERVISORY TIME HH:MM (current setting)*, enter the desired 4-digit time value. For example, enter 0330 to set the supervisory time for 3:30 A.M. The display flashes the entered setting. Press # and the display shows the new setting.

**RF Tx Timeout (Timers—Global)
(0301)**

(Default = 12 hours) This setting determines how many hours (2–24) the panel has to receive at least one signal from a wireless sensor (learned into a supervised group). If the panel does not receive a signal from any supervised wireless sensor within the set time, the panel reports a supervisory condition to the central station.

➤ **To set the RF Tx Timeout:**

- ◆ With the display showing *RF TX TIMEOUT nn HOURS (current setting)*, enter the desired time-out value (2–24). The display flashes the entered setting. Press # and the display shows the new setting.

**Phone Test Freq. (Timers—Global)
(0302)**

(Default = 7 days) This setting determines how often the panel conducts the automatic phone test (see “Auto Phone Test” under *PHONE OPTIONS—GLOBAL*). The system can be set to perform an automatic phone test anywhere from every day to every 255 days.

➤ **To set the Phone Test Freq:**

- ◆ With the display showing *PHONE TEST FREQ nnn DAYS (current setting)*, enter the number of days (1–255). The display flashes the entered setting. Press # and the display shows the new setting.

**Next Phone Test (Timers—Global)
(0303)**

(Default = 7 days) This setting is used by the Auto Phone Test feature (see *PHONE OPTIONS—GLOBAL*) to determine when the next automatic phone test should occur. This setting should be the same as, or less than, the Phone Test Freq. setting.

➤ **To set the Next Phone Test:**

- ◆ With the display showing *NEXT PHONE TEST nnn DAYS (current setting)*, enter the number of days (1–255). The display flashes the entered setting. Press # and the display shows the new setting.

Note

Use the default setting (#) to avoid conflicts between the security system and other phone devices and services. Many phone devices (such as answering machines, computer modems, and FAX machines) and services (such as call-waiting, call-forwarding, and some banking transactions) require * to initiate their operation, so using * for this security feature could cause conflicts.

Note

The panel clock must be set with the correct time for accurate supervisory time reporting. See “Time and Date Menu” on page 54.

Note

For U.L. Listed commercial installations, the RF Tx Timeout must be set to 4 hours. For U.L. Listed residential installations, the RF Tx Timeout must be set to 24 hours.

Note

For U.L. Commercial Listed installations (UL 1610), this feature must be set to 1.

Note

For U.L. Commercial Listed installations (UL 1610), this feature must be set to 1.

**Output Trip Time (Timers—Global)
(0304)**

(Default = 4 sec) This setting determines how long outputs are activated when tripped (if they are configured for a momentary response).

➤ **To set the Output Trip Time:**

- ◆ With the display showing *OUTPUT TRIP TIME nn SECS (current setting)*, enter the number of seconds (1–12). The display flashes the entered setting. Press # and the display shows the new setting.

**Activity Timeout (Timers—Global)
(0305)**

(Default = 24 hours) This setting determines when the system sends a “no activity” report. The panel can be set to wait from 1–42 hours. If no user interaction or device activation occurs in that time, the panel sends a report to the central station.

➤ **To set the Activity Timeout:**

- ◆ With the display showing *ACTIVITY TIMEOUT nn HOURS (current setting)*, enter the number of hours (1–42). The display flashes the entered setting. Press # and the display shows the new setting.

**Daylight Saving (Timers—Global)
(0306)**

(Default = on) When this setting is on, the panel clock automatically adjusts for daylight saving time changes.

➤ **To turn Daylight Saving off or on:**

- ◆ With the display showing *DAYLIGHT SAVING OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

The following sections describe the timer settings that appear under *PARTITION 1-2*.

**Entry Delay (Timers—Partition 1-2)
(partition 1: 0310, partition 2: 0320)**

(Default = 32 sec) This setting determines how much time the user has to disarm the system (after entering the armed premises through a “designated delay door”) without causing an alarm.

➤ **To set the Entry Delay:**

- ◆ With the display showing *ENTRY DELAY nnn SECS (current setting)*, enter the desired time value (32–240 using 8-second intervals). The display flashes the entered setting. Press # and the display shows the new setting.

Note

For residential UL Listed installations, the Entry Delay must be set to 45 seconds or less.

**Exit Delay (Timers—Partition 1-2)
(partition 1: 0311, partition 2: 0321)**

(Default = 64 sec) This setting determines how much time the user has (after arming the system) to leave the premises through a “designated delay door” without causing an alarm.

➤ **To set the Exit Delay:**

- ◆ With the display showing *EXIT DELAY nnn SECS (current setting)*, enter the desired time value (48–184 using 8-second intervals). The display flashes the entered setting. Press # and the display shows the new setting.

Note

For residential UL Listed installations, the Exit Delay must be set to 60 seconds or less.

**Extended Delay (Timers—Partition 1-2)
(partition 1: 0312, partition 2: 0322)**

(Default = 4 minutes) This setting determines how much time the user has (after arming the system) to enter or exit the premises through a “designated extended delay door” (1–8 minutes).

➤ **To set the Extended Delay:**

- ◆ With the display showing *EXTENDED DELAY n MINUTES (current setting)*, enter the desired time value (1–8). The display flashes the entered setting. Press # and the display shows the new setting.

Note

For UL Listed installations Extended Delay may not be used.

**Siren Timeout (Timers—Partition 1-2)
(partition 1: 0313, partition 2: 0323)**

(Default = 4 minutes) This setting determines how long sirens sound (1–30 minutes) if no one is present to disarm the system.

Note

For UL Listed installations, the Siren Timeout must be set to 4 minutes or more.

➤ **To set the Siren Timeout:**

- ◆ With the display showing *SIREN TIMEOUT nn MINUTES (current setting)*, enter the desired time value (1–30). The display flashes the entered setting. Press # and the display show the new setting.

Sleep Time (Timers—Partition 1-2)
(partition 1: 0314, partition 2: 0324)

(Default = 22:00 [10:00 pm.]) This setting determines the start time of a 10 hour window during which trouble beeps are suppressed. The initial occurrence of an event that causes trouble beeps within this window will not sound trouble beeps until the Sleep Time window expires. If trouble beeps from a previous event are due to be restarted during the sleep time window, they will be restarted one hour prior to Sleep Time.

➤ **To set the Sleep Time:**

- ◆ With the display showing *SLEEP TIME hh:mm (current setting)*, enter the desired time value (00:00-23:50 using 10 minute intervals). The display flashes the entered setting. Press # and the display show the new setting.

Light Control Menu

The *LIGHT CONTROL* menu lets you set up light activation for a specific partition.

The following describes how to program the light control settings that appear under *PARTITION 1* and *PARTITION 2*.

Entry Lights (Light Control—Partition 1-2)
(partition 1: 0400, partition 2: 0410)

(Default = none) This setting determines which X-10 controlled lights turn on during entry and exit delays.

➤ **To set the Entry Lights:**

1. With the desired partition selected, press #. The display shows *ENTRY LIGHTS nnnnnnn (current setting)*.
2. Enter *all* the desired light numbers (3–9 based on the UNIT dial setting on each X-10 Lamp Module). The display flashes the entered setting(s). Press # and the display shows the new setting(s).

➤ **To delete Entry Lights:**

- ◆ Enter any light number that appears on the display, then press #. The number disappears from the display.

House Code (Light Control—Partition 1, 2)
(partition 1: 0401, partition 2: 0411)

(Defaults: partition 1 = 01-B; partition 2 = 02-C) This setting enables X-10 controlled lights to work in a selected partition without interfering with the X-10 controlled lights of the other partition.

After setting the panel house code for each partition, you must set the X-10 controlled lights for that partition to the same house code. The letter that appears automatically after the house code number indicates the necessary HOUSE dial setting for X-10 modules in that partition.

➤ **To set the House Code:**

1. With the desired partition selected, press A or B until the display shows *HOUSE CODE nn-x (current setting)*.
2. Enter the desired number (1–255). The display flashes the entered number. Press # and the display shows the new house code.

Touchpad Options Menu

The *TOUCHPAD OPTIONS* menu lets you set up touchpad panic and arming operation. The following section describes the touchpad option settings that appear under *GLOBAL*.

Latchkey Zones (Touchpad Options—Global)
(0500)

(Default = none) This setting defines the range of keychain touchpads that will function as a latchkey user. The value entered in this section can be any valid zone number. When a zone number is entered, all zones *at* or *below* that zone number will function as a latchkey user. For exam-

Note

For light control to work, X-10 Powerhouse Lamp Modules must be installed at desired lamps.

Note

X-10 Lamp Modules set to 1 always turn on during the entry and exit delays.

X-10 Lamp Modules set to 2 always flash the arming level when arming the system. For example, lights flash two times when arming to STAY (level 2), and three times when arming to AWAY (level 3).

ple, if 5 is entered, any keychain touchpads learned into zones 1–5 will be latchkey users and all others (6–76) will not.

➤ **To set the number of Latchkey Zones:**

1. With the display showing *LATCHKEY ZONES nnn (current setting)*, enter the desired number of latchkey zones (1–76). The display flashes the entered setting.
2. Press # and the display shows the new setting.

➤ **To delete/disable Latchkey Zones:**

- ◆ With the display showing *LATCHKEY ZONES nnn (current setting)*, press D.

The following sections describe the touchpad option settings that appear under *PARTITION 1-2*.

Fire Panic (Touchpad Options—Partition 1-2)
(partition 1: 0510, partition 2: 0520)

(Default = on) This setting determines whether touchpad fire panic buttons are enabled (on) or disabled (off).

➤ **To change the Fire Panic setting:**

- ◆ With the display showing *FIRE PANIC OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Aux. Panic (Touchpad Options—Partition 1-2)
(partition 1: 0511, partition 2: 0521)

(Default = on) This setting determines whether touchpad auxiliary panic buttons are enabled (on) or disabled (off).

➤ **To change the Auxiliary Panic setting:**

- ◆ With the display showing *AUXILIARY PANIC OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Police Panic (Touchpad Options—Partition 1-2)
(partition 1: 0512, partition 2: 0522)

(Default = on) This setting determines whether touchpad police panic buttons are enabled (on) or disabled (off).

➤ **To change the Police Panic setting:**

- ◆ With the display showing *POLICE PANIC OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Keychain TP Arm (Touchpad Options—Partition 1-2)
(partition 1: 0513, partition 2: 0523)

(Default = off) When this setting is on, pressing the lock button on keychain touchpads arms the system directly to AWAY with NO DELAY.

When this setting is off, each key-press increments the arming level (i.e., from OFF to STAY, from STAY to AWAY).

➤ **To change the Keychain Touchpad Arming setting:**

- ◆ With the display showing *KEYCHAIN TP ARM OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Star Is No Delay (Touchpad Options—Partition 1-2)
(partition 1: 0514, partition 2: 0524)

(Default = off) This setting determines whether the keychain touchpad star button controls an output (off) or the No Delay feature (on).

➤ **To change the keychain Star Is No Delay setting:**

- ◆ With the display showing *STAR IS NO DELAY OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Reporting Menu

The *REPORTING* menu lets you set up which system events are reported to the central monitoring station. The following describes how to program the reporting settings that appear under *GLOBAL*

Note

For commercial UL Listed installations (UL 1610) the 24-Hour Tamper must be set to on.

**24-Hour Tamper (Reporting—Global)
(06000)**

(Default = off) When this setting is on, the panel sounds sirens and reports a tamper alarm (even when the system is disarmed), when wireless sensor tamper switches are activated.

➤ **To turn 24-Hour Tamper off or on:**

- ◆ With the display showing *24 HOUR TAMPER OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

**Buffer Control (Reporting—Global)
(06001)**

(Default = off) When this setting is on, only arming level changes are logged in the buffer (memory) of the panel. When this setting is off, *all* system events are logged in the buffer.

➤ **To turn Buffer Control off or on:**

- ◆ With the display showing *BUFFER CONTROL OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

**Back In Service (Reporting—Global)
(06002)**

(Default = on) When this setting is on, the panel reports to the central station when AC and backup battery power are restored (after an extended power outage).

➤ **To turn Back In Service reports off or on:**

- ◆ With the display showing *BACK IN SERVICE OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

**Bypass Reports (Reporting—Global)
(06003)**

(Default = off) When this setting is on, the panel reports to the central station whenever sensors or zones are bypassed.

➤ **To turn Bypass Reports off or on:**

- ◆ With the display showing *BYPASS REPORTS OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

**Low CPU Battery (Reporting—Global)
(06004)**

(Default = on) When this setting is on, the panel reports a low panel battery to the central station before shutting down.

➤ **To turn Low CPU Battery reports off or on:**

- ◆ With the display showing *LOW CPU BATTERY OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

**Battery Restoral (Reporting—Global)
(06005)**

(Default = off) If this setting is on, the panel reports to the central monitoring station when a wireless sensor or touchpad reports a battery replacement to the panel.

➤ **To turn Battery Restoral reports off or on:**

- ◆ With the display showing *BATTERY RESTORAL OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

**Buffer Full Rpt (Reporting—Global)
(06006)**

(Default = off) When this setting is on, the panel sends an “event buffer full” report to the central monitoring station when the event buffer is nearly full.

➤ **To turn Buffer Full Report off or on:**

- ◆ With the display showing *BUFFER FULL RPT OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Note

For UL Listed installations, the Low CPU Battery feature must be set to on.

Zone Restorals (Reporting—Global) (06007)

Note

As with all GE Interlogix panels, hardwire smoke detectors connected to Concord or SnapCard hardwire zones do not send restorals.

(Default = off) When this setting is on, the panel reports a restoration to the central monitoring station for wireless or hardwire zones in alarm before the alarm is canceled.

➤ **To turn Zone Restoration reporting off or on:**

- ◆ With the display showing *ZONE RESTORALS OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Two Trip Error (Reporting—Global) (06008)

Note

For UL Listed installations, the Two Trip Error feature must be set to off.

(Default = off) This setting works with the Alarm Verify setting (see “Alarm Verify” later in this section and Appendix B: Table B1 “Sensor Table Characteristics”). If Alarm Verify is on, then the panel waits for a second sensor trip before sending an alarm.

If Two Trip Error is also on and a second sensor trip *does not occur* within a 4-minute time period, then the panel sends an error report to the central monitoring station.

➤ **To turn Two Trip Error off or on:**

- ◆ With the display showing *TWO TRIP ERROR OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

TP Panic RPT FMT (Reporting—Global) (06009)

(Default = off) This setting determines how the panel formats touchpad panic alarm reports to the central station.

When this feature is turned on, touchpad panic alarms report using the following 3-digit codes: Auxiliary—597, Police—598, Fire—599

When turned off, touchpad panic alarms report using a 3-digit code from 500 to 515, with the last digit identifying the touchpad device number.

➤ **To turn TP Panic RPT FMT off or on:**

- ◆ With the display showing *TP PANIC RPT FMT OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

AC Failure (Reporting—Global) (06010)

Note

For UL Listed installations, AC Failure must be set to on.

(Default = off) When this setting is on, the panel reports to the central station 15 minutes after AC power to the panel is lost.

➤ **To turn AC Failure reports off or on:**

- ◆ With the display showing *AC FAILURE OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Receiver Failure (Reporting—Global) (06011)

(Default = off) When this setting is on, the panel reports a receiver failure under the following conditions:

- No wireless sensor signals have been received for two hours or
- The receiver is being jammed with a constant signal.

➤ **To turn Receiver Failure reports off or on:**

- ◆ With the display showing *RECEIVER FAILURE OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Note

For UL Listed installations using wireless devices, Receiver Failure must be set to on.

RF Low Bat Rpt (Reporting—Global) (06012)

(Default = weekly) This setting determines whether the panel sends daily or weekly low battery reports to the central monitoring station when a wireless device is reporting a low battery condition to the panel.

➤ **To set RF Low Battery Report to daily or weekly:**

- ◆ With the display showing *RF LOW BAT RPT DAILY/WEEKLY (current setting)*, press 1 (daily) or 2 (weekly). The display flashes the entered setting. Press # and the display shows the new setting.

**RF Supv Report (Reporting—Global)
(06013)**

(Default = weekly) This setting determines whether the panel sends daily or weekly reports to the central monitoring station when the panel detects a supervisory condition in a wireless device.

➤ **To set RF Supv Report to daily or weekly:**

- ◆ With the display showing *RF SUPV REPORT DAILY/WEEKLY (current setting)*, press 1 (daily) or 2 (weekly). The display flashes the entered setting. Press # and the display shows the new setting.

**Swinger Limit (Reporting—Global)
(06014)**

(Default = 1) This setting determines the maximum number of times (1–2) a sensor or zone can go into alarm (during a single arming period) before the panel automatically bypasses that sensor or zone. This feature only applies to sensors or zones in groups 00–20, 29, 34, or 35.

When set to 1, the panel automatically bypasses a sensor or zone after it causes an alarm. When set to 2, the panel waits until a sensor or zone has caused a second alarm (during the same arming period) before bypassing it. At any setting, the automatic bypass is logged into the event buffer.

A bypassed sensor or zone will be cleared (automatically unbypassed) if the system receives no further activations from that sensor or zone over the next 48–50 hours.

Changing the arming level also clears all automatically bypassed sensors and zones and resets the Swinger Limit count on all sensors and zones.

➤ **To set the Swinger Limit:**

- ◆ With the display showing *SWINGER LIMIT n (current setting)*, press the desired number (1–2). The display flashes the entered setting. Press # and the display shows the new setting.

**Program Report (Reporting—Global)
(06015)**

(Default = off) When this setting is on, the panel sends a report to the central station when someone enters or exits installer programming.

➤ **To turn Program Report on or off:**

- ◆ With the display showing *PROGRAM REPORT ON/OFF (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

The following sections describe the settings that appear under *REPORTING—PARTITION 1-2*.

**Opening Reports (Reporting—Partition 1-2)
(partition 1: 06100, partition 2: 06200)**

(Default = off) When this setting is on, the panel sends an opening report to the central station after disarming the system.

➤ **To turn Opening Reports off or on:**

- ◆ With the display showing *OPENING REPORTS OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

**Closing Reports (Reporting—Partition 1-2)
(partition 1: 06101, partition 2: 06201)**

(Default = off) When this setting is on, the panel sends a closing report to the central station after arming the system.

➤ **To turn Closing Reports off or on:**

- ◆ With the display showing *CLOSING REPORTS OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

**Recent Closings (Reporting—Partition 1-2)
(partition 1: 06102, partition 2: 06202)**

(Default = on) When this setting is on, the panel sends a recent closing report to the central station if an alarm occurs within two minutes *after* the exit delay time expires. Such a report is used to identify a possible exit fault.

➤ **To turn Recent Closings off or on:**

- ◆ With the display showing *RECENT CLOSINGS OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Note

To use this feature, the Open/Close Reports settings under the PHONES menu must be turned on for the specific CS Phone or Pager number.

Note

To use this feature, the Open/Close Reports settings under the PHONES menu must be turned on for the specific CS Phone or Pager number.

**No Activity (Reporting—Partition 1-2)
(partition 1: 06103, partition 2: 06203)**

(Default = off) When this setting is on, the panel sends a no activity report to the central station when the activity timeout expires (see *TIMERS—ACTIVITY TIMEOUT*).

➤ **To turn No Activity reports off or on:**

- ◆ With the display showing *NO ACTIVITY OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

**Duress Option (Reporting—Partition 1-2)
(partition 1: 06104, partition 2: 06204)**

(Default = off) When this setting is on, the system can be controlled using a programmed duress code (see *SECURITY—PARTITION N—DURESS CODE*).

Do not use a duress code unless it is absolutely necessary. Using duress codes often results in false alarms due to code entry errors. If a duress code is absolutely necessary, use it with the audio verification module to reduce false alarms and accidental dispatches.

➤ **To turn Duress Option off or on:**

- ◆ With the display showing *DURESS OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

**Force Armed (Reporting—Partition 1-2)
(partition 1: 06105, partition 2: 06205)**

(Default = off) When this setting is on, the panel reports to the central monitoring station when a user “force arms” the system.

➤ **To turn Force Armed off or on:**

- ◆ With the display showing *FORCE ARMED OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

**Latchkey Format (Reporting—Partition 1, 2)
(06106—partition 1, 06206—partition 2)**

(Default = off) This setting determines whether the selected partition is set up for basic (off) or advanced (on) latchkey opening report operation.

Basic:

If the partition is armed by entering 2 (or 3) + CODE, *disarming using a designated latchkey user code or keychain touchpad within an assigned time schedule* sends a page.

If the partition is armed by entering 2 (or 3) + CODE + 6 (Latchkey), *disarming using a designated latchkey user code or keychain touchpad inside or outside of an assigned time schedule* sends a page.

Advanced:

If the partition is armed by entering 2 (or 3) + CODE + 6 (Latchkey), *disarming using a latchkey designated user code or keychain touchpad within an assigned time schedule* sends a page.

Refer to the *User's Guide* for complete Latchkey setup and operation.

➤ **To turn Latchkey Format off or on:**

1. With the desired partition selected, press A or B until the display shows *LATCHKEY FORMAT OFF/ON (current setting)*.
2. Press 1 (off—basic) or 2 (on—advanced). The display flashes the entered setting. Press # and the display shows the new setting.

**Freeze Alarm (Reporting—Partition 1, 2)
(06107—partition 1, 06207—partition 2)**

(Default = off) This setting determines whether the panel reports a freeze alarm to the central station or pager, when the selected partition's energy saver module detects a temperature that matches a predetermined setting (see *BUS DEVICES—UNIT ID—ENERGY OPTIONS—FREEZE TEMP*).

➤ **To turn Freeze Alarm reporting off or on:**

1. With the desired partition selected, press A or B until the display shows *FREEZE ALARM OFF/ON (current setting)*.
2. Press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Note

For UL Listed installations, Duress Option must be set to off.

Note

Forced arming occurs if the user presses *BYPASS* when arming the system with open sensors or zones protesting.

Auto-forced arming occurs if the user does not press *BYPASS* (when arming the system with open sensors/zones protesting) and the siren time expires.

Auto-forced arming always reports to the central monitoring station.

Alarm Verify (Reporting—Partition 1-2)
(partition 1: 06108, partition 2: 06208)

(Default = off) This setting determines whether the panel reports to the central monitoring station after a single sensor or zone trip (off) or waits for a second trip before reporting (on).

This setting affects sensors/zones in groups 10 through 20. If Alarm Verify is set to on, group 18 responds the same as group 17 (see “Appendix B, Table B1 “Sensor Group Characteristics”).

➤ **To turn Alarm Verify off or on:**

- ◆ With the display showing *ALARM VERIFY OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

System Tamper (Reporting—Partition 1-2)
(partition 1: 06109, partition 2: 06209)

(Default = off) This setting determines how the panel handles possible tamper situations. When this feature is on, the panel reacts in the following two ways:

- The system goes into alarm if several attempts are made to disarm the system with incorrect access codes (40 consecutive keypresses).
- The panel reports to the central station if a bus device stops communicating with the panel.

➤ **To change the System Tamper setting:**

- ◆ With the display showing *SYSTEM TAMPER OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Siren Options Menu

The *SIREN OPTIONS* menu lets you set up siren operation and supervision.

The following describes how to program the siren option settings that appear under *GLOBAL*

Immediate Beeps (Siren Options—Global)
(0700)

(Default = off) This setting determines whether the panel activates trouble beeps as soon as a wireless device supervisory condition is detected (on), or if the panel waits until “supervisory time” to activate trouble beeps (off). (Refer to *TIMERS—GLOBAL—SUPERVISORY TIME*).

➤ **To turn Immediate Beeps off or on:**

- ◆ With the display showing *IMMEDIATE BEEPS OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Disable Trouble Beeps (Siren Options—Global)
(0701)

(Default = off) When this setting is on, the panel will not beep to alert users of wireless device supervisory trouble.

➤ **To turn Disable Trouble Beeps off or on:**

- ◆ With the display showing *DISABLE TR BEEPS OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

UL 98 Options (Siren Options—Global)
(0702)

(Default = off) This setting determines whether the panel complies with UL 98 requirements (4-hour trouble beep restart, 4-hour backup battery test, 4-hour smoke (group 26) zone supervisory).

➤ **To turn UL 98 Options off or on:**

- ◆ With the display showing *UL 98 OPTIONS OFF/ON (current setting)*, press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

SWS Supv Code (Siren Options—Global)
(0703)

(Default = 3) This setting determines the system house code number used for supervising wireless sirens.

Supervised Wireless Sirens receive signals from the panel through the existing electrical wiring. If sirens fail to receive or process these signals, the siren transmits a wireless signal to the panel/receiver.

Note

For UL Listed installations, Alarm Verify must be set to off.

Note

For UL Commercial Listed installations (UL 1610), System Tamper must be set to on.

Note

For UL Listed installations, this feature must be on.

Note

For UL Listed installations, Disable Trouble Beeps must be set to off.

Note

For UL Listed installations, this feature must be on.

Note

To supervise wireless sirens, Concord hardwire panels must include a SuperBus 2000 RF Receiver. For all Concord panels, the siren must be learned into sensor group 33 for the system to process radio signals from wireless sirens.

Note

You must set both the SWS Supv Code and the partition House Code (see the LIGHT CONTROL menu) before plugging in Supervised Wireless Sirens.

➤ **To set the SWS Supv Code:**

- ◆ With the display showing *SWS SUPV CODE nnn* (current code), enter the desired code (1–255). The display flashes the entered code. Press # and the display shows the new code.

Global Fire (Siren Options—Global) (0704)

(Default = off) This setting determines whether or not sirens in both partitions sound (on) if either partition activates a fire alarm.

➤ **To turn Global Fire off or on:**

- ◆ With the display showing *GLOBAL FIRE OFF/ON* (current setting), press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

The following sections describe the settings that appear under *SIREN OPTIONS—PARTITION 1*.

Siren Verify (Siren Options—Partition 1) (0710)

(Default = off) This setting determines whether or not the panel supervises the panel speaker terminals (7–8). When this feature is on, the panel will indicate a trouble condition if no speaker is connected to panel speaker terminals.

➤ **To turn Siren Verify off or on:**

- ◆ With the display showing *SIREN VERIFY OFF/ON* (current setting), press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Note

For UL Listed installations, Siren Verify must be set to on.

Sensors Menu

The *SENSORS* menu gives you access to the following settings:

- *LEARN SENSORS* lets you add (learn) hardwire zones, wireless sensors, and wireless touchpads into panel memory.
- *SENSOR TEXT* lets you “name” the sensors and zones you have added to the system.
- *DELETE SENSORS* lets you delete zones and sensors from panel memory.
- *EDIT SENSORS* lets you view and, if desired, change a sensor group or partition assignment. You can also identify whether a zone is wireless or hardwire, whether it is configured as Normally Closed (N/C) or Normally Open (N/O), or if the zone is a touchpad.

Table 7: How to Trip Sensors

Sensor	Steps to Trip Sensor
Hardwire Zones	Start with the zone in its “normal” state, then trip the zone into its alarm state. A normally closed door, for example, should be closed when you begin the Learn Sensors process. To trip the zone, open the door.
Wireless Sensors	Follow the instructions included with each sensor.
Wireless Door/Window Sensors with External Contacts	Place the external contact in the alarm condition, then activate the sensor tamper switch.
Self Actuated Bell	Activate the tamper switch.
Handheld Wireless Touchpads	Press the BYPASS button.
Keychain Touchpads	Press and hold the lock and unlock buttons together until the touchpad LED flashes.
ELM Keychain Touchpads	<ol style="list-style-type: none"> 1. Press and release the unlock button twice quickly, then press and hold until the LED flashes three times. 2. Press and release the unlock button once quickly, then press and hold until the LED flashes two times. 3. Press and hold the unlock button until the LED flashes once.

The following describes how to program the sensor settings that appear under *LEARN SENSORS*.

Note

The panel comes with factory programmed onboard hardwire zones. Install 2k-ohm, end of line (EOL) resistors on all unused factory programmed onboard hardwire zones. If you don't want to install EOL resistors, delete any unused zones from memory. See Table 8 for onboard hardwire zone factory programming.

Note

Sensors must be placed in a partition and group. To change the sensor group or partition assignment after adding a sensor or zone, use the EDIT SENSORS menu.

Learn Sensors (Sensors) (080)

(Default = none) The following describes how to add (learn) hardwire zones and wireless devices into panel memory.

➤ **To Learn Sensors into panel memory:**

1. With the display showing *SENSORS*, press # and the display shows *LEARN SENSORS*.
2. Press # and the display shows *SENSOR PTN 1*.
3. Press # to select partition 1 or press 2 + # to select partition 2. The display should show *SENSOR GROUP 0*.
4. Enter the desired sensor group + # (see Table B1 in “Appendix B” for a description of all sensor group characteristics). The display shows *TRIP SENSOR nn*, where nn is the displayed (next available) sensor number.
5. To change the displayed sensor number, enter the desired sensor number + #. The desired sensor number is displayed.
6. With the desired sensor number displayed, use the guidelines in Table 7 to force the sensor or zone you are adding (learning) into the panel memory to send a signal to the panel.
7. To add another sensor to the same sensor group and partition, go back to step 5.
8. To add sensors to another sensor group or partition, press * twice and go back to step 1 (*LEARN SENSORS*).

Table 8: Onboard Hardwire Zone Factory Programming

Zone Input	Group No. & Description
1	10–Entry/Exit
2	17–Instant Interior Follower
3	13–Instant Perimeter
4	13–Instant Perimeter
5	13–Instant Perimeter
6	13–Instant Perimeter
7	13–Instant Perimeter
8	13–Instant Perimeter
<p>Note If the panel memory is cleared, all onboard hardwire zone factory programming will be erased.</p>	

Sensor Text (Sensors) (081)

(Default = none) Use the following guidelines to “name” zone and sensor locations:

- Use the item numbers that appear in Appendix B, Table B2 “Item Numbers and Sensor Text” for characters and words listed there.
- If a desired word does not appear in Table B2, create it using the characters (custom text).
- When using words from Table B2, spaces between them appear automatically. When using characters from Table B2 to create words, you must reserve an item number for a ‘space’ after the word.
- Each character or word uses up one item number. For example, a word from the list counts as one item number. A created word (such as BOY’S) counts as six item numbers—4 letters, 1 apostrophe, and 1 space.
- Only 16 item numbers are allowed for each zone or sensor name, so plan ahead before programming sensor text. You may need to abbreviate words to avoid running out of item numbers.

➤ **To program Sensor Text:**

1. Press A or B until the display shows *SENSOR TEXT*.
2. Press # and the display shows *TEXT FOR SN 01*.
3. Press A or B until the display shows the desired sensor number (or enter the desired sensor number and press #).
4. Press # and the display shows: *SN 1 ITEM 0 0 - _____*. Where *ITEM 0* is the first character/word location and *0* is the character/word number.
5. Enter the number of the desired character or word, or scroll through the numbers by pressing B (forward) or A (backward). If you make a mistake, simply enter the correct number or continue scrolling through choices.

6. Press # to accept the displayed choice and the display shows: *SN 1 ITEM 1 0 -*.
7. Repeat steps 5 and 6 as needed to complete the zone or sensor name.
8. Press * after entering the last character or word number. The display shows the complete text name. For example: *TEXT FOR SN 01 FRONT ENTRY DOOR*

Delete Sensors (Sensors) (082)

(Default = none) The following procedure describes how to remove hardwire zone and wireless sensor numbers from panel memory.

➤ **To Delete Sensors from panel memory:**

1. Press A or B until the display shows *DELETE SENSORS*.
2. Press # and the display shows *DELETE SENSOR nn* (lowest zone/sensor number in panel memory).
3. Press # to delete the displayed sensor or—enter the desired sensor number, then press #.
4. Repeat steps 2 and 3 until all desired sensors are deleted.

Edit Sensors (Sensors) (083)

(Default = none) This menu lets you view and, if desired, change the group and partition assignment for each learned zone or sensor. For example, the display shows: *S01 P1 G13 NC HW BACK DOOR*. Where: *S01* = zone/sensor number, *P1* = partition 1, *G13* = sensor group 13, *NC* = normally closed, *HW* = hardwired, and *BACK DOOR* is the programmed text name.

Other description codes include, *RF* = wireless sensor, *TP* = touchpad, *NO* = normally open.

➤ **To Edit Sensors:**

1. Press A or B until the display shows *EDIT SENSORS*.
2. Press # and the display shows the sensor or zone with the lowest number.
3. Press A or B to scroll through all learned zones and sensors.
4. When the desired zone or sensor is displayed, press #. The display shows *SENSOR PTN n* (current partition assignment).
5. Enter the desired partition number, then press #. The display shows the new partition assignment.
6. Press A or B and the display shows *SENSOR GROUP nn* (current group assignment).
7. Enter the desired group number, then press #. The display shows the new group assignment.

Audio Verification Menu

The *AUDIO VERIFICATION* menu lets you set up the audio verification module (AVM) operation in partition 1. If you want audio verification for partition 2, you must install a “stand-alone” audio verification module and a 4-Relay Output Module (HOM) (60-770) output for that partition.

The following sections describe the audio verification settings that appear under *PARTITION 1*.

Audio Verify (Audio Verification—Partition 1) (0900)

(Default = off) This setting determines whether or not the system can be accessed by phone for alarm verification.

➤ **To turn Audio Verification off or on:**

1. With the display showing *AUDIO VERIFICATION*, press #. The display shows *PARTITION 1*.
2. Press # again and the display shows *AUDIO VERIFY OFF/ON* (current setting).
3. Press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

Audio Mode (Audio Verification—Partition 1) (0901)

(Default = 1) This setting determines how the audio verification module operates. Choose one of the following:

- **(1) Instant**—Allows the central station operator instant access for an audio session by entering the AVM code or by pressing * (if an AVM access code is not programmed) upon completion of panel alarm report (also see *ACCESS TIMEOUT*).
- **(2) Callback**—Allows the central station operator to contact persons on the premises after one ring and verify the alarm report. Operator must press * or enter the AVM access code within 20 seconds after ring. The panel does not report any alarms during the AVM session, except for fire alarms.

Note

Deleting sensors does not delete sensor text associated with the deleted sensor number. To delete sensor text, enter the SENSOR TEXT menu and enter 000 (nulls) for each item number.

- **(3) Callback Silent**—Same as Callback, except premises phones do not ring.

➤ **To set Audio Mode:**

1. With the display showing *AUDIO VERIFY OFF/ON*, press A or B until the display shows *AUDIO MODE nn (current setting)*.
2. Enter the desired mode number (1–3). The display flashes the entered setting. Press # and the display shows the new setting.

**Fire Shutdown (Audio Verification—Partition 1)
(0902)**

(Default = off) This setting determines whether system sirens turn off during a fire alarm audio session.

➤ **To turn Fire Shutdown off or on:**

1. With the display showing *AUDIO VERIFY OFF/ON*, press A or B until the display shows *FIRE SHUTDOWN OFF/ON (current setting)*.
2. Press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

**Silent Talkback (Audio Verification—Partition 1)
(0903)**

(Default = off) This setting determines whether the central station operator can speak to persons on the premises (on) or only listen (off) during a silent or duress alarm audio session.

➤ **To turn Silent Talkback off or on:**

1. With the display showing *AUDIO VERIFY OFF/ON*, press A or B until the display shows *SILENT TALKBACK OFF/ON (current setting)*.
2. Press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

**Access Timeout (Audio Verification—Partition 1)
(0904)**

(Default = 90 sec) If the Audio Mode is set to “Instant,” then this setting determines how much time (30–300s, in 2-second increments) the central station operator has to enter the AVM access code after the panel is accessed for an audio session.

➤ **To change the Access Timeout:**

1. With the display showing *AUDIO VERIFY OFF/ON*, press A or B until the display shows *ACCESS TIMEOUT nn SECS (current setting)*.
2. Enter the desired time. The display flashes the entered setting. Press # and the display shows the new setting.

**Beep Delay (Audio Verification—Partition 1)
(0905)**

(Default = 02 sec) This setting determines how long AVM access beeps are delayed (0–300s, in 2-second intervals) at the beginning of a 2-way audio session.

➤ **To change the Beep Delay:**

1. With the display showing *AUDIO VERIFY OFF/ON*, press A or B until the display shows *BEEP DELAY nn SECS (current setting)*.
2. Enter the desired time. The display flashes the entered setting. Press # and the display shows the new setting.

**Access Code (Audio Verification—Partition 1)
(0906)**

(Default = or none) This setting determines the code required to access the audio verification module to start an audio session. If no code is programmed, pressing * starts an audio session.

➤ **To change the Access Code:**

1. With the display showing *AUDIO VERIFY OFF/ON*, press A or B until the display shows *ACCESS CODE mnnn (current code)*.
2. Enter the desired **4-digit access code**. The display flashes the entered code. Press # and the display shows the new setting.

➤ **To delete an Access Code:**

1. With the display showing *AUDIO VERIFY OFF/ON*, press A or B until the display shows *ACCESS CODE nnnn (current code)*.
2. Press D to delete.

Accessory Modules Menu

The *ACCESSORY MODULES* menu gives you access to the following menus:

- *BUS DEVICES*—this menu lets you read bus device unit numbers, assign bus devices to a partition, and configure other features associated with a specific bus device.
- *SNAPCARDS*—this menu lets you set the configuration number for each SnapCard output, assign SnapCard outputs to a partition, and name the SnapCard outputs.

The following procedure describes how to program the settings that appear under *ACCESSORY MODULES—BUS DEVICES*.

Unit - ID (Acc. Modules—Bus Devices) (10000 thru 10015)

(Default = none) This menu lets you identify all connected bus devices, view each Unit Number, view the Device ID number, and configure other settings based on a specific device. This menu also lets you delete learned bus devices.

➤ To identify bus device Unit and ID:

1. With the display showing *BUS DEVICES*, press #. The display shows the bus Unit Number and the 8-digit Device ID number. For example: *UNIT - ID 0—02110185*. Where 0 is the Unit Number and 02110185 is the Device ID number.
2. Press A or B to identify all other bus Unit Numbers (0–15) and Device ID numbers.

➤ To delete learned Unit Numbers:

1. With the display showing *BUS DEVICES*, press #. The display shows the bus device set to Unit Number 0.
2. Press A or B until the bus device Unit Number you want to delete is displayed.
3. Press D. The display changes the Unit Number to *NONE*.

Device ID (Acc. Modules—Bus Devices—Unit ID—Change ID)

(Default = none) This menu lets you change the bus device ID number when replacing a defective bus device.

➤ To change a Device ID:

1. With the display showing the desired bus device, press # + #. The display shows *DEVICE ID (current ID)*.
2. Enter the ID of the new bus device. The display flashes the entered selection. Press # and the display shows the new setting.
3. Exit programming mode.
4. Remove AC and battery power from the panel.
5. Replace the defective bus device with a new one.
6. Apply AC and battery power to the panel.

Partition Assign (Acc. Modules—Bus Devices—Unit ID—Device Partition)

(Default = 1) This menu lets you assign bus devices to work in the desired partition.

➤ To assign bus devices to partitions:

1. With the display showing the desired bus device, press #.
2. Press A or B until the display shows *DEVICE PTN* and then press #. The display shows *PARTITION ASSIGN n*.
3. Press 1 or 2 to select the desired partition. The display flashes the entered selection. Press # and the display shows the new setting.

Output Programming (Acc. Modules—Unit ID—Outputs)

Use these settings to program the output points of any installed SuperBus 2000 Hardwire Output Module. The installer programs a HOM output point into the Concord security panel by entering three kinds of information.

- **Partition** -the system partition (1 or 2).
- **Trigger** - the event that activates the output point. Trigger events can be partition alarms, trouble conditions, open sensors, etc. (see Appendix B: Reference Tables).

Note

Most settings under *ACCESSORY MODULES—BUS DEVICES* have no shortcut numbers.

Note

To help identify bus devices, the 8-digit Device ID number is also located on a label on each SuperBus 2000 device.

Note

SuperBus 2000 8Z Input Modules, SuperBus 2000 4-Relay Output Modules, and SuperBus 2000 RF Receivers are not assigned to partitions.

- **Response** - how the output responds when trigger event occurs (see Appendix B: Reference Tables).

This section describes how to program each of the HOM output point configurations into the security panel. The point configuration number is *tttrr*, where *ttt* is the trigger number and *rr* is the response number.

Note

HOM output points cannot be configured for user control. Only the onboard and SnapCard outputs can be configured for user control.

1. With the display showing the desired bus device, press #.
2. Press A or B until the display shows *OUTPUTS*.
3. Press #. The display shows *OUTPUT 1*.
4. Press A or B to select an output, then press #. The display shows *PARTITION ASSIGN 1*.
5. Press 1 or 2 to select the desired partition assignment for this relay. The display flashes the entered setting. Press # and the display shows the new setting.
6. Press A or B. The display shows *CONFIGURATION ttrr (current setting)*.
7. Enter the desired 5-digit configuration number for this relay. The display flashes the entered setting. Press # and the display shows the new setting.
8. Press # and repeat steps 4 through 8 until all outputs are programmed

Status Beeps (Acc. Modules—Bus Device—Unit ID—Keypad Options)

(Default = on) This setting determines whether or not the selected touchpad sounds status beeps. Each touchpad can be set individually.

This feature is usually turned off for a touchpad that is located in or near bedrooms, to avoid disturbing sleeping persons.

Note

For UL Listed installations, Status Beeps must be set to on.

➤ **To turn touchpad Status Beeps on or off:**

1. With the display showing the desired touchpad, press # then A or B until the display shows *KEYPAD OPTIONS*.
2. Press # and the display shows *STATUS BEEPS OFF/ON (current setting)*.
3. Press 1 (off) or 2 (on) to select the desired setting. The display flashes the entered selection. Press # and the display shows the new setting.

Key Beeps (Acc. Modules—Bus Devices—Unit ID—Keypad Options)

(Default = on) This setting determines whether or not selected touchpads beep when their buttons are pressed.

This feature is usually turned off for a touchpad that is located in or near bedrooms, to avoid disturbing sleeping persons.

➤ **To turn Key Beeps on or off:**

1. With the display showing the desired touchpad, press # then A or B until the display shows *KEYPAD OPTIONS*. Next, press # then A or B until the display shows *KEY BEEPS OFF/ON (current setting)*.
2. Press 1 (off) or 2 (on) to select the desired setting. The display flashes the entered selection. Press # and the display shows the new setting.

Freeze Temp (Acc. Modules—Bus Devices—Unit ID—Energy Options)

(Default = 42°F) This setting determines the temperature point that the Energy Saver Module detects a potential freeze (heating failure) condition. The adjustable range is from 40° to 90°F.

➤ **To change the Freeze Temp setting:**

1. With the display showing the desired bus device press #, then A or B until the display shows *ENERGY OPTIONS*. Next, press # then A or B until the display shows *FREEZE TEMP nn DEGREES (current setting)*.
2. Enter the desired freeze temperature (40°–90° F). The display flashes the entered selection. Press # and the display shows the new setting.

Temperature (Acc. Modules—Bus Devices—Unit ID—Energy Options)

(Default = none) This setting lets you adjust the Energy Saver Module (ESM) room temperature setting to match the premises thermostat. The adjustable range is from 40°–90°F.

➤ **To change the ESM Temperature setting:**

1. With the display showing the desired bus device press #, then A or B until the display shows *ENERGY OPTIONS*. Next, press # and then A or B until the display shows *TEMPERATURE nn DEGREES (current setting)*.
2. Enter the desired temperature (40°–90° F). The display flashes the entered selection. Press # and the display shows the new setting.

Note

To ensure accuracy, wait at least 15 minutes before setting the ESM temperature to allow the ESM to warm or cool to actual room temperature.

Cellular System (Acc. Modules—Bus Devices—Unit ID—Cellular Options)

(Default = B) This setting determines the cellular transmission system (A or B) used for cellular communication. This information is provided by the cellular provider based on installation ZIP code.

➤ **To set the Cellular System:**

- ◆ With the display showing the desired bus device press 1, (B) or 2 (A). The display flashes the entered selection. Press # and the display shows the new setting.

The following describes how to program the settings that appear under *SNAPCARDS*.

Output Programming (Acc. Modules—SnapCards—Output Programming) (101001—output 1, 101011—output 2, 101021—output 3, 101031—output 4)

(Defaults: Partition Assign = all 1, Configuration Output 1 = 01400, Output 2 = 00410, Output 3 = 00903, Output 4 = 01003) This setting lets you assign a partition and a 5-digit configuration number for each SnapCard relay output. This number determines both which system event activates the output and the duration or time the output is activated.

1. Partition: the system partition (1 or 2).
2. Configuration number: The combination of a trigger and a response.

Trigger: the event that activates the output point. Trigger events can be partition alarms, trouble conditions, open sensors, etc. (see Appendix B: Reference Tables).

Response: how the output responds when trigger event occurs (see Appendix B: Reference Tables).

This section describes how to program each of the output point configurations into the security panel. The point configuration number is *ttrr*, where *t* is the trigger number and *r* is the response number.

➤ **To assign configuration numbers to SnapCard Relay outputs:**

1. With the display showing *SNAPCARDS*, press #. Then press A or B until the display shows *OUTPUT PROGRAMMING*.
2. Press # again and the display shows *OUTPUT 1*.
3. Press A or B to select the desired output (1–4), then press #.
4. With the display showing *PARTITION ASSIGN 1*, press 1 or 2 to select the desired partition. Press # to confirm the partition.
5. Press A or B until the display shows *CONFIGURATION ttrr* (current setting).
6. Enter the desired 5-digit configuration number for this relay. Press # to confirm the setting.
7. Press # and repeat steps 3 through 6 until all outputs are programmed.

Output Text (Acc. Modules—SnapCards—Output Text) (10110—output 1, 10111—output 2, 10112—output 3, 10113—output 4)

(Default = none) Entering text for an output allows the user to control it directly or by schedule. Use the following guidelines to “name” SnapCard outputs:

- Use the item numbers that appear in “Appendix B, Table B2” for characters and words listed there.
- If a desired word does not appear in Table B2, create it using the characters (custom text).
- When using words from Table B2, spaces between them appear automatically. When using characters from Table B2 to create words, you must reserve an item number for a ‘space’ after the word.
- Each character or word uses up one item number. For example, a word from the list counts as one item number. A created word (such as BOY’S) counts as six item numbers—4 letters, 1 apostrophe, and 1 space.
- Only 16 item numbers are allowed for each output name, so plan ahead before programming output text. You may need to abbreviate words to avoid running out of item numbers.

➤ **To program Output Text:**

1. With the display showing *SNAPCARDS*, press #, then A or B until the display shows *OUTPUT TEXT*.
2. Press # and the display shows *OUTPUT 1*.
3. Press A or B until the desired output number is displayed.
4. Press # and the display shows: *OUTPUT N ITEM 00* - . Where *ITEM 0* is the first character/word location and *0* is the character/word number.
5. Enter the number of the desired character or word, or scroll through the numbers by pressing B (forward) or A (backward). If you make a mistake, simply enter the correct number or continue scrolling through choices.

Note

If you desire an output for User Output Control you must use the Output Text feature to name the output. If no Output Text is programmed, the user will not have access to the output.

6. Press # to accept the displayed choice and the display shows: *OUTPUT N ITEM 1 0 -*.
7. Repeat steps 4 and 5 as needed to complete the output name.
8. Press * after entering the last character or word number. The display shows the complete text name. For example: *OUTPUT 1 GARAGE DOOR*.

Onboard Options Menu

The *ONBOARD OPTIONS* menu lets you set up the following built-in options:

- *INPUTS*—This menu lets you turn the Smoke Verification and the Two Wire Smoke features off or on.
- *OUTPUT PROGRAMMING*—This menu lets you set configuration numbers for the two built-in panel outputs and assign the outputs to partitions.
- *OUTPUT TEXT*—This menu lets you assign text to the output allowing the output to be controlled by the user.

The following sections describe the settings that appear under *ONBOARD OPTIONS—INPUTS*.

Smoke Verify (Onboard Options—Inputs) (1100)

(Default = off) This setting determines whether the panel requires one alarm signal (off) or two alarm signals (on) within five minutes before activating system sirens and reporting to a central station. This setting affects 2-wire and 4-wire smoke detectors connected to SnapCard or onboard zone inputs that are learned into sensor group 26 (FIRE).

➤ **To turn Smoke Verify off or on:**

1. With the display showing *ONBOARD OPTIONS*, press # twice. The display shows *SMOKE VERIFY OFF/ON (current setting)*.
2. Press 1 (off) or 2 (on). The display flashes the entered number. Press # and the display shows the new setting.

Two Wire Smoke (Onboard Options—Inputs) (1101)

(Default = off) This setting determines how onboard hardwire zone 8 is configured. When this setting is on, zone 8 will be configured for two wire smoke detectors. When off, it will be configured for a normal hardwire input.

➤ **To turn Two Wire Smoke off or on:**

1. With the display showing *ONBOARD OPTIONS*, press # twice. The display shows *SMOKE VERIFY OFF/ON (current setting)*.
2. Press A or B until the display shows *TWO WIRE SMOKE ON/OFF (current setting)*.
3. Press 1 (off) or 2 (on). The display flashes the entered number. Press # and the display shows the new setting.

The following sections describe the settings that appear under *ONBOARD OPTIONS—OUTPUT PROGRAMMING*.

Output 1, 2 (Onboard Options—Output—Programming) Output 1: partition assign—11100, configuration—11101 Output 2: partition assign—11110, configuration—11111

(Defaults: Output 1 = Ptn 1, 01614; Output 2 = Ptn. 1, 01710) This setting lets you assign the partition and the 5-digit configuration number. The configuration number determines

- which system event activates the selected output, and
- the duration or time the output is activated.

The first three digits represent the trigger number of an event (such as triggering an alarm, opening a sensor, or arming the system). The last two digits represent how the output responds (such as momentary switching, maintained (or latched) switching, or switching for a preset time).

Use the system event trigger and response numbers listed in Appendix B: Reference Tables.

➤ **To set up onboard Output 1 & 2 partition and configuration assignments:**

1. With the display showing *ONBOARD OPTIONS*, press # + B. The display shows *OUTPUT PROGRAMMING*.
2. Press # and the display shows *OUTPUT 1*. Press B to select *OUTPUT 2*.
3. Press # and the display shows *PARTITION ASSIGN n (current setting)*.
4. Press 1 or 2 to assign the output to the desired partition, then press #. The display shows *PARTITION ASSIGN (new setting)*.

Note

For California State Fire Marshall (CSFM) Listed installations, Smoke Verify must be set to off.

Note

If you want to configure an output for user Output Control you must use the Output Text feature to name the output. If no Output Text is programmed, Output Control will not function for that output.

5. Press B and the display shows *CONFIGURATION ttrr* (current setting).
6. Enter the desired configuration number. The display flashes the entered number. Press # and the display shows the new setting.
7. Press # and repeat steps 2 through 6 until all outputs are programmed.

**Output Text (Onboard Options—Output Text—Output 1, 2)
(1120—output 1, 1121—output 2)**

(Default = none) Use the following guidelines to “name” onboard outputs:

- Use the item numbers listed in “Appendix B, Table B2” for characters and words.
- If a desired word does not appear in Table B2, create it using the characters (custom text).
- When using words from Table B2, spaces between them appear automatically. When using characters from Table B2 to create words, you must reserve an item number for a ‘space’ after the word.
- Each character or word uses up one item number. For example, a word from the list counts as one item number. A created word (such as BOY’S) counts as six item numbers—4 letters, 1 apostrophe, and 1 space.
- Only 16 item numbers are allowed for each output name, so plan ahead before programming output text. You may need to abbreviate words to avoid running out of item numbers.

➤ **To program Output Text:**

1. With the display showing *ONBOARD OPTIONS*, press # then press B twice and the display shows *OUTPUT TEXT*.
2. Press # and the display shows *OUTPUT 1*.
3. Press # and the display shows: *OUTPUT 1 ITEM 0 0 -*. Where *ITEM 0* is the first character or word location and *0* is the character or word number.
4. Enter the number of the desired character or word, or scroll through the numbers by pressing B (forward) or A (backward). If you make a mistake, simply enter the correct number or continue scrolling through choices.
5. Press # to accept the displayed choice and the display shows: *OUTPUT 1 ITEM 1 0 -*.
6. Repeat steps 4 and 5 as needed to complete the output name.
7. Press * after entering the last character or word number. The display shows the complete text name. For example: *OUTPUT 1 GARAGE DOOR*.

Note

If you want to configure an output for user Output Control you must use the Output Text feature to name the output. If no Output Text is programmed, Output Control will not function for that output.

Exiting Programming Mode

After all installer/dealer programming is completed, use the following procedure to exit programming mode.

➤ **To exit programming mode:**

1. Press * until the display shows *SYSTEM PROGRAMMING*.
2. Press A or B until the display shows *EXIT PROGRAMMING READY*.
3. Press # and the touchpad displays the *TIME AND DATE*.

Entering User Programming Mode

The user programming mode lets you view system version information and program the following system settings:

- Time and Date
- User Codes
- Options
- Set Up Schedules
- Attach Schedules to Events
- Energy Saver
- Attach Lights to Sensors
- System Version

You can enter user programming from an alphanumeric or fixed display touchpad by using the system or partition master code. The default system master code is 1234.

➤ **To enter user-programming mode:**

- ◆ Press 9 + CODE. The display shows *TIME AND DATE*.

Note

Setting the time and date is important for accurate tracking of system events stored in the event buffer.

Time and Date Menu

The panel uses a global clock and calendar for time and date. Alphanumeric touchpads display the panel time and date whenever the system is disarmed.

The *TIME AND DATE* menu lets you set this clock and calendar. The following procedures tell you how.

Time (Time and Date) (020)

(Default = 00:00) This setting lets you adjust the panel clock to the correct time. The panel uses a 24-hour clock. For example, to set the time to 4:17 P.M., enter 1617.

➤ To set the Time:

1. With the display showing *TIME AND DATE*, press # and the display shows *TIME hh:mm (current time)*.
2. Enter the correct time (0000–2359). The display flashes the entered time. Press # and the display shows the new time.

Date (Time and Date) (021)

(Default = 01/01/00) This setting lets you adjust the panel calendar to the correct month, day, and year.

➤ To set the Date:

1. With the display showing *TIME AND DATE*, press #, then A or B until the display shows *DATE nn/nn/nn (current date)*.
2. Enter the correct month (01–12), day (01–31), and year (00–99). For example, enter 090100 for September 1, 2000. The display flashes the entered date. Press # and the display shows the new date.

User Codes Menu

The *USER CODES* menu lets you program/change regular user access codes, partition master codes, and the system master code. You can enter up to 60 separate user codes, allowing up to 60 different “users” access to the security system. You can also specify whether or not a specific user is able to perform specific actions like, bypass sensors or test the system.

User NN (User Codes—Reg. User Codes—User NN) (030nn0 where nn=user number 00-59)

(Default = none) User codes perform basic arming and disarming functions. The system allows up to 60 user codes (user numbers 00–59). User numbers that show indicate no code is currently programmed for that user number.

➤ To program Regular User Codes:

1. With the display showing *USER CODES*, press # and the display shows *REGULAR USER CODES*.
2. Press # and the display shows *USER nn (first available user number)*.
3. Press A or B to select the desired user number, then press #. The display shows *USER nn - nnnn*.
4. With the desired user number displayed, enter a 4-digit user code. The display flashes the entered code. Press # and the display shows *USER nn - nnnn (new code)*.

➤ To delete Regular User Codes:

1. With the display showing *USER CODES*, press # and the display shows *REGULAR USER CODES*.
2. Press # and the display shows *USER nn - nnnn (first available user number)*.
3. Press A or B to select the desired user number/user code you want to delete (if it is not already displayed), then press #. The display shows *USER nn - nnnn*.
4. Enter the system or partition master code. The display flashes the entered code. Press # and the display shows *USER nn -- **** (no code)*.

Direct Bypassing (User Codes—Reg. User Codes—User NN) (030nn1 where nn=user number 00-59)

(Default = off) This setting determines whether or not a specific user code provides access to the “bypass sensors” feature. Set this feature to “on” for all users who need to be able to bypass sensors.

➤ To turn user code Direct Bypassing off or on:

1. With the display showing *USER CODES*, press # and the display shows *REGULAR USER CODES*.
2. Press # and the display shows *USER nn* (*first available user number*).
3. Press A or B to select the desired user number, then press #. The display shows *USER nn - nnnn*.
4. Press A or B until the display shows *DIRECT BYPASSING OFF/ON* (*current setting*).
5. Press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

**Remote Access (User Codes—Reg. User Codes—User NN)
(030nn2 where nn=user number 00-59)**

(Default = off) This setting determines whether or not the user can access the panel from a remote phone (a phone located off the premises).

➤ **To turn user code Remote Access off or on:**

1. With the display showing *USER CODES*, press # and the display shows *REGULAR USER CODES*.
2. Press # and the display shows *USER nn* (*first available user number*).
3. Press A or B to select the desired user number, then press #. The display shows *USER nn - nnnn*.
4. Press B until the display shows *REMOTE ACCESS ON/OFF* (*current setting*).
5. Press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

**Partition Jump (User Codes—Reg. User Codes—User NN)
(030nn3 where nn=user number 00-59)**

(Default = off) This setting determines whether or not a specific user code can access one or both partitions. When this is set to on, the user can access both partitions.

➤ **To turn user code Partition Jump off or on:**

1. With the display showing *USER CODES*, press # and the display shows *REGULAR USER CODES*.
2. Press # and the display shows *USER nn* (*first available user number*).
3. Press A or B to select the desired user number, then press #. The display shows *USER nn - nnnn*.
4. Press B until the display shows *PARTITION JUMP OFF/ON* (*current setting*).
5. Press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

**System Tests (User Codes—Reg. User Codes—User NN)
(030nn4 where nn=user number 00-59)**

(Default = off) This setting determines whether or not a specific user code provides access to the phone and sensor tests. Set this feature to “on” for all users who need to be able to conduct phone and sensor tests.

➤ **To turn user code System Tests off or on:**

1. With the display showing *USER CODES*, press # and the display shows *REGULAR USER CODES*.
2. Press # and the display shows *USER nn* (*first available user number*).
3. Press A or B to select the desired user number, then press #. The display shows *USER nn - nnnn*.
4. Press A or B until the display shows *SYSTEM TESTS OFF/ON* (*current setting*).
5. Press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

**Latchkey Report (User Codes—Reg. User Codes—User NN)
(030nn5 where nn=user number 00-59)**

(Defaults: 00–05 = on, 06–59 = off) This setting determines whether or not the user code causes a latchkey report to be sent to a pager when the code is used to change arming levels.

➤ **To assign the Latchkey Report attribute to user codes:**

1. With the display showing *USER CODES*, press # and the display shows *REGULAR USER CODES*.
2. Press # and the display shows *USER nn* (*first available user number*).
3. Press A or B to select the desired user number, then press #. The display shows *USER nn - nnnn*.
4. Press A or B until the display shows *LATCHKEY OFF/ON* (*current setting*).
5. Press 1 (off) or 2 (on). The display flashes the entered setting. Press # and the display shows the new setting.

**Partition Master (User Codes—Partition Master Code)
(partition 1: 0310, partition 2: 0311)**

(Default = none) The Partition Master Code provides access to all system operations and user programming *for a single partition*.

Note

You must be “in” the partition of the partition master code you wish to change.

➤ **To change the Partition Master Code:**

1. With the display showing *USER CODES*, press # then A or B until the display shows *PARTITION MASTER CODE*.
2. Press # and the display shows *PARTITION nnnn (current code)*.
3. Enter a new 4-digit code. The display flashes the entered code. Press # and the display shows the new code.

**System Master (User Codes—System Master Code)
(0320)**

(Default = 1234) The System Master Code provides access to all system operations and user programming.

➤ **To change the System Master Code:**

1. With the display showing *USER CODES*, press # then A or B until the display shows *SYSTEM MASTER CODE*.
2. Press # and the display shows *SYSTEM MASTER nnnn (current code)*.
3. Enter a new 4-digit code. The display flashes the entered code. Press # and display shows the new code.

Options Menu

The *OPTIONS* menu lets you set up the system for downloading and silent arming. You can also adjust alphanumeric touchpad display brightness from this menu.

**Downloading (Options)
(040)**

(Default = on) When this setting is on, the panel can communicate with ToolBox[®] software for programming the system from off-site.

➤ **To turn Downloading off or on:**

1. Press A or B until the display shows *OPTIONS*.
2. Press #, then A or B until the display shows *DOWNLOADING OFF/ON (current setting)*.
3. Press 1 (off) or 2 (on). The display flashes the entered selection. Press # and the display shows the new setting.

**Silent Arming (Options)
(041)**

(Default = off) This setting determines whether or not the panel sounds status beeps from sirens and the touchpad when the system is armed.

➤ **To turn Silent Arming off or on:**

1. Press A or B until the display shows *OPTIONS*.
2. Press #, then A or B until the display shows *SILENT ARMING OFF/ON (current setting)*.
3. Press 1 (off) or 2 (on). The display flashes the entered selection. Press # and the display shows the new setting.

**Touchpad Brightness (Options)
(042)**

(Default = 2) This setting lets the user lighten or darken the background on touchpad displays. Each touchpad can be set to compensate for lighting conditions in the touchpad location.

➤ **To adjust Touchpad Brightness:**

1. Press A or B until the display shows *OPTIONS*.
2. Press #, then A or B until the display shows *TOUCHPAD BRIGHTNESS n (current setting)*.
3. Enter a setting from 0 (darkest background) to 3 (brightest background). The display flashes the entered selection. Press # and the display shows the new setting.

**Volume (Options)
(043)**

(Default = 4) This setting determines the volume level of status sounds from speakers connected to the Phone Interface/Voice Module.

Note

For this feature to work, the panel must be connected to a phone line and be programmed with *REMOTE ACCESS on*, with a *Downloader phone number*, and with a *Downloader code*.

Note

When this feature is on, the user does not need to press 5 (*SILENT*) before arming the system to prevent status sounds.

Note

This menu appears only if a Phone Interface/Voice Module is connected to the panel.

➤ **To adjust status sound Volume:**

1. Press A or B until the display shows *OPTIONS*, then press #.
2. Next, press A or B until the display shows *VOLUME n (current setting)*.
3. Enter a setting from 0 (off) to 7 (loudest). The display flashes the entered selection. Press # and the display shows the new setting.

Voice Chime (Options)
(044)

(Default = on) This setting determines whether speakers connected to the Phone Interface/Voice Module announce perimeter sensor/zone numbers that are tripped when the Chime feature is on. For example, “Sensor one open.”

➤ **To turn Voice Chime off or on:**

1. Press A or B until the display shows *OPTIONS*.
2. Press # then A or B until the display shows *VOICE CHIME OFF/ON (current setting)*.
3. Press 1 (off) or 2 (on). The display flashes the entered selection. Press # and the display shows the new setting.

Chime On Close (Options)
(045)

(Default = off) When this setting is on, the panel sounds a single chime when a perimeter door or window is closed.

➤ **To turn Chime On Close off or on:**

1. Press A or B until the display shows *OPTIONS*.
2. Press # then A or B until the display shows *CHIME ON CLOSE OFF/ON (current setting)*.
3. Press 1 (off) or 2 (on). The display flashes the entered selection. Press # and the display shows the new setting.

Set Up Schedules Menu

The *SET UP SCHEDULES* menu lets you set up time frames for light control and exception opening/closing reports. The system (all partitions) allows you to set up to 16 schedules (00–15).

Setting up schedules consists of setting a start and stop time for each schedule, then selecting which days of the week the schedule will be active. You can also set up a *rollover* schedule, which starts on one day and ends on another day. This saves programming time and leaves more schedules available (in case they are needed later).

Rollover Schedule Example: To set up a schedule to rollover from Tuesday evening to Wednesday morning, set a schedule start time for 2200 (10:00 P.M.) and a stop time for 0500 (5:00 A.M.). Set the schedule to turn on Tuesday. Because the stop time is set for morning, the system automatically carries the schedule over to the next day.

If you use the same start and stop times described above and set the schedule to turn on Monday through Friday, then one schedule will cover the entire week.

Set Up Schedules

(05XXY, where XX = schedule 00 thru 15 and Y = start [0]/stop[1] 0 thru 8—Monday thru Sunday [2–8])

(Default = 00:00) This menu lets you set up start/stop times for each day of the week.

➤ **To set up a Time Schedule:**

1. Press A or B until the display shows *SET UP SCHEDULES*.
2. Press # and the display shows *SCHEDULE 00*. If you want a different schedule number, press A or B until the desired schedule number appears.
3. Press # and the display shows *START TIME hh:mm (current setting)*.
4. Enter the desired starting time (00:00–23:59). The display flashes the entered time. Press # and the display shows *START TIME hh:mm (new setting)*.
5. Press B and the display shows *STOP TIME hh:mm (current setting)*.
6. Enter the desired stop time (00:00–23:59). The display flashes the entered time. Press # and the display shows *STOP TIME hh:mm (new setting)*.
7. Press B and the display shows *MONDAY OFF/ON (current setting)*. To select a different day, continue pressing B until the desired day appears.
8. Press 1 (off) or 2 (on). The display flashes the entered selection. Press # and the display shows the new setting for the selected day.
9. Repeat steps 7 and 8 until all desired settings for each day are set.

Note

If you are programming schedules for your customer, be sure to record the settings in the User's Manual

Attach Schedules to Events Menu

The *ATTACH SCHEDULES TO EVENTS* menu lets you link the following system events to time schedules:

- **Latchkey Opening**—sends a report if system is disarmed within the attached time schedule.
- **Latchkey Closing**—sends a report if system is armed within the attached time schedule.
- **Exception Opening**—sends a report if system is not disarmed within the attached time schedule.
- **Exception Closing**—sends a report if system is not armed within the attached time schedule.
- **Lights (1–9)** activate X-10 controlled lights by the attached time schedule.
- **Outputs (1–6)** allow users to attach onboard (1–2) and SnapCard outputs to a schedule.
- **Arming**—Allows the user to arm the panel at the schedule start time.

Latchkey Reports (Attach Schedules To Events)

(060nn—Opening, 061nn—Closing where nn = Schedule number [0 to 15])

(Default = off) This setting lets you attach the Latchkey Opening report feature and the Latchkey Closing report feature to time schedules.

➤ **To Attach a Schedule to Latchkey Opening or Latchkey Closing:**

1. Press A or B until the display shows *ATTACH SCHEDULES TO EVENTS*.
2. Press # then A or B until the display shows *LATCHKEY OPENING OR LATCHKEY CLOSING*.
3. Press # and the display shows *SCHEDULE 00 OFF/ON (current setting)*. If you want a different schedule, press A or B until the desired schedule appears.
4. Press 1 (off) or 2 (on). The display flashes the entered selection. Press # and the display shows the new setting for the selected schedule.

Exception Reports (Attach Schedules To Events)

(062nn—Opening, 063nn—Closing, where nn = Schedule number [0 to 15])

(Default = off) This setting lets you attach the Exception Opening report feature and the Exception Closing report feature to time schedules.

➤ **To Attach a Schedule to Exception Opening or Exception Closing:**

1. Press A or B until the display shows *ATTACH SCHEDULES TO EVENTS*.
2. Press # then A or B until the display shows *EXCEPTION OPENING OR EXCEPTION CLOSING*.
3. Press # and the display shows *SCHEDULE 00 OFF/ON (current setting)*. If you want a different schedule, press A or B until the desired schedule appears.
4. Press 1 (off) or 2 (on). The display flashes the entered selection. Press # and the display shows the new setting for the selected schedule.

Lights (Attach Schedules To Events)

(064xnn where nn = Schedule number [0 to 15] and x = light number [1 to 9] minus 1)

(Default = off) This setting lets you attach light controls to a time schedule.

➤ **To Attach Schedules to Lights:**

1. Press A or B until the display shows *ATTACH SCHEDULES TO EVENTS*.
2. Press # then A or B until the display shows *LIGHTS*. Press # to enter the *LIGHTS* menu.
3. Press A or B until the desired light appears.
4. Press # and the display shows *SCHEDULE 00 OFF/ON (current setting)*. If you want a different schedule, press A or B until the desired schedule appears.
5. Press 1 (off) or 2 (on). The display flashes the entered selection. Press # and the display shows the new setting for the selected schedule.
6. Repeat steps 3, 4, and 5 until all desired lights are attached to schedules.

Outputs (Attach Schedules To Events)

(065xnn where nn = Schedule number [0 to 15] and x = output number [1 to 6] minus 1)

(Default = off) This setting lets you attach outputs to a time schedule. Onboard outputs are 1–2, SnapCard outputs are 3–6.

➤ **To Attach Schedules to Outputs:**

1. Press A or B until the display shows *ATTACH SCHEDULES TO EVENTS*.
2. Press # then A or B until the display shows *OUTPUTS*. Press # to enter the *OUTPUTS* menu.
3. Press A or B until the desired output appears.
4. Press # and the display shows *SCHEDULE 00 OFF/ON (current setting)*. If you want a different schedule, press A or B until the desired schedule appears.

Note

Outputs can only be scheduled if text has been entered in installer programming. Only onboard and SnapCard outputs can be scheduled.

5. Press 1 (off) or 2 (on). The display flashes the entered selection. Press # and the display shows the new setting for the selected schedule.
6. Repeat steps 3, 4, and 5 until all desired outputs are attached to schedules.

**Arming (Attach Schedules To Events)
(0660nn where nn = Schedule number [0 to 15])**

(Default = off) This setting lets you arm according to a time schedule.

➤ **To Attach Schedules to Arming:**

1. Press A or B until the display shows *ATTACH SCHEDULES TO EVENTS*.
2. Press # then A or B until the display shows *ARMING*.
3. To select arm to AWAY press #.
4. Press # and the display shows *SCHEDULE 00 OFF/ON (current setting)*. If you want a different schedule, press A or B until the desired schedule appears.
5. Press 1 (off) or 2 (on). The display flashes the entered selection. Press # and the display shows the new setting for the selected schedule.
6. Repeat steps 4 and 5 until all desired schedules are attached.

Energy Saver Menu

The *ENERGY SAVER* menu lets you set the energy saver module low- and high-setpoints. These setpoints determine when the module relay closes, thereby completing the circuit through the thermostat to the furnace/air-conditioner.

**Low Setpoint (Energy Saver)
(070)**

(Default = 50°F) This setting determines the temperature at which the energy saver module relay closes to activate the furnace.

➤ **To set the Low Setpoint:**

1. With the display showing *ENERGY SAVER*, press #, then A or B until the display shows *LOW SETPOINT nn DEGREES (current setting)*.
2. Enter the desired temperature (45–89°). The display flashes the entered setting. Press # and the display shows the new setting.

**High Setpoint (Energy Saver)
(071)**

(Default = 90°F) This setting determines the temperature at which the energy saver module relay closes to activate the air-conditioner.

➤ **To set the High Setpoint:**

1. With the display showing *ENERGY SAVER*, press #, then A or B until the display shows *HIGH SETPOINT nn DEGREES (current setting)*.
2. Enter the desired temperature (46–90°). The display flashes the entered setting. Press # and the display shows the new setting.

Attach Lights to Sensors Menu

The *ATTACH LIGHTS TO SENSORS* menu lets you assign a light number to a sensor. Each time the sensor is activated, the attached light will turn on for 5 minutes. When the 5 minute timer expires the light will turn off. If the same light is scheduled, it will only turn on during the schedule time

**Light x to Sensor Y (Attach Lights to Sensors)
(08n where n = light number [1–9] minus 1)**

(Default = 0) This menu attaches light x to sensor y. Each time a selected sensor is tripped, the selected light will turn on and a 5 minute timer will start.

➤ **To attach a light to a sensor:**

1. With the display showing *LIGHT 1 TO SENSOR y (current setting)*, press A or B to select the desired light number.
2. Enter the desired sensor number (01–76). The display flashes the entered setting. Press # and the display shows the new setting.
3. Repeat steps 1 through 2 until all desired lights are attached to sensors.

➤ **To detach a light from a sensor:**

1. With the display showing *LIGHT 1 TO SENSOR y (current setting)*, press A or B to select the desired light number.
2. Enter 0 as the sensor number and press #.

Note

This setting will allow you to arm to AWAY only. There is no disarm schedule.

Note

The low setpoint cannot be set equal to or higher than the high setpoint.

Note

The high setpoint cannot be set equal to or lower than the low setpoint.

Note

The sensor must be learned into the current partition before it can be attached.

System Version Menu

The *SYSTEM VERSION* menu lets you view and identify panel hardware and software. This information is primarily used for troubleshooting purposes.

System Version

(010 = factory code, 011= system number, 012= system level)

(Default = N/A) This menu lets you view and identify panel hardware and software version.

➤ **To view and identify the System Version:**

1. Press A or B until the display shows *SYSTEM VERSION*.
2. Press # and the display shows *FACTORY CODE nnn*nnnn*.
3. Press B and the display shows *SYSTEM NUMBER *nnnnnnnn*.
4. Press B again and the display shows *SYSTEM LEVEL nnnn*.

Downloader Programming

The panel can be programmed remotely using ToolBox. Use the information you recorded in Appendix A to inform the downloading operator of the programming requirements for this system.

ToolBox Downloader Programming

➤ **To initiate a ToolBox download session:**

1. Contact your download station and ask the operator to prepare to download to the panel.
2. Make sure the system is disarmed.
3. Press 8 + system master code + 7 + 0 (any), 1 (down), or 2 (up). The display shows *SYSTEM DOWNLOAD IN PROGRESS* during the downloading process.

If the alphanumeric touchpad does not display *SYSTEM DOWNLOAD IN PROGRESS*, call the downloader operator to verify the downloader phone number. Also, make sure ToolBox is set up properly. Refer to the “Troubleshooting” section if the problem persists.

Note

A Downloader Phone Number must be programmed and the user-programmable option “Downloading” must be on for remote downloader programming to work.

Testing the System

Note

Before testing, it is recommended that you have covers on all modules (mounted outside the cabinet) and the panel cabinet door closed. The testing environment should match the system working environment.

This section describes the following:

- Basic System Commands
- Testing Zones/Sensors
- Testing Phone Communication
- Testing Central Station Communication
- Testing Outputs and Sirens
- Testing Light Control
- Testing the Energy Saver Module
- Changing Fixed Display Touchpads
- Testing the Audio Verification Module
- Testing Cellular Backup Communication

You should test the system after installing or servicing and after adding or removing devices from the system.

Refer to the “Troubleshooting” section if correct test results are not achieved.

Basic System Commands

Table 9 describes basic touchpad operating commands. For complete details on system operation, including user programming, refer to the system *User’s Manual*.

Table 9: Basic Touchpad Commands

Command	System Response
* (STATUS)	Indicates current system status
* + *	Indicates AC power and battery status
1 + CODE	Disarms system to OFF
2 + CODE	Arms system to STAY
3 + CODE	Arms system to AWAY
2 (quick arm on)	Arms system to STAY

Table 9: Basic Touchpad Commands (Continued)

Command	System Response
3 (quick arm on)	Arms system to AWAY
2 or 3 + CODE + 4 or 2 or 3 + 4	Arm system—No Delay (no exit or entry delay)
5 + 2 or 3 + CODE or 5 + 2 or 3	Arms system silently (no arming status beeps)
7 + 1	Turns chime feature on and off
7 + 2	Turns Energy Saver on and off
7 + 6	Identifies alarms in memory
7 + 7 + n (n = output number [1–6]) 1–2 = onboard outputs 3–6 = module outputs	Turns the output on or off. (This command is only functional after output text is entered into panel memory.)
8 + CODE + 6	Partition jump
8 + CODE + 2	Initiates a phone test
8 + CODE + 3	Initiates a sensor test
8 + installer CODE + 3	Initiates a dealer sensor test

Testing Zones/Sensors

Test sensors/zones after all programming is completed, whenever there is a change in environment, equipment, or programming, and whenever a zone- or sensor-related problem occurs.

If the system does not respond as described in the following procedure, see the “Troubleshooting” section.

Note

While the sensor test is a valuable installation and service tool, it only tests sensor operation for the current conditions. You should perform a sensor test after any change in environment, equipment, or programming.

1. Place all sensors and zones in their non-alarm state.
2. At an alphanumeric touchpad, enter the sensor test mode by pressing 8 + installer code + 3. The touchpad sounds one beep and displays *SENSOR TEST*. The panel starts a 15 minute timer.
3. Trip each zone/sensor one at a time. Touchpads (and interior sirens) should sound one short, high-pitched beep and the display should show the sensor name (or number) and *OK*.
4. Press the STATUS button when you think all zones/sensors are tested. The touchpad displays any untested sensors/zones and touchpad panics. If all sensors/zones and touchpad panics have been tested, the display shows *SENSOR TEST OK*.
5. Test any untested zones/sensors and touchpad panics.
6. The system stays in sensor test mode for 15 minutes. When less than 5 minutes remain, touchpads and interior sirens beep and the panel announces the remaining time over the speakers once every minute. After 15 minutes the panel disarms to *OFF*, automatically. If you need more time to complete the sensor test, press 8 + installer CODE + 3 while the system is still in sensor test mode. This restarts the 15 minutes of test time.
7. When all sensors/zones and touchpad panics have been tested, press 1 + installer CODE to exit sensor test mode.

Note

If you hear a long, low-pitched beep, proceed to the following section “If a Wireless Sensor Does Not Test.”

If a Wireless Sensor Does Not Test

If touchpads display *SENSOR FAILURE* and sirens sound a long, low-pitched beep when a zone or sensor is tripped, this indicates that the wireless sensor signal strength is below acceptable limits. Distance from the receiver, the installation environment, or both, are most likely affecting the sensor signal strength.

When possible, locate wireless sensors within 100 feet of the panel. While a transmitter may have a range of 1,000 feet or more out in the open, the environment at the installation site can have a significant effect on transmitter range. Refer to the “Troubleshooting” section to resolve the problem.

For wireless sensors that don’t respond, use an RF Sniffer (60-401) test tool to verify that the sensor is transmitting. Constant beeps from the RF Sniffer indicate a runaway (faulty) sensor. Remove the sensor battery(s) and replace the sensor.

Testing Phone Communication

Perform a phone test to check the phone communication between the panel and the central monitoring station.

➤ **To perform a phone test:**

1. Contact the central monitoring station to inform them that you are testing the system.
2. Press 8 + system master CODE + 2. The display reads *PHONE TEST* and the touchpad sounds one beep. When the panel completes the test, the system returns to the previous arming level automatically.

If the display continues to show *PHONE TEST* for 1½ minutes or more, enter 1 + system master CODE and refer to the “Troubleshooting” section.

Testing Central Station/Pager Communication

After performing sensor and phone tests, check that the system is reporting alarms successfully to the central station or pager.



Be sure to contact the central monitoring station *before* activating outputs that trigger from an alarm condition.

Caution

Note

The way information is displayed varies with pager services and may not match the example above. Account numbers with alpha-characters also vary when displayed, depending on pager service. Account numbers are not displayed if STREAMLINING is turned on.

➤ **To test communication with the central station/pager:**

1. Call the central station and tell the operator that you will be testing the system.
2. Arm the system.
3. Test each of the touchpad and wireless panic buttons and trip at least one sensor of each type (fire, intrusion, etc.) to verify correct operation.
4. Check pager displays to verify reports are received. Pagers display an event code, digit sensor number, and the last four digits of the account number. For example, a pager display of 999 002 7468 indicates the following:
999 = alarm condition,
002 = sensor/zone in alarm or user number,
7468 = last four digits of account number.
5. When you finish testing the system, call the central monitoring station to verify that the alarms were received.

Table 10 describes pager system event codes.

Table 10: Pager System Event Codes

Code	System Event
009	Zone Restoral
111	System Disarmed
115	Sensor Test Exit
118	Trouble condition cleared
119	Alarm Canceled
222	System Armed to STAY
333	System Armed to AWAY
555	Phone/Sensor Test
888	System Trouble Condition
999	System in Alarm

Table 11 describes pager sensor/zone number and user number report codes.

Table 11: Pager Sensor/Zone Code and Numbers

Code	Sensor/Zone or User Number
000	System event not caused by a zone or user
001–076	Sensor/Zone Numbers 1–76
600–659	Regular User Codes 0–59 used
678	System Master Code used

Table 11: Pager Sensor/Zone Code and Numbers

Code	Sensor/Zone or User Number
679	Installer Code used
680	Dealer Code used
697	Quick Arm used
698	Keyswitch Sensor used
699	System Armed Itself (during service or power-up)

Testing Outputs and Sirens

All outputs (onboard and SnapCard) should be tested to verify configuration programming.



Caution

Be sure to contact the central monitoring station *before* activating outputs that trigger from an alarm condition.

➤ **To test outputs:**

1. Contact the central monitoring station to inform them you are testing the system.
2. Verify that all wiring at the panel and output devices is correct.
3. Activate the appropriate device to trigger each output as programmed.
4. Verify that each output responds according to the programmed configuration number. For outputs that trigger sirens, verify that the correct alarm sounds are produced from these sirens. Table 12 describes the system alarm sounds you should hear for each alarm event.
5. Contact the central monitoring station when you are finished testing.

Table 12: System Alarm Sounds

Alarm Type	Alarm Sound
Fire	Repeating series of three beeps
Police/Intrusion	Continuous tone
Auxiliary	Rapid beeps

Testing Light Control

Test all lights plugged into X-10 Lamp Modules to verify house code and light number settings.

➤ **To test light control:**

1. Press 0 + 0 repeatedly to turn all lights on and off together.
2. Press 0 + 1 repeatedly to turn light 1 on and off.
3. Repeat step 2 for remaining lights (0 + 2 for light 2, 0 + 3 for light 3, etc.).
4. Arm the system to Away. All lights plugged into modules set to Unit 1 (or set as entry lights) should turn on and stay on for 5 minutes. All lights plugged into modules set to Unit 2 should blink three times to indicate the arming level. Remaining lights should not be affected.
5. Disarm the system. If Unit 1 (or entry) lights were on for an entry or alarm, they will turn off in 5 minutes. Unit 2 lights should blink once to indicate the system is off. Remaining lights should not be affected.
6. All lights should turn on and remain on during fire and auxiliary/medical alarms. All lights should flash during a police or intrusion alarm.

Testing the Energy Saver Module (ESM)

Test the Energy Saver Module to verify it overrides the thermostat.

➤ **To test the Energy Saver Module:**

1. Press * (status) + * (status) to display the system status, *ENERGY SAVER OFF*, and the present *TEMPERATURE nm°*. The temperature displayed (and/or announced) should match the house thermostat. If the temperatures do not match, refer to the *ACCESSORY MODULES—BUS DEVICES* menu in the “Programming” section.

Note

The system must have high- and low-temperature limits set to test the Energy Saver Module.

Note

There is a 5-minute delay after the Energy Saver Module returns control to the furnace/AC before it will override the furnace/AC again.

2. Press 7 + 2 to turn on the ESM. The display shows *ENERGY SAVER ON* and the ESM relay will click once.
3. Press 7 + 2 again to turn the ESM off. The display shows *ENERGY SAVER OFF*.

Changing Fixed Display LCD Touchpad Chime and Trouble Beep Tones

The frequency (pitch) of chime and trouble beep tones from a fixed display touchpad can be adjusted to a more desirable or distinct tone, or to compensate for hearing impaired persons.

➤ **To change status tone pitch:**

1. Press and hold the * and 0 buttons together until you hear a steady tone, then release the buttons.
2. Press and hold 1 to lower the pitch or press and hold 2 to raise the pitch.
3. Release the button when the desired pitch is heard.

After about 15 seconds of no touchpad activity, the steady tone stops sounding.

Adjusting Touchpad Display Contrast

Touchpad displays can be adjusted for easier viewing to help compensate for lighting conditions in the touchpad location. The contrast adjustment lightens or darkens the text.

➤ **To adjust display contrast:**

1. Enter configuration mode by pressing the D and 6 buttons together for at least two seconds. The display shows *DA nnn*.
2. Press and release the 1 and 2 buttons together repeatedly, until the desired contrast level is displayed.
3. Press * and the display briefly shows *DONE*, then shows the time and date.

Testing Audio Verification Module (AVM) Communication

Test the Audio Verification Module from off-site and the central station to verify that it works properly.

➤ **To test the module from off-site:**

You will need a helper and touch-tone phone at an off-site location to perform this test. When testing the AVM from off-site the following guidelines must be followed.

- The Remote Access feature must be set to on (default).
 - The Audio Verify feature must be set to on.
 - The system must be in a non-alarm state.
 - Optional Ring/Hang/Ring feature must be on (default) to work with steps 1 and 2 below. Otherwise wait for 12 rings and the panel will pick up automatically.
1. The off-site helper calls the panel, lets the phone ring twice, and hangs up.
 2. The helper must call the panel again in 10 to 40 seconds. The panel answers *System hello*.
 3. The helper dials the following on the phone, # 1234 # 8 (AVM access CODE) 5.
 4. The helper should now be able to hear you through the AVM.
 5. Walk through the vicinity of the AVM while speaking at a normal conversation level.
 6. Tell the helper to dial a 1 and speak to you. To return to listen mode, the helper dials a 3.
 7. When testing is complete, have the helper dial 99 and hang up.

➤ **To test the module with the central station:**

1. Inform the central station that you will be sending an alarm and testing an AVM.
2. Give them the programming selections you made for the panel (see “Audio Verification Menu” for programming information).
3. Use a touchpad panic button to initiate an auxiliary alarm.
4. The central station operator waits for the alarm to be reported and initiates an audio session.
5. Walk through the vicinity of the AVM while speaking at a normal conversation level.
6. Have the operator speak to you.
7. When testing is complete, the operator will end the session.

Testing Cellular Backup Communication

Perform this test to check the cellular communication between the panel and the central monitoring station.

Note

Chime and trouble beep tones sound using the default frequency during, or within 15 seconds of, any button activity at that specific touchpad.

Note

Vacuum fluorescent displays do not have a contrast adjustment.

Note

If the current settings do not match the test settings, record the current settings (Table 13), so that they can be restored when this test is complete.

➤ **To test Cellular Communication:**

1. Contact the central monitoring station to inform them that you are testing the system.
2. Install and activate the SuperBus 2000 Cellular Backup Module.
3. Verify or change the following CS PHONE 1 panel option settings.
4. Disconnect the phone line by unplugging the Db-8 cord from the RL-31X Jack.
5. Initiate a phone test (8 + System Master Code + 2).
6. The phone test attempt should fail via the phone line within 5 minutes. The panel will emit a long low tone (and speak “phone failure 1” if so equipped).
7. Wait for the phone test to succeed via the cell backup. The panel should emit a short high tone (and speak “phone test ok” if so equipped).
8. Verify the CS report.
9. If success does not occur, verify that the signal strength (RSSI) shown on the Cellular Backup Module is acceptable and repeat steps 5-8.
10. Restore previous CS PHONE 1 settings if needed.


Table 13: Current Phone Settings

CS PHONE 1 Option	Test Setting	Previous Setting
PHONE NUMBER	Central station phone number	
HIGH LEVEL RPTS	ON	
BACKUP	OFF*	
CELLULAR BACKUP	ON	

** Can be set to ON if no CS PHONE 2 PHONE NUMBER is programmed.*

Troubleshooting

This section describes what to do if you experience problems with system operation. If after performing the troubleshooting procedures the panel still malfunctions, please call Technical Support at 1-800-777-2624.

Feature	Problem	Action/Solution
Panel Power		
	Panel does not power up. Touchpads don't display or respond.	<ol style="list-style-type: none"> 1. Verify that the panel transformer is plugged into an unswitched outlet. 2. Check the AC circuit breaker to be sure the circuit is live. 3. Check that the backup battery is installed correctly and the AC power transformer is plugged in. 4. Check for proper panel and transformer wiring. 5. Measure the incoming AC voltage at panel terminals 1 and 2. It should read about 24 VAC.
	No incoming AC voltage at panel terminals 1 and 2.	<ol style="list-style-type: none"> 1. Unplug the AC power transformer and disconnect the wires from the transformer and the panel. 2. Check transformer to panel wire for short or open circuits. 3. Plug in the transformer and check for 24 VAC at the transformer unconnected terminals. If zero (0) volts, replace the transformer.
	Touchpad display indicates <i>System Low Battery</i> or voice sounds " <i>System low battery.</i> "	<ol style="list-style-type: none"> 1. Check that the backup battery is installed correctly and the AC power transformer is plugged in. 2. Measure the incoming AC voltage at panel terminals 1 and 2. It should read about 24 VAC. 3. Check for 11.75 to 13.5 VDC battery voltage between the backup battery spade lugs. If the battery voltage is not within this range, replace the battery. <p>Note <i>When the panel is running a backup battery test, the reading at the connected battery can range from 11.2 to 13.5 VDC. The panel automatically runs a backup battery test under the following conditions: (1) on initial power-up, (2) during user sensor test, (3) once every minute when backup battery has failed, (4) once every 24 hours at the programmed STIME (UL 98 Options off) or once every 4 hours (UL 98 Options on).</i></p> <p><i>With the AC power transformer plugged in, the panel automatically charges the battery. While the battery is charging for the first time it is normal for the system to indicate System Low Battery. This can take a number of hours depending on the initial battery charge. Once the battery reaches 12.5 VDC (full charge as measured while in battery test), the condition clears. If the trouble condition persists after 24 hours, replace the backup battery.</i></p>
	After pressing STATUS the touchpads flash AC or display <i>AC Power Failure/AC Failure</i> . (Panel continues to operate from backup battery).	<ol style="list-style-type: none"> 1. Check the AC circuit breaker to be sure the circuit is live. 2. Check for proper panel and transformer wiring. 3. Check that the transformer is plugged into a nonswitched outlet and secured with the provided screw. 4. Check that the transformer is supplying AC to the panel. (Transformer internal fuse may be blown.) <p> Warning Be careful when securing the transformer to an outlet with a metal cover. Hold the cover tightly in place. You could receive a serious shock if the metal outlet cover drops down onto the prongs of the plug while you are securing the transformer and cover to the outlet box.</p>
Access Codes		
	Customer cannot remember access code(s).	<ol style="list-style-type: none"> 1. Check your records to see if you have the customer's access code(s) on file. 2. Verify the access code(s) using the Downloader. 3. Clear memory and reprogram the panel locally. 4. Clearing the memory will erase onboard hardware zone factory programming.
	Installer cannot remember install code.	

Feature	Problem	Action/Solution
		<ol style="list-style-type: none"> 1. Check your records to see if you have the install code on file. 2. Verify the install code using the Downloader. 3. Use the Dealer Code to enter program mode and view the installer code.
	Installer cannot remember dealer code.	Check your records to see if you have the dealer code on file.
Arming and Disarming		
	System protests and won't arm.	<ol style="list-style-type: none"> 1. If arming to level 2, make sure all monitored perimeter doors and windows are closed. 2. If arming to level 3, make sure all perimeter and interior sensors are closed. 3. Press STATUS for an indication of the problem.
	System won't disarm.	<ol style="list-style-type: none"> 1. Disarming using incorrect code. Enter correct code. 2. Access code is not programmed or set up in user programming to disarm system. 3. Wireless touchpad is not learned into system or hardwire touchpad is not communicating to panel. Check installer programming for learned wireless touchpads. 4. The installer code is being used to disarm the system. The system is designed <i>not to disarm</i> using the installer code. Use a regular or system master code to disarm the system.
Bypassing		
	Touchpad indicates <i>Invalid</i> and/or " <i>Invalid</i> " is heard when you attempt to bypass a sensor.	<ol style="list-style-type: none"> 1. Attempting to bypass a 24-hour sensor that cannot be bypassed (group 26 fire sensors). 2. Sensor is not active in the current arming level.
	System cancels sensor bypass when you try to arm to level 2 or 3.	Sensor is being bypassed before arming to 2—STAY or 3—AWAY. Arm to the desired level before bypassing a sensor.
Wireless Sensor and Touchpad Batteries		
	System indicates <i>Sensor/Touchpad nn low battery</i> .	<p>Replace the indicated device battery. Test the sensor/touchpad after replacing the battery.</p> <p>Note <i>If the sensor/touchpad is not tested after battery replacement, the system continues to show a low battery condition, since that was the last signal it received from the device. Testing the sensor/touchpad with new batteries allows the panel to receive a signal with good battery information.</i></p>
Central Station/Pager Reporting		
	Central station/pager is not receiving reports.	<ol style="list-style-type: none"> 1. Check that the premises phone line is working. 2. Perform a phone test. 3. Check that the DB-8 cord is plugged into the RJ-31X/CA-38A jack. 4. Check that the DB-8 cord is wired correctly to the panel. 5. Check for correct phone line wiring between the TELCO block and RJ-31X/CA-38A jack. 6. Replace faulty RJ-31X/CA-38A jack. 7. Replace faulty DB-8 cord. 8. Verify that central station/pager phone number is programmed into the panel. Reprogram the phone number and retest, if necessary. 9. Verify that the correct phone format (SIA or CID) is being used. 10. For pagers, extend the pager delay setting (see the <i>PHONE OPTIONS—GLOBAL</i> menu in the "Programming" section).
Alphanumeric Touchpads		
	Display shows all *****.	Touchpad is not connected to panel bus terminals or is wired incorrectly. Check and correct wiring.
Alphanumeric Touchpads (continued)		
	Display is blank.	

Feature	Problem	Action/Solution
		<ol style="list-style-type: none"> 1. Check that panel is powered up. 2. Check for touchpad power and/or bus miswiring, opens, or shorts. 3. Check touchpad brightness setting (see the user-programming <i>OPTIONS</i> menu in the “Programming” section).
	Touchpad buttons don't beep when pressed.	
		<ol style="list-style-type: none"> 1. Check for touchpad power and/or bus miswiring, opens, or shorts. 2. Check that key beeps option is set to on (see the <i>ACCESSORY MODULES—BUS DEVICES</i> menu in the “Programming” section).
Fixed Display Touchpads		
	Display is lit but does not respond to key presses.	
		Touchpad is not connected to panel bus terminals or is wired incorrectly. Check and correct wiring.
	Display is blank.	
		<ol style="list-style-type: none"> 1. Check that panel is powered up. 2. Check for touchpad power and/or bus miswiring, opens, or shorts. 3. Check touchpad brightness setting (see the user-programming <i>OPTIONS</i> menu in the “Programming” section).
	Touchpad buttons don't beep when pressed.	
		<ol style="list-style-type: none"> 1. Check for touchpad power and/or bus miswiring, opens, or shorts. 2. Check that key beeps option is set to on (see the <i>ACCESSORY MODULES—BUS DEVICES</i> menu in the “Programming” section).
Speakers		
	Speakers don't sound alarms.	
		<ol style="list-style-type: none"> 1. Check for correct wiring at speaker and panel terminals; correct where necessary. 2. Speaker output has shut down because panel detected terminal 7 or 8 is shorted to ground. Disconnect panel AC and battery backup power. Locate short and correct. Apply panel AC and backup battery power and retest. 3. Alarm is in partition 2 and speaker is connected to panel terminals 7 and 8, which activate only for partition 1 alarms.
Sirens		
	Piezo sirens connected to SnapCard, or onboard (panel) outputs 1 and/or 2 don't produce any alarm sounds.	
		<ol style="list-style-type: none"> 1. Check for incorrect wiring between siren and panel; correct where necessary. 2. Output has not been configured (set up) to activate sirens. Enter program mode and configure output (see <i>ACCESSORY MODULES—BUS DEVICES—SNAP CARD</i>, or <i>ONBOARD OPTIONS—OUTPUT 1, 2</i> in the “Programming” section).
Supervised Wireless Sirens		
	Sirens don't produce any sounds and LED doesn't respond.	
		<ol style="list-style-type: none"> 1. Check to make sure siren is not plugged into an outlet controlled by a switch. Move siren to a nonswitched outlet location and test. 2. Panel doesn't have a Power Line Carrier (PLC) card installed. Install PLC card. 3. Panel is not powered by a power line carrier transformer. Replace existing transformer with a power line carrier transformer. 4. Power transformer and sirens are not plugged into outlets on the same electrical phase. Relocate sirens at different outlets to determine working locations. 5. Siren is programmed with incorrect partition house code. Clear siren house code by pressing and holding siren button for 20 seconds. Reprogram with correct partition house code and retest. See “Installing Supervised Wireless Sirens” (60-736-95) on page 10 for more information. 6. Siren house code is not programmed into panel. Enter program mode and set SWS and partition house codes.
Supervised Wireless Sirens (continued)		
	Siren only works part of the time and/or at odd, irregular intervals.	
		Check that siren and/or panel transformer is not plugged into an outlet shared with a major appliance, television, or computer which may generate noise and degrade the line carrier signal.
Hardwire Zones		

Feature	Problem	Action/Solution
	System doesn't go into alarm when zone is tripped.	<ol style="list-style-type: none"> 1. System is disarmed. Arm system and then trip the zone. 2. Zone is not learned into panel memory. Enter installer/dealer program mode—<i>LEARN SENSORS</i>, and learn zone into memory. 3. Zone is learned into wrong partition. Delete zone and learn into correct partition or change the partition in the <i>EDIT SENSORS</i> menu. 4. For HIM zones, check that the HIM LED is blinking to verify communication with the panel. If LED is off, check wiring between HIM and panel.
	Zone reports trouble condition.	<ol style="list-style-type: none"> 1. Check that onboard HIM and SnapCard zone inputs have a 2k-ohm EOL resistor installed at the last device on the loop in series for N/C loops, in parallel for N/O loops. 2. Check for zone wire fault—short circuit on N/C loops, open circuit on N/O loops. 3. Make sure all devices on zone are in non-alarm state, then enter disarm command to reset zone.
Wireless Sensor Zones		
	System doesn't respond (in sensor test or when armed) when sensor is tripped.	<ol style="list-style-type: none"> 1. Verify that receiver antennas are installed and connections are secure. 2. Check that the wireless sensor battery(s) are installed. 3. Check the sensor battery(s) for low voltage. Replace battery(s) if necessary. 4. Use an RF Sniffer (60-401) to verify that sensor is transmitting. 5. Sensor is not learned into panel memory. Enter installer/dealer program mode—<i>LEARN SENSORS</i>, and learn sensor into memory. 6. Zone is learned into wrong partition. Delete zone and learn into correct partition or change the partition in the <i>EDIT SENSORS</i> menu.
	Sensor reports trouble condition.	<ol style="list-style-type: none"> 1. Sensor tamper switch is tripped—sensor cover is off, not latched securely, or sensor is not mounted securely. Secure sensor mounting and/or cover, then trip sensor to clear the condition. 2. Check the sensor battery for low voltage. Replace batteries, if necessary.
	Touchpad indicates [sensor #] supervisory and/or Sensor [sensor #] supervisory is heard.	<ol style="list-style-type: none"> 1. Use an RF Sniffer (60-401) to verify that sensor is transmitting. If sensor is not transmitting, check battery for low or no voltage and replace. 2. Change mounting position of sensor (from horizontal to vertical or vice versa) and test sensor several times for consistency. 3. Sensor signal is not reaching panel/receiver because sensor is too far away. Remove sensor from mounted location and test from other locations. Mount sensor in area where signal can reach panel/receiver.
	Smoke sensor beeps once every 44 seconds.	Sensor batteries are getting low. Replace batteries.
Wireless Touchpads		
	System doesn't respond to commands entered from wireless touchpad.	<ol style="list-style-type: none"> 1. Verify that receiver antennas are installed and connections are secure. 2. Check that touchpad battery(s) are properly installed. 3. Check the touchpad battery(s) for low voltage. Replace battery(s), if necessary. 4. Use an RF Sniffer (60-401) to verify that touchpad is transmitting. 5. Touchpad is not learned into panel memory. Enter program mode and learn touchpad into memory (see <i>LEARN SENSORS</i>). 6. Touchpad is learned into wrong partition. Delete touchpad and learn into correct partition or change the partition in the <i>EDIT SENSORS</i> menu.
Wireless Touchpads (continued)		
	Touchpad reports trouble condition.	Check the touchpad battery(s) for low voltage. Replace battery(s), if necessary.
Phones		
	Loss of dial tone at on-site phones after wiring RJ-31X jack or connecting the DB-8 cord.	

Feature	Problem	Action/Solution
		<ol style="list-style-type: none"> 1. Wait 2 minutes and try again. The panel may be busy trying to report to the central station. 2. Disconnect the panel DB-8 cord from the RJ-31X jack. If the phone still doesn't work, the system is okay and the problem is in the wiring. 3. Check RJ-31X jack wiring and TELCO block wiring. Replace RJ-31X jack if necessary. 4. Check DB-8 cord connections at the panel and RJ-31X jack. Replace cord if necessary. 5. Perform a phone test after troubleshooting the phone line.
	Constant dial tone, preventing dial-out on premises phones.	
		One or more polarity-sensitive phones exist on-site. Reverse the phone wires connected to the brown and gray wire terminals on the RJ-31X jack.
Light Control		
	Light controlled by X-10 Lamp Module is not working.	
		<ol style="list-style-type: none"> 1. Check that the lamp has a working bulb and that the lamp switch is on. 2. Check to make sure X-10 module is not plugged into an outlet controlled by a switch. Move to a nonswitched outlet location and test. 3. Panel doesn't have a Power Line Carrier (PLC) card installed. Install PLC card. 4. Panel is not powered by a power line carrier transformer. Replace existing transformer with a power line carrier transformer. 5. Power transformer and X-10 modules are not plugged into outlets on the same electrical phase. Relocate modules or transformer to different outlets to determine working locations. 6. Check that the HOUSE dial on the X-10 module matches the partition house code programmed into the panel. 7. X-10 module is located in wrong partition. Move module to correct partition and retest. 8. Partition house codes are not programmed into panel. Enter program mode and set partition house codes.
Energy Saver Module		
	Module does not respond to system commands or appear to control furnace.	
		<ol style="list-style-type: none"> 1. Check that the module is wired correctly to the panel terminals. 2. Verify the module LED is flashing continuously. If the LED is not flashing, remove power and check wiring. 3. There is a 5-minute delay after the module returns control to the furnace/AC thermostat, before the module overrides the thermostat again. Wait 5-minutes and try again.
	Module temperature does not match actual room temperature.	
		The module room temperature setting has not been adjusted or was adjusted before the module warmed or cooled to room temperature. To ensure accuracy, wait at least 15 minutes after installing the module before adjusting the temperature. To adjust the module room temperature setting, see <i>TEMPERATURE</i> under the <i>ACCESSORY MODULES—BUS DEVICES—UNIT-ID—ENERGY OPTIONS</i> menu in the section "Programming the Panel."
Automation Module		
	Module is not controlling or communicating with the panel and panel indicates a " <i>BUS FAILURE UNIT nn</i> " where nn is the Automation Module bus unit number.	
		<ol style="list-style-type: none"> 1. Check that the module is wired correctly to the panel terminals. 2. Verify the SuperBus Module's red LED is flashing continuously. If the LED is not flashing, remove power and check wiring.
	Module is not controlling or communicating with the panel and panel indicates a " <i>BUS FAILURE UNIT AMnn</i> " where nn is the Automation Module bus unit number.	
		<ol style="list-style-type: none"> 1. Check that the RS-232 cable is firmly connected to the Automation Module and the Automation Device. 2. Verify the Automation Device is powered and turned on.
	Module is not controlling or communicating with the panel and panel does not indicate a bus failure.	
		<ol style="list-style-type: none"> 1. Verify the Automation Module is learned on the bus. 2. Make sure another Automation or Gateway Module isn't learned into the panel's memory. Concord panels support only one Automation or Gateway Module.
Cellular Backup Module		
	Cellular backup report does not occur.	

Feature	Problem	Action/Solution
		<ol style="list-style-type: none"> 1. Verify the Cellular Backup option is on for the CS phone number being tested. 2. Verify that the module is learned on the bus. 3. Check that the Cellular Backup Module has been activated as outlined in the device Installation Instructions.
	The panel indicates "auxiliary phone trouble 1."	
		<ol style="list-style-type: none"> 1. Check the antenna connection. 2. Adjust the antenna positioning for maximum signal. 3. Verify Cellular System setting. 4. Check that the Cellular Backup Module has been activated as outlined in the device Installation Instructions.
	The panel indicates "auxiliary phone trouble 2."	
		<ol style="list-style-type: none"> 1. Check the antenna connection. 2. Adjust the antenna positioning for maximum signal. 3. Verify Cellular System setting.
	The panel indicates "auxiliary phone trouble 3."	
		<ol style="list-style-type: none"> 1. Check the antenna connection. 2. Adjust the antenna positioning for maximum signal.
	The panel indicates "auxiliary phone trouble 4."	
		Contact the cellular provider for details.
	The panel indicates "auxiliary phone trouble 5."	
		Contact the cellular provider for details.
	The panel indicates "auxiliary phone trouble 6."	
		Replace the module.
SuperBus 2000 Wireless Gateway Module		
	Module is not communicating on Bus and indicates a "Bus Failure Unit nn". Where nn represents the Wireless Gateway unit number.	
		<ol style="list-style-type: none"> 1. Check that the module is wired correctly to the panel terminals. 2. Verify that the module's red Bus LED is flashing. If not, remove power and check all the wiring.
	Module's status LED's don't turn on after initial power-up.	
		<ol style="list-style-type: none"> 1. Wait 5 - 8 minutes for the module to communicate with alarm.com. 2. Access code Lock feature must be turned off to work properly. 3. Make sure another Automation or Gateway Module isn't learned into the panel's memory. Concord panels support only one Automation or Gateway Module.
	Module doesn't communicate with alarm.com.	
		<ol style="list-style-type: none"> 1. Check module's status LED's. Refer to the "SuperBus 2000 Wireless Gateway Module" instructions for a description of the LED's.

**Appendix A:
System
Planning
Worksheets**

Customer Name _____
 Address _____
 City _____ County _____ State ____
 Zip _____ Phone (____) _____

Table A1: Wireless Devices

Part No.	Description	Qty.
60-362	Door/Window Sensor	
60-670	SAW Door/Window Sensor	
60-741-95	Micro Recessed Door/Window Sensor	
60-499	Slim Line Door/Window Sensor	
60-688	Micro Door/Window Sensor	
60-641	Long-Life Door/Window Sensor	
60-461*	Shock Sensor	
60-459*	Sound Sensor	
60-462*	Glass Guard Sensor	
60-506	System Sensor Smoke Sensor	
60-838-95R	2100ARFT Smoke Sensor	
60-460	Rate-of-Rise Heat Sensor	
60-589*	Manual Fire Pull Sensor	
60-504*	Freeze Sensor	
60-452	Pendant Panic Sensor	
60-458	Single Button Panic Sensor	
60-457	Dual Button Panic Sensor	
60-578	Water-Resistant Panic Sensor	
60-511-01-95	DS924i PIR Motion Sensor	
60-639-95R	SAW Indoor PIR Motion Sensor	
60-639-95R-OD	SAW Outdoor PIR Motion Sensor (Not for intrusion protection)	
60-703-95	Crystal Indoor PIR Motion Sensor	
60-834-95	FlexGard Sound Sensor	
60-597	HiTech Handheld Wireless Touchpad	
60-607	2-Button Keychain Touchpad	
60-606	4-Button Keychain Touchpad	
60-659-95	SAW 4-Button Keychain Touchpad	

Table A2: Hardwire Devices

Part No.	Description	Qty.	mA (Max.)	Sub Total
Hardwire Sensors/Detectors				
13-068	Magnetic Contact 3/8" press fit		N/A	
13-070	Magnetic Contact – surface mount		N/A	
N/A	System Sensor models 2100D, 2100TD, 2100S, 2100TS, 2400, or 2400TH or ESL series 429AT, 521B or 521BXT		10 mA	
13-082	PIR Motion Detector		10 mA	
Sirens				
60-736*	Supervised Wireless Siren		N/A	
60-483-01	Slim Line Hardwire Interior Siren		120 mA	
13-046	Hardwire Exterior Siren		145 mA	
SuperBus 2000/Miscellaneous Components				
60-746-01	2x16 LCD Alphanumeric Touchpad		90 mA	
60-820	Fixed Display LCD Touchpad		30 mA	
60-803	2x20 LCD Alphanumeric Touchpad		120 mA	
60-804	2x20 VFD Alphanumeric Touchpad		120 mA	
60-777-01	Phone Interface/Voice Module		600 mA	
60-764-01-95R	RF Receiver		30 mA	
60-755	Power Line Carrier Card		110 mA	
60-756	4 Input/2 Output SnapCard		185 mA	
60-757	8Z Hardwire Zone Expander SnapCard		230 mA	
60-758	4 Output SnapCard		130 mA	
60-774	Hardwire Input Module		18 mA	
60-770	Hardwire Output Module		91 mA	
60-620-01	Energy Saver Module		20 mA	
60-677*	Interrogator 200 Audio Verification Module		10 mA	
60-850 Standard	Cellular Backup Module		1600 mA	
60-850-01 High Power			1900 mA	
60-783-02	Automation Module		35 mA	
Total power consumption:				mA
Total power consumption using 30 VA transformer and 4.0 AH backup battery not to exceed:				1,000 mA
Total power consumption using 50 VA transformer and 7.0 AH backup battery not to exceed:				2,000 mA

* These devices not listed, investigated, or verified by UL.

† Listed, but not tested for compatibility by UL.

Table A3: Zone and Sensor Assignments

No.	RF Zone	Module Bus ID Number	Module Input Number	Group	Partition	Zone/Sensor Text
01						
02						
03						
04						
05						
06						
07						
08						
09						
10						
11						
12						
13						
14						
15						
16						
17						
18						
19						
20						
21						
22						
23						
24						
25						
26						
27						
28						
29						
30						
31						
32						
33						
34						
35						
36						
37						
38						
39						
40						
41						
42						
43						
44						

Table A3: Zone and Sensor Assignments (Continued)

No.	RF Zone	Module Bus ID Number	Module Input Number	Group	Partition	Zone/Sensor Text
45						
46						
47						
48						
49						
50						
51						
52						
53						
54						
55						
56						
57						
58						
59						
60						
61						
62						
63						
64						
65						
66						
67						
68						
69						
70						
71						
72						
73						
74						
75						
76						

Table A4: System Settings Index and Record

Setting (reference) default	Shortcut No.	Setting
Installer Programming—8 + Installer/Dealer CODE + 00		
24 Hour Tamper Off	06000	
AC Failure Off	06010	
Access Code Lock (On)	0003	
Access Timeout 90 sec	0904	
Account No. 00000	0010, 0020	1_____ 2_____
Activity Timeout 24 hrs	0305	
Alarm Verify Off	06108, 06208	1_____ 2_____
Audio Mode 1	0901	
Audio Verify Off	0900	
Auto Phone Test Off	02001	
Auto Stay Arming On	0014, 0024	1_____ 2_____
Auto Test Reset On	02002	
Auxiliary Panic On	0511, 0521	1_____ 2_____
AVM Access Code None	0906	
Back In Service On	06002	
Backup CS Phone 1 On, CS Phone 2-3 Off	0105, 0115, 0125	1_____ 2_____ 3_____
Battery Restoral Off	06005	
Beep Delay 2 sec	0905	
Buffer Control Off	06001	
Buffer Full Report Off	06006	
Bypass Reports Off	06003	
Call Wait Cancel None	02009	
Cancel Message On	02007	
Cellular Backup CS Phone 1 On, CS Phone 2-3 Off	0107, 0117, 0127	1_____ 2_____ 3_____
Cellular System B		
Closing Reports Off	06101, 06201	1_____ 2_____
Comm. Failure On	02003	
CS Phone 1-3 None	0100, 0110, 0120	1_____ 2_____ 3_____
Daylight Saving On	0306	
Dealer Code None	0002	
Delete Sensors None	082	
Dial Tone Detect On	02010	
Dialer Abort On	02005	
Dial Abort Delay 30 sec	02006	
Disable Trouble Beeps Off	0701	
Downloader Code 12345	0000	
Downloader Phone No. None	0180	
DTMF Dialing On	02004	
Duress Code None	0017, 0027	1_____ 2_____
Duress Option Off	06104, 06204	1_____ 2_____
Edit Sensors None	083	
Entry Delay 32 sec	0310, 0320	1_____ 2_____
Entry Lights none	0400, 0410	1_____ 2_____

Table A4: System Settings Index and Record (Continued)

Setting (reference) default	Shortcut No.	Setting
Exception Reports (phones) Off	0103, 0113, 0123	1 _____ 2 _____ 3 _____
Exception Reports (pagers) Off	0133, 0143, 0153, 0163, 0173	1 _____ 2 _____ 3 _____ 4 _____ 5 _____
Exit Delay 64 sec	0311, 0321	1 _____ 2 _____
Exit Extension On	0013, 0023	1 _____ 2 _____
Extended Delay 4 min	0312, 0322	1 _____ 2 _____
Fire Panic On	0510, 0520	1 _____ 2 _____
Fire Shutdown Off	0902	
Force Armed Off	06105, 06205	1 _____ 2 _____
Freeze Alarm Off	06107, 06207	1 _____ 2 _____
Global Fire Off	0704	
High Level Reports (phones) CS Phone 1 On, CS Phone 2-3 Off	0101, 0111, 0121	1 _____ 2 _____ 3 _____
High Level Reports (pagers) On	0131, 0141, 0151, 0161, 0171	1 _____ 2 _____ 3 _____ 4 _____ 5 _____
House Code 1B, 2C	0401, 0411	1 _____ 2 _____
Immediate Beeps Off	0700	
Installer Code 4321	0001	
Keychain TP Arming Off	0513, 0523	1 _____ 2 _____
Keyswitch Sensor None	0015, 0025	1 _____ 2 _____
Keyswitch Style Transition	0016, 0026	1 _____ 2 _____
Latchkey Format Off	06106, 06206	1 _____ 2 _____
Latchkey Reports (pagers) On	0135, 0145, 0155, 0165, 0175	1 _____ 2 _____ 3 _____ 4 _____ 5 _____
Latchkey Zones None	0500	
Learn Sensors None	080	
Line Fail Delay None	0213	
Local Phone Control On	0210, 0220	1 _____ 2 _____
Low CPU Battery On	06004	
Low Level Reports (phones) CS Phone 1 On, CS Phone 2-3 Off	0102, 0112, 0122	1 _____ 2 _____ 3 _____
Low Level Reports (pagers) Off	0132, 0142, 0152, 0162, 0172	1 _____ 2 _____ 3 _____ 4 _____ 5 _____
Next Phone Test 7 days	0303	
No Activity Off	06103, 06203	1 _____ 2 _____
Open/Close Reports (phones) Off	0104, 0114, 0124	1 _____ 2 _____ 3 _____
Open/Close Reports (pagers) Off	0134, 0144, 0154, 0164, 0174	1 _____ 2 _____ 3 _____ 4 _____ 5 _____
Opening Reports Off	06100, 06200	1 _____ 2 _____
Onboard Output 1 01614- any audible alarm	11101	
Onboard Output 2 01710 - status & alarm tones	11111	
Output Trip Time 4 sec	0304	
Pager Delay 15 sec	02008	
Pager Partition Assignment 1	0137, 0147, 0157, 0167, 0177	1 _____ 2 _____ 3 _____ 4 _____ 5 _____
Pager Phone 1-5 None	0130, 0140, 0150, 0160, 0170	1 _____ 2 _____ 3 _____ 4 _____ 5 _____
Phone Access Key #	0216, 0226	1 _____ 2 _____
Phone Panic Off	0215, 0225	1 _____ 2 _____

Table A4: System Settings Index and Record (Continued)

Setting (reference) default	Shortcut No.	Setting
Phone Test On	02000	
Phone Test Freq. 7 days	0302	
Police Panic On	0512, 0522	1 _____ 2 _____
Program Report Off	06015	
Quick Arm Off	0011, 0021	1 _____ 2 _____
Quick Exit On	0012, 0022	1 _____ 2 _____
Receiver Failure Off	06011	
Recent Closings On	06102, 06202	1 _____ 2 _____
Remote Access On	0211, 0221	1 _____ 2 _____
RF Low Battery Rpt Weekly	06012	
RF Supervisory Rpt Weekly	06013	
RF TX Timeout 12 hrs	0301	
Ring/Hang/Ring On	0212, 0222	1 _____ 2 _____
Reporting Format (SIA/CID) CID	0106, 0116, 0126	1 _____ 2 _____ 3 _____
Sensor Text None	081	
Silent Talkback Off	0903	
Siren Timeout 4 min	0313, 0323	1 _____ 2 _____
Siren Verify Off	0710	
Sleep Time Off	0314, 0324	1 _____ 2 _____
Smoke Verify Off	1100	
SnapCard Output 1 (01400 - keychain touchpad star button activation)	101001	
SnapCard Output 2 (00410 - any audible alarm)	101011	
SnapCard Output 3 (00903 - arming to STAY or AWAY)	101021	
SnapCard Output 4 (01003 - arming to AWAY)	101031	
Star Is No Delay Off	0514, 0524	1 _____ 2 _____
Streamlining On	0136, 0146, 0156, 0166, 0176	1 _____ 2 _____ 3 _____ 4 _____ 5 _____
Supervisory Time 03:00	0300	
Swinger Limit 1	06014	
SWS Code 003	0703	
System Tamper Off	06109, 06209	1 _____ 2 _____
Toll Saver On	0214, 0224	1 _____ 2 _____
TP Panic RPT FMT Off	06009	
Two Trip Error Off	06008	
Two Wire Smoke Off	1101	
UL 98 Options Off	0702	
Zone Restorals Off	06007	

Appendix B: Reference Tables

Table B1: Sensor Group Characteristics

No.	Name	Application	Alarm	Delay	Restoral	Supervisory	CS Report	Chime (Level 1 only)	Active Levels
00	Fixed Panic	24-hour audible fixed emergency buttons.	Police	Instant		√	√		1, 2, 3
01	Portable Panic	24-hour audible portable emergency buttons.	Police	Instant			√		1, 2, 3
02	Fixed Panic	24-hour silent fixed emergency buttons.	Silent	Instant		√	√		1, 2, 3
03	Portable Panic	24-hour silent portable emergency buttons.	Silent	Instant			√		1, 2, 3
04	Fixed Auxiliary	24-hour auxiliary sensor, such as Pendant Panic or holdup button.	Auxiliary	Instant		√	√		1, 2, 3
05	Fixed Auxiliary	24-hour auxiliary emergency button. Siren shutoff confirms CS report.	Auxiliary	Instant		√	√		1, 2, 3
06	Portable Auxiliary	24-hour portable auxiliary alert button.	Auxiliary	Instant			√		1, 2, 3
07	Portable Auxiliary	24-hour portable auxiliary button. Siren shutoff confirms CS report.	Auxiliary	Instant			√		1, 2, 3
08	Special Intrusion	Special belongings, such as gun cabinets and wall safes.	Police	Instant	√	√	√		1, 2, 3
09	Special Intrusion	Special belongings, such as gun cabinets and wall safes.	Police	Standard	√	√	√		1, 2, 3
10	Entry/Exit Delay	Entry and exit doors that require a standard delay time.	Police	Standard	√	√	√	√	2, 3
11	Entry/Exit Delay	Garage doors and entrances that require an extended delay time. *	Police	Extended	√	√	√	√	2, 3
12	Entry/Exit Delay	Driveway gates and entrances that require a twice extended delay time. *	Police	Twice Extended	√	√	√	√	2, 3
13	Instant Perimeter	Exterior doors and windows.	Police	Instant	√	√	√	√	2, 3
14	Instant Interior	Interior doors.	Police	Follower	√	√	√		2, 3
15	Instant Interior	Interior PIR motion sensors. *	Police	Follower		√	√		2, 3
16	Instant Interior	Interior doors.	Police	Follower	√	√	√		3
17	Instant Interior	PIR motion sensors. *	Police	Follower		√	√		3
18	Instant Interior	PIR motion sensors subject to false alarms. * †	Police	Follower		√	√		3
19	Delayed Interior	Interior doors that initiate a delay before going into alarm. *	Police	Standard	√	√	√		3
20	Delayed Interior	PIR motion sensors that initiate a delay before going into alarm. *	Police	Standard		√	√		3
21	Local Instant Interior	24-hour local alarm zone protecting anything that opens and closes.	Police	Instant	√	√			1, 2, 3
22	Local Delayed Interior	Same as group 21, plus activation initiates a delay before going into alarm.	Police	Standard	√	√			1, 2, 3
23	Local Instant Auxiliary	24-hour local alarm zone protecting anything that opens and closes. ‡	Auxiliary	Instant	√	√			1, 2, 3
24	Local Instant Auxiliary	24-hour local alarm zone protecting anything that opens and closes. Sirens shut off at restoral. *	Auxiliary	Instant	√	√			1, 2, 3

Table B1: Sensor Group Characteristics (Continued)

No.	Name	Application	Alarm	Delay	Restoral	Supervisory	CS Report	Chime (Level 1 only)	Active Levels
25	Local Special Chime	Notify the user when a door is opened. Sounds emit from a local annunciator. *	Special Chime	Instant		√			1, 2, 3
26	Fire	24-hour fire, rate-of-rise heat, and smoke sensors.	Fire	Instant	√	√	√		1, 2, 3
27	Output Module	Hardwire Output Module (HOM) lamp control or other customer feature. †	Silent	Instant	√	√			1, 2, 3
28	Output Module	HOM, PIR motion sensor, sound sensor, or pressure mat. ‡	Silent	Instant		√			1, 2, 3
29	Auxiliary	Freeze sensor.	Auxiliary	Instant	√	√	√		1, 2, 3
32	Output Module	HOM, PIR motion sensor, sound sensor, or pressure mat. ‡	Silent	Instant					
33	Siren	Wireless Siren Supervision. †	Silent	Instant		√	√		1, 2, 3
34	Gas	Carbonmonoxide (CO) Gas Detectors ‡	Auxiliary	Instant	√	√	√		1, 2, 3
35	Local Instant Police (Day Zone)	Local alarm in levels 1 and 2. Report to CS in level 3.	Police	Instant	√	√	√ (level 3 only)		1, 2, 3

Note: Check marks (√) represent characteristics present in a group.

* This group is not certified as a primary protection circuit for UL-listed systems and is for supplementary use only.

† Sounds instant police siren if two or more sensors are tripped within 4 minutes. Otherwise sensors are followers to delayed sensors. If Alarm Verification is on, group 18 functions like group 17.

‡ This group has not been investigated by UL.

§ This group is required for UL-listed residential fire alarm applications.

Table A2: Item Numbers and Sensor Text

Item #	Sensor Text	Item #	Sensor Text	Item #	Sensor Text	Item #	Sensor Text	Item #	Sensor Text	Item #	Sensor Text
001	Aborted	041	Date	081	Gas	121	North	161	Siren	201	G
002	AC	042	Daughter's	082	Glass	122	Not	162	Sliding	202	H
003	Access	043	Degrees	083	Goodbye	123	Now	163	Smoke	203	I
004	Active	044	Delay	084	Hallway	124	Number	164	Son's	204	J
005	Activity	045	Den	085	Heat	125	Off	165	Sound	205	K
006	Alarm	046	Desk	086	Hello	126	Office	166	South	206	L
007	All	047	Detector	087	Help	127	OK	167	Special	207	M
008	AM	048	Dining	088	High	128	On	168	Stairs	208	N
009	Area	049	Disarmed	089	Home	129	Open	169	Stay	209	O
010	Arm	050	Door	090	House	130	Opening	170	Supervisory	210	P
011	Armed	051	Down	091	In	131	Panic	171	System	211	Q
012	Arming	052	Download	092	Install	132	Partition	172	Tamper	212	R
013	Attic	053	Downstairs	093	Interior	133	Patio	173	Temperature	213	S
014	Auxiliary	054	Drawer	094	Intrusion	134	Pet	174	Test	214	T
015	Away	055	Driveway	095	Invalid	135	Phone	175	Time	215	U
016	Baby	056	Duct	096	Is	136	Please	176	To	216	V
017	Back	057	Duress	097	Key	137	PM	177	Touchpad	217	W
018	Bar	058	East	098	Kids	138	Police	178	Trouble	218	X
019	Basement	059	Energy Saver	099	Kitchen	139	Pool	179	Unbypass	219	Y
020	Bathroom	060	Enter	100	Latchkey	140	Porch	180	Unit	220	Z
021	Battery	061	Entry	101	Laundry	141	Power	181	Up	221	(space)
022	Bedroom	062	Error	102	Left	142	Press	182	West	222	'(apostrophe)
023	Bottom	063	Exit	103	Level	143	Program	183	Window	223	- (dash)
024	Breezeway	064	Exterior	104	Library	144	Progress	184	Zone	224	_ (underscore)
025	Building	065	Factory	105	Light	145	Quiet	185	0	225	*
026	Bus	066	Failure	106	Lights	146	Rear	186	1	226	#
027	Bypass	067	Family	107	Living	147	Receiver	187	2	227	:
028	Bypassed	068	Father's	108	Load	148	Report	188	3	228	/
029	Cabinet	069	Feature	109	Loading	149	RF	189	4	229	?
030	Canceled	070	Fence	110	Low	150	Right	190	5		
031	Car	071	Fire	111	Lower	151	Room	191	6		
032	Carbon Monoxide	072	First	112	Main	152	Safe	192	7		
033	Central	073	Floor	113	Master	153	Schedule	193	8		
034	Chime	074	Force	114	Mat	154	Screen	194	9		
035	Closed	075	Foyer	115	Medical	155	Second	195	A		
036	Closet	076	Freeze	116	Memory	156	Sensor	196	B		
037	Closing	077	Front	117	Menu	157	Service	197	C		
038	Code	078	Furnace	118	Mother's	158	Shed	198	D		
039	Computer	079	Gallery	119	Motion	159	Shock	199	E		
040	Control	080	Garage	120	No	160	Side	200	F		

Table B3: System Event Trigger Numbers

System Event	Description	Trigger No.
Null Trigger (used for direct control)	Activated only by schedule or direct command.	000
Fire Alarm	When Fire sirens are started.	001
Police Alarm	When Police sirens are started.	002
Auxiliary Alarm	When Auxiliary sirens are started.	003
Any Audible Alarm	When any of the above sirens are started.	004
Silent Alarm (sensor groups 2, 3, and duress)	When a sensor in group 2 or 3 goes into alarm or when a duress alarm is activated (does not include groups 25, 27, 28, or 32).	005
Any Audible or Silent Alarm	When any alarm is started (does not include groups 25, 27, 28, or 32).	006
HOM Group 27, 28, 32 in Alarm	When a sensor in group 27, 28, or 32 goes into alarm.	007
Major Trouble (phone or receiver failure)	When a receiver failure (S94) or a phone failure (S96) occurs.	008
Arming to STAY or AWAY	When the panel is armed to level 2 or 3.	009
Arming to AWAY	When the panel is armed to level 3.	010
AVM is Interactive (audio session in progress)	When the central station operator begins listening or talking to the premises.	011
Fail-to-Communicate (panel can't call CS or pager)	When the fail-to-communicate output is activated.	012
AVM Trip (edge)	When an AVM alarm occurs, output is activated momentarily.	013
Keychain Touchpad Star Button-Press	When the star button on a keychain touchpad is pressed.	014
Smoke Power (for resetting 4-wire smoke detectors)	Deactivated when hardwire smoke detectors need to be reset.	015
Exterior Siren	Activated for police or fire alarms.	016
Interior Siren	Activation follows all system noises	017
AVM Trip (pulse)	When an AVM alarm occurs, output is deactivated for 10 ms	018
State of System Status	Follows the state of system status (ready or trouble).	019
Tamper Condition	When any tamper is tripped	020
Closing Report Sent	When a closing report has been successfully transmitted to the central station.	021
Group XX in Alarm	When any sensor in group XX goes into alarm	see Table B4
Sensor XX in Alarm	When sensor number XX goes into alarm	see Table B4
Sensor XX Open	When sensor number XX is opened	see Table B4

Table B4: Sensor Group Event Trigger Numbers

Sensor Group	Trigger No.
Group 00 in alarm	064
Group 01 in alarm	065
Group 02 in alarm	066
Group 03 in alarm	067
Group 04 in alarm	068
Group 05 in alarm	069
Group 06 in alarm	070
Group 07 in alarm	071
Group 08 in alarm	072
Group 09 in alarm	073
Group 10 in alarm	074
Group 11 in alarm	075
Group 12 in alarm	076
Group 13 in alarm	077
Group 14 in alarm	078
Group 15 in alarm	079
Group 16 in alarm	080
Group 17 in alarm	081
Group 18 in alarm	082
Group 19 in alarm	083
Group 20 in alarm	084
Group 21 in alarm	085
Group 22 in alarm	086
Group 23 in alarm	087
Group 24 in alarm	088
Group 25 in alarm	089
Group 26 in alarm	090
Group 27 in alarm	091
Group 28 in alarm	092
Group 29 in alarm	093
Group 32 in alarm	096
Group 33 in alarm	097
Group 34 in alarm	098
Group 35 in alarm	099

Table B5: Sensor Number Event Trigger Numbers

Sensor Number	State	Trigger No.	State	Trigger No.
Sensor 01	in alarm	129	open	257
Sensor 02	in alarm	130	open	258
Sensor 03	in alarm	131	open	259
Sensor 04	in alarm	132	open	260
Sensor 05	in alarm	133	open	261
Sensor 06	in alarm	134	open	262
Sensor 07	in alarm	135	open	263
Sensor 08	in alarm	136	open	264
Sensor 09	in alarm	137	open	265
Sensor 10	in alarm	138	open	266
Sensor 11	in alarm	139	open	267
Sensor 12	in alarm	140	open	268
Sensor 13	in alarm	141	open	269
Sensor 14	in alarm	142	open	270
Sensor 15	in alarm	143	open	271
Sensor 16	in alarm	144	open	272
Sensor 17	in alarm	145	open	273
Sensor 18	in alarm	146	open	274
Sensor 19	in alarm	147	open	275
Sensor 20	in alarm	148	open	276
Sensor 21	in alarm	149	open	277
Sensor 22	in alarm	150	open	278
Sensor 23	in alarm	151	open	279
Sensor 24	in alarm	152	open	280
Sensor 25	in alarm	153	open	281
Sensor 26	in alarm	154	open	282
Sensor 27	in alarm	155	open	283
Sensor 28	in alarm	156	open	284
Sensor 29	in alarm	157	open	285
Sensor 30	in alarm	158	open	286
Sensor 31	in alarm	159	open	287
Sensor 32	in alarm	160	open	288
Sensor 33	in alarm	161	open	289
Sensor 34	in alarm	162	open	290
Sensor 35	in alarm	163	open	291
Sensor 36	in alarm	164	open	292
Sensor 37	in alarm	165	open	293
Sensor 38	in alarm	166	open	294
Sensor 39	in alarm	167	open	295
Sensor 40	in alarm	168	open	296
Sensor 41	in alarm	169	open	297
Sensor 42	in alarm	170	open	298

Table B5: Sensor Number Event Trigger Numbers

Sensor Number	State	Trigger No.	State	Trigger No.
Sensor 43	in alarm	171	open	299
Sensor 44	in alarm	172	open	300
Sensor 45	in alarm	173	open	301
Sensor 46	in alarm	174	open	302
Sensor 47	in alarm	175	open	303
Sensor 48	in alarm	176	open	304
Sensor 49	in alarm	177	open	305
Sensor 50	in alarm	178	open	306
Sensor 51	in alarm	179	open	307
Sensor 52	in alarm	180	open	308
Sensor 53	in alarm	181	open	309
Sensor 54	in alarm	182	open	310
Sensor 55	in alarm	183	open	311
Sensor 56	in alarm	184	open	312
Sensor 57	in alarm	185	open	313
Sensor 58	in alarm	186	open	314
Sensor 59	in alarm	187	open	315
Sensor 60	in alarm	188	open	316
Sensor 61	in alarm	189	open	317
Sensor 62	in alarm	190	open	318
Sensor 63	in alarm	191	open	319
Sensor 64	in alarm	192	open	320
Sensor 65	in alarm	193	open	321
Sensor 66	in alarm	194	open	322
Sensor 67	in alarm	195	open	323
Sensor 68	in alarm	196	open	324
Sensor 69	in alarm	197	open	325
Sensor 70	in alarm	198	open	326
Sensor 71	in alarm	199	open	327
Sensor 72	in alarm	200	open	328
Sensor 73	in alarm	201	open	329
Sensor 74	in alarm	202	open	330
Sensor 75	in alarm	203	open	331
Sensor 76	in alarm	204	open	332

Table B6: System Feature Event Trigger Numbers

Feature	State	Trigger No.
Phone Test	initiated	225
AC Failure	for 15 minutes	226
CPU Low Battery	detected (excluding first minute after power-up)	227
Auto Phone Test	begun	228
Receiver Failure	detected	229
Back In Service	alarm (AC loss, battery drain, then AC restore)	230
Phone Failure	detected	231
Buffer Full	detected	232
Two Trip Error	detected	233
System Tamper	alarm (40 incorrect code entry keystrokes)	236
Freeze	alarm	237
No Activity	alarm	238
Fire Panic	alarm	239
Police Panic	alarm	240
Auxiliary Panic	alarm	241
Opening Report	occurred	242
Closing Report	occurred	243
Latchkey Opening or Closing	occurred	244
Duress	alarm	245
Force Armed Report	occurred	246
Fire in Partition	alarm	247
Recent Closing Report	occurred	248
Sensor Test	entered	249

Table B7: Response Characteristics

Response Characteristics	Description
Momentary trip time	The point will remain activated for <i>nn</i> seconds (n is 1-12 seconds). The default is 4 seconds
3 minute trip time	The point will remain activated for 3 minutes
Siren-time trip time	The point will remain activated while the interior siren is sounding
Sustained trip time	The point will remain activated for the duration of the event
Siren pattern	The point will activate and deactivate according to the current alarm type: Auxiliary -- fast on/off/on Police -- constant on Fire -- repeating)
Trip delay	The point will activate 30 seconds after the trigger event occurs

Table B8: Response Numbers

Siren Tracking	Trip Delay	Response Time	Response No.
no	no	momentary	00
no	no	3 minutes ⁵	01
no	no	siren time ²	02
no	no	sustained ³	03
no	yes ⁴	momentary	04
no	yes ⁴	3 minutes ⁵	05
no	yes ⁴	siren time ²	06
no	yes ⁴	sustained ³	07
yes ¹	no	momentary	08
yes ¹	no	3 minutes ⁵	09
yes ¹	no	siren time ²	10
yes ¹	no	sustained ³	11
yes ¹	yes ⁴	momentary	12
yes ¹	yes ⁴	3 minutes ⁵	13
yes ¹	yes ⁴	siren time ²	14
yes ¹	yes ⁴	sustained ³	15

Note

The mechanical lifetime of the relay may be exceeded if an output is set up for a siren tracking response and a pulsing siren (auxiliary or fire) is active for long time periods. A SnapCard relay output's lifetime expectancy is about 350 total pulsing hours.

Note


The trip delay is factory set for 30 seconds and cannot be changed.

Notes for Table B8: Response Numbers

1. If an event does not trigger sirens, siren tracking response numbers activate without turning on the output. If sirens are triggered by another event, the output pulses to match the siren. If the siren cadence changes (from police to fire, for example), outputs set up for siren tracking change to match the siren and all pulsing outputs pulse to one common cadence.
2. If an event does not trigger sirens, siren time response times activate outputs only if sirens are active for another reason.
3. If an alarm event does not necessarily require disarming (no activity, closing report, etc.), outputs set up for a sustained response time remain activated until the next arming level change.
4. If an event occurs that activates an output set up for trip delay, the delay and output activation can be canceled by trigger event restoral.
5. Activated outputs set up for a 3-minute response time remain active for the entire three minutes. To deactivate the output before the 3-minute time expires, you must enter program mode or remove panel power. Activated outputs set up for a momentary or 3-minute response time restart if the same trigger event occurs again.



Appendix C: Settings

To Enter Programming Mode:
8 + Installer or
Dealer Code + 0 + 0




Tier 2 Menus (Continued)


Phones (Continued)



Tier 2 Menus (Continued)



Tier 2 Menus (Continued)



* The panel comes with eight factory programmed onboard hardwire zones. The factory programmed settings are listed below:

- Zone 1: 10-Entry/Exit
- Zone 2: 17-Instant Interior Follower
- Zone 3: 13-Instant Perimeter
- Zone 4: 13-Instant Perimeter
- Zone 5: 13-Instant Perimeter
- Zone 6: 13-Instant Perimeter
- Zone 7: 13-Instant Perimeter
- Zone 8: 13-Instant Perimeter


Clearing panel memory also clears all factory programmed zones.


Install an end-of-line resistor on all unused, factory programmed, onboard panel zones.

OR

Delete the unused zone(s) from panel memory.

Tier 2 Menus (Continued)





Specifications

Power Requirements:Class II, 24 VAC, 30 or 50 VA, 60 Hz

Rechargeable Batteries: ..12 VDC, 4Ah Lead-Acid (part no. 60-681) OR 12 VDC, 7Ah (part no. 60-680).
The battery will last 24 hours with no AC and specified standby load

Radio Frequency:319.5 MHz

Nominal Range:1000 feet (305 meters) typical open air

Storage Temperature Range:- 30° to 140° F (-34° to 60° C)

Operating Temperature Range: 32° to 120° F (0° to 49° C)

Maximum Humidity:90% Relative Humidity (non-condensing)

Auxiliary Power Output: 12 V @ 1.0 A (30 VA Transformer) OR 2.0 A (50 VA Transformer)

Dimensions:12 in. (30.5 cm) x 12 in. (30.5 cm) x 3.0 in. (7.6 cm) (H x W x D)

System Wiring Notes

Note 1

Class II power transformer must be plugged into an unswitched AC power receptacle. Do not short the transformer terminals together. The transformer contains an internal fuse that permanently disables the output if the terminals are shorted.

Note 2

An alphanumeric touchpad is required for on-site programming.

Note 3

Speaker terminals 7 and 8 activate only for alarms in partition 1. Use speakers with an 8-ohm or higher impedance. When connecting two or more 8-ohm speakers, they must be wired in series as shown in the wiring diagram. Wiring two or more 8-ohm speakers in parallel can permanently damage the panel.

Note 4

Onboard outputs 1 and 2 are open-collector type rated for 200 mA maximum. Output 1 defaults to configuration number 01614 (exterior siren). Output 2 defaults to configuration number 01710 (interior siren). Refer to panel installation instructions for all possible settings.

Note 5

Zone (loop) wiring shown is an example that applies to all zones (except when zone 8 is configured for 2-wire smoke detectors). Install EOL resistors across all unused zone (loop) inputs.

Note 6

For UL Listed installations, wire multiple supervised hardwire smoke detectors (10 maximum) only as shown. Maximum 10 uA current draw per detector. Maximum 80 mA current draw in alarm.

Note 7

Some telephones are polarity-sensitive. Green and red wires may need to be reversed.

Note 8

A maximum of two Audio Verification Modules (60-677) are allowed (partition 1 only). Wire multiple speakers in series, and power and microphone wires in parallel. Use shielded cable where shown in diagram to prevent cross-talk between the speaker and microphone. Audio Verification Modules shall not be used in UL Listed installations.

Note 9

Connect multiple piezo sirens in parallel. Slim Line Hardwire Interior Siren status volume switch settings have no effect.

Note 10

Refer to the *SuperBus 2000 Energy Saver Module Installation Instructions* for thermostat wiring details.

Note 11

Wire Hardwire Module zone (loop) inputs as shown for the panel. Install EOL resistors across all unused zone (loop) inputs. Refer to the *Module Installation Instructions* for complete details.

