

MAESTRO-600, MAESTRO-1000

6 and 10 Zone Alarm Control Panel



Programming Guide

1. INTRODUCTION

The **Maestro-600** and **Maestro-1000** alarm control panels enable reduced number of programming steps. End-users can access most system features at the touch of just one key.

A "streamlined programming" feature further simplifies the programming process, by saving data automatically and leading the installer through the programming addresses without the need to enter them manually.

The control panel programming includes "Intellizone" definition, "Auto Zone Shutdown", "Beep On Exit Delay", "Programmable Delay before Alarm Transmission" and "Recent Closing" report.

Each control panel can be used to monitor two distinct security systems. Partitioning provides a practical and flexible solution in situations where combined systems are a necessity. Zones can be assigned to "System A", "System B", both systems or given no system assignment.

Almost any control panel condition or event may be used to activate the **MAESTRO'S** programmable output (PGM). Once a panel status mode is selected for the PGM to follow, the polarity and duration of the output may also be programmed.

The **MAESTRO-1000** control panel includes the Advanced Technology Zoning (ATZ) feature, which was developed to permit connection of 2 zones on one zone input terminal, as well as providing wire fault recognition on both zones. ATZ simplifies the task of meeting the zone requirements of any installation while reducing installation costs.

Before you begin programming the control panel, it is recommended to read sections 5 through 11 of the Maestro-600 and Maestro-1000 Installation Instructions, in order to acquire a good understanding of the control panel and its functions.

2. HEXA PROGRAMMING

Addresses 000 to 043 and 300 to 527 are programmed using the Hexa Programming method. In this mode, you can enter any hexa-digit from 0-F where keys [1] to [9] represent digits 1 to 9 respectively; the other keys represent hexa digits A to F as shown in figure 1.




FIGURE 2




FIGURE 1

To program using the Hexa Programming method:

- 1) Press [ENT] + [INSTALLER CODE]
- 2) The red "PRG" indicator will flash indicating that you are in programming mode
- 3) Enter the desired [3-DIGIT ADDRESS] and the red "PRG" indicator will remain illuminated
- 4) The keypad will display the 2-digit data currently saved at this address as described in figure 2
- 5) Enter [2-DIGIT DATA]; after entering data you do not need to press [ENT], the software will automatically save the data into the selected address.
- 6) Return to step 2 to continue programming or press [CLR] to exit programming mode

3. STREAMLINED SECTION PROGRAMMING

This is an alternate method to Hexa Programming. The addresses (000-043 and 300-527) programmed in the Hexa Programming method are grouped into 67 sections where each section contains four addresses (i.e. section 11 = addresses 300-303). Using this method allows you to program 8 digits (4 addresses) without having to exit and re-enter addresses. Note, the keypad will not display the

current data in the Hexa Streamlined Programming method.

To program using the Hexa Streamlined Section method:

- 1) Press [ENT] + [INSTALLER CODE] + [7].
- 2) The red "PRG" and "2ND" LED indicators will flash to indicate you are in programming mode.
- 3) Enter [2-DIGIT SECTION] (00-67).

- 4) The red "PRG" indicator will remain on and "2ND" LED indicator will turn off.
- 5) Enter [8-DIGIT DATA] to program the section.
- 6) The keypad will emit a confirmation "beep" to indicate that the section has been programmed, data is saved and that the software has advanced to the next section.
- 7) Return to step 5 to continue programming at the next address or press [CLR] to exit the programming mode.

INSTALLER CODE (Default 1111)

Full access to programming, except user access codes. No access to arming/disarming. Use only numeric keys from [1] to [0].

Streamline Data Description Address

section

00	--/--	Installer code (1st , 2nd digit)	000
	--/--	Installer code (3rd , 4th digit)	001
	--/--	Installer code (5th , 2nd digit)	002
	--/--	Panel answer options	003

↓

└─┬─┘ Number of rings (Max. 15)

Table 1 - Answering machine override

[2ND] or [1] = disabled	[5] = 40 seconds
[2] = 16 seconds	[6] = 48 seconds
[3] = 24 seconds	[7] = 56 seconds
[4] = 32 seconds	[8] to [F] = 60 seconds

Streamline Data Description Address

section

01	--/--	Panel identifier (1st , 2nd digit)	004
	--/--	Panel identifier (3rd , 4th digit)	005
	--/--	PC password (1st , 6th digit)	006
	--/--	PC Password (3rd, 4th digit)	007

Identifies the control panel to the PC

Identifies the PC to the control panel

TELEPHONE AND ACCOUNT NUMBERS

CAUTION: If only one central station phone number is used, program the same number for telephone number 1 and 2. If only one account number is required, the same number must be entered for both account "A" and "B". (No Default)

[HOME] = * [BYPASS] = switch from pulse to tone while dialing
 [AWAY] = # [MEM] = pause 4 seconds
 [TRBL] = end of number

COMPUTER TELEPHONE NUMBER (View at addresses 008 to 015.)

Streamline section	Streamline section
02 _/_/_/_/_/_/_/_	03 _/_/_/_/_/_/_/_
1 2 3 4 5 6 7 8	9 10 11 12 13 14 15 16

Caution: Press [TRBL] to end phone number if less than 16 digits are programmed.

CENTRAL STATION TELEPHONE NUMBER 1 (View at addresses 016 to 023.)

Streamline section	Streamline section
04 _/_/_/_/_/_/_/_	05 _/_/_/_/_/_/_/_
1 2 3 4 5 6 7 8	9 10 11 12 13 14 15 16

Caution: Press [TRBL] to end phone number if less than 16 digits are programmed.

CENTRAL STATION TELEPHONE NUMBER 2 (View at addresses 024 to 031.)

Streamline section	Streamline section
06 _/_/_/_/_/_/_/_	07 _/_/_/_/_/_/_/_
1 2 3 4 5 6 7 8	9 10 11 12 13 14 15 16

Caution: Press [TRBL] to end phone number if less than 16 digits are programmed

ACCOUNT "A" AND "B": (View at addresses 032 to 035.)

Streamline section	Streamline section
08 _/_/_/_/_/_/_/_	_/_/_/_/_/_/_/_
1 2 3 4 5 6 7 8	A B

Caution: For 3 digit account numbers, enter [2ND] as first digit.

Streamline section	Data	Description	Address
09	[2ND]/[2ND]	Future use	036
	[2ND]/__	1st digit: value must be entered i.e. [2nd]. 2nd digit: time correction (see time correction, table 2)	037
	__/_	1st digit: telephone 1 format. 2nd digit: telephone 2 format see communicator formats, table 3)	038
	__/[2ND]	1st digit: PGM 1 type	039
10	__/_	PGM 1	040
	[2ND]/[2ND]	N/A	041
	__/_	PGM mask 1	042
	[2ND]/[2ND]	n/a	043

Table 2 - Time correction:
(address 037 second digit)

[2nd] - No adjustment	[8] - Minus 4 sec.
[1] - Plus 4 sec.	[9] - Minus 8 sec.
[2] - Plus 8 sec.	[0] - Minus 12 sec.
[3] - Plus 12 sec.	[HOME] - Minus 16 sec.
[4] - Plus 16 sec.	[AWAY] - Minus 20 sec.
[5] - Plus 20 sec.	[BYPASS] - Minus 24 sec.
[6] - Plus 24 sec.	[MEM] - Minus 28 sec.
[7] - Plus 28 sec.	[TRBL] - Minus 32 sec.

Table 3 - COMMUNICATOR FORMATS

KEY	KEY
[2nd] = ADEMCO slow (1400Hz, 1900Hz, 10bps)	[6] = RADIONICS with PARITY (1400Hz, 40bps).
[1] = (1400Hz, 1800Hz, 10bps)	[7] = RADIONICS with PARITY (2300Hz, 40bps).
[2] = SILENT KNIGHT fast - (1400Hz, 1900Hz, 20bps)	[8] = * ADEMCO express
[3] = SESCOA (2300Hz, 1800Hz, 20bps)	[9] = * ADEMCO contact ID (programmable codes)
[4] = RADIONICS (40bps with 1400Hz handshake).	[0] = * ADEMCO contact ID (all codes)
[5] = RADIONICS (40bps with 2300Hz handshake).	[TRBL] = *DTMF - no handshake (personal dialing)
	* = 4-Digit Account Codes Only

PROGRAMMABLE CONTACT ID EVENT CODES

All addresses from 300 to 527 (sections 11 to 67) programmed with value other than [2ND] [2ND] will report the contact ID codes corresponding to the values programmed. Values to be programmed should be selected from this table.

CID	REPORTING CODE	PROG. VALUE
100:	AUXILIARY ALARM	[2ND] / [1]
110:	FIRE ALARM	[2ND] / [2]
111:	FIRE SMOKE	[2ND] / [3]
112:	COMBUSTION	[2ND] / [4]
113:	WATER FLOW	[2ND] / [5]
114:	HEAT	[2ND] / [6]
115:	PULLSATION	[2ND] / [7]
116:	DUCT	[2ND] / [8]
117:	FLAME	[2ND] / [9]
118:	NEAR ALARM	[2ND] / [0]
120:	PANIC ALARM	[2ND] / [HOME]
121:	DURESS	[2ND] / [AWAY]
122:	SILENT PANIC	[2ND] / [BYPASS]
123:	AUDIBLE PANIC	[2ND] / [MEM]
130:	BURGLARY	[2ND] / [TRBL]
131:	PERIMETER BURG.	[1] / [2ND]
132:	INTERIOR BURG.	[1] / [1]
133:	24HR BURGLARY	[1] / [2]
136:	BURGLARY OUTDOOR	[1] / [3]
137:	BURGLARY TAMPER	[1] / [4]
138:	BURGLARY NEAR ALARM	[1] / [5]
140:	GENERAL ALARM	[1] / [6]
150:	24 HOUR AUX	[1] / [7]
151:	GAS DETECTED	[1] / [8]
152:	REFRGERATION	[1] / [9]
153:	LOSS OF HEAT	[1] / [0]
154:	WATER LEAKAGE	[1] / [HOME]
155:	FOIL BREAK ALARM	[1] / [AWAY]
156:	DAY TROUBLE ALARM	[1] / [BYPASS]
157:	LOW GAS LEVEL	[1] / [MEM]
158:	HIGH TEMPERATURE	[1] / [TRBL]
159:	LOW TEMPERATURE	[2] / [2ND]
161:	LOSS AIR FLOW	[2] / [1]

CID	REPORTING CODE	PROG. VALUE
300:	YSTEM TROUBLE	[2] / [2]
301:	AC LOSS	[2] / [3]
302:	LOW SYSTEM BATTERY	[2] / [4]
305:	SYSTEM RESET	[2] / [5]
306:	PROGRAM CHANGED	[2] / [6]
309:	BATTERY TEST FAIL	[2] / [7]
320:	SOUNDER/RELAY TROUBLE	[2] / [8]
321:	BELL 1 TROUBLE	[2] / [9]
323:	ALARM RELAY TROUBLE	[2] / [0]
350:	COMMUNICATION TROUBLE	[2] / [HOME]
351:	TELCO 1 FAULT	[2] / [AWAY]
354:	FAIL TO COMMUNICATE	[2] / [BYPASS]
370:	PROTECTION LOOP TROUBLE	[2] / [MEM]
371:	PROTECTION LOOP OPEN	[2] / [TRBL]
372:	PROTECTION LOOP SHORT	[3] / [2ND]
373:	FIRE LOOP TROUBLE	[3] / [1]
382:	SENSOR TYROUBLE	[3] / [2]
383:	SENSOR TAMPER	[3] / [3]
400:	OPEN/CLOSE	[3] / [4]
401:	OPEN/CLOSE BY USER #	[3] / [5]
402:	GROUP OPEN/CLOSE	[3] / [6]
403:	AUTOMATIC OPENING/CLOSING	[3] / [7]
404:	LATE TO OPEN/CLOSE	[3] / [8]
407:	REMOTE ARM DOWNLOAD	[3] / [9]
410:	REMOTE ACCESS	[3] / [0]
441:	OPEN/CLOSE - STAY MODE	[3] / [HOME]
570:	BYPASS	[3] / [AWAY]
572:	24 HOUR ZONE BYPASS	[3] / [BYPASS]
573:	BURGLARY BYPASS	[3] / [MEM]
574:	GROUP BYPASS	[3] / [TRBL]
601:	MANUAL TEST	[4] / [2ND]
602:	PERIODIC TEST	[4] / [1]
625:	TIME/DATE RESET	[4] / [2]

For address 044 to 126, see sections 5 and 6.

4. REPORTING CODES

All digits from [1] to [F] are valid. Entering [2ND] = digit will not be reported except for contact I.D. programming codes. For single digit reporting enter [2ND] as first digit. (Default = "empty" [2ND] [2ND]).

If CONTACT I.D. format (all codes) is selected, addresses 300 to 527 (sections 11 - 67) do not have to be programmed. (Select Contact I.D. (all codes - key [0] for both central station numbers at section 09 - address 038)

ARMING (closing) CODES

Streamline section	Data	Description	Address
11	—/—	Auto	300
	—/—	Master	301
	—/—	User code 1	302
	—/—	User code 2	303

12	—/—	User code 3	304
	—/—	User code 4	305
	—/—	User code 5	306
	—/—	User code 6	307
13	—/—	User code 7	308
	—/—	User code 8	309
	—/—	User code 9	310
	—/—	User code 10	311
14	—/—	User code 11	312
	—/—	User code 12	313
	—/—	User code 13	314
	—/—	User code 14	315

15	[—/—	User code 15	316
		—/—	User code 16	317
		—/—	User code 17	318
		—/—	User code 18	319
16	[—/—	User code 19	320
		—/—	User code 20	321
		—/—	User code 21	322
		—/—	User code 22	323
17	[—/—	User code 23	324
		—/—	User code 24	325
		—/—	User code 25	326
		—/—	User code 26	327
18	[—/—	User code 27	328
		—/—	User code 28	329
		—/—	User code 29	330
		—/—	User code 30	331
19	[—/—	User code 31	332
		—/—	User code 32	333
		—/—	User code 33	334
		—/—	User code 34	335
20	[—/—	User code 35	336
		—/—	User code 36	337
		—/—	User code 37	338
		—/—	User code 38	339
21	[—/—	User code 39	340
		—/—	User code 40	341
		—/—	User code 41	342
		—/—	User code 42	343
22	[—/—	User code 43	344
		—/—	User code 44	345
		—/—	User code 45	346
		—/—	User code 46	347
23	[—/—	User code 47	348
		—/—	User code 48/Duress	349

26	[—/—	User code 9	360
		—/—	User code 10	361
		—/—	User code 11	362
		—/—	User code 12	363
27	[—/—	User code 13	364
		—/—	User code 14	365
		—/—	User code 15	366
		—/—	User code 16	367
28	[—/—	User code 17	368
		—/—	User code 18	369
		—/—	User code 19	370
		—/—	User code 20	371
29	[—/—	User code 21	372
		—/—	User code 22	373
		—/—	User code 23	374
		—/—	User code 24	375
30	[—/—	User code 25	376
		—/—	User code 26	377
		—/—	User code 27	378
		—/—	User code 28	379
31	[—/—	User code 29	380
		—/—	User code 30	381
		—/—	User code 31	382
		—/—	User code 32	383
32	[—/—	User code 33	384
		—/—	User code 34	385
		—/—	User code 35	386
		—/—	User code 36	387
33	[—/—	User code 37	388
		—/—	User code 38	389
		—/—	User code 39	390
		—/—	User code 40	391
34	[—/—	User code 41	392
		—/—	User code 42	393
		—/—	User code 43	394
		—/—	User code 44	395
35	[—/—	User code 45	396
		—/—	User code 46	397
		—/—	User code 47	398
		—/—	User code 48/Duress	399

REPORTING CODES: (reset code "empty")

Disarming (opening) codes

23	[—/—	User code Visload	350
		—/—	User code Master	351
24	[—/—	User code 1	352
		—/—	User code 2	353
		—/—	User code 3	354
		—/—	User code 4	355
25	[—/—	User code 5	356
		—/—	User code 6	357
		—/—	User code 7	358
		—/—	User code 8	359

ALARM CODES ZONE 1 TO 10

Streamline section	Data	Description	Address
36	—/—	Zone 1	400
	—/—	Zone 2	401
	—/—	Zone 3 (fire)	402 (see add. 100)
	—/—	Zone 4	403

37	[—/—	Zone 5	404
		—/—	Zone 6	405
		—/—	Zone 7	406
		—/—	Zone 8	407
38	[—/—	Zone 9	408
		—/—	Zone 10	409
		[2nd]/2nd	N/A	410
		[2nd]/2nd	N/A	411

55	[—/—	Tamper 5 (ATZ) (*)	476
		[2nd]/2nd	N/A	477
		—/—	Tamper 7 (ATZ) (*)	478
		[2nd]/2nd	N/A	479

*(Maestro-1000 only)

56	[[2nd]/2nd	N/A	480
		[2nd]/2nd	N/A	481
		[2nd]/2nd	N/A	482
		[2nd]/2nd	N/A	483

REPORTING CODES: (reset code "empty")

ZONES 1 TO 10 RESTORE CODES:

Streamline	Data	Description	Address	
42	[—/—	Zone 1	424
		—/—	Zone 2	425
		—/—	Zone 3 (fire)	426 (*)
		—/—	Zone 4	427
* (see add. 100)				
43	[—/—	Zone 5	428
		—/—	Zone 6	429
		—/—	Zone 7 (Maestro-1000 only)	430
		—/—	Zone 8 (Maestro-1000 only)	431
44	[—/—	Zone 9 (Maestro-1000 only)	432
		—/—	Zone 10 Maestro-1000 only	433
		—/—	N/A	434
		—/—	N/A	435

ZONES 1 TO 10 SHUTDOWN CODES:

Streamline	Data	Description	Address	
48	[—/—	Zone 1	448
		—/—	Zone 2	449
		—/—	Zone 3	450
		—/—	Zone 4	451
49	[—/—	Zone 5	452
		—/—	Zone 6	453
		—/—	Zone 7 (Maestro-1000 only)	454
		—/—	Zone 8 (Maestro-1000 only)	455
50	[—/—	Zone 9 (Maestro-1000 only)	456
		—/—	Zone 10 Maestro-1000 only	457
		[2nd]/2nd	N/A	458
		[2nd]/2nd	N/A	459

ZONES 1 TO 10 TROUBLE CODES:

Streamline	Data	Description	Address	
54	[—/—	Tamper 1 (ATZ) (*)	472
		—/—	Tamper 2	473
		—/—	Tamper 3 (ATZ) (*)	474
		—/—	Tamper 4	475

*(Maestro-1000 only)

TROUBLE CODES

Streamline	Data	Description	Address	
60	[—/—	Max. auxiliary current	496
		—/—	Bell disconnect / max. bell current	497
		—/—	Battery disconnect / Low voltage	498
		—/—	Power failure	499
61	[—/—	Fire loop trouble	500
		—/—	Timer loss	501
		[2nd]/2nd	Future use	502
		[2nd]/2nd	Future use	503

TROUBLE RESTORE CODES:

Streamline	Data	Description	Address	
62	[—/—	Max. auxiliary current	504
		—/—	Bell disconnect	505
		—/—	Battery disconnect / Low voltage	506
		—/—	Power failure	507
63	[—/—	Fire loop trouble	508
		—/—	Timer programmed	509
		—/—	Tamper / wiring fault	510
		—/—	TLM trouble restore	511


SPECIAL CODES:

Streamline	Data	Description	Address	
64	[—/—	Test report	512
		—/—	Panic 1	513
		—/—	Panic 2	514
		—/—	Panic 3	515
65	[—/—	Late to close	516
		—/—	No movement	517
		—/—	Partial arming	518
		—/—	Recent close	519
66	[—/—	Duress	520
		[2nd]/2nd	Future use	521
		[2nd]/2nd	Future use	522
		[2nd]/2nd	Future use	523
67	[—/—	Log-in (Visload)	524
		—/—	Program change	525
		[2nd]/2nd	Future use	526
		[2nd]/2nd	Future use	527

5. DECIMAL PROGRAMMING


- 1) Press [ENT] + [INSTALLER CODE]
- 2) The red "PRG" indicator will flash to indicate you are in programming mode
- 3) Enter [3-DIGIT ADDRESS] (044-061) and the "PRG" indicator will remain on
- 4) The keypad will now display the 3-digit data currently saved at this address as described in figure 3
- 5) Enter [3-DIGIT DATA] (000-255); after entering data you do not need to press [ENT], the software will automatically save the data into the selected address
- 6) Return to step 2 to continue programming or press [CLR] to exit programming mode

**Figure 3
DECIMAL DISPLAY - MAESTRO-601**



As shown above, each LED indicator from 1-6, including the 2ND and TRBL indicators, represent a specific value when lit. If an LED indicator is not lit, it will represent the value 0. Add the values of all the lit LED indicators to obtain the entered data value as shown in the example below.

Example



Therefore 8 + 4 + 1 + 32 = 045

- 044: ___/___/___ (hours) Auto arm time (between "000" and "023")
- 045: ___/___/___ (minutes) Auto arm time (between "000" and "059")
- 046: ___/___/___ (days) Auto test report every ? days (between "001" and "255") (000 = disabled)
- 047: ___/___/___ (hours) Auto test report (between "000" and "023")
- 048: ___/___/___ (minutes) Auto test report (between "000" and "059")
- 049: ___/___/___ (seconds) Exit delay (factory default 60 seconds)
- 050: ___/___/___ (seconds) Entry delay 1 (factory default 45 seconds)
- 051: ___/___/___ (seconds) Entry delay 2 (factory default 45 seconds)
- 052: ___/___/___ (minutes) Bell cut-off time (factory default 5 minutes)
- 053: ___/___/___ (x 15 mSec.) Zone speed (factory default 600 mSec.)
- 054: ___/___/___ (minutes) Power failure report delay (factory default 30 minutes) (000 = disabled)
- 055: ___/___/___ (x 15 minutes) "No movement" report time (factory default 8 hours) (000 = disabled)
- 056: ___/___/___ PGM timer setting (001 to 127 for seconds and 129 to 255 for minutes) (factory default 5 seconds)
Add 128 to desired value in minutes (i.e. for 5 minutes: enter 5 + 128 = 133)
- 057: ___/___/___ Intellizone delay (in seconds, minimum = 10 seconds) (factory default 48 seconds)
- 058: ___/___/___ Installer code lock (147 = locked, 000 = unlocked)
- 059: ___/___/___ (seconds) Programmable delay before alarm transmission (5 to 63 seconds) (000 = disabled)
- 060: ___/___/___ (seconds) Recent closing delay (000 = disabled)
- 061: ___/___/___ Future Use

6. FEATURE SELECT PROGRAMMING

Addresses 062-126. " ON" /" OFF" status of the LED indicators determines feature selection. In programming mode, enter 3 digit memory address (062 to 126). To save entries, press [ENT]. To exit programming mode press [CLR]. Reset = "OFF" for addresses 062 to 126.

		CODE PRIORITY															
Keypad select	LED indicators:	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]	[9]	[0]	[HOME]	[AWAY]	[BYPASS]	[MEM]	[TRBL]	[2ND]
	User #:	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
062:	SYSTEM "A" / HOME	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	User #:	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
064:	SYSTEM "A" / HOME	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	User #:	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48
066:	SYSTEM "A" / HOME	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	User #:	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
068:	SYSTEM "B" / AWAY	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	User #:	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
070:	SYSTEM "B" / AWAY	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	User #:	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48
072:	SYSTEM "B" / AWAY	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	User #:	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
074:	Codes with bypass access	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	User #:	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
076:	Codes with bypass access	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	User #:	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48
078:	Codes with bypass access	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Address 080 to 085 for future use

FEATURE & SELECT PROGRAMMING (continued)

(On/off status of LED indicators determines which feature is selected)

086

See "TLM" table.....

Keyswitch = regular arming.....

Keyswitch arming.....

Call back

Auto arm on time

Auto arm on no movement

Pulse dialing

Partitioning.....

Silent zone/panic generates a silent alarm..

(1:2) Pulse Europe.....

See "Reporting" table.....

N/A

Bell squawk on arm/disarm

Auto zone shutdown.....

LED INDICATOR

OFF / ON

<input type="checkbox"/>	[2ND]	<input type="checkbox"/>
<input type="checkbox"/>	[1]	<input type="checkbox"/>



See "TELEPHONE LINE MONITOR" on next page

[2]

home arm/system A

[3]

enabled

[4]

enabled

[5]

enabled

[6]

enabled

[7]

Tone dialing (DTMF)

[8]

enabled

[9]

generates only report

[0]

(1:1.5) pulse USA

<input type="checkbox"/>	[HOME]	<input type="checkbox"/>
<input type="checkbox"/>	[AWAY]	<input type="checkbox"/>



See "REPORTING OPTIONS" on next page

[BYPASS]

N/A

[MEM]

enabled

[TRBL]

enabled

088:

Automatic event buffer transmission.....

Panic 1 (key [1] & [3]).....

Panic 2 (key [4] & [6]).....

Panic 3 (key [7] & [9]).....

Panic 1 silent

Panic 2 silent

Panic 3 silent

Key [QUICK] regular arm

Key [HOME] quick home or "system A" arm

4 digit access codes

Tamper recognition.....

Beep on exit delay

Report zone restore on bell cut-off

Zones with EOL (1KΩ).....

Always report disarm

LED INDICATOR

OFF / ON

[2ND]

enabled

[1]

enabled

[2]

enabled

[3]

enabled

[4]

audible

[5]

audible

[6]

fire

[7]

enabled

[8]

enabled

[9]

6 digit

<input type="checkbox"/>	[0]	<input type="checkbox"/>
<input type="checkbox"/>	[HOME]	<input type="checkbox"/>



See "TAMPER / WIRE FAULT DEFINITION" on next page

[AWAY]

enabled

[BYPASS]

on zone closure

[MEM]

no EOL

[TRBL]

only after alarm

090:

Exclude power failure from trouble display

Zone 4 enabled

Auto arm = regular arm

N/A.....

N/A.....

N/A.....

No tamper bypass.....

N/A

Zone doubling (ATZ)

Audible trouble warning

Duress

Keypad 1 zone supervision.....

Keypad 2 zone supervision.....

N/A

N/A

N/A

LED INDICATOR

OFF / ON

[2ND]

enabled

[1]

disabled (in case of fire zone 3 only)

[2]

home / System A

[3]

N/A

[4]

N/A

[5]

N/A

[6]

Tamper follows zone bypass definition

[7]

N/A

[8]

enabled

[9]

enabled

[0]

enabled

[HOME]

enabled

[AWAY]

enabled

[BYPASS]

N/A

[MEM]

N/A

[TRBL]

N/A

REPORTING OPTIONS

Address 086, key [HOME] [AWAY]

LED		TYPE	DIALING SEQUENCE (tel. No.)
[HOME]	[AWAY]		
OFF	OFF	- Reporting disabled	
OFF	ON	- Regular reporting	- 1,2,1,2,1,2,1,2, fail to comm.
ON	OFF	- Split reporting: Alarms * System report	- 1,1,1,1,1,1,1,1, fail to comm. - 2,2,2,2,2,2,2,2, fail to comm.
ON	ON	- Double reporting	- 1,1,1,1,1,1,1,1, fail to comm. - 2,2,2,2,2,2,2,2, fail to comm.

* On alarm, all reports are made to Tel. # 1 until system is disarmed. (Once disarmed, system reports are made to Tel. # 2)

TELEPHONE LINE MONITOR

Address 086, key [2nd] [1]

LED		
[2nd]	[1]	
OFF	OFF	- TLM disabled
OFF	ON	- TLM generates trouble only
ON	OFF	- Generates an alarm if armed
ON	ON	- Silent alarm becomes audible

(address 086, key [9] has to be OFF)

TAMPER / WIRE FAULT DEFINITIONS

Address 088, key [0] [HOME]

	KEY		
	[0]	[HOME]	
SYSTEM ARMED Alarm as per individual zone definitions	OFF	OFF	SYSTEM DISARMED* - Tamper supervision disabled
Always generates trouble and alarm audible or silent as per individual zone definitions	OFF	ON	- No alarm, trouble code reported
	ON	OFF	- Silent alarm. Trouble and alarm codes reported.
	ON	ON	- Audible alarm. Trouble and alarm codes reported**

* Exception: for 24 hour zones the tamper definition will follow the audible/silent alarm definition of the 24 hour zone.

** Silent zones will generate a silent alarm.

ZONE DEFINITION: (reset = "OFF")											
LED INDICATORS:		[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]	[9]	[10]
Intellizone = ON	092	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Silent = ON	096	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
24HR./Fire = ON	100	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
▲ When zone 3 is defined "24 Hour" it becomes a fire zone											
Instant = ON	104	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Follow = ON	108	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Delay 2 = ON	112	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
System A / HOME											
If ON, zone is armed on home or "system A" arming	116	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
System B											
If ON, zone is armed in "system B" arming	120	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Bypass enable = ON	124	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Zones that are not selected at addresses 100 to 112 become "Delay 1" zones.

Note: Do not use Intellizone feature and an entry delay on the same zone, otherwise an alarm may occur as a user tries to disarm the system.

7. KEY ACCESS PROGRAMMING

Programs features quickly, without entering addresses or section numbers.

To activate "key access programming", press [ENT], followed by the installer, master or user code 1. (Code required depends on the feature you wish to access - see below.) Press the key corresponding to the desired feature. Press [ENT] or [CLR] to exit.

key

[8] Installer test mode (installer code only)

In installer test mode, a confirmation beep (intermittent) indicates test is "on", a "rejection" beep (long) indicates test is "off". The bell will squawk during walk testing to indicate opened, functional zones.

[9] "Auto arming" time program (all 3 codes)

"9" indicator flashes. Enter two digits (00 to 23) for hours + 2 digits (00 to 59) for minutes.

[MEM] "Panel time" and clear "trouble 8" (all 3 codes)

"MEM" indicator flashes. Enter two digits (00 to 23) for hours + 2 digits (00 to 59) for minutes.

[BYP] Test report (all 3 codes)

Reporting is enabled at address 086, keys [HOME], [AWAY]. A value must be entered at address 512, and both telephone and account numbers must be programmed.

[TRBL] Call Visload via telephone (all 3 codes)

Panel identifier and PC password (addresses 004-007) and computer telephone number (addresses 008-015) must be programmed.

[AWAY] Answer Visload (all 3 codes)

This feature is available when using the ADP-1 adapter (ADP-1 is a module that can be used to connect a modem directly to the panel without the phone line). In Visload, "blind dial" must be activated in "modem setup" section, and panel phone number programmed (works also without ADP-1).

[HOME] Cancel communication attempts (master code and user 1 can only stop calls to Visload)

Until next reportable event (installer code - all communications).

8. CONNECTION DIAGRAMS

The system hardware will recognize the following zone conditions:

SINGLE ZONE CONNECTIONS




FIGURE 4

N.C. Contacts, Without EOL Resistor




FIGURE 5

N.O. Contacts, With EOL Resistor

FIGURE 6

N.C. Contacts, With EOL Resistor




FIGURE 7

N.C. Contacts, Without EOL Resistor, With Tamper Recognition




FIGURE 8

N.C. Contacts, With EOL Resistor, With Tamper and Wire Fault Recognition

TAMPER / WIRE FAULT DEFINITIONS

Address 088, key [0] [HOME]

SYSTEM ARMED	KEY		SYSTEM DISARMED*
	[0]	[HOME]	
Alarm as per individual zone definitions	OFF	OFF	- Tamper supervision disabled
Always generates trouble and alarm audible or silent as per individual zone definitions	OFF	ON	- No alarm, trouble code reported
	ON	OFF	- Silent alarm. Trouble and alarm codes reported.
	ON	ON	- Audible alarm. Trouble and alarm codes reported**

* Exception: for 24 hour zones the tamper definition will follow the audible/silent alarm definition of the 24 hour zone.

** Silent zones will generate a silent alarm.

FIGURE 9






FIGURE 10



Address 088, [MEM] = "on" (without EOL resistor)
 [0] = "off"
 [HOME] = "off" { Tamper/Wire Fault Disabled
 Address 090, [8] = "on" (ATZ enabled; MAESTRO-1000)

FIGURE 11


ATZ N.C. Contacts, Without EOL Resistor
for Maestro-1000 only



Address 088, [MEM] = "on" (without EOL resistor)
 [0] } Refer to Tamper/Wire Fault
 [HOME] } Recognition Options
 Address 090, [8] = "on" (ATZ enabled; MAESTRO-1000 only)

FIGURE 12

ATZ N.C. Contacts, Without EOL Resistor, With
Tamper Recognition - for Maestro-1000 only



Address 088, [MEM] = "off" (with EOL resistor)
 [0] } Refer to Tamper/Wire Fault
 [HOME] } Recognition Options
 Address 090, [8] = "on" (ATZ enabled; MAESTRO-1000 only)

FIGURE 13

ATZ N.C. Contacts, With EOL Resistor, With
Tamper & Wire Fault Recognition
for Maestro-1000 only

KEYPAD ZONE CONNECTION DIAGRAMS

Note: Keypad zones always use (1K OHM) EOL resistor.




FIGURE 14
(for Maestro-1000 only)





FIGURE 15


WIRING DIAGRAM



FIRE ALARM ZONE CONNECTIONS

For Maestro-600 only

Address 090; LED [1] on
Address 100; LED [3] on
To set zone 3 as a fire zone




FIRE ALARM ZONE CONNECTIONS


For Maestro-1000 only

Without ATZ
Address 090; LED [1] on
Address 100; LED [3] on
To set zone 3 as a fire zone


With ATZ enabled
Address 090; LED [1] off
Address 100; LED [3] off



GROUND START CIRCUIT



PGM OUTPUT RELAY



WARRANTY

Visonic Ltd. and/or its subsidiaries and its affiliates ("the Manufacturer") warrants its products hereinafter referred to as "the Product" or "Products" to be in conformance with its own plans and specifications and to be free of defects in materials and workmanship under normal use and service for a period of twelve months from the date of shipment by the Manufacturer. The Manufacturer's obligations shall be limited within the warranty period, at its option, to repair or replace the product or any part thereof. The Manufacturer shall not be responsible for dismantling and/or reinstallation charges. To exercise the warranty the product must be returned to the Manufacturer freight prepaid and insured.

This warranty does not apply in the following cases: improper installation, misuse, failure to follow installation and operating instructions, alteration, abuse, accident or tampering, and repair by anyone other than the Manufacturer.

This warranty is exclusive and expressly in lieu of all other warranties, obligations or liabilities, whether written, oral, express or implied, including any warranty of merchantability or fitness for a particular purpose, or otherwise. In no case shall the Manufacturer be liable to anyone for any consequential or incidental damages for breach of this warranty or any other warranties whatsoever, as aforesaid.

This warranty shall not be modified, varied or extended, and the Manufacturer does not authorize any person to act on its behalf in the modification, variation or extension of this warranty. This warranty shall apply to the Product only. All products, accessories or attachments of others used in conjunction with the Product, including batteries, shall be covered solely by their own warranty, if any. The Manufacturer shall not be liable for any damage or loss whatsoever, whether directly, indirectly, incidentally, consequentially or otherwise, caused by the malfunction of the Product due to products, accessories, or attachments of others, including batteries, used in conjunction with the Products.

The Manufacturer does not represent that its Product may not be compromised and/or circumvented, or that the Product will prevent any death, personal and/or bodily injury and/or damage to property resulting from burglary, robbery, fire or otherwise, or that the Product will in all cases provide adequate warning or protection. User understands that a properly installed and maintained alarm may only reduce the risk of events such as burglary, robbery, and fire without warning, but it is not insurance or a guarantee that such will not occur or that there will be no death, personal damage and/or damage to property as a result.

The Manufacturer shall have no liability for any death, personal and/or bodily injury and/or damage to property or other loss whether direct, indirect, incidental, consequential or otherwise, based on a claim that the Product failed to function. However, if the Manufacturer is held liable, whether directly or indirectly, for any loss or damage arising under this limited warranty or otherwise, regardless of cause or origin, the Manufacturer's maximum liability shall not in any case exceed the purchase price of the Product, which shall be fixed as liquidated damages and not as a penalty, and shall be the complete and exclusive remedy against the Manufacturer.

Warning: The user should follow the installation and operation instructions and among other things test the Product and the whole system at least once a week. For various reasons, including, but not limited to, changes in environmental conditions, electric or electronic disruptions and tampering, the Product may not perform as expected. The user is advised to take all necessary precautions for his /her safety and the protection of his/her property.

6/91



VISONIC LTD. (ISRAEL): P.O.B 22020 TEL-AVIV 61220 ISRAEL. PHONE: (972-3) 645-6789, FAX: (972-3) 645-6788

VISONIC INC. (U.S.A.): 10 NORTHWOOD DRIVE, BLOOMFIELD CT. 06002-1911. PHONE: (860) 243-0833, (800) 223-0020 FAX: (860) 242-8094

VISONIC LTD. (UK): UNIT 1, STRATTON PARK, DUNTON LANE, BIGGLESWADE, BEDS. SG18 8QS. PHONE: (01767) 600857 FAX: (01767) 601098

VISONIC LTD. 1998 MAESTRO-600, MAESTRO-1000 DE5280P (REV. 0, 9/98)