



Home Why Us? Products Your System Which System? False Alarms FAQs Tips In-Home Presentation



Up to 12 Keypads

- ⌘ up to 8 hardwired keypads and 4 wireless keypads
- ⌘ 4 hardwired keypads available with zone input...
 - P832-08Z eight zone LED keypad
 - P832-16Z sixteen zone LED keypad
 - P832-32Z thirty two zone LED keypad
 - P832-LCDZ alphanumeric keypad
- ⌘ PWLS910... wireless handheld keypad
- ⌘ added wireless control is provided by ...
 - PWLS908... wireless panic pendant
 - PWLS909... wireless key

32 Zones Hardwired or Wireless ... 2 Partitions

Hardwired

- ⌘ 8 zones on main panel
- ⌘ 8 keypad zones
- ⌘ P5108 - 8 zone expansion module
- ⌘ P5108L - 8 zone expansion module plus Downlook video on P-832DL panels
- ⌘ P5100 - 32 zone addressable multiplexed loop interface module
- ⌘ P5700 ... *Canada only* - 4 general purpose zones, 2 waterflow zones, 1 ground fault

Advanced Communications

- ⌘ supports all major formats including SIA and Contact ID
- ⌘ LINKS1000™ cellular communication
- ⌘ LINKS2150™ and LINKS2450™ long range radio communication
- ⌘ DVACS communication using P5400 or P5720 modules
- ⌘ Downlook video transmission using P5108L module with the P-832DL main control panel
- ⌘ event initiated personal paging
- ⌘ 3 phone numbers (3rd backs up primary number)
- ⌘ 2 account numbers

Integrated Intercom Audio

- ⌘ supports Central Station Two Way Voice and Home Intercom features using P5928 audio interface module, P5922 intercom stations, and P5904 two way listen-in stations

Integrated CCTV

- ⌘ supports Downlook still frame video transmission using P5108L module with the P-832DL main control panel
- ⌘ provides local VCR/monitor video switching for 8 cameras

- zone, plus dual supervised telephone lines
- ⌘ **P5720** ... *Canada only* - 5 general purpose zones, 2 waterflow zone, 1 ground fault zone, plus printer or DVACS communications

Wireless

- ⌘ **P5132** - 32 zone wireless zone expansion module

14 PGM Outputs

- ⌘ **up to 5 high current outputs... 1 on main panel plus:**
 - P5204** - 4 output high current power supply module
 - 1 output fully supervised for siren output
- ⌘ **up to 9 low current outputs... 1 on main panel plus:**
 - P5208** - 8 low current output module

Integrated Voice Assisted Security & Home Automation

- ⌘ **P5580 & P5580TC Escort provide voice assisted security and automation control for up to 32 X-10 devices plus thermostat control on the P5580TC**

Efficient Installation

- ⌘ **4 wire communications bus (KEYBUS)**
 - connect modules up to 1000' (305m) from control panel
 - P5204 - 4 output high current power supply module provides up to 1A auxiliary power
 - main panel provides up to 550mA auxiliary power

P-832/P-832DL Main Control Panels

- ⌘ **P-832 main control panel - alarm only**
- ⌘ **P-832DL main control panel - alarm plus Downlook video capability**
- ⌘ **support up to 32 zones using any combination of up to:**
 - 8 hardwire zones on main panel
 - 8 hardwire zones using P5108L video matrix module (on P-832DL only)
 - 4 general purpose hardwire zones and 2 waterflow hardwire zones using P5700 fire module (in Canada only)
 - 24 hardwire zones using P5108 eight zone expander modules
 - 8 keypad zones
 - 32 wireless zones using P5132 wireless receiver module

System Operation

- ⌘ **2 system partitions... 2 account numbers**
 - each partition acts as a separate alarm system with any number of zones, user codes, keypads and individually programmable features
- ⌘ **38 - 4 or 6 digit access codes**
 - 32 user codes, 1 system master code, 2 partition master codes, 2 duress codes, and 1 maintenance code
- ⌘ **automatic arming by partition**
 - each partition may be programmed to auto-arm at its own time each day

⌘ zone programming

- all zones programmable as burglary or fire
- zone options include: Normally Closed loop, Single End of Line (EOL) resistor, and Double EOL resistor (1)

(1) keypad zones cannot be programmed as fire zones and cannot support Double EOL resistor supervision

- 27 programmable zone types, 8 programmable zone options

⌘ audible alarm output

- supervised bell output
- 700mA @ 12Vdc, PTC protected, current limited at 3A
- steady, pulsed, temporal pattern, or strobe fire output
- additional supervised siren output is available using P5204 power supply module

⌘ programmable voltage outputs

- 1 high current 300mA PGM... can also be used for 2 wire smoke with a maximum of 20 detectors at 15mA per detector
- 1 low current 50mA PGM
- 8 additional low current PGM outputs using P5208 module
- 4 additional high current PGM outputs using P5204 module
- 24 programmable options

⌘ local PCLINK™ and remote upload/download capability

- program system using Comm-Link DLS software and direct PC connection to control panel or via remote PC over telephone line
- view status and trouble conditions, and system 128 event buffer
- remote access can be controlled by owner to prevent unauthorized access to system

⌘ power supply

- 550mA @ 12.5Vdc auxiliary power (400mA for UL applications)
- positive temperature coefficient (PTC) protected battery, AUX, and Bell output
- electronic protection of KEYBUS
- supervision of AC power loss, low battery, auxiliary power failure
- internal clock locked to AC power frequency

⌘ EEPROM memory

⌘ keypad lockout

- panel can be programmed to lockout keypad if a series of incorrect access code entries are made

⌘ 'quick arm' and 'quick exit'

- allows users to arm and exit easily

⌘ 'stay/away' zones and 'stay' arming

- security of perimeter arming while premise is occupied

⌘ door chime

- programmable by zone
- monitor a door by having keypad beep when the door is opened and again when door is closed

⌘ 128 event buffer

- all events automatically stored with time and date stamp to buffer
- events can be printed on-site using the P5400 serial printer interface module, viewed through an LCD Keypad, or viewed and printed via PC using Comm-Link DLS software

Full Supervision

The system continuously monitors the following trouble conditions

⌘ AC power failure

⌘ trouble by zone

⌘ fire trouble

⌘ telephone line trouble

⌘ low battery

⌘ bell output trouble

⌘ loss of internal clock

⌘ tamper by zone

⌘ fail to communicate

⌘ aux power supply fault

⌘ module fault (supervisory or tamper)

⌘ camera troubles (on P-832DL with Downlook)

False Alarm Prevention Features

⌘ audible exit delay

⌘ audible exit fault

- will not lose programming or system status on complete AC and battery failure
 - ⌘ **digital communicator**
 - supports all major formats including SIA & Contact ID
 - supports LINKS1000™ cellular communications - supports LINKS2150™ and LINKS2450™ long range radio communications
 - 3 phone numbers (3rd backs up primary)
 - 2 account numbers
 - DTMF or pulse dialing
 - DPDT line seizure
 - anti-jam feature
 - split reporting of selected events to each telephone number
 - event initiated personal paging
 - ⌘ **battery required:** 12V, 4Ah, rechargeable sealed lead acid
 - ⌘ **transformer required:** 16.5Vac, 40VA
 - ⌘ **quick exit**
 - ⌘ **urgency on entry delay**
 - ⌘ **swinger shutdown**
 - ⌘ **cross zone alarm**
 - ⌘ **recent closing transmission**
 - ⌘ **burglary verified timer***
 - ⌘ **double hit timer***
 - ⌘ **communication delay**
 - ⌘ **rotating keypress buffer**
 - ⌘ **arm/disarm bell squawk**
- * on P-832DL v2.2x and higher

Interfaces & Expansion Modules

P832-LCDZ Plain Language Keypad



The P-832 security system is fully programmable from the attractive, easy to use dual-language P832-LCDZ keypad:

LED Keypads



The P-832 system is fully programmable from any of the attractive, easy to use, LED keypads:

- ⌘ **3 keypads available:**

- ⌘ **connect up to 8 keypads, combination LED and/or LCD**
- ⌘ **zone input**
 - connect detector to keypad to avoid separate wiring back to panel
- ⌘ **multi-language** (*languages vary according to country*)
 - supervised bell output
 - 700mA @ 12Vdc, PTC protected, current limited at 3A
 - steady, pulsed, temporal pattern, or strobe fire output
 - additional supervised siren output is available using P5204 power supply module
 - simple key entry to toggle between languages while viewing keypad
- ⌘ **rotating keypress buffer reduces access code entry false alarms**
- ⌘ **large 32 character display**
 - zone identification
 - system instructions
 - system status
 - 128 event buffer
 - trouble conditions
- ⌘ **plain language operating instructions**
 - menu for user functions
 - what key to press for specific functions
 - steps for programming functions
- ⌘ **automatic scrolling of alarms in memory**
 - scrolls through alarms in memory while keypad is idle
- ⌘ **12 hour or 24 hour clock display**
- ⌘ **5 programmable function keys with 25 options such as Home Arm, Away Arm, Quick Exit etc.**
- ⌘ **4 keypad-activated alarm: Fire, Auxiliary, Panic, and Duress**
- ⌘ **3 LED indicators: Ready, Armed and Trouble**
 - allow system status to be viewed at a glance

- P832-08Z... 8 zone LED keypad
- P832-16Z... 16 zone LED keypad
- P832-32Z... 32 zone LED keypad

- ⌘ **zone input**
 - connect detector to keypad to avoid separate wiring back to panel
- ⌘ **rotating keypress buffer reduces access code entry false alarms**
- ⌘ **5 programmable function keys with 25 options such as Home Arm, Away Arm, Quick Exit etc.**
- ⌘ **LED indicators:** Ready, Armed, Trouble, Memory, Bypass, Fire, Program
- ⌘ **4 keypad-activated alarms...Panic, Auxiliary, Fire, and Duress**
- ⌘ **backlit display**...with Backlighting Boost to provide extra high key lighting when any key is pressed
- ⌘ **piezo buzzer**...provides audible feedback for correct key entries, pre-alert, and system trouble status... with adjustable buzzer tone
- ⌘ **connect to 4 wire KEYBUS up to 1,000' (305m) from control panel**
- ⌘ **specifications**
 - current draw: 85mA with backlighting boost
 - dimensions: 5.75"W x 4.5"H x 1"D (144 x 114 x 25mm)

P5400 Printer Interface Module



- ⌘ **both P5400 and P5400DV may be used at the same time on a system**
- ⌘ **provides RS232 serial printer connection for report of events logged to the system event buffer... prints event, partition, time, and date that event occurred**

- ⌘ **backlit display**
 - display and keys backlit for easy viewing in low light conditions
 - adjustable brightness and contrast
 - Backlighting Boost provides extra high key lighting when any key is pressed
- ⌘ **piezo buzzer**
 - provides audible feedback for correct key entries, pre-alert, and system trouble status
 - adjustable buzzer tone
- ⌘ **connect to 4 wire KEYBUS up to 1,000' (305m) from control panel**
- ⌘ **specifications**
 - current draw : 85mA with backlighting boost
 - dimensions : 5.75"W x 4.5"H x 1"D (144 x 114 x 25mm)
- ⌘ **supports any 300, 1200, 2400 or 4800 BPS serial printer**
- ⌘ **connect printer up to 200' (61m) from P5400**
- ⌘ **connect P5400 up to 1,000' (305m) from control panel via KEYBUS**
- ⌘ **current draw: 65mA @ 12VDC**
- ⌘ **maximum one module per system**

P5400DV - DVACS Interface Module

- ⌘ **both P5400 and P5400DV may be used at the same time on a system**
- ⌘ **provides ULC Level 3 Line Security.**
- ⌘ **provides full DVACS reporting of all system events.**
- ⌘ **module is pre-programmed to SIA zone definitions**
- ⌘ **events simultaneously communicated via DVACS and other installed communications mode such as digital or cellular**
- ⌘ **full cross supervision between the system control panel and the DVACS module e.g... problems with one will be communicated to the central station by the other.**
- ⌘ **central station requires Sur-Gard**

P5720 Fire/Printer/DVACS Module ...Canada only

- ⌘ **a zone expansion module which can also be used to provide either a serial printer or DVACS communications interface**
- ⌘ **8 zone inputs include:**
 - 2 ClassA supervisory waterflow zones
 - ground fault detection zone
 - 5 general purpose fire or burglary zones
- ⌘ **as RS232 printer interface:**
 - baud rates... 300, 1200, 2400, 4800
 - connect printer up to 200' (61m) from the P5720 module
- ⌘ **as DVACS interface: same as P5400DV**

receiver with DVL2A version 2 or higher software.

- ⌘ complete with 8 pin jack, and communications and power cables for connection to F1/F2 subset.
- ⌘ connect up to 1,000' (305m) from control panel via KEYBUS
- ⌘ module current draw: 65mA @ 12VDC

Hardwired Expansion

P5108 - 8 Zone Expansion Module

- ⌘ adds 8 hardwired general purpose burglary or fire zones
- ⌘ provides 100mA @ 12VDC auxiliary current, PTC protected
- ⌘ connect up to 1000' (305m) from control panel via KEYBUS
- ⌘ module current draw: 35mA @ 12VDC

P5100 - 32 Zone Addressable Loop Interface Module

- ⌘ add 32 DSC addressable devices on a 2-wire multiplexed loop. Devices include:
 - Partner AMA-100... glassbreak detector
 - Partner AMS-220 series... photoelectric smoke detectors
 - Partner AMB-300... PIR motion detector
 - Partner AMB-500... ceiling mount 360° PIR
 - Partner AMB-600... dual element pet immune PIR
 - Partner AMP-700 series... contact modules
- ⌘ connect up to 1,000' (305m) from control panel via KEYBUS
- ⌘ module current draw: 40mA @ 12VDC
- ⌘ addressable loop maximum current draw: 170mA @ 12VDC
- ⌘ compatible with P-832v2.x and P-

Wireless Expansion

P5132 Wireless Receiver



- ⌘ add up to 32 DSC wireless detectors* including:
 - PWLS904 passive infrared alarm
 - PWLS906 photoelectric smoke alarm
 - PWLS907 universal transmitter/contact
 - PWLS912 glassbreak detector
 - PWLS914 dual element pet immune PIR
 - PWLS915 door/window contact
 - PWLS917 recessed door/window contact
- ⌘ 900MHz true 'Spread Spectrum' technology, fully supervised for communication integrity
- ⌘ easy sensor enroll process
- ⌘ supervisory transmissions every 12 minutes
- ⌘ programmable 1-24hr supervisory window
- ⌘ connect up to 1,000' (305m) from control panel via KEYBUS
- ⌘ module current draw: 130mA @ 12VDC

Wireless Control Devices



- ⌘ PWLS908 Wireless Panic Pendant
 - communicates a non-medical alarm to central station

832DLv2.x or higher

...Canada only
P5700 Fire Zone Expansion Module

- ⌘ **a zone expansion module which provides:**
 - dual supervised telephone lines
 - 2 Class A supervisory waterflow zones
 - ground fault detection zone
 - 4 general purpose fire or burglary zones
- ⌘ **tamper and trouble reporting codes**
- ⌘ **connect up to 1000' (305m) from control panel via KEYBUS**
- ⌘ **module current draw: 150mA @ 12VDC**

- 32 pendants maximum...each occupying 1 alarm zone
- sealed non-replaceable battery

- ⌘ **PWLS909 Wireless Key**
 - remote arm/disarm control
 - up to 16 keys per system
 - 3 photo/electronic 1.5V batteries included
- ⌘ **PWLS910 Wireless Hand-Held Keypad**
 - personal remote keypad
 - up to 4 wireless keypads per system (in addition to hardwired keypads)
 - 3 'AAA' batteries included

Integrated Voice Assisted Security & Home Automation



P5580 Escort Voice Assisted Security & Automation Control Module

- ⌘ **turns any touch-tone phone into a fully functional keypad with Global and Partition control**
- ⌘ **built-in power line interface for control of 32 X-10 automation control devices**
 - 16 schedules with On Time, Off Time, and Day of Week

Integrated Intercom Audio Interface



P5928 Audio Interface Module with P5922 Series Intercom Stations & P5904 Two Way Listen-In Stations

P5922 Internal Intercom Station



also available:
P5922EXT...external intercom

- 8 user controlled automation modes
- full range of dimming levels for lighting control
- event activated control for any PGM output supported by the main panel
- ⌘ **an extensive library of voice prompts for security and automation operation, programming, and system status feedback**
 - 250 system words for pre-programmed system functions
 - 240 word library for user programmable voice prompts for Automation Item Labels, Automation Mode Labels, Partition Labels, and Zone Labels
- ⌘ **program up to 6 words per voice label**
- ⌘ **powerful 'say number' command can announce numbers from 0-999 in three different ways**
- ⌘ **connect up to 1000' (305m) from control panel via KEYBUS**
- ⌘ **module current draw: 150mA @ 12VDC**

P5580TC Escort

- ⌘ **all the features of the P5580 Escort plus thermostat control**
- ⌘ **supports up to four EMS-100 thermostats**
- ⌘ **EMS-100 has 4 temperature control modes:**
 - day occupancy mode
 - night occupancy mode
 - auxiliary occupancy mode
 - away occupancy mode
- ⌘ **each thermostat optionally supports:**
 - up to six EMS-ITS remote indoor temperature sensors for interior temperature averaging
 - one EMS-OTS outdoor temperature sensor for display of outdoor temperature

station
P5922EXT/R...external intercom station with relay for operation of existing door bell

- ⌘ **P5928 audio interface module**
 - provides 7 output ports for connection of P5922 Series Intercom Stations - connect up to 1,000' (305m) from control panel via KEYBUS

- ⌘ **local intercom functions:**
 - page/answer
 - do not disturb
 - doorbell function
 - door strike release

- ⌘ **listen-in broadcast** ...allows any station to be programmed as a 'broadcast station' to which all other internal stations in the system may listen in

- ⌘ **programmable as sounder for fire/burglar alarms**

- ⌘ **answer telephone calls received on regular voice line**
 - ringing programmable by station
 - supports call waiting
 - allows call transfer to in-house phones

- ⌘ **audio user help**
 - provides plain language prompts for system programming, operation, and system status reports when installed with P5580 Escort Voice Prompt Module and keypads mounted with P5922 Intercom Stations

- ⌘ **P5904 central station 2-way listen-in station**
 - programmable control tones (from central station)
 - select zone, listen/talk, extend on-line time, hang up

Integrated CCTV



P5108L Downlook Interface Module ***for P-832DL only***

- ✧ provides an interface between the P-832DL alarm control panel and the Downlook DLM-4L still frame video transmission module
- ✧ communicates alarm followed by video over a single telephone line in one transmission to a Sur-Gard MLR2 digital receiver
- ✧ 8 inputs for video cameras, VCRs, or video switchers
- ✧ 8 general purpose burglary or fire alarm zone inputs
- ✧ any alarm zone (up to 32) or group of zones can be programmed to initiate video capture of 4 frames from any 4 sources - in any sequence
- ✧ programmable on-site sequential video switcher mode
 - view and capture images on a monitor / VCR setup
 - select cameras for viewing manually using an LED keypad or program system to switch automatically between selected cameras at programmed dwell times
- ✧ supervised by main panel
- ✧ programmable via downloading using modem or direct PC-Link

PGM Output Expansion


P5204 Power Supply/High Current Output Module

- ✧ provides 1A @ 12.5Vdc auxiliary power for additional modules and devices
- ✧ includes 4 fully programmable high current outputs
 - rated at 1A @ 12Vdc, PTC protected
 - will provide 3A short term if battery backup connected
 - each output can sink up to 3A
- ✧ output #1 may also be used as a supervised bell output - 700mA max
- ✧ each output programmable to activate for any of 24 options
- ✧ connect up to 1000' (305m) from control panel via KEYBUS
- ✧ fully supervised for: tamper, low battery, AC power loss, and auxiliary power trouble
- ✧ maximum 1 module per system
- ✧ module current draw: 20mA @ 12VDC
- ✧ battery required: 4Ah minimum
- ✧ transformer required: 16.5Vac, 40VA

P5208 Low Current Output Module

- ✧ module provides 8 low current transistor switch outputs
 - each output can sink up to 50mA
 - up to 250mA max at one time
- ✧ each output programmable to activate for any of 24 options

- ≪ connect up to 1,000' (305m) from control panel via KEYBUS
- ≪ module current draw: 60mA @ 12VDC



- ≪ connect up to 1000' (305m) from control panel via KEYBUS
- ≪ fully supervised for tamper
- ≪ maximum 1 module per system
- ≪ module current draw: 20mA @ 12VDC

— Note —
P-832 Engineer's Specifications are available on separate copy and on the Partner web site



[Back to Products List](#)

[Top of Page](#)