



# ***VISTA-128B***



## **Commercial Burglary Partitioned Security System** with Scheduling

### **Quick Start Guide**

**® ADEMCO**

## Table Of Contents

---

RECOMMENDED PROGRAMMING PROCEDURE .....	4
PROGRAM FIELD CATEGORIES .....	6
VISTA-128B PROGRAMMING FORM.....	7
PARTITION-SPECIFIC PROGRAMMING FORM.....	12
PROGRAMMING WITH #93 MENU MODE .....	14
SYSTEM LAYOUT WORKSHEETS.....	15
OUTPUT RELAYS WORKSHEETS .....	27
ALPHA DESCRIPTOR VOCABULARY.....	30
RELAY VOICE DESCRIPTORS AND CUSTOM WORD SUBSTITUTES VOCABULARY .....	31
SCHEDULING MENU PROMPTS.....	32
SCHEDULING WORKSHEETS .....	33
5800 SERIES RF TRANSMITTER LOOP DESIGNATIONS.....	38
VISTA-128B SUMMARY OF CONNECTIONS.....	39

---

The purpose of this document is to provide a quick and easy way to program your entire system. A recommended programming procedure is included, followed by a list of program fields with the corresponding program group they belong to (system-wide, partition-specific, scheduling, etc.). Two program forms are included, one contains all the programming fields, and the other contains the partition-specific fields. If you are setting up a single-partition system, the partition-specific fields become system-wide fields.

Following the program forms are system layout worksheets. We recommend that you use these sheets to plan your system before programming is performed. If you need further information about specific programming options, see the VISTA-128B INSTALLATION INSTRUCTIONS.

- Make sure that one two-line alpha keypad is connected to the control and is set to device address "00."

### Single Partition System

- The system default is for a single partition system. Use the VISTA-128B SINGLE PARTITION PROGRAMMING FORM when programming for single partition usage. Follow the steps outlined in RECOMMENDED PROGRAMMING PROCEDURE of this document for proper programming procedure.

### Multiple-Partition System

- You must enter the number of partitions you are using in data field 2\*00 to set the system for multiple partitions. Use the VISTA-128B SINGLE PARTITION and the PARTITION-SPECIFIC PROGRAM FORMS when programming the system for multiple partitions. Follow the steps outlined in RECOMMENDED PROGRAMMING PROCEDURE of this document for proper programming procedure.

### SUMMARY OF PROGRAMMING COMMANDS

- |  |
|--|
| <ul style="list-style-type: none"><li>• <b>To enter program mode</b>, enter installer code + [8] + [0] + [0] + [0]</li><li>• <b>To set standard defaults</b>, press *97</li><li>• <b>To set communication defaults</b>, press *94 + one of the following: *80=low speed; *81=Ademco Express; *82=Ademco High Speed; *83=Ademco's Contact ID</li><li>• <b>To change to next page of program fields</b>, press *94</li><li>• <b>To return to previous set of fields</b>, press *99</li><li>• <b>To erase account &amp; phone number field entries</b>, press [*] + field number + [*]</li><li>• <b>To assign zone descriptors</b>, press #93 + follow menu prompts</li><li>• <b>To add custom words</b>, press #93 + follow menu prompts</li><li>• <b>To enter Installer's Message</b>, press #93 + follow menu prompts</li><li>• <b>To exit program mode</b>, press *99 OR *98: *99 allows re-access to programming mode by installer code. *98 prevents re-access to programming mode by installer code.</li></ul> |
|--|

Standard default (\*97) values are shown in brackets [ ], otherwise default = 0.

## Recommended Programming Procedure

---

The following is a step-by-step procedure recommended for programming your VISTA-128B system.

- 1. Set the keypads (and other peripheral devices) to the appropriate addresses.**
- 2. Set factory defaults by pressing \*97.**

This will automatically enable keypad addresses 00-01, so be sure at least one keypad is set to one of these addresses
- 3. Program system-wide (global) data fields.**

Using the programming form as a guide, enter program mode and program all system wide programming fields. These options affect the entire system, regardless of partitions. They include control options, downloader and dialer options, RF options, event logging options, etc. Refer to the COMPLETE LIST OF PROGRAMMING FIELDS for a listing of the program fields arranged by function.

**Note that field 2\*00 (number of partitions) must be programmed before continuing.**
- 4. Program partition-specific fields.**

When the system-wide fields have been programmed, program all partition-specific programming fields by first pressing \*91 to select a partition (while still in data field program mode). Then enter the first partition-specific field number \*09. The next partition-specific field will automatically be displayed when you are finished entering the value for field \*09. Partition-specific fields can have different values for each partition. To program the fields for the next partition, press \*91, enter the desired partition number, then enter field \*09. Refer to the MECHANICS OF PROGRAMMING section in the VISTA-128B INSTALLATION INSTRUCTIONS for detailed instructions.
- 5. Use #93 Menu Mode for device programming.**

Refer to the DEVICE PROGRAMMING section to assign keypad ID numbers and default partitions for each keypad, and to selectively suppress certain keypad sounding options. Also use this mode to assign RF receivers, relay modules, the VIP module, the ecp Long Range Radio, and the Vista Gateway Module.
- 6. Use #93 Menu Mode for zone programming.**

Refer to the ZONE PROGRAMMING section to program zone response types, assign right loop zones and wireless zones, assign zones to partitions, and to program alarm report codes.
- 7. Use #93 Menu Mode for programming relays.**

Refer to the RELAY PROGRAMMING section to program desired relay operation.
- 8. Program Communication options.**

Refer to the COMMUNICATION PROGRAMMING section for further instructions to load communication defaults and to program related fields. Then use #93 mode to program report codes if necessary.
- 9. Use #93 Menu Mode for programming alpha descriptors.**

Refer to the ALPHA PROGRAMMING section to enter zone and partition descriptors and a custom installer's message.
- 10. Use #93 Menu Mode for relay voice descriptors and custom word substitutes.**

Refer to the RELAY VOICE DESCRIPTORS section for further instructions for programming relay descriptors to be annunciated by the VIP module, as well as the CUSTOM INDEX section for custom word substitutes.
- 11. Use #80 Mode for programming schedules.**

Refer to the SCHEDULING section to program open/close schedules, temporary and holiday schedules, limitation of access schedules, and time driven events.
- 12. Define user access codes.**

Refer to SECURITY ACCESS CODES section to program authority level, O/C reporting option, partition assignments, and wireless key assignments for each user.

### **13. Exit Programming Mode.**

Exit programming mode by pressing either \*98 or \*99. Additional entries of \*99 is required if the exit is being done from fields 1\*00 and above.

To prevent re-access to programming mode using the Installer's code, use \*98. The only way to re-access programming mode is by depressing both the [\*] and [#] keys at the same time within 30 seconds of power up.

Exiting by using \*99 always allows reentry into programming mode using the Installer's code. Either way of exiting will allow access via downloading. Note that if local programming lockout is set via downloading, programming mode cannot be entered at the keypad.

## Program Field Categories

---

In the following pages, the programming fields have been arranged by category. Use this index to cross reference the numerical ordered fields on the programming form.

Field	Group	Field	Group	Field	Group
*00	System-Wide	*51	Communications	1*29	System-Wide
*09	Partition-Specific	*52	Communications	1*30	System-Wide
*10	Partition-Specific	*53	Communications	1*31	System-Wide
*11	Partition-Specific	*56	Communications	1*33	Communications
*12	Partition-Specific	*57	Communications	1*34	Communications
*13	Partition-Specific	*58	Communications	1*42	Communications
*14	System-Wide	*59	Communications	1*43	Partition-Specific
*15	System-Wide	*64	Communications	1*44	System-Wide
*16	Partition-Specific	*65	Communications	1*45	Partition-Specific
*17	System-Wide	*66	Communications	1*47	Partition-Specific
*19	System-Wide	*67	Communications	1*48	System-Wide
*20	System-Wide	*68	Communications	1*49	System-Wide
*21	System-Wide	*69	Communications	1*52	Partition-Specific
*22	Partition-Specific	*70	Communications	1*53	System-Wide
*23	Partition-Specific	*71	Communications	1*56	System-Wide
*24	System-Wide	*72	Communications	1*57	System-Wide
*25	System-Wide	*73	Communications	1*58	System-Wide
*26	Communications	*74	Communications	1*60	System-Wide
*27	Communications	*75	Communications	1*70	System-Wide
*28	System-Wide	*76	Communications	1*71	System-Wide
*29	Partition-Specific	*79	Communications	1*72	System-Wide
*30	Communications	*80	Communications	1*73	System-Wide
*31	Communications	*83	Communications	1*74	System-Wide
*32	Partition-Specific	*84	Partition-Specific	1*75	System-Wide
*33	Communications	*85	Partition-Specific	1*76	Partition-Specific
*34	Communications	*87	Partition-Specific	2*00	System-Wide
*35	System-Wide	*88	Partition-Specific	2*01	System-Wide
*36	System-Wide	*89	Communications	2*02	System-Wide
*37	System-Wide	*90	Partition-Specific	2*05	Partition-Specific
*38	Partition-Specific	1*07	System-Wide	2*06	Partition-Specific
*39	Partition-Specific	1*10	System-Wide	2*07	Partition-Specific
*40	Communications	1*17	System-Wide	2*08	Partition-Specific
*41	System-Wide	1*18	Partition-Specific	2*09	Partition-Specific
*42	Communications	1*19	Partition-Specific	2*10	Partition-Specific
*43	Communications	1*20	System-Wide	2*11	System-Wide
*44	Communications	1*21	System-Wide	2*18	Partition-Specific
*45	Communications	1*22	System-Wide	2*19	Partitioning
*46	Communications	1*23	System-Wide	2*20	Partition-Specific
*47	Communications	1*24	System-Wide	2*21	System-Wide
*48	Communications	1*25	System-Wide	2*22	Partition-Specific
*49	Communications	1*26	System-Wide	2*23	Partition-Specific
*50	Communications	1*28	System-Wide	2*24	Partition-Specific

# VISTA 128B Programming Form

Some fields are programmed for each partition (shown as shaded fields). If Programming a Multiple Partition System, see the PARTITION-SPECIFIC section for programming these fields. Standard default (\*97) values are shown in brackets [ ], otherwise default = 0.

<p><b>*00</b> INSTALLER CODE <input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/> Enter 4 digits, 0-9 [4140]</p> <p><b>*09</b> ENTRY DELAY #1 [02] <input type="text" value=""/><input type="text" value=""/> 00-15 times 15 seconds Maximum "03" for UL Commercial Burglary.</p> <p><b>*10</b> EXIT DELAY #1 [03] <input type="text" value=""/><input type="text" value=""/> 00-15 times 15 seconds Maximum "04" for UL Listed installations.</p> <p><b>*11</b> ENTRY DELAY #2 [06] <input type="text" value=""/><input type="text" value=""/> 00-15 times 15 seconds (must be longer than Entry Delay #1). Maximum "03" for UL Commercial Burglary installations.</p> <p><b>*12</b> EXIT DELAY #2 [08] <input type="text" value=""/><input type="text" value=""/> 00-15 times 15 seconds (must be longer than Exit Delay #1) Maximum "04" for UL Commercial Burglary installations.</p> <p><b>*13</b> BELL TIMEOUT [04] <input type="text" value=""/><input type="text" value=""/> 01-15 times 2 minutes. Minimum 16 min. for UL Commercial Burglary.</p> <p><b>*14</b> ZONE 9 RESPONSE TIME [0] <input type="checkbox"/> Enter 1 for fast response (10 msec) Enter 0 for slow response (350 msec)</p> <p><b>*15</b> KEYSWITCH ASSIGNMENT [0] <input type="checkbox"/> Enter partition in which keyswitch used, 1-8; 0=disable</p> <p><b>*16</b> CONFIRMATION OF ARMING DING [0] <input type="checkbox"/> 1=enable; 0=disable. Must be "1" for UL Burglary Installations.</p> <p><b>*17</b> AC LOSS KEYPAD SOUNDING [0] <input type="checkbox"/> 1=yes; 0=no</p> <p><b>*19</b> RANDOMIZE AC LOSS REPORT [0] <input type="checkbox"/> 1=10-40 min; 2=6-12 hrs; 0=normal report (about 2 min. after AC loss). Must be "2" for Central and Remote Station alarm systems.</p> <p><b>*20</b> VIP MODULE PHONE CODE <input type="text" value=""/><input type="text" value=""/> Enter 01 - 09 for the first digit; enter [00] , [11] 11 for "*" or 12 for "#" for the second digit. This field Must be set to "0" for UL Commercial Burglary installations.</p> <p><b>*21</b> PREVENT FIRE TIMEOUT [0] <input type="checkbox"/> 1=No timeout 0=Timeout.</p> <p><b>*22</b> KEYPAD PANIC ENABLE [001] <input type="text" value=""/><input type="text" value=""/><input type="text" value=""/> 1=enable; 0=disable 995 996 999</p> <p><b>*23</b> MULTIPLE ALARMS [1] <input type="checkbox"/> 1=yes; 0=no</p>	<p><b>*24</b> IGNORE EXPANSION ZONE TAMPER [0] <input type="checkbox"/> 1=Ignore; 0=Enable tamper for RF and RPMs. Must be "0" for UL installations if using these devices.</p> <p><b>*25</b> BURG.TRIGGER FOR RESPONSE TYPE 8 [1] <input type="checkbox"/> 1=enable; 0=disable</p> <p><b>*26</b> INTELLIGENT TEST REPORTING [0] <input type="checkbox"/> 1=yes, (no report sent if any other report was recently sent); 0=no.. Must be 0 for UL Commercial Burglary.</p> <p><b>*27</b> TEST REPORT INTERVAL [024] <input type="text" value=""/><input type="text" value=""/><input type="text" value=""/> Enter interval in hours, 001-999; 000=no report ; Max. 024 for UL Commercial.</p> <p><b>*28</b> POWER UP IN PREVIOUS STATE [1] <input type="checkbox"/> 1=yes; 0=no; "1" for UL.</p> <p><b>*29</b> QUICK ARM [1] <input type="checkbox"/> 1=yes; 0=no</p> <p><b>*30</b> DIALER (TOUCHTONE OR ROTARY) [0] <input type="checkbox"/> 1=TouchTone; 0=rotary</p> <p><b>*31</b> PABX ACCESS CODE <input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/> 00-09; B-F (11-15)</p> <p><b>*32</b> PRIM. SUBS. ACCT # <input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/> Enter 00-09; B-F (11-15) [15 15 15 15]</p> <p><b>*33</b> PRIMARY PHONE NUMBER <input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/> <input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/> Enter 0-9 for each digit. Enter #11 for *, #12 for #, #13 for 2 second pause</p> <p><b>*34</b> SECONDARY PHONE NUMBER <input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/> <input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/> Enter 0-9 for each digit. Enter #11 for *, #12 for #, #13 for 2 second pause</p> <p><b>*35</b> DOWNLOAD PHONE No. <input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/> <input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/> Enter 0-9 for each digit. Enter #11 for *, #12 for #, #13 for 2 second pause</p> <p><b>*36</b> DOWNLOAD ID No. <input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/><input type="text" value=""/> Enter 00-09; A-F (10-15) [15 15 15 15 15 15 15 15]</p>
---	--



**\*73 PAGER PHONE # FOR SYSTEM**

Enter 0-9 for each digit; #11 for \*; #12 for #; #13 for 2 sec. pause

**\*74 PAGER ID # FOR SYSTEM**

Enter up to 10 digits for the pager id #

**\*75 PAGER PHONE # FOR TEST**

Enter 0-9 for each digit; #11 for \*; #12 for #; #13 for 2 sec. pause

**\*76 PAGER ID # FOR TEST**

Enter up to 10 digits for the pager id #

**ZONE TYPE RESTORE ENABLES**

**\*79 FOR ZONE TYPES 1-8**      **\*80 FOR TYPES 9/10**

1    2    3    4    5    6    7    8                      9    10

1=enable; [0=disable]

**\*83 FIRST TEST REPORT TIME**

[Day 00; hour 12; min 00] Days 01-07 Hours 00-23 Min 00-59; 00 in all boxes=instant (Day 01= Monday)

**\*84 SWINGER SUPPRESSION** [03]

01-15 alarms; Must be "00" (disabled) for UL.

**\*85 ENABLE DIALER REPORTS**

FOR PANICS & DURESS      995    996    999    Duress

1=enable; [0=disable]

**\*87 ENTRY WARNING** [1]

1=continuous; 0=3 beeps

**\*88 BURG. ALARM COMM. DELAY** [0]

1=16 seconds; 0=no delay. Must be "0" for UL Commercial Burg. installations.

**\*89 RESTORE REPORT TIMING** [0]

0=Instant; 1=After bell timeout if zone is restored; 2=when system is disarmed. Must be "0" for UL Commercial Burg. installations.

**\*90 SEC. SUBS. ACCT #**

Enter 00-09; B-F (11-15) [15 15 15 15]

**1\*07 DISPLAY TRBL INSTEAD OF CHECK** [0]

0=display TRBL; 1=display CHECK

**1\*10 FIRE DISPLAY LOCK** [0]

0=scroll all alarms; 1=lock display of first fire alarm.

**1\*17 LOBBY PARTITION** [0]

Enter the "common lobby" partition (1-8)

**1\*18 AFFECTS LOBBY** [0]

Enter 1 if this partition affects the common lobby; enter 0 if it does not. Must be "0" for Commercial UL installations.

**1\*19 ARMS LOBBY** [0]

Enter 1 if arming this partition attempts to arm lobby; enter 0 if it does not. Must be "0" for Commercial UL installations.

**1\*20 EXIT ERROR LOGIC** [0]

0=No; 1=Bypass E/E and Interior zones faulted after exit delay. Must be "0" for Commercial UL installations.

**1\*21 EXIT DELAY RESET** [0]

0=No; 1=Resets Exit Delay to 60 seconds after zone is closed. Must be "0" for Commercial UL installations.

**FIELDS 1\*22-1\*25:** Allow four sets of two zones each to be linked so that both must fault within a five minute period to cause an alarm.

**1\*22 CROSS-ZONING PAIR ONE**

**1\*23 CROSS-ZONING PAIR TWO**

**1\*24 CROSS-ZONING PAIR THREE**

**1\*25 CROSS-ZONING PAIR FOUR**

**1\*26 PANIC BUTTON OR SPEEDKEY**

[00, 00, 00, 00]

A                  B                  C                  D

Enter speedkey macro # (01-35) to use keys A-C for macro. Otherwise enter 00 to use as panic. For D key, enter macro # or 00 to select macro when key is pressed.

**MISCELLANEOUS WIRELESS OPTIONS**

**Fields 1\*28 - 1\*32 are not applicable for commercial UL installations.**

**1\*28 RF TX LOW BATTERY SOUND** [0]

1=immediate; 0=when disarmed

**1\*29 RF TX LOW BATTERY REPORT ENABLE** [0]

1=enable; 0=disable

**1\*30 RF RCVR CHECK-IN INTERVAL** [02]

02-15 times 2 hours; 00 disables supervision

**1\*31 RF TRANSMITTER CHECK-IN INTERVAL** [02]

02-15 times 2 hours; 00 disables transmitter supervision

**1\*33 TOUCH-TONE W/ROTARY BACKUP** [0]

1=enable; 0=disable

**1\*34 COMM. SPLIT REPORT SELECTION** [0]

0=no; 1=alarms and alarm restores primary, others secondary; 2=open/close, test secondary, others primary. See \*51 for comments if using with dual reporting.

**1\*42 CALL WAITING DEFEAT** [0]

1=Yes; 0=No.

**1\*43 PERM. KEYPAD BACKLIGHT** [0]

1=enable; 0=disable When disabled, display lights when any key is pressed, and turns off after period of keypad inactivity.

**1\*44 WIRELESS KEYPAD** [0]

**TAMPER DETECT ENABLE** 1=enable; 0=disable. Must be "0" for Commercial UL installations.



- 1\*45** EXIT DELAY SOUNDING [0]   
1=enable; 0=disable. Produces quick beeping during exit delay if enabled.
- 1\*46** AUXILIARY OUTPUT MODE [0]   
Enter **0** for ground start output.  
Enter **1** for open/close trigger (produced only if ALL partitions are armed).  
Enter **2** for keypad-like sounding. This option applies only to the partition enabled in field \*15.  
Enter **3** if AAV module is being used.  
**NOTE:** Only one of the above options may be active within the system.
- 1\*47** CHIME ON BELL 1 [0]   
1=enable; 0=disable
- 1\*48** WIRELESS KEYPAD ASSIGNMENT [0]   
0=disable; enter partition in which RF keypad used, 1-8. Must be "0" for Commercial UL installations.
- 1\*49** SUPPRESS TX SUPERVISION SOUND [1]   
1=disable; 0=enable. Must be "0" for Commercial UL installations.
- 1\*52** SEND CANCEL IF ALARM + OFF [0]   
1=no restriction; 0=within bell timeout period only
- 1\*53** DOWNLOAD CALLBACK [0]   
1=callback not required; 0=callback required; Must be "0" for Commercial UL installations.
- 1\*56** 50/60 Hz CLOCK SPEED [0]   
1=50 Hz; 0=60 Hz.
- 1\*57** ENABLE 5800 RF BUTTON GLOBAL ARM [0]   
1=enable; 0=disable
- 1\*58** 5800 RF BUTTON FORCE ARM [0]   
Enter "1" to enable. If a zone is faulted after pressing button, console will beep once. User should press button again within 4 sec. to force bypass those zones. Enter "0" to disable.  
Must be "0" for Commercial UL installations.
- 1\*60** ZONE 5 AUDIO ALARM VERIFICATION [0]   
Enter 1 If 2-way audio (AAV) is being used; Enter 0 if it is not.  
Must be "0" for Commercial UL installations.
- 1\*70** EVENT LOG TYPES  
[1 0 0 0 1 0]        
Alrm Chck BypS O/C Syst Test  
1=enable; 0=disable
- 1\*71** 12/24 HOUR TIME STAMP FORMAT [0]   
0=12 hour; 1=24 hour
- 1\*72** EVENT LOG PRINTER ON-LINE [0]   
0=disable; 1=enable
- 1\*73** PRINTER BAUD RATE 1=300; 0=1200 [0]   
Must be 1200 if using pager interface
- 1\*74** RELAY TIMEOUT XX MINUTES [000]   
Enter the relay timeout, **0-127** in multiples of 2 minutes, desired for #80 Menu Mode time driven event relay command numbers "04/09" and #93 Menu Mode Relay Programming output command "56".

- 1\*75** RELAY TIMEOUT YY SECONDS [000]   
Enter the relay timeout, **0-127** seconds, desired for #80 Menu Mode time driven event relay command numbers "05/10" and #93 Menu Mode Relay Programming command "57".

- 1\*76** ACCESS CONTROL RELAY FOR PART.[00]   
Relay will be pulsed for 2 seconds whenever code + [0] is pressed. Enter 00-16; 00=none. Must be "00" for Commercial UL..

### 3rd Page Programming Fields (press \*94)

- 2\*00** NUMBER OF PARTITIONS [1]   
Enter 1-8
- 2\*01** DAYLIGHT SAVINGS TIME [04, 10]    
START/END MONTH Start End  
00-12; if no daylight savings time, enter 00,00
- 2\*02** DAYLIGHT SAVINGS TIME [1, 5]   
START/END WEEKEND # Start | End  
Enter 1-7. 1=first; 2=second; 3=third; 4=fourth; 5=last; 6=next to last; 7=3rd from last [1,5; 1st Sunday in April, last in Oct.]
- 2\*05** AUTO-ARM DELAY [15]   
Enter the time between the end of the arming window and the start of auto-arming warning period, in values of 1-14 times 4 minutes 00=instant; [15=no auto arm at all]. When this delay expires, the Auto-Arm Warning Period begins.
- 2\*06** AUTO-ARM WARNING PERIOD [15]   
This is the time during which the user is warned to exit the premises prior to the auto-arming of the system (beeps every 15 seconds; "ALERT" displayed). Enter 01-15 minutes. 00=instant at end of arming delay .
- 2\*07** AUTO-DISARM DELAY [15]   
This is the time between the end of the disarming window and the start of auto-disarming. Enter 01-14 times 4 minutes; 00=instant at end of window; 15=no auto-disarm.
- 2\*08** ENABLE FORCE ARM FOR AUTO-ARM [0]   
0=disable; 1=enable
- 2\*09** OPEN/CLOSE REPORTS BY EXCEPTION [0]   
1=enable; 0=disable; If enabled, only openings and closings occurring outside the scheduled opening/closing windows will trigger dialer reports. Opening reports will also be suppressed during the closing window, in order to prevent false reports when the user arms the system and then reenters the premises to retrieve a forgotten item.
- 2\*10** ALLOW DISARMING ONLY DURING [0]   
ARMING/DISARMING WINDOWS  
0=disable; 1=enable  
See system-wide field 2\*11 if enabling field 2\*10. This feature adds high security to the installation.
- 2\*11** ALLOW DISARM OUTSIDE WINDOW [0]   
IF ALARM OCCURS  
Used only if field 2\*10 (partition-specific field) is set to "1". If this field is enabled ("1") the system can be disarmed outside the disarm window if an alarm has occurred. If "0", disarming can only be done during the disarm window. If field 2\*10 is set to "0" for a partition, this field has no effect for that partition.

- 2\*18** ENABLE GOTO FOR THIS PARTITION [0]   
 1=Allow log-on from other partitions; 0=disable
- 2\*19** USE PARTITION DESCRIPTORS [0]   
 0=disable; 1=enable
- 2\*20** ENABLE J2 TRIGGERS by PARTITION [1]   
 0=disable for displayed partition; 1=enable for displayed partition
- 2\*21** ENABLE SUPERVISION PULSES FOR LRR  
 TRIGGER OUTPUTS [000]     
 Used for supervised connection to 7920SE. F B S  
 Enter 0 to disable or 1 to enable the listed outputs.  
 F= Fire; B= Burglary; S= Silent panic/duress. Enter 1 for  
 Commercial Burglary and UL.
- 2\*22** DISPLAY FIRE ALARMS OF [0]   
 OTHER PARTITIONS  
 0=No; 1=Yes.
- 2\*23** DISPLAY BURG & PANIC ALARMS OF [0]   
 OTHER PARTITIONS  
 0=No; 1=Yes.
- 2\*24** DISPLAY TROUBLES OF OTHER [0]   
 PARTITIONS  
 0=No; 1=Yes.

**SUMMARY OF PROGRAMMING COMMANDS**

- **To enter program mode**, enter installer code + [8] + [0] + [0] + [0]
- **To set standard defaults**, press \*97
- **To set communication defaults**, press \*94 + one of the following: \*80=low speed; \*81=Ademco Express; \*82=Ademco High Speed; \*83=Ademco's Contact ID
- **To change to next page of program fields**, press \*94
- **To return to previous set of fields**, press \*99
- **To erase account & phone number field entries**, press [\*] + field number + [\*]
- **To assign zone descriptors**, press #93 + follow menu prompts
- **To add custom words**, press #93 + follow menu prompts
- **To enter Installer's Message**, press #93 + follow menu prompts
- **To exit program mode**, press \*99 OR \*98: \*99 allows re-access to programming mode by installer code. \*98 prevents re-access to programming mode by installer code.

## Partition-Specific Fields

(Duplicate this page for each partition in the installation.)

To program these fields,

1. Press \*91 to select a partition.
2. Enter a partition-specific field number (ex. \*09).
3. Make the required entry.
4. Repeat steps 1-3 for each partition in the system.

### PARTITION # \_\_\_\_\_ PROGRAM FIELDS

#### 1st Page Fields

- \*09** ENTRY DELAY #1 [02]    
 00-15 times 15 seconds. Maximum 03 for UL Listed installations.
- \*10** EXIT DELAY #1 [03]    
 00-15 times 15 seconds. Maximum 04 for UL Listed installations.
- \*11** ENTRY DELAY #2 [06]    
 00-15 times 15 seconds. Maximum 03 for UL Commercial Burglary installations.
- \*12** EXIT DELAY #2 [08]    
 00-15 times 15 seconds. Maximum 04 for UL Commercial Burglary installations.
- \*13** BELL TIMEOUT [04]    
 01-15 times 2 minutes. Minimum 16 minutes for UL Commercial Burglary installations.
- \*16** CONFIRMATION OF ARMING DING [0]   
 1=enable; 0=disable. Must be "1" for UL Commercial Burglary installations.
- \*22** KEYPAD PANIC ENABLES [001]     
 1=enable; 0=disable 995 996 999
- \*23** MULTIPLE ALARMS [1]   
 1=yes; 0=no. Enter 1 for UL Commercial Burglary installations.
- \*29** QUICK ARM [1]   
 1=yes; 0=no
- \*32** PRIM. SUBS. ACCT #      
 Enter 00-09; B-F (11-15) [15 15 15 15]
- \*38** PREVENT ZONE XXX BYPASS [000]     
 001-128; 000 if all zones can be bypassed
- \*39** ENABLE OPEN/CLOSE REPORT FOR INSTALLER CODE [1]   
 1=enable; 0=disable
- \*84** SWINGER SUPPRESSION [03]     
 01-15 alarms; Must be "00" (disabled) for Commercial UL installations..
- \*85** ENABLE DIALER REPORTS      
 FOR PANICS & DURESS 995 996 999 Duress  
 1=enable; [0=disable]
- \*87** ENTRY WARNING [1]   
 1=continuous; 0=3 beeps
- \*88** BURG. ALARM COMM. DELAY [0]    
 1=16 seconds; 0=no delay. Must be "0" for UL Commercial Burglary installations.
- \*90** SEC. SUBS. ACCT #      
 Enter 00-09; B-F (11-15) [15 15 15 15]
- 1\*18** AFFECTS LOBBY [0]   
 Enter 1 if this partition affects the common lobby; enter 0 if it does not.
- 1\*19** ARMS LOBBY [0]   
 Enter 1 if arming this partition attempts to arm lobby; enter 0 if it does not

#### 2nd Page Fields

- 1\*26** PANIC BUTTON OR SPEEDKEY [00, 00, 00, 00]      
 A B C D  
 Enter speedkey macro # (01-35) to use keys A-C for macro. Otherwise enter 00 to use as panic. For D key, enter macro # or 00 to select macro when key is pressed.
- 1\*43** PERM. KEYPAD BACKLIGHT [0]   
 1=enable; 0=disable When disabled, display lights when any key is pressed, and turns off after period of keypad inactivity.
- 1\*45** EXIT DELAY SOUNDING [0]   
 1=enable; 0=disable Produces quick beeping during exit delay if enabled.
- 1\*47** CHIME ON BELL 1 [0]   
 1=enable; 0=disable
- 1\*52** SEND CANCEL IF ALARM + OFF [0]   
 1=no restriction; 0=within Bell Timeout period only
- 1\*76** ACCESS CONTROL RELAY FOR PART.[00]    
 Relay will be pulsed for 2 seconds whenever code + [0] is pressed. Enter 00-16; 00=none. Must be "00" for Commercial UL.

#### 3rd Page Fields

- 2\*05** AUTO-ARM DELAY [15]    
 Enter the time between the end of the arming window and the start of auto-arming warning period, in values of 1-14 times 4 minutes 00=instant; [15=no auto arm at all]. When this delay expires, the Auto-Arm Warning Period begins.

**2\*06** AUTO-ARM WARNING PERIOD [15]

This is the time during which the user is warned to exit the premises prior to the auto-arming of the system (beeps every 15 seconds; "ALERT" displayed). Enter 01-15 minutes. 00=instant at end of arming delay .

**2\*07** AUTO-DISARM DELAY [15]

This is the time between the end of the disarming window and the start of auto-disarming. Enter 01-14 times 4 minutes; 00=instant at end of window; 15=no auto-disarm.

**2\*08** ENABLE FORCE ARM FOR AUTO-ARM [0]

0=disable; 1=enable.

**2\*09** OPEN/CLOSE REPORTS BY EXCEPTION [0]

1=enable; 0=disable; If enabled, only openings and closings occurring outside the scheduled opening/closing windows will trigger dialer reports. Opening reports will also be suppressed during the closing window, in order to prevent false reports when the user arms the system and then reenters the premises to retrieve a forgotten item.

**2\*10** ALLOW DISARMING ONLY DURING [0]

ARMING/DISARMING WINDOWS

See system-wide field 2\*11 if enabling field 2\*10. This feature adds high security to the installation. 0=disable; 1=enable

**2\*18** ENABLE GOTO FOR THIS PARTITION [0]

1=Allow log-on from other partitions; 0=disable

**2\*20** ENABLE J7 TRIGGERS by PARTITION [1]

0=disable for displayed partition; 1=enable for displayed partition

**2\*22** DISPLAY FIRE ALARMS OF [0]

OTHER PARTITIONS

0=No; 1=Yes

**2\*23** DISPLAY BURG/PANIC ALARMS OF [0]

OTHER PARTITIONS

10=No; 1=Yes

**2\*24** DISPLAY TROUBLES OF OTHER [0]

PARTITIONS

0=No; 1=Yes

### SUMMARY OF PROGRAMMING COMMANDS

- **To enter program mode**, enter installer code + [8] + [0] + [0] + [0]
- **To set standard defaults**, press \*97
- **To set communication defaults**, press \*94 + one of the following: \*80=low speed; \*81=Ademco Express; \*82=Ademco High Speed; \*83=Ademco's Contact ID
- **To change to next page of program fields**, press \*94
- **To return to previous set of fields**, press \*99
- **To erase account & phone number field entries**, press [\*] + field number + [\*]
- **To assign zone descriptors**, press #93 + follow menu prompts
- **To add custom words**, press #93 + follow menu prompts
- **To enter Installer's Message**, press #93 + follow menu prompts
- **To exit program mode**, press \*99 OR \*98: \*99 allows re-access to programming mode by installer code. \*98 prevents re-access to programming mode by installer code.

## Programming With #93 Menu Mode

**NOTE: The following field should be preset before beginning: 2\*00 Number of Partitions. In addition, receivers should be programmed via Device programming.**

After programming all system related programming fields in the usual way, press #93 while still in programming mode to display the first choice of the menu driven programming functions. Press 0 (NO) or 1 (YES) in response to the displayed menu selection. Pressing 0 will display the next choice in sequence. Menu selections are as follows:

ZONE PROG? 0=No    1=Yes	For programming the following: <ul style="list-style-type: none"> <li>• Zone Number</li> <li>• Zone Response Type</li> <li>• Partition Number for Zone</li> <li>• Dialer report code for zone</li> <li>• Input Device Type for zone (whether RF, polling loop, etc.)</li> <li>• Enrolling serial numbers of 5800 series transmitters &amp; serial polling loop devices into the system.</li> </ul>
SEQUENTIAL LEARN? 0=No    1=Yes	For programming the following: <ul style="list-style-type: none"> <li>• Input Device Type for zone (whether RF, polling loop, etc.)</li> <li>• Enrolling serial numbers of 5800 series transmitters &amp; serial polling loop devices into the system (all other zone characteristics must be pre-programmed).</li> </ul>
REPORT CODE PROG? 0=No    1=Yes	For programming the following: <ul style="list-style-type: none"> <li>• Alarm report codes for zones</li> <li>• Restore &amp; supervisory codes</li> <li>• All other system report codes</li> </ul>
ALPHA PROG? 0=No    1=Yes	For entering alpha descriptors for the following: <ul style="list-style-type: none"> <li>• Zone Descriptors</li> <li>• Installer's Message</li> <li>• Custom Words</li> <li>• Partition Descriptors</li> <li>• Relay Descriptors</li> </ul>
DEVICE PROG? 0=No    1=Yes	For defining the following device characteristics for addressable devices, including keypads, RF receivers (5881), output relay modules (4204/4204CF), 4285/4286 VIP Module, ECP long range radio (7820), and vista gateway module: <ul style="list-style-type: none"> <li>• Device Address</li> <li>• Device Type</li> <li>• Keypad Options (incl. partition assignment)</li> <li>• RF House ID</li> <li>• LRR Options (incl. programming radio)</li> </ul>
RELAY PROG? 0=No    1=Yes	For defining output relay functions.
RLY VOICE DESCR? 0=No    1=Yes	For entering voice descriptors for relays to be used with the 4285/4286 VIP Module.
CUSTOM INDEX ? 0=No    1=Yes	For creating custom word substitutes for VIP Module annunciation.
CLEAR RF SERIAL#? 1=Yes    0=No	For deleting all RF serial numbers presently in the system, if an undesired transmitter has been enrolled during sequential enrolling.

### #93 MENU MODE KEY COMMANDS

The following is a list of commands used while in the menu mode.

#93	Enters Menu mode
[★]	Serves as ENTER key. Press to have keypad accept entry.
[#]	Backs up to previous screen.
0	Press to answer NO
1	Press to answer YES
001-009	All data entries are either 2-digit or 3-digit entries.
000	Exits menu mode, back into field programming mode, when entered at the first question for each category.

## System Layout Worksheets

As with any security system, you should first define the installation. This includes determining how many partitions will be used, how many zones per partition, and how many users per partition. You will also need to determine what peripheral devices will be needed, and basic system options such as exit/entry delays, etc. The control panel itself should be located in an area that will facilitate wire runs to all partitions, and will allow access to power and telephone circuits.

To help you lay out a partitioned system, use the following worksheet. This will further simplify the programming process.

PARTITIONS				
Partition #	Descriptor (4 char max)	Prim. Sub. #	Sec. Sub. #	Alpha Default Message (32 character maximum)
Partition 1				
Partition 2				
Partition 3				
Partition 4				
Partition 5				
Partition 6				
Partition 7				
Partition 8				
Keyswitch Arming Partition Assignment (1-8):				
Wireless Keypad Partition Assignment (1-8):				
Voice Module Partition Assignment (1-8):				
Use Partition Descriptor (yes/no)?				
Common Lobby Partition Assignment (1-8):				

COMMUNICATION OPTIONS BY PARTITION									
Option	Part. 1	Part. 2	Part. 3	Part. 4	Part. 5	Part. 6	Part. 7	Part. 8	
Swinger Suppression Count 00-15; 00=no suppression									
Cancel Report After Disarm									
Dialer Reports for Panic (* + 1)									
Dialer Reports for Panic (# + 3)									
Dialer Reports for Panic (* + #)									
Dialer Reports for Duress									
Burglary Alarm Communications Delay (16 sec.)									

**SYSTEM DEFINITIONS BY PARTITION 9enter values or yes/no)**

<b>Option</b>	<b>Part. 1</b>	<b>Part. 2</b>	<b>Part. 3</b>	<b>Part. 4</b>	<b>Part. 5</b>	<b>Part. 6</b>	<b>Part. 7</b>	<b>Part. 8</b>
Entry Delay #1 (15-225 seconds):								
Exit Delay #1 (15-225 seconds):								
Entry Delay #2 (15-225 seconds):								
Exit Delay #2 (15-225 seconds):								
Quick Arming								
Multiple Alarms per Arming								
Console Panic for zone 995 (* + 1)								
Console Panic for zone 996 (# + 3)								
Console Panic for zone 999 (* + #)								
Allow Sign-on (GOTO function)								
Non-Bypassable Zone*								
Sounder Timeout Duration for Bell (2 min. increments)								
Console Annunciation During Entry**								
Console Annunciation During Exit								
Confirmation of Arming Ding for Bell								
Chime on Bell								
Access Control Relay (field 1*76)								
Affects Lobby (check partitions that apply)								
Arms Lobby (check partitions that apply)								
Displays Fire Alarms of Other Partitions								
Displays Burg & Panic Alarms of Other Partitions								
Displays Troubles of Other Partitions								

\*Can be any zone 001-128.

\*\*no= 3 beeps yes=continuous

**PRINTER OPTIONS**

12 or 24 hour Time format	
Printer On-Line (yes/no)	
*1200 or 300 baud Printer Baud Rate	

\*Note: Must be 1200 if using pager interface

**EVENT LOG TYPES**

<b>Option</b>	<b>No</b>	<b>Yes</b>
Alarm		
Trouble		
Bypass		
Open/Close		
System		
Test		

DEVICES (keypads, 4204, rf receivers, vip module, lrr, vgm)											
Device Address	Type	Home Part	Sound Opt	Supv CF?	Keypad Global	Device Address	Type	Home Part	Sound Opt	Supv CF?	Keypad Global
00						16					
01						17					
02						18					
03						19					
04						20					
05						21					
06						22					
07						23					
08						24					
09						25					
10						26					
11						27					
12						28					
13						29					
14						30					
15						31					

**Type:**

- 0 = Device Not Used
- 1 = Alpha Console
- 3 = RF Receiver
- 4 = Output Relay Module
- 5 = Voice Module
- 6 = Long Range Radio
- 9 = Vista Gateway Module

**Console Sounder Options:**

- 00 = No Suppression
- 01 = Suppress Arm/Disarm and Entry/Exit Beeps
- 02 = Suppress Chime Mode Beeps Only
- 03 = Suppress Arm/Disarm, Entry/Exit and Chime Mode Beeps

**Defaults:**

Addresses 00-01 = Alpha Keypad; No Suppression





**ZONE DEFINITIONS FOR ZONES 001-024**

<b>Zone No.</b>	<b>Zone Type</b>	<b>Partition (1-8)</b>	<b>Input Type (1-8)</b>	<b>Serial # Device Loop</b>	<b>Report Code</b>	<b>Zone Information (part numbers) &amp; Alpha Descriptor (3 words max.)</b>
01						
02						
03						
04						
05						
06						
07						
08						
09						
010						
011						
012						
013						
014						
015						
016						
017						
018						
019						
020						
021						
022						
023						
024						

**ZONE DEFINITIONS FOR ZONES 025-048**

<b>Zone No.</b>	<b>Zone Type</b>	<b>Partition (1-8)</b>	<b>Input Type (1-8)</b>	<b>Serial # Device Loop</b>	<b>Report Code</b>	<b>Zone Information (part numbers) &amp; Alpha Descriptor (3 words max.)</b>
025						
026						
027						
028						
029						
030						
031						
032						
033						
034						
035						
036						
037						
038						
039						
040						
041						
042						
043						
044						
045						
046						
047						
048						

**ZONE DEFINITIONS FOR ZONES 049-072**

<b>Zone No.</b>	<b>Zone Type</b>	<b>Partition (1-8)</b>	<b>Input Type (1-8)</b>	<b>Serial # Device Loop</b>	<b>Report Code</b>	<b>Zone Information (part numbers) &amp; Alpha Descriptor (3 words max.)</b>
049						
050						
051						
052						
053						
054						
055						
056						
057						
058						
059						
060						
061						
062						
063						
064						
065						
066						
067						
068						
069						
070						
071						
072						

**ZONE DEFINITION FOR ZONES 073-096**

<b>Zone No.</b>	<b>Zone Type</b>	<b>Partition (1-8)</b>	<b>Input Type (1-8)</b>	<b>Serial # Device Loop</b>	<b>Report Code</b>	<b>Zone Information (part numbers) &amp; Alpha Descriptor (3 words max.)</b>
073						
074						
075						
076						
077						
078						
079						
080						
081						
082						
083						
084						
085						
086						
087						
088						
089						
090						
091						
092						
093						
094						
095						
096						

**ZONE DEFINITION FOR ZONES 097-120**

<b>Zone No.</b>	<b>Zone Type</b>	<b>Partition (1-8)</b>	<b>Input Type (1-8)</b>	<b>Serial # Device Loop</b>	<b>Report Code</b>	<b>Zone Information (part numbers) &amp; Alpha Descriptor (3 words max.)</b>
097						
098						
099						
100						
101						
102						
103						
104						
105						
106						
107						
108						
109						
110						
111						
112						
113						
114						
115						
116						
117						
118						
119						
120						

**ZONE DEFINITION FOR ZONES 121-128**

Zone No.	Zone Type	Partition (1-8)	Input Type (1-8)	Serial # Device Loop	Report Code	Zone Information (part numbers) & Alpha Descriptor (3 words max.)
121						
122						
123						
124						
125						
126						
127						
128						

**ZONE DEFINITIONS FOR KEYPAD PANIC ZONES 995, 996, & 999**

Zone No.	Zone Type	Enter yes/no for each partition-field *22								Report Code	Zone Information (part numbers) & Alpha Descriptor (3 words max.)
		1	2	3	4	5	6	7	8		
995											
996											
999											

**ZONE DEFINITIONS FOR SYSTEM ZONES; 970, 988; 990 & 997**

Zone No.	Zone Type	Report Code	Zone Information (part numbers) & Alpha Descriptor (3 words max.)
970			
988			
990			
997			

**ZONE DEFINITIONS FOR RELAY SUPERVISORY ZONES 601-616**

<b>Zone No.</b>	<b>Zone Type</b>	<b>Report Code</b>	<b>Zone Information (part numbers) &amp; Alpha Descriptor (3 words max.)</b>	<b>Zone No.</b>	<b>Zone Type</b>	<b>Report Code</b>	<b>Zone Information (part numbers) &amp; Alpha Descriptor (3 words max.)</b>
601				617			
602				618			
603				619			
604				620			
605				621			
606				622			
607				623			
608				624			
609				625			
610				626			
611				627			
612				628			
613				629			
614				630			
615				631			
616				632			



**ZONE DEFINITIONS FOR SUPERVISORY OF ECP DEVICE ZONES 800-831**

<b>Zone No.</b>	<b>Zone Type</b>	<b>Report Code</b>	<b>Zone Information (part numbers) &amp; Alpha Descriptor (3 words max.)</b>	<b>Zone No.</b>	<b>Zone Type</b>	<b>Report Code</b>	<b>Zone Information (part numbers) &amp; Alpha Descriptor (3 words max.)</b>
800				816			
801				817			
802				818			
803				819			
804				820			
805				821			
806				822			
807				823			
808				824			
809				825			
810				826			
811				827			
812				828			
813				829			
814				830			
815				831			

**Zone Types:** 00=zone not used      06=24 hour silent      21=arm away  
 01=entry/exit 1      07=24 hour audible      22=disarm  
 02=entry/exit 2      08=24 hour auxiliary      23=no alarm response  
 03=perimeter      09=supervised fire      27=access control  
 04=interior (follower)      10=interior (delay)      28=MLB supervision  
 05=day/night burglary      20=arm stay

**Input Types:** 00=not used      06=serial number polling loop  
 01=hardwired      07=dip switch type polling loop  
 03=supervised RF transmitter      08=right loop dip switch polling loop  
 04=unsupervised RF transmitter      09=keypad input  
 05=RF button transmitter      10=PassPoint ACS input

## Output Relays Worksheets

Applicable only if Relays Modules (4204/4204CF) or Powerline Carrier Devices (X-10) are to be used.

**Output Devices** – Programmed in the #93 Menu Mode in the Relay Programming Section. Fill in the required data on the worksheet below and follow the procedure in the installation instructions as you enter the data during the displays and prompts that appear in sequence.

- Notes:**
1. For Relays, 4204/4204CF the Device Programming section must be programmed for the device address. Set the dip switches on the 4204/4204CF for that address.
  2. For Powerline Carrier Devices (X-10) use the 4300 transformer in place of the transformer that comes in the box with the control panel.

OUTPUT DEV #	(A)	S T A R T				S T O P			1=4204 2=X-10	Device Address 4204(CF)  House Code for (X-10)	Relay # for 4204  Unit Code for (X-10)
		(EV)	(ZL)	(ZT)	(P)	(ZL)	(ZT)	(P)			
1	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
2	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
4	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
5	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
6	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
7	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
8	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
9	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
10	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
11	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
12	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
13	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
14	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
15	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
16	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
17	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
18	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
19	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

**OUTPUT RELAYS WORKSHEET (cont'd)**

OUTPUT DEV #	S T A R T					S T O P			1=4204 2=X-10	Device Address 4204(CF)  House Code for (X-10)	Relay # for 4204  Unit Code for (X-10)
	(A)	(EV)	(ZL)	(ZT)	(P)	(ZL)	(ZT)	(P)			
20	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
21	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
22	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
23	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
24	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
25	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
26	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
27	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
28	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
29	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
30	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
31	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
32	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

**A = DEVICE ACTION** 0 = No Response; 1 = Close for 2 sec; 2 = Close and stay closed; 3 = Pulse on and off; 4 = Toggle alternately between START and STOP events.

**EV = EVENT** 0 = Not used; 1 = Alarm; 2 = Fault; 3 = Trouble; 4 = Restore

**Z L = ZONE LIST** 1-8, 0 = Not Used.

"START" ZONE LIST: Upon alarm, fault, or trouble of ANY zone in this list, device action will START.

"STOP" ZONE LIST: Upon restore of ALL zones on this list, device action will STOP. It need not be same list as used for START.

**ZT = ZONE TYPE/SYSTEM OPERATION**

**Choices for Zone Types are:**

- |                        |                       |                      |
|------------------------|-----------------------|----------------------|
| 00=Zone Not Used       | 05=Day/Night Burglary | 10=Interior (Delay)  |
| 01=Entry/Exit 1        | 06=24 Hour Silent     | 23=No Alarm Response |
| 02=Entry/Exit 2        | 07=24 Hour Audible    | 27=Access Control    |
| 03=Perimeter           | 08=24 Hour Auxiliary  | 28=MLB Supervision   |
| 04=Interior (Follower) | 09=Supervised Fire    |                      |

**NOTE:** Any zone in "ZT" for Start, going into alarm, fault, or trouble will activate the relay.  
Any zone in "ZT" for Stop, that restores will stop the relay action.

**Choices for System Operation are:**

- |                              |                             |  |
|------------------------------|-----------------------------|--|
| 20 = Arming-Stay             | 36 = At Bell Time-out*      | 45 = Polling Loop Failure                |
| 21 = Arm Away                | 37 = 2 Times Bell Time-out* | 51 = RF Receiver Failure                 |
| 22 = Disarming               | 38 = Chime                  | 52 = Kissoff                             |
| 30 = On Second Off           | 39 = Fire Alarm             | 54 = Fire Zone Reset                     |
| 31 = End of Exit Time        | 40 = Bypassing              | 55 = Disarm + 1 Minute                   |
| 32 = Start of Entry Time     | 41 = AC Power Fail          | 56 = XX Minutes (enter XX in field 1*74) |
| 33 = Any Burglary Alarm      | 42 = System Battery Low     | 57 = YY seconds (enter YY in field 1*75) |
| 34 = Code + # + 71 Key Entry | 43 = Communication Failure  | 58 = Duress                              |
| 35 = Code + # + 72 Key Entry | 44 = RF Low Battery         | 60 = Audio Alarm Verification**          |

\*Or at disarming, whichever occurs first

\*\*Must be selected for both START and STOP operation

**P = PARTITION No.** 1-8, 0 = Any

**ZONE LISTS FOR OUTPUT DEVICES** – Programmed in the #93 Menu Mode in the Relay Programming Section. Fill in the required data on the worksheet below and follow the procedure in the installation instructions as you enter the data during the displays and prompts that appear in sequence.

**Note:** Record desired zone numbers below. More or fewer boxes than shown may be needed, since any list may include *any* or *all* of system's zone numbers.

**Zone List 1:** Started or stopped by zone numbers (enter 00 to end entries).

,   ,   ,   ,   ,   ,   ,   ,   ,   ,   ...etc.

**Zone List 2:** Started or stopped by zone numbers (enter 00 to end entries).

,   ,   ,   ,   ,   ,   ,   ,   ,   ,   ...etc.

**Zone List 3:** Started or stopped by zone numbers (enter 00 to end entries).

,   ,   ,   ,   ,   ,   ,   ,   ,   ,   ...etc.

**Zone List 4:** Started or stopped by zone numbers (enter 00 to end entries).

,   ,   ,   ,   ,   ,   ,   ,   ,   ,   ...etc.

**Zone List 5:** Started or stopped by zone numbers (enter 00 to end entries).

,   ,   ,   ,   ,   ,   ,   ,   ,   ,   ...etc.

**Zone List 6:** Started or stopped by zone numbers (enter 00 to end entries).

,   ,   ,   ,   ,   ,   ,   ,   ,   ,   ...etc.

**Zone List 7:** Started or stopped by zone numbers (enter 00 to end entries).

,   ,   ,   ,   ,   ,   ,   ,   ,   ,   ...etc.

**Zone List 8:** Started or stopped by zone numbers (enter 00 to end entries).

,   ,   ,   ,   ,   ,   ,   ,   ,   ,   ...etc.

# Alpha Descriptor Vocabulary

(For entering alpha descriptors. To select a word, press [#] followed by the word's 3-digit number.)

**NOTE: This vocabulary is not to be used for relay voice descriptors. See the *Relay Voice Descriptors* section when programming relay voice descriptors.**

000 (Word Space)	• 052 DETECTOR	102 INTERIOR	151 POLICE	202 TRANSMITTER
• 001 AIR	• 053 DINING	103 INTRUSION	152 POOL	203 TRAP
• 002 ALARM	054 DISCRIMINATOR		• 153 POWER	
003 ALCOVE	055 DISPLAY	104 JEWELRY		204 ULTRA
004 ALLEY	056 DOCK	• 105 KITCHEN	154 QUAD	• 205 UP
005 AMBUSH	• 057 DOOR			• 206 UPPER
• 006 AREA	058 DORMER	• 106 LAUNDRY	155 RADIO	• 207 UPSTAIRS
• 007 APARTMENT	• 059 DOWN	• 107 LEFT	• 156 REAR	• 208 UTILITY
008 ART	• 060 DOWNSTAIRS	108 LEVEL	157 RECREATION	209 VALVE
• 009 ATTIC	061 DRAWER	• 109 LIBRARY	158 REFRIG	210 VAULT
010 AUDIO	• 062 DRIVEWAY	• 110 LIGHT	159 REFRIGERATION	211 VIBRATION
011 AUXILIARY	063 DRUG	111 LINE	160 RF	212 VOLTAGE
	• 064 DUCT	112 LIQUOR	• 161 RIGHT	
• 012 BABY		• 113 LIVING	• 162 ROOM	213 WALL
• 013 BACK	• 065 EAST	• 114 LOADING	163 ROOF	214 WAREHOUSE
• 014 BAR	066 ELECTRIC	115 LOCK		215 WASH
015 BARN	067 EMERGENCY	116 LOOP	164 SAFE	• 216 WEST
• 016 BASEMENT	068 ENTRY	117 LOW	165 SCREEN	• 217 WINDOW
• 017 BATHROOM	• 069 EQUIPMENT	• 118 LOWER	166 SENSOR	218 WINE
• 018 BED	070 EXECUTIVE		• 167 SERVICE	• 219 WING
• 019 BEDROOM	• 071 EXIT	• 119 MACHINE	• 168 SHED	220 WIRELESS
020 BELL	072 EXTERIOR	120 MAGNETIC	169 SHOCK	221 WORK
• 021 BLOWER		121 MAIDS	• 170 SHOP	
• 022 BOILER	• 073 FACTORY	122 MAIN	171 SHORT	222 XMITTER
023 BOTTOM	074 FAILURE	• 123 MASTER	172 SHOW	
024 BOX	075 FAMILY	124 MAT	• 173 SIDE	223 YARD
025 BREAK	• 076 FATHERS	• 125 MEDICAL	174 SKYLIGHT	
• 026 BUILDING	• 077 FENCE	126 MEDICINE	175 SLIDING	224 ZONE (No.)
027 BURNER	078 FILE	127 MICROWAVE	• 176 SMOKE	• 225 ZONE
	• 079 FIRE	128 MONEY	177 SONIC	
028 CABINET	• 080 FLOOR	129 MONITOR	• 178 SONS	• 226 0
• 029 CALL	081 FLOW	• 130 MOTHERS	• 179 SOUTH	• 227 1
030 CAMERA	082 FOIL	• 131 MOTION	180 SPRINKLER	• 228 1ST
031 CAR	• 083 FOYER	132 MOTOR	181 STAMP	• 229 2
032 CASE	084 FREEZER	133 MUD	• 182 STATION	• 230 2ND
033 CASH	• 085 FRONT		183 STEREO	• 231 3
034 CCTV	086 FUR	• 134 NORTH	184 STORE	• 232 3RD
035 CEILING	087 FURNACE	135 NURSERY	• 185 STORAGE	• 233 4
036 CELLAR			186 STORY	• 234 4TH
• 037 CENTRAL	088 GALLERY	• 136 OFFICE	187 STRESS	• 235 5
038 CIRCUIT	• 089 GARAGE	137 OIL	188 STRIKE	• 236 5TH
039 CLIP	• 090 GAS	• 138 OPEN	189 SUMP	• 237 6
• 040 CLOSED	091 GATE	139 OPENING	190 SUPERVISED	• 238 6TH
041 COIN	• 092 GLASS	• 140 OUTSIDE	191 SUPERVISION	• 239 7
042 COLD	093 GUEST	141 OVERFLOW	192 SWIMMING	• 240 7TH
043 COATROOM	094 GUN	142 OVERHEAD	193 SWITCH	• 241 8
044 COLLECTION				• 242 8TH
045 COMBUSTION	• 095 HALL	143 PAINTING	194 TAMPER	• 243 9
• 046 COMPUTER	• 096 HEAT	• 144 PANIC	195 TAPE	• 244 9TH
047 CONTACT	097 HIGH	145 PASSIVE	196 TELCO	250 Custom Word 1
	098 HOLDUP	• 146 PATIO	197 TELEPHONE	to
• 048 DAUGHTERS	099 HOUSE	147 PERIMETER	198 TELLER	269 Custom Word 20
049 DELAYED		• 148 PHONE	• 199 TEMPERATURE	
• 050 DEN	100 INFRARED	149 PHOTO	200 THERMOSTAT	
051 DESK	• 101 INSIDE	150 POINT	• 201 TOOL	

## CHARACTER (ASCII) CHART

(For Adding Custom Words)

32 (space)	42 *	52 4	62 >	72 H	82 R
33 !	43 +	53 5	63 ?	73 I	83 S
34 "	44 ,	54 6	64 @	74 J	84 T
35 #	45 -	55 7	65 A	75 K	85 U
36 \$	46 .	56 8	66 B	76 L	86 V
37 %	47 /	57 9	67 C	77 M	87 W
38 &	48 0	58 :	68 D	78 N	88 X
39 '	49 1	59 ;	69 E	79 O	89 Y
40 (	50 2	60 <	70 F	80 P	90 Z
41 )	51 3	61 =	71 G	81 Q	

## Relay Voice Descriptors And Custom Word Substitutes Vocabulary

<b>Word</b>	<b>Index</b>	<b>Word</b>	<b>Index</b>	<b>Word</b>	<b>Index</b>	<b>Word</b>	<b>Index</b>	<b>Word</b>	<b>Index</b>
Air .....	116	Daughter's .....	208	Front .....	087	No .....	165	Side .....	153
Alarm .....	255	Den .....	052	Garage.....	023	North.....	146	Six .....	075
And .....	067	Detector .....	128	Gas .....	138	Not .....	012	Sixth .....	219
Apartment .....	117	Device.....	060	Glass .....	139	Off.....	011	Smoke .....	024
Appliances .....	161	Dim .....	163	Hall .....	050	Office .....	147	Son's.....	223
Area .....	118	Dining .....	031	Heat .....	010	On.....	058	South .....	155
Attic.....	119	Door.....	016	Inside .....	209	One.....	070	Stairs .....	006
		Down .....	008	Kitchen.....	022	Open.....	148	Station .....	156
Baby .....	120	Downstairs.....	184	Laundry.....	140	Outside .....	210	Storage.....	157
Back.....	121	Driveway.....	130	Left.....	027	Panic.....	013	Sun .....	154
Bar .....	122	Duct .....	131	Light.....	019	Partition .....	090	System .....	062
Basement .....	021	East .....	132	Living .....	030	Patio .....	149		
Bathroom .....	051	Eight .....	077	Loading.....	142	Phone .....	061	Temperature....	158
Battery .....	053	Eighth .....	221	Lower.....	094	Power .....	063	Third .....	159
Bed .....	092	Equipment .....	133	Machine .....	143	Pump .....	166	Three .....	072
Bedroom .....	015	Exit.....	004	Master.....	144	Rear .....	088	Tool .....	213
Blower.....	123	Factory.....	134	Medical .....	014	Right .....	028	Two.....	071
Boiler .....	124	Father's.....	211	Motion.....	145	Room.....	018	Up.....	025
Bright .....	162	Fence.....	135	Nine .....	078	's .....	007	Upper.....	187
Building.....	125	Fifth.....	218	Ninth .....	222	Second .....	056	Upstairs .....	183
Burglary .....	039	Fire .....	040			Service .....	150	Utility.....	185
		First .....	136			Seven .....	076		
Call .....	009	Five.....	074			Seventh .....	220	West .....	215
Central .....	089	Floor .....	029			Shed .....	151	Window.....	017
Chime .....	054	Four .....	073			Shop .....	152	Wing .....	216
Closed .....	126	Fourth .....	217					Zero .....	069
Computer.....	127	Foyer .....	137					Zone .....	002
Console .....	066								

## Scheduling Menu Prompts

---

To program schedules, enter Scheduling program mode by pressing [Installer Code] + # + 80 to display the first choice of the menu driven programming functions. Press 0 (NO) or 1 (YES) in response to the displayed menu selection. Pressing 0 will display the next choice in sequence. Menu selections are as follows:

Time Window ? 1 Yes 0 = No 0	For defining up to 20 time windows each with a start and a stop time programmed by entering the hours and minutes.
O/C Schedules ? 1 Yes 0 = No 0	For defining the daily open and close schedules for the 8 partitions. Each partition can be programmed with an opening and closing window for each day of the week and holidays.
Holidays ? 1 Yes 0 = No 0	For defining up to 16 holidays for which partitions they apply.
Timed Events ? 1 Yes 0 = No 0	For defining up to 20 time driven events with the following parameters: <ul style="list-style-type: none"> <li>• Time window</li> <li>• Action desired</li> <li>• Action specifier</li> <li>• Activation time</li> <li>• Days of the week</li> </ul>
Access Sched. ? 1 Yes 0 = No 0	For defining the limitation of access schedules for the user codes. Each schedule can be programmed with two window for each day of the week and holidays

### #80 & #81 MENU MODE KEY COMMANDS

The following is a list of commands used while in the menu mode.

#80 or #81	Enters Menu mode
[*]	Serves as ENTER key. Press to have keypad accept entry.
[#]	Backs up to previous screen.
0	Press to answer NO
1	Press to answer YES
01-09	All data entries are either 2-digit entries.
00	Escapes from menu mode, back normal operation mode, when entered at the first question for each category.

## Scheduling Worksheets

---

**Time Windows Definitions Worksheet.** The system provides 20 time windows that are defined with start and stop times. They are programmed in the #80 Menu Mode. Fill in the required data on the worksheet below and follow the procedure in the installation instructions as you enter the data during the displays and prompts that appear in sequence.

Time Window Number	Start Time (HH:MM)	Stop Time (HH:MM)
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		
20		

(Keep this worksheet handy, as you will be asked for a given time window number later in this section).



Since the time windows are shared among all partitions, it is important to make sure that changing a time window does not adversely affect desired actions in other partitions.

**Daily Open/Close Schedule Worksheet:** Using the time windows previously defined, fill in the required data on the worksheet below and follow the procedure in the installation instructions as you enter the data during the displays and prompts that appear in sequence.

Part	Mon		Tues		Wed		Thur		Fri		Sat		Sun		Hol	
	Op	Cl	Op	Cl	Op	Cl	Op	Cl	Op	Cl	Op	Cl	Op	Cl	Op	Cl
1																
2																
3																
4																
5																
6																
7																
8																



**Holiday Schedule Worksheet:** The system provides up to 16 holidays that can be assigned for the system. Each holiday can be assigned to any combination of partitions. Fill in the required data on the worksheet below and follow the procedure in the installation instructions as you enter the data during the displays and prompts that appear in sequence.

HOL	Partition								
	Month/Day	1	2	3	4	5	6	7	8
1	/								
2	/								
3	/								
4	/								
5	/								
6	/								
7	/								
8	/								
9	/								
10	/								
11	/								
12	/								
13	/								
14	/								
15	/								
16	/								

**Time-Driven Event Worksheet:** The system provides up to 20 time driven events that can be programmed for the system. Fill in the required data on the worksheet below and follow the procedure in the installation instructions as you enter the data during the displays and prompts that appear in sequence.

Sched Num.	Time Window	Day(s)										Action Desired	Action Specifier	Activation Time
		M	T	W	T	F	S	S	H					
1														
2														
3														
4														
5														
6														
7														
8														
9														
10														
11														
12														
13														
14														
15														
16														
17														
18														
19														
20														

Below is a list of the "Action" codes (desired actions) used when programming time driven events. Note that these codes are independent of the "relay codes" programmed during the #93 Menu Mode—Relay Programming mode. **If using Time Driven Events to control relays, the following menu items must first be programmed using #93 Menu Mode - Relay Programming:**

Enter Relay No.	(reference identification number)
Relay Group	(if applicable)
Restriction	
Relay Type	(4204/4204CF or X-10)
ECP Address	(4204/4204CF)
Relay No.	(4204/4204CF)
House Code	(X-10)
Unit Code	(X-10)

**Relay commands:**

Action Specifier for commands 01-05 is Relay #, for commands 06-10 is Relay Group #.

01 = Relay On	02 = Relay Off
03 = Relay Close for 2 seconds	04 = Relay Close XX minutes (field 1*74)
05 = Relay Close YY seconds (field 1*75)	06 = Relay Group On
07 = Relay Group Off	08 = Relay Group Close for 2 seconds
09 = Relay Group Close XX minutes (field 1*74)	10 = Relay Group Close YY seconds (field 1*75)

**Arm/Disarm commands:**

Action Specifier for commands 20-24 is Partition(s), Activation times 1 (Beginning), 2 (End), 3 (During) are the only valid choices for auto-arming and disarming functions.

20 = Arm-Stay	21 = Arm Away
22 = Disarm	23 = Force Arm Stay (Auto-bypass faulted zns)
24 = Force Arm Away (Auto-bypass faulted zns)	

**Bypass commands:**

Action Specifier for commands 30-31 is Zone List #, Activation times 1 (Beginning), 2 (End), 3 (During) are the only valid choices for bypass commands.

30 = Auto bypass - Zone list	31 = Auto unbypass - Zone list
------------------------------	--------------------------------

**Open/Close Windows:**

Action Specifier for commands 40-41 is Partition(s), for 42 is Access Group, and for 50 no specifier is programmed. Activation time 3 (During) is the only valid choice for these commands.

40 = Enable Opening Window	41 = Enable Closing Window	42 = Enable Access Window
50 = Off-Normal Reminder (Starts local keypad beeping if fire off-normal condition exists)		

**Activation time:**

Refers to when the action is to take place relative to the time window.

- 1 = Beginning of time window
- 2 = End of time window
- 3 = During time window active period only (On at beginning of window, off at end).
- 4 = Beginning and end of time window (ex. -Coffee break buzzer).

**Limitation of Access Worksheet** The system provides up to 8 Access Schedules that can be programmed for the system. Fill in the required data on the worksheet below and follow the procedure in the installation instructions as you enter the data during the displays and prompts that appear in sequence.


Acc Sch	Mon		Tues		Wed		Thurs		Fri		Sat		Sun		Hol	
	W1	W2	W1	W2	W1	W2	W1	W2	W1	W2	W1	W2	W1	W2	W1	W2
1																
2																
3																
4																
5																
6																
7																
8																

**Temporary Schedule #81 Menu Mode** The system provides a Temporary Schedule for each partition. Enter the temporary scheduling mode by pressing [Installer Code] + #81. Fill in the required data on the worksheet below and follow the procedure in the installation instructions as you enter the data during the displays and prompts that appear in sequence.


Partition/Windows		Mon	Tue	Wed	Thu	Fri	Sat	Sun
1	<b>Disarm Window</b>							
	Start Time HH:MM							
	Stop Time HH:MM							
	<b>Arm Window</b>							
	Start Time HH:MM							
	Stop Time HH:MM							
2	<b>Disarm Window</b>							
	Start Time HH:MM							
	Stop Time HH:MM							
	<b>Arm Window</b>							
	Start Time HH:MM							
	Stop Time HH:MM							
3	<b>Disarm Window</b>							
	Start Time HH:MM							
	Stop Time HH:MM							
	<b>Arm Window</b>							
	Start Time HH:MM							
	Stop Time HH:MM							
4	<b>Disarm Window</b>							
	Start Time HH:MM							
	Stop Time HH:MM							
	<b>Arm Window</b>							
	Start Time HH:MM							
	Stop Time HH:MM							

5	<b>Disarm Window</b>							
	Start Time HH:MM							
	Stop Time HH:MM							
	<b>Arm Window</b>							
	Start Time HH:MM							
	Stop Time HH:MM							
6	<b>Disarm Window</b>							
	Start Time HH:MM							
	Stop Time HH:MM							
	<b>Arm Window</b>							
	Start Time HH:MM							
	Stop Time HH:MM							
7	<b>Disarm Window</b>							
	Start Time HH:MM							
	Stop Time HH:MM							
	<b>Arm Window</b>							
	Start Time HH:MM							
	Stop Time HH:MM							
8	<b>Disarm Window</b>							
	Start Time HH:MM							
	Stop Time HH:MM							
	<b>Arm Window</b>							
	Start Time HH:MM							
	Stop Time HH:MM							


# 5800 Series RF Transmitter Loop Designations




**5801**  
ENROLL AS "UR" OR "RF"




**5802/5802CP**  
ENROLL AS "BR"




**5802MN**  
ENROLL AS "UR" OR "RF"




**5804**  
ENROLL AS "BR"




**5804BD**  
ENROLL AS "BR"




**5806/5807/5808**  
(5806 SHOWN)  
ENROLL AS "RF"




**5816**  
ENROLL AS "RF"




**5816MN**  
ENROLL AS "RF"





**5817**  
ENROLL AS "RF"




**5818**  
ENROLL AS "RF"




**5819**  
ENROLL AS "RF"



**5849**  
ENROLL AS "RF"



**5890**  
ENROLL AS "RF"



**ADEMCO**  
**GROUP**

165 Eileen Way, Syosset, New York, 11791  
Copyright © 1997 PITTWAY CORPORATION



K3271-PR 7/98