

First Alert FA140C/142C Installer Notes M. Leuck

1. Programming can only be done by 6139 Alpha keypads, standard 6128 keypad cannot be used to program zones
2. Program new Master Code in section *20 (old version) or Installer Code + 8 + 2 + New Master Code (new version)
3. Enter programming: Master Code + 8 + 0 + 0 (FA140C)
Or Installer Code + 8 + 0 + 0 (FA142C)
4. Another method of entering programming: Power system down, then back up and within 30 seconds press * and # at the same time.
5. If system is armed when first powering up, power system back down, hold * and # while powering up system (not afterwards) to enter programming
6. Exit programming with *99
7. To program a location press * then location. To view what is in Location press # then Location, keypad will read off what is currently programmed
8. To erase a location (Example: Phone Number) press * then Location then * again
9. Duress/Hostage Code may be 1 digit above any User Code (old version), or User Code 8 (new version)

Downloading Information

It is **IMPORTANT** to enable downloading when first entering programming

1. Press * 96 (Keypad will beep)
2. Press * 95 and enter # + 15
3. Entering a Download Phone number is not necessary

- *48 15 SEC DIALER DELAY (BURG) † 0 [0 = no]; 1 = yes
- *49 PERIODIC TEST MESSAGE † 0 [0 = none]; 1 = 24 hrs; 2 = wkly; 3 = mnthly. Enter Test Code in field *64.
- *50 SESCOA/RADIONICS SELECT † 0 [0 = Radionics (0-9, B-F reporting)]; 1 = SESCOA (0-9 only reporting) Select 0 for all other formats.
- *51 CONFIRMATION OF ARMING DING † 0 [0 = no]; 1 = yes; 2 = yes, but with RF arming only.
- *52 ZONE 3 RESPONSE TO OPEN † 0 [0 = 400 ms nominal]; 1 = 10 ms nominal.

† Entry of a number other than one specified will give unpredictable results.

***56 ZONE ASSIGNMENT/ALARM REPORT CODES** (See explanation on next page) ➤

| ZONE ALPHA | ZONE No. (Zn) | ZONE TYPE (ZT) | ALARM RPT CODE Hex (RC) | INPUT DEVICE (In) | LEARNED RF INPUT (L) |
|--------------------------|---------------|---|--|-------------------|----------------------|
| ZONES ON CONTROL: | | | | | |
| ZONE 01 | 01 | <input type="checkbox"/> 0 <input type="checkbox"/> 1 [0] [1] | <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/> 0 [00] | HW | -- |
| ZONE 02 | 02 | <input type="checkbox"/> 0 <input type="checkbox"/> 4 [0] [4] | <input type="checkbox"/> 0 <input type="checkbox"/> 2 <input type="checkbox"/> 0 <input type="checkbox"/> 0 [00] | HW | -- |
| ZONE 03 | 03 | <input type="checkbox"/> 0 <input type="checkbox"/> 3 [0] [3] | <input type="checkbox"/> 0 <input type="checkbox"/> 3 <input type="checkbox"/> 0 <input type="checkbox"/> 0 [00] | HW | -- |
| ZONE 04 | 04 | <input type="checkbox"/> 0 <input type="checkbox"/> 3 [0] [3] | <input type="checkbox"/> 0 <input type="checkbox"/> 4 <input type="checkbox"/> 0 <input type="checkbox"/> 0 [00] | HW | -- |
| ZONE 05 | 05 | <input type="checkbox"/> 0 <input type="checkbox"/> 9 [0] [9] | <input type="checkbox"/> 0 <input type="checkbox"/> 5 <input type="checkbox"/> 0 <input type="checkbox"/> 0 [00] | HW | -- |
| ZONE 06 | 06 | <input type="checkbox"/> 0 <input type="checkbox"/> 3 [0] [7] | <input type="checkbox"/> 0 <input type="checkbox"/> 6 <input type="checkbox"/> 0 <input type="checkbox"/> 0 [00] | HW | -- |
| ZONE 07 | 07 * #, B | <input type="checkbox"/> 0 <input type="checkbox"/> 7 [0] [6] | <input type="checkbox"/> 0 <input type="checkbox"/> 7 <input type="checkbox"/> 0 <input type="checkbox"/> 0 [00] | -- | -- |
| ZONE 08 | 08 Duress | -- -- N A | <input type="checkbox"/> 0 <input type="checkbox"/> 0 <input type="checkbox"/> 0 <input type="checkbox"/> 0 [00] | -- | -- |
| ZONE 09 | 09 Tamper | 0 5 N A | <input type="checkbox"/> 0 <input type="checkbox"/> 0 <input type="checkbox"/> 0 <input type="checkbox"/> 0 [00] | -- | -- |
| ZONE 95 | 95 1 *, A | <input type="checkbox"/> 0 <input type="checkbox"/> 9 [0] [0] | <input type="checkbox"/> 0 <input type="checkbox"/> 8 <input type="checkbox"/> 0 <input type="checkbox"/> 0 [00] | -- | -- |
| ZONE 96 | 96 3 #. C | <input type="checkbox"/> 0 <input type="checkbox"/> 8 [0] [0] | <input type="checkbox"/> 0 <input type="checkbox"/> 9 <input type="checkbox"/> 0 <input type="checkbox"/> 0 [00] | -- | -- |

| EXPANSION ZONES: | | 4219/4229 can add up to 8 wired expansion zones. With 4281L, up to 4 RF expansion zones also available: 4281M/5881L, up to 8; 5881M, up to 16; 4281H/5881H, up to 30 (minus, in the last case, the number of 4219/4229 zones used). | | | LOOP No. | ENTER FOR 5800 ONLY |
|------------------|----------------|---|--------------------------|--------------------------|----------|--------------------------|
| ZONE ## | 1st Exp'n Zone | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 2nd | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 3rd | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 4th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 5th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 6th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 7th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 8th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 9th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 10th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 11th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 12th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 13th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 14th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 15th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 16th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 17th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 18th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 19th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 20th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 21st | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 22nd | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 23rd | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 24th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 25th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 26th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 27th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 28th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 29th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |
| ZONE ## | 30th | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | -- | <input type="checkbox"/> |

IN THE PREVIOUS PAGE'S ZONE ASSIGNMENT TABLE:

Zn = ZONE NUMBER Zone Nos. are from 01 to 63, 95, 96. Some are pre-assigned.
 With Field *25 set for auxiliary wired loops (4219 or 4229), use Zone Nos. 10-17 for loops A-H.
 With Field *22 set for RF (5700 or 5800), use Zone Nos. 10-63.

ZT = ZONE TYPE

| | | |
|------------------------|------------------------------|------------------------|
| 00 = Zone Not Used | 05 = Trouble Day/Alarm Night | 10 = Interior w/Delay |
| 01 = Entry/Exit | 06 = 24 Hr Silent | 20 = Arm-Stay |
| 02 = Do Not Use | 07 = 24 Hr Audible | 21 = Arm-Away |
| 03 = Perimeter | 08 = 24 Hr Aux | 22 = Disarm |
| 04 = Interior Follower | 09 = Fire | 23 = No Alarm Response |

| DEFAULT VALUES | | | | | |
|----------------|------|------|------|------|------|
| Zn: | 01 | 02 | 03 | 04 | 05 |
| ZT: | [01] | [04] | [03] | [03] | [09] |
| Zn: | 06 | 07 | 95 | 96 | |
| ZT: | [07] | [06] | [00] | [00] | |

*20, 21, and 22 used for 5800 RF systems only.

RC = ALARM REPORT CODE Two Hex Digits. For each Hex Digit, enter: 00-09 for 0-9
 10 for A, 11 for B, 12 for C, 13 for D, 14 for E, 15 for F.

If "00" is entered in the first pair of boxes, there will be no report for that zone.
 For Contact ID reporting, this is an enabling code only. Make any Hex digit entry (other than "00") in the first pair of boxes. The second pair of boxes will be ignored.

In = LOOP INPUT DEVICE

| | |
|-----------------------------|---------------------------------|
| HW: Hard Wire | 3 = RF: RF Supervised w/out S/N |
| AW: Aux Wire (4219 or 4229) | 4 = UR: Unsupervised RF |
| | 5 = BR: Button Type RF |

These are automatically assigned, except "UR" and "BR" for 5800 RF.

L = LEARNED RF INPUT Used with self-learning (5800) RF Loop Input Devices. Record transmitter input number.

TO PROGRAM SYSTEM STATUS, & RESTORE REPORT CODES (*60-*75):

With a 3+1 or 4+1 Standard Format: Enter a code in the *first* box: 1-9, 0, B, C, D, E, or F. Enter "#+10" for 0, "#+11" for B, "#+12" for C, "#+13" for D, "#+14" for E, "#+15" for F.
 A "0" (not "#+10") in the *first* box will disable a report.
 A "0" (not "#+10") in the *second* box will result in automatic advance to the next field when programming.

With an Expanded or 4+2 Format: Enter codes in boxes (1st and 2nd digits) for 1-9, 0, or B-F, as described above.
 A "0" (not "#+10") in the *second* box will eliminate the expanded message for that report.
 A "0" (not "#+10") in *both* boxes will disable the report

With Ademco Contact ID Reporting: Enter any digit (other than "0") in the *first* box, to enable zone to report (entries in the *second* boxes will be ignored).
 A "0" (not "#+10") in the *first* box will disable the report.

- *71 TROUBLE RESTORE REPORT CODE [00]
- *72 BYPASS RESTORE REPORT CODE [00]
- *73 AC RESTORE REPORT CODE [00]
- *74 LOW BAT RESTORE REPORT CODE [00]
- *75 RF XMTR LO BAT RESTORE REPORT CODE [00]

Examples: For Code 3 (Single Digit), enter:
 For Code 32 (Two Digits), enter:
 For Code B2 (Hexadecimal), enter:

- OUTPUT AND SYSTEM SETUP (*80-*92)**
- *80 OUTPUT RELAYS
 - *81 ZONE LISTS FOR OUTPUT RELAYS Program only if Relays are to be used. See next page.
 - *82 CUSTOM ALPHA EDITING: (Also entered from field *56):
See procedure in instructions.
 - *83 ADD/DELETE 5800 RF INPUT IDs: (Also can be accomplished from field *56): *See procedure in instructions, under field *56.*
 - *91 CUSTOM OPTION SELECTION (See Field *98)

SYSTEM STATUS REPORT CODES (*60-*68)

- *60 TROUBLE REPORT CODE [00]
 - *61 BYPASS REPORT CODE [00]
 - *62 AC LOSS REPORT CODE [00]
 - *63 LOW BATTERY REPORT CODE [00]
 - *64 TEST REPORT CODE [00]
 - *65 OPEN/EXIT ALARM REPORT CODE [00]
- 2nd digit of OPEN REPORT is automatically sent as the user number if expanded or 4+2 reporting is selected.
- 2nd digit of EXIT ALARM REPORT is automatically sent as the 2nd digit of the zone alarm report code programmed in *56, if expanded or 4+2 reporting is selected.
- *66 AWAY/STAY CLOSE REPORT CODE [00]
- 2nd digit of any CLOSE REPORT is automatically sent as the user number, if expanded or 4+2 reporting is selected.
- *67 RF XMTR LOW BAT REPORT CODE [00]
 - *68 CANCEL REPORT CODE [00]

- [0 = None selected] 4 = AAV (Audio Alarm Verification) 6 = Sounder Delay + AAV
 - 1 = Local Lockout 5 = Local Lockout + AAV 7 = Local Lockout + Sounder Delay + AAV
 - 2 = Sounder Delay
 - 3 = Local Lockout + Sounder Delay
- *92 REPORTS PER ARMED PERIOD [0]
- [0 = 10 max total alarm + alarm restore], 1 = unlimited

RESTORE REPORT CODES (*70-*75)

- *70 ALARM RESTORE REPORT CODE [0]
- 2nd digit is automatically sent as the 2nd digit of the zone alarm report code programmed in *56, if expanded or 4+2 reporting is selected.

- DOWNLOAD INFO (*94, *95)**
- DOWNLOAD PHONE No.**
- Enter up to 12 digits: 0-9; #+11 for '*'; #+12 for '#'; #+13 for a pause. Do not fill unused spaces. If fewer than 12 digits entered, exit field by pressing * (and press 95, if entering next field).
 To clear entries from field, press *94*.
- *95 RING DET COUNT FOR DOWNLOADING
- [0=Disable Station Initiated Download]; 1 - 14=number of rings (1-9, #+10=10, #+11=11, #+12=12, #+13=13, #+14=14); 15=answering machine defeat (#+15=15)
- *96 INITIALIZES DOWNLOAD ID, SUBSCRIBER ACCOUNT No. FOR INITIAL DOWNLOAD: No entry required.
 - *97 SETS ALL PROGRAM FIELDS TO DEFAULT VALUES: No entry required.

TO EXIT PROGRAM MODE (*98 or *99)

- Press *98 or *99 if exiting programming, or next field number if continuing.
- *98 EXITS PROGRAMMING MODE and prevents re-entry by: Master Code + Code + 0.
 - *99 EXITS PROGRAMMING MODE and allows re-entry by: Master Code + Code + 0 or by: Power-up + * + #.

OUTPUT RELAYS WORKSHEET FOR FIELDS *80, and *81.

Applicable only if relays are to be used.

Fill in required data and follow detailed programming procedure described in **PROGRAMMING DATA FIELDS** section of Installation Instructions

***80 OUTPUT RELAYS**

- Notes:**
- Field *25 must be programmed for a 4229 (Relays 01 and 02) or a 4204 (Relays 01 to 04).
 - If an AAV (Audio Alarm Verification) option is selected in field *91, Relay 01 should *not* be programmed here.
 - Tampers of contacts or expansion unit cannot be used to operate relays.

| OUTPUT RELAY | RELAY ACTION (A) | START either or both | | | STOP either or both | | |
|------------------------|------------------|-------------------------|----------------|---------------------------|-----------------------------|---------------------------|--|
| | | EVENT (EV) | ZONE LIST (ZL) | ZONE TYPE /SYST OP'N (ZT) | "RESTORE of" ZONE LIST (ZL) | ZONE TYPE /SYST OP'N (ZT) | |
| 01 SEE NOTE 2 ABOVE | 0 | 0 | 0 | 0 0 | 0 | 0 0 | |
| 02 | 0 | 0 | 0 | 0 0 | 0 | 0 0 | |
| 03 | 0 | 0 | 0 | 0 0 | 0 | 0 0 | |
| 04 | 0 | 0 | 0 | 0 0 | 0 | 0 0 | |

Where: **A = RELAY ACTION** 0 = No Response; 1 = Close for 2 sec; 2 = Close and stay closed; 3 = Pulse on and off
EV = EVENT 0 = Not used; 1 = Alarm; 2 = Fault; 3 = Trouble
ZL = ZONE LIST 1,2, or 3 (from Field *81) or 0 = Not Used.

START ZONE LIST: Upon alarm, fault, or trouble of ANY zone on this list, relay action will START.
STOP "RESTORE of" ZONE LIST: Upon restore of ALL zones on this list, relay action will STOP.
 It need not be same list as used for START.

ZT = ZONE TYPE/SYSTEM OPERATION

Choices for Zone Types are:

- | | |
|------------------------------|-----------------------|
| 00 = Not Used | 06 = 24 Hr Silent |
| 01 = Entry/Exit | 07 = 24 Hr Audible |
| 02 = Not Used | 08 = 24 Hr Aux |
| 03 = Perimeter | 09 = Fire Trouble |
| 04 = Interior Follower | 10 = Interior w/Delay |
| 05 = Trouble Day/Alarm Night | |

Note: Any zone in "ZT" going into alarm, fault, or trouble will actuate relay.
 Any zone of that type that restores will stop relay action.

Choices for System Operation are:

- | | | |
|-----------------------------|-----------------------------|-------------------------|
| 20 = Arming-Stay | 33 = Any Burglary Alarm | 39 = Any Fire Alarm |
| 21 = Arming-Away | 34 = Code + # + 7 Key Entry | 40 = Bypassing |
| 22 = Disarming (Code + OFF) | 35 = Code + # + 8 Key Entry | 41 = AC Power Failure |
| 31 = End of Exit Time | 36 = At Bell Timeout** | 42 = System Battery Low |
| 32 = Start of Entry Time | 38 = Chime | 58 = Duress |

**Or at Disarming, whichever occurs earlier.

***81 ZONE LISTS FOR OUTPUT RELAYS** Record desired zone numbers. More or fewer boxes than shown may be needed, since any list may include *any* or *all* of system's zone numbers.

Zone List 1: Started or stopped by zone numbers (enter 00 to end entries).
 , , , , , , , , , , ...etc.

Zone List 2: Started or stopped by zone numbers (enter 00 to end entries).
 , , , , , , , , , ...etc.

Zone List 3: Started or stopped by zone numbers (enter 00 to end entries).
 , , , , , , , , ...etc.

Monitronics FA142C Quick Reference Guide (M. Leuck)


Monitoring and Service call 800-447-9239

| | |
|-------------------------------|---|
| Arming (Away) | Enter 4-digit code + AWAY key (2), the display will show AWAY (If NOT READY press * to view open zones) |
| Disarming or Silencing Alarms | Enter 4-digit code + OFF key (1) If turning off an alarm enter 4 digit code + OFF key again to clear display |
| Arming (Stay) | Enter 4-digit code + STAY key (3), system will arm and the display will show STAY |
| Zone Bypassing | Enter 4-digit code + BYPASS key (6) + zone to be bypassed (01, 02, 03..) then arm system. The display will show "Bypass" and the zone bypassed, this must be done quickly! |
| Additional Codes | While system is disarmed enter MASTER CODE + CODE key (8) then user code you wish to program (3, 4 and 5) then enter desired code, system will beep once when completed. To change Master Code enter MASTER CODE + CODE (8) + 2 + New MASTER CODE twice (May not be available) |
| Door Chimes | To turn chimes on or off enter 4-digit code then the CHIME key (9) |
| Instant Doors | Enter 4-digit code then the INSTANT key (7) to arm system, all Entry/Exit doors will arm with no entry delay and all motion or interior zones will be bypassed. The display will show both STAY and INSTANT |
| Trouble Lights | Loss of AC power is indicated when the display shows NO AC on the keypad A display of LOW BAT indicates possible battery trouble, if zone also shows, a wireless sensor battery is low A display of CHECK indicates a problem elsewhere with the system or if a fault is detected in a fire zone. |
| Panic Buttons | To use the 3 panic buttons hold down both keys for 2 seconds for Police, Medical and Fire (if available) On many systems holding down a combination of numbers will activate the panics Holding down * and # keys activate a POLICE panic Holding down 1 and * keys activate a FIRE panic Holding down 3 and # keys activate a MEDICAL panic (Fire and Medical Panics may not be enabled) |



First Alert LCD Program Guide (6139 Alpha Keypad Required!)


1.



1 = Yes
0 = No

This is the first thing you see after entering * 56
For most installations press 0 to move to next screen

2.



Press * to move forward through menus. # to move backward

Enter zone to program, Lets program zone 10 as an example

Zones 01 to 06 = Hardwire

Zone 07 = Police Panic


Zone 08 = Hostage/Duress Code

Zone 10 and up = Wireless Zones

Zones 95 & 96 = Fire & Medical Panics

After programming Zone Type press * to move to next menu # for previous menu


3.



This screen shows programming summary of Zone 10
(This one shows nothing programmed yet)

Press * to move to next menu # for previous menu

4.




This programs Zone Type, above shows Zone 10 as
a Perimeter (03) Zone

To change enter Zone Type from list below then * to continue

| | |
|--------------------------------|--------------------------|
| 00 = Zone Disabled/Deleted | 08 = 24 hour Aux/Medical |
| 01 = Delay Zone | 09 = Fire |
| 02 = Secondary Delay Zone | 10 = Int Delay |
| 03 = Perimeter/Instant | 20 = Arm-Stay |
| 04 = Interior Follower/Motions | 21 = Arm-Away |
| 06 = 24 hour Silent/Holdup | 22 = Disarm |
| 07 = 24 hour Police Panic | 23 = No Alarm Response |

Press * to move to next menu # for previous menu

5.




This is Zone 10's Report Code divided into 4 digits

Make all zone report codes different to properly send all signals
(Example, Zone 01 = 01 00, Zone 02 = 02 00, Zone 07 = 07 00 etc)

We have programmed Zone 10 to be 11 00 which actually enters B0

Press * to move to next menu

6.



Zone 10 is wireless, select Type of Wireless & Loop here

RF will be flashing, most sensors are RF so press *


to move to Loop Number Loop Number

3 = Supervised RF (Doors, Smokes Motions etc are RF)

5 = RF Button Type (Keyfobs & Panic Buttons)

Press * to move to next menu # for previous menu

7.



LP# will now flash, enter Loop Number from below list

Door Switch - Internal = Loop 2, External switch = Loop 1

Glassbreak - Loop 1

Motions - Loop 1


Smoke Det. - Loop 1

Keyfobs - Loops 1 to 4, assign for each button

If sensor does not confirm while learning it may have wrong loop number

Press * to move to next menu # for previous menu

8.



= Yes, learn now

= No, Learn later

Press 1 (Yes) then * to continue

If you press 0 you can learn in "sequential" mode later

Learn sensors 2 ways

1. Input Serial number of sensor (printed on bottom of sensor)
or
2. Open and close sensor once to learn, twice to confirm
(keypad will beep when learned, again if confirmed)

If sensor does not confirm it may have wrong loop number

9.




This shows summary of new programming in this order
Zone Number/Zone Type/Report Code/Wireless Type/Loop

The "s" at indicates sensor was "Learned" into system

Press * to move to next menu # for previous menu

10.




1 = Yes

0 = No

Press 1 to program Zone Descriptions or 0 to finish (For most installations press 0)

11.



When finished you will return to the "Enter Zn Num" prompt, enter next zone or 00 to end and return to regular programming