Wiring V4000 to the Vista Series alarm panel

- 1. Connect Handset side Tip and Ring on the Control panel to the V4000 Tip and Ring Terminals.
- 2. Connect the video cables form the CCTV cameras to the BNC connectors.
- 3. Ensure that the designated trigger zones on the control panel are installed.
- 4. Connect the keypad bus terminals (ECP)
- 5. Connect the power supply to the power supply terminals on the V4000.
- 6. Power up the system.

