DocShow Page 1 of 1

addressing of receiver

Step-by-Step 50837466

If using the CE3 on an Ademco NON addressable panel nothing needs to be done in panel program. Just make sure we don't exceed the number of keypads the panel supports. If being using on an Ademco addressable panel the receiver will use address 03. If being used on the plus series panels (15p,20p) it will use address 17.