

# Survival Guide

## 4140XMP 64 Zone Control

- 64 Zones Max.  
9 Wired Zones Standard (*2K EOLR, disabled in \*41*)  
55 Vplex Zones  
63 Wireless Zones (5700) (*Can have up to 2 4280/1 receivers address 0 & 1*)
  - Keypads: 4127/AD, 4137, 6127,6137, 6128/RF, 6150/RF, 5137/AD, 6138, & 6138, 6160 Address 31
  - 16 2-Wire Smokes on Zone 1
  - 220 Word Dictionary + 20 Custom
  - Custom Message Display
  - Keyswitch on Zone 7 (4146)
  - Built-In Clock (*Code + # + 63*)
  - Quick Arming
  - Ground Start
  - 4 Voltage Trigger Outputs
  - 10 Day History  
(*Code + 0*) *After viewing History is deleted!*
  - Fully Downloadable  
*Direct Wire Downloadable via 4100SM*
  - High Speed Format & Contact ID
  - 70 Users 4 or 6-digits (*High sec. 1\*54*)  
(*Babysitter = # 22 ; Duress = 1-digit higher*)
  - 750mA Aux. 2.8A Alarm Power
  - 3 Console Panics
  - Power Up in Previous State
- Added Features:**  
*Confirmation of Arm Ding*  
*Forced Bypass*  
*Split/Dual Reporting*  
*AC Randomize*  
*1-199Hr. Test Report*  
*L.R.R. Outputs*  
*Chime on External Sounder*