



## Quick Reference Card

For assistance with your system, call your C&K Dealer at this number:

---

(fold here)

### To Bypass a Zone:

1. Press the  key.
2. Enter the two-digit zone number.
3. Enter your user code. (If you have Quick Bypassing, no user code is needed.)

**Remember: bypassed zones are not protected.**

(fold here)

### To Disarm:

1. Enter your user code.

### To Cancel an Alarm:

1. Press the  key.
2. Enter your user code.

## To Full Arm:

Full arming arms both the interior and perimeter zones. You cannot be inside the building while it is armed.

1. Enter your user code.

(fold here)

## To Home Arm:

Home arming arms only the perimeter zones. You can remain inside the building while it is armed.

1. Press the  key,
2. Enter your user code. (If your system is programmed for Quick Home-Arming, you do not need to enter your code.)

(fold here)

## To Instant Home-Arm:

The instant a door opens, an alarm sounds.

1. Press and hold the  [instant] key.
2. Enter your user code. (If your system is programmed for Quick Instant Home-Arming, you do not need to enter your code.)