



## ADT

### SUPPLEMENT FOR ADT-NIB-96

(For MANUAL #A15666 Rev. A)

Document 50336 Rev A 6/27/95 ECN 95-305

*Add the following note to Figure 2-1 on page 6:*

7. Wiring from the ADT-NIB-96 that goes outside the building:
- cannot exceed 1000 meters
  - cannot cross any power lines
  - cannot be in the vicinity of any high voltage

*Replace the first paragraph under the heading **NFPA Standards - Unimode II Master Systems** on page 8 with the following:*

When installed in accordance with the Unimode II Installation Manual, the Unimode II/ADT-AIM-200 master control panel meets the requirements of the following NFPA 72-1993 Standards National Fire Alarm Code:

Local Protective Signaling Systems  
Central Station Service - Protected Premises Unit  
Remote Station Protective Signaling System  
Proprietary Signaling System Protected Premises Unit

*Under the heading **NIB Power Requirements** on page 9, add the following:*

24 VDC power-limited power supply

*Add the following note to Figure 5-2 on page 14:*

**Note:** All connections shown are power-limited.