

**Canadian  
Annunciator Application  
Supplement**

Document 51972 Rev A 03/26/02 ECN 02-165

*In Canada, the ACM Series annunciator modules must be used to annunciate the fire alarm input points/zones only.*

**For Canadian applications, the following LED colors must be employed:**

- **Red must be used to indicate active alarm inputs**
- **Yellow must be used to indicate supervisory, burglary or trouble signals**
- **Green must be used to indicate the presence of power or an activated output**