

**OmniLT Controllers**

21A00-1	OmniLT Controller	OmniLT controller with enclosure, RJ31X jack and cable, manuals, accessory kit.
21A00-2	OmniLT Board Only	OmniLT controller board only
21A00-11	OmniLT for Leviton	OmniLT controller on mounting plate for Leviton SMC enclosures, Two-way X-10 Kit, RJ31X jack and cable, manuals, accessory kit, & wiring label for enclosure door. Also fits in "open house" type enclosures

**OmniLT Packages**

Promo9	OmniLT with Surface Console	OmniLT controller in enclosure, RJ31X jack and cable, Surface Mount Console, manuals, accessory kit.
<b>NEW!</b> Promo9CS	OmniLT with Surface Console - Case of 6	Case of 6 Promo9
Promo10	OmniLT Kit	OmniLT controller in enclosure, Surface Mount Console, Two way X-10 kit, RJ31X jack and cable, RC-80 Thermostat, Indoor/Outdoor Temperature Sensor, serial cable, manuals.
Promo10S	OmniLT for Leviton Kit	OmniLT controller on mounting plate for Leviton SMC enclosures, Surface Mount Console, Two way X-10 kit, RJ31X jack and cable, RC-80 Thermostat, Indoor/Outdoor Temperature Sensor, serial cable, manuals.
Promo11	OmniLT Starter Kit	OmniLT controller in enclosure, 1105W Dealer Software, Surface Mount Console, Two Way X-10 kit, RJ-31X jack and cable, lock and keys, serial cable, sample home control programs, manuals

**OmniLT Accessories**

22A00-1	OmniLT Expansion Module	16 zones plus 8 voltage output expansion module w/ accessory kit
10A09-7	Two way X-10 Transceiver Kit	Two Way X-10 protocol powerline carrier transceiver, 7 foot cable, instructions
21A06-1	Enclosure Lock and 2 Keys	Lock for Omni LT enclosure, two keys
21A07-2	Mounting Plate for OmniLT	Mounting plate, hardware kit, & instructions. Used to mount OmniLT controllers in Leviton SMC and "open house" type structured wiring enclosures.
27A00-2	OmniLT Demo Adapter Kit	Demo adapter board, instructions

**Omni II, OmniPro II Controllers**

20A00-1	Omni II Controller	Omni II controller with enclosure, lock set w/ two keys, Two way X-10 transceiver, RJ31X cord and jack, manuals
20A00-4	Omni II Commercial Controller	Omni II controller with commercial attack proof enclosure, lock set w/ two keys, Two way X-10 transceiver, RJ31X cord and jack, manuals, wiring label for enclosure door
20A00-7	Omni II Controller for Structured Wiring Enclosures	Omni II controller on mounting plate for Leviton, OnQ, UStec, Siemon and "open house" type enclosures, Two way X-10 transceiver, RJ31X cord and jack, manuals, accessory kit, & wiring diagram for enclosure door
20A00-2	OmniPro II Controller	OmniPro II controller with enclosure, lock set w/ two keys, Two way X-10 transceiver, RJ31X cord and jack, manuals
20A00-5	OmniPro II Commercial Controller	OmniPro II controller with commercial attack proof enclosure, lock set w/ two keys, Two way X-10 transceiver, RJ31X cord and jack, manuals
20A00-8	OmniPro II Controller for Structured Wiring Enclosures	OmniPro II controller on mounting plate for Leviton, OnQ, UStec, Siemon and "open house" type enclosures, Two way X-10 transceiver, RJ31X cord and jack, manuals, accessory kit, & wiring diagram for enclosure door
20A00-11	Omni II Board Only	Omni II controller board only
20A00-21	OmniPro II Board Only	Omni Pro II controller board only

**Omni II, OmniPro II Packages**

Promo12	Omni II Kit with Flush Console	Omni II controller with enclosure, lock set w/ two keys, Surface Mount Console, Flush Mount Kit, RC-80 thermostat, Indoor/Outdoor Temperature Sensor, Two way X-10 transceiver, RJ31X cord and jack, serial cable, manuals
Promo12S	Omni II for Structured Wiring Kit with Flush Console	Omni II controller on a Structured Wiring Backplate, Surface Mount Console, Flush Mount Kit, RC-80 thermostat, Indoor/Outdoor Temperature Sensor, Two way X-10 transceiver, RJ31X cord and jack, serial cable, manuals
Promo14	Omni II Starter Kit	Omni II controller with enclosure, lock set w/ two keys, Surface Mount Console, Flush Mount Kit, 1105W Dealer Software, RC-80 thermostat, Indoor/Outdoor Temperature Sensor, Two way X-10 transceiver, RJ31X cord and jack, serial cable, manuals
Promo15	OmniPro II Kit with Flush Console and Hardwire Expander	OmniPro II controller with enclosure, lock set w/ two keys, Surface Mount Console, Flush Mount Kit, 10A06 expander, RC-80 thermostat, Indoor/Outdoor Temperature Sensor, Two way X-10 transceiver, RJ31X cord and jack, serial cables, manuals
Promo15S	OmniPro II for Structured Wiring Kit with Flush Console and Hardwire Expander	OmniPro II controller on a Structured Wiring Backplate, Surface Mount Console, Flush Mount Kit, 10A06 expander, RC-80 thermostat, Indoor/Outdoor Temperature Sensor, Two way X-10 transceiver, RJ31X cord and jack, serial cables, manuals
Promo16	OmniPro II Starter Kit	OmniPro II controller with enclosure, lock set w/ two keys, Surface Mount Console, Flush Mount Kit, 1105W Dealer Software, RC-80 thermostat, Indoor/Outdoor Temperature Sensor, Two way X-10 transceiver, RJ31X cord and jack, serial cables, manuals

**Omni Family Consoles**

<b>NEW!</b> 33A00-1	Omni Console	LCD surface mount console, silk screen front, connector kit, instructions
<b>NEW!</b> 33A00-1CS	Omni Console - Case Lot of 12	Case of 12 33A00-1 Consoles
<b>NEW!</b> 33A00-3	Omni Console Flush Mount Kit	White Flush Mount Back Box, Mounting Brackets, Mounting Hardware, instructions

**OmniTouch Touchscreen**

32A00-1	HAI OmniTouch Touchscreen	Color touchscreen in flush mount enclosure, includes white, beige, and almond faceplates, connector kit, instructions
32A07-1	OmniTouch trim ring	White trim ring - intended for retrofitting OmniTouch in place of 11A00-2 Flush Console. White, paintable to wall color

**Omni Family Accessories**

10A06-1	16 Zone Hardwire Expander	16 Zone expansion module w/ accessory kit (for Omni II and OmniPro II)
10A07-1	4 Relay Module	4 relay module w/ mounting tape
10A09-1	Dual X-10 Transmitter Kit	Two way X-10 transceiver, 25' phone line w/ connectors and adapter to use two X-10 transmitters for more signal strength
10A09-2	Split X-10 Signal Kit	Two way X-10 transceiver, 25' phone line w/ connectors and adapter to separate receive and transmit function of transceivers
10A11-1	Two-Way Voice Module	Two way voice board, mounting material, instructions
10A17-1	RS-232/RS-485 Serial Board	RS-232/485 serial board, accessories kit, 20 pin cable, instructions
1101A	PESM	Programmable energy saver module w/ instructions
14A00-8	Water Temperature Sensor	Water temperature sensor module, probe, accessories, instructions
17A00-1	16 Zone/16 Output Expansion Enclosure	16 input/16 output expansion board with enclosure, lock set w/ two keys, accessories kit, instructions (for OmniPro II)
<b>NEW!</b> 17A00-8	16 Zone/16 Output Expansion Board Only	16 input/16 output expansion board only
17A00-9	16 Zone/16 Output Expansion Board on a Universal Mounting Plate	16 input/16 output expansion board on a universal mounting plate with accessories kit, instructions for installation in Siemon, Leviton, UStec, OnQ and "open house" type structured wiring enclosures
18A00-5	Demo Adapter Kit	Demo adapter board, instructions (for Omni II and OmniPro II)
19A00-1	8 Relay Module	8 relay module w/ accessory kit - mounts in 17A00 Expansion Enclosure
20A07-2	Universal Mounting Plate for Omni II/Omni Pro II	Mounting plate, hardware kit, & instructions. Used to mount Omni family controllers, expanders, and accessories in Siemon, Leviton, OnQ, UStec, and "open house" type structured wiring enclosures.
21A05-2	Serial Cable	7 foot cable, modular to DB-9F - connects LT, Omni II, Pro II serial ports to computer RS-232 port
28A00-1	Surface Speaker/Microphone Module	Speaker and microphone, surface mount enclosure, instructions
28A00-2	Flush Speaker/Microphone Module	Speaker and microphone, flush mount enclosure, instructions
31A00-1	Indoor/Outdoor Temperature Sensor	Indoor/outdoor temperature sensor, accessories kit, instruction sheet
31A00-2	Indoor/Outdoor Temperature and Humidity Sensor	Indoor/outdoor temperature and humidity sensor, accessories kit, instruction sheet

**Omnistats & Accessories**

RC 80	Single Stage Heat/Cool	Single stage (1 heat/1 cool) thermostat, accessories kit, manuals
<b>NEW!</b> RC 80B	Single Stage Heat/Cool, Lighted	Single stage (1 heat/1 cool) thermostat with lighted LCD, accessories kit, manuals
RC 90	Single Stage Heat/Cool for Zoned Systems	Single stage (1 heat/1 cool, with B & O terminals) for zoned systems thermostat, accessories kit, manuals
<b>NEW!</b> RC 90B	Single Stage Heat/Cool for Zoned Systems, Lighted	Single stage (1 heat/1 cool, with B & O terminals) for zoned systems thermostat with lighted LCD, accessories kit, manuals
RC 100	Heat Pump	Heat pump thermostat, (2 heat/1 cool) accessories kit, manuals
<b>NEW!</b> RC 100B	Heat Pump, Lighted	Heat pump thermostat, (2 heat/1 cool) with lighted LCD, accessories kit, manuals
RC 112	Two Speed Heat Pump	Two speed heat pump thermostat (3 heat/2 cool), accessories kit, manuals
<b>NEW!</b> RC 112B	Two Speed Heat Pump, Lighted	Two speed heat pump thermostat (3 heat/2 cool) with lighted LCD, accessories kit, manuals
RC 122	Two Stage Heat/Cool	Two stage thermostat (2 heat/2 cool), accessories kit, manuals
<b>NEW!</b> RC 122B	Two Stage Heat/Cool, Lighted	Two stage thermostat (2 heat/2 cool) with lighted LCD, accessories kit, manuals
23A00-1	Remote Indoor Temp Sensor/Surface	Surface indoor temperature sensor for Omnistat thermostats
23A00-2	Remote Indoor Temp Sensor/Flush	Flush indoor temperature sensor for Omnistat thermostats
RC 201	Serial Cable	9 ft serial cable, nine-pin DB-9 serial to four-pin HAI Omnistat connector. Used to connect RC- series thermostats to PC (Not required for Omni family controllers)
29A00-1	Thermostat Isolation Module	Relay isolation module for RC-80 series thermostats, mounting clips, instructions
30A00-1	Thermostat Power Supply Module	Power booster for RC-80 series thermostats, instructions

**ALC Interface & Switches**

25A00-1	ALC Interface, 1 branch	1 branch ALC Hardwire Lighting Control Interface
25A00-2	ALC Interface, 4 branch	4 branch ALC Hardwire Lighting Control Interface
363142-01	ALC Relay Switch White	
363142-02	ALC Relay Switch Ivory	
363143-01	ALC Dimmer Switch 500W White	
363143-02	ALC Dimmer Switch 500W Ivory	
363144-01	ALC Program Switch White	
363144-02	ALC Program Switch Ivory	
363145-01	ALC Auxiliary Switch White	
363145-02	ALC Auxiliary Switch Ivory	
364335-01	ALC 1000W Dimmer Switch White	
364335-02	ALC 1000W Dimmer Switch Ivory	
364355-01	ALC Cluster Switch White	
364355-02	ALC Cluster Switch Ivory	

**Brochures & Documentation**

SA13	Thermostat Spec Sheets	pack of 250
SA14	Omni Accessory Spec Sheets	pack of 250
SA20	HAI Automation Simplified... Brochure	pack of 50
SA21	OmniLT Spec Sheets	pack of 250
SA23	HAI Model Home Wall Displays	Merchandising kit to show features of Omni systems in model homes
SA24	Web-Link II Spec Sheets	pack of 250
SA25	Omni II Spec Sheets	pack of 250
SA26	OmniPro II Spec Sheets	pack of 250
SA27	Leviton Spec Sheets	pack of 250
SA28	Model Home FAQ	pack of 100
OMNILT-MS	Omni LT Owner's/Installation Manuals	
OMNI II-MS	Omni II Owner's/Installation Manuals	
OMNIPRO II-MS	OmniPro II Owner's/Installation Manual	
TRAINMAN	HAI Omni Series Training Manual	

**Software****(Software must be registered for HAI technical support.)**

1105W	HAI Upload/Download IBM-PC for Windows
1106W	HAI End User Software/IBM-PC for Windows
1108	HAI Web-Link II Software

**Demonstration Kits**

18A00-10	Omni II Demo System with Two Way X-10	Fully assembled and operational Omni II demo system including Omni II controller, RC-80 programmable thermostat, LCD surface mount silk screen console, demo board adapter kit, Two way X-10 transceiver, serial cable, touch tone speaker phone packaged in robust black travel case
18A00-11	Omni Pro II Demo System with Two Way X-10	Fully assembled and operational Omni Pro II demo system including Omni Pro II controller, RC-80 programmable thermostat, LCD surface mount silk screen console, demo board adapter kit, Two way X-10 transceiver, serial cable, touch tone speaker phone packaged in robust black travel case
27A00-1	OmniLT Demo System with ALC	Fully assembled and operational OmniLT demo system including OmniLT controller, RC-80 programmable thermostat, LCD surface mount silk screen console, demo board adapter kit, ALC Interface, ALC Dimmer switch and demo lamp in Decora-style enclosure, serial cable, touch tone speaker phone packaged in robust black travel case
27A00-3	OmniLT Demo System with Two Way X-10	Fully assembled and operational OmniLT demo system including OmniLT controller, RC-80 programmable thermostat, LCD surface mount silk screen console, demo board adapter kit, Two way X-10 transceiver, serial cable, touch tone speaker phone packaged in robust black travel case

**Omni Family Upgrade Chips**

21A03-1UPG	OmniLT Upgrade Chip Version X.X	Upgrade chip for OmniLT, instructions
20A04-1UPG	Omni II Chip Upgrade Version X.X	EPROM chip upgrade with installation instructions
20A04-2UPG	OmniPro II Chip Upgrade Version X.X	EPROM chip upgrade with installation instructions
10A05-1	Omni Chip Upgrade Version 1.9	EPROM chip upgrade with installation instructions
10A05-9	OmniPro Chip Upgrade Version 1.9	EPROM chip upgrade with installation instructions