

MAKE: Linear

MODEL: SSD

ARM ALARM:

*/ Your Code/ HOME button or AWAY button

DISARM ALARM:

*/ Your Code/ OFF button

DISARM FIRE ALARM:

*/ Your Code/ OFF button

RESET ALARM:

*/ Code # / OFF button/ Code # / OFF button

STOP TROUBLE BEEP:

any key

SILENCE ALARM:

*/ Code # / OFF

DIGITS IN CODE: 4

CHANGE CODE:

service ticket

NOTES: Technical Support #: 1-800-421-1587
(DO NOT GIVE TO CUSTOMER)