


KEEPSAFER

SSD SECURITY

WIRELESS KEYPAD


For Use With SSD Security Console

Installation Instructions




Help Line 1-800-835-2680

1. KEYPAD DETAIL




2. TYPICAL WIRELESS KEYPAD PLACEMENT




3. TABLE-TOP USE

USE THE FOUR SCRATCH DETERRENT PADS PROVIDED FOR TABLE TOP USE




4. OPENING KEYPAD FOR WALL MOUNT USE

FROM TOP OF CASE TWIST SCREWDRIVER BETWEEN CASE HALVES UNTIL IT POPS OPEN




5. WALL MOUNTING (INDOORS ONLY)

ATTACH REAR CASE TO WALL WITH THE FOUR SCREWS PROVIDED



MOUNT AT A CONVENIENT LOCATION NEAR PRIMARY ENTRY/EXIT DOOR

6. CLOSING THE KEYPAD



7. PROGRAM KEYPAD INTO CONSOLE

