

Linear Wireless Sensor Cross-Reference Guide

TD/TX sensors = 433.92Mhz

DXS sensors = 315Mhz

DXT sensors = 315Mhz

SSD sensors = 433.92Mhz

CP-90 sensors work with CP-90/21st Sentry panel or SXR-64 64-Channel Receiver

DXS Sensors generally work with DVS12 00/2400/2408/Dual 824 panels

DXS sensors work with DX and DXS external add-on receivers

DXT sensors "may" work with DVS1200/2400/2408/Dual 824 panels

SSD sensors only work with SSD/Defiant-16 panel

D-2R 2-Channel Receiver

D-4B 4-Channel, 4-Button Handheld Transmitter
ET-1B Emergency Transmitter
ET-2-19 Miniature Transmitter
ET-2-12 Miniature Transmitter
D-21A Normally Open Wall-mount Transmitter
D-22A 1-Channel, 1-Button Handheld Transmitter
D-22B 2-Channel, 2-Button Handheld Transmitter
D-22C 2-Channel, 2-Button Independent Code Transmitter
D-22D 2-Channel, 2-Button Lockout Transmitter
D-23R Bill Trap Transmitter
D-24A Normally Closed Wall-mount Transmitter

D-4R 4-Channel Receiver

D-4B 4-Channel, 4-Button Handheld Transmitter
ET-1B Emergency Transmitter
ET-2-19 Miniature Transmitter
ET-2-12 Miniature Transmitter
D-21A Normally Open Wall-mount Transmitter
D-22A 1-Channel, 1-Button Handheld Transmitter
D-22B 2-Channel, 2-Button Handheld Transmitter
D-22C 2-Channel, 2-Button Independent Code Transmitter
D-22D 2-Channel, 2-Button Lockout Transmitter
D-23R Bill Trap Transmitter
D-24A Normally Closed Wall-mount Transmitter

D-67 1-Channel Receiver

D-4B 4-Channel, 4-Button Handheld Transmitter
ET-1B Emergency Transmitter
ET-2-19 Miniature Transmitter
ET-2-12 Miniature Transmitter
D-21A Normally Open Wall-mount Transmitter
D-22A 1-Channel, 1-Button Handheld Transmitter
D-22B 2-Channel, 2-Button Handheld Transmitter
D-22C 2-Channel, 2-Button Independent Code Transmitter
D-22D 2-Channel, 2-Button Lockout Transmitter
D-23R Bill Trap Transmitter
D-24A Normally Closed Wall-mount Transmitter

D-8C 8-Channel Receiver

D-4B 4-Channel, 4-Button Handheld Transmitter
ET-1B Emergency Transmitter
ET-2-19 Miniature Transmitter
ET-2-12 Miniature Transmitter
D-21A Normally Open Wall-mount Transmitter
D-22A 1-Channel, 1-Button Handheld Transmitter
D-22B 2-Channel, 2-Button Handheld Transmitter
D-22C 2-Channel, 2-Button Independent Code Transmitter
D-22D 2-Channel, 2-Button Lockout Transmitter
D-23R Bill Trap Transmitter
D-24A Normally Closed Wall-mount Transmitter

DXR-701 1-Channel/DXR-702 2-Channel Receiver
DXT-54 Passive Infrared Motion Detector Transmitter
DXT-31 Door/Window Transmitter
DXT-81 Bill Trap Transmitter
DXT-41 1-Button, 1-Channel Key Ring Transmitter
DXT-42 2-Button, 3-Channel Key Ring Transmitter
DXT-21 2-Button, 1-Channel Handheld Transmitter
DXT-23 3-Button, 4-Channel Handheld Transmitter
DXT-25 5-Button, 8-Channel Handheld Transmitter
DXT-61A 1-Button, 1-Channel Pendant Transmitter

D-4B 4-Button Transmitter
D-67 1-Channel Receiver
D-67L 1-Channel Latching Receiver
DX-12 1-Channel Amplified Receiver
D-2R 2-Channel Receiver
D-4R 4-Channel Receiver
D-8C 8-Channel Receiver

D-21/21A Universal Transmitter
D-67 1-Channel Receiver
D-67L 1-Channel Latching Receiver
DX-12 1-Channel Amplified Receiver
D-2R 2-Channel Receiver
D-4R 4-Channel Receiver
D-8C 8-Channel Receiver

D-22A/ 1-Button Panic
D-67 1-Channel Receiver
D-67L 1-Channel Latching Receiver
DX-12 1-Channel Amplified Receiver
D-2R 2-Channel Receiver
D-4R 4-Channel Receiver
D-8C 8-Channel Receiver

D-22B/D-22C/D-22D 2 Button Panic
D-67 1-Channel Receiver
D-67L 1-Channel Latching Receiver
DX-12 1-Channel Amplified Receiver
D-2R 2-Channel Receiver
D-4R 4-Channel Receiver
D-8C 8-Channel Receiver

D-23R Bill Trap
D-67 1-Channel Receiver
D-67L 1-Channel Latching Receiver
DX-12 1-Channel Amplified Receiver
D-2R 2-Channel Receiver
D-4R 4-Channel Receiver
D-8C 8-Channel Receiver

D-24A Universal Transmitter
D-67 1-Channel Receiver
D-67L 1-Channel Latching Receiver
DX-12 1-Channel Amplified Receiver
D-2R 2-Channel Receiver
D-4R 4-Channel Receiver
D-8C 8-Channel Receiver

D-26A Universal Transmitter
D-67 1-Channel Receiver
D-67L 1-Channel Latching Receiver
DX-12 1-Channel Amplified Receiver
D-2R 2-Channel Receiver
D-4R 4-Channel Receiver
D-8C 8-Channel Receiver

D-30 Miniature Door Sensor
D-67 1-Channel Receiver
D-67L 1-Channel Latching Receiver
DX-12 1-Channel Amplified Receiver
D-2R 2-Channel Receiver
D-4R 4-Channel Receiver
D-8C 8-Channel Receiver

ET-1B Pendant Panic
D-67 1-Channel Receiver
D-67L 1-Channel Latching Receiver
DX-12 1-Channel Amplified Receiver
D-2R 2-Channel Receiver
D-4R 4-Channel Receiver
D-8C 8-Channel Receiver

ET-2 Pendant Panic
D-67 1-Channel Receiver
D-67L 1-Channel Latching Receiver
DX-12 1-Channel Amplified Receiver
D-2R 2-Channel Receiver
D-4R 4-Channel Receiver
D-8C 8-Channel Receiver

DXS-10 Remote Keypad
DUAL - 824
DVS-1200
DVS-2400

DXS-21 2-Button Keyfob
DUAL - 824
DXSR-1504
DXSR-1508
DVS-1200
DVS-2400

DXS-23 3-Button Keyfob
DUAL - 824
DXSR-1504
DXSR-1508
DVS-1200
DVS-2400

DXS-25 5-Button Keyfob
DXSR-1504
DXSR-1508

DXS-31 Door Sensor
DUAL - 824
DXSR-1504
DXSR-1508
DVS-1200
DVS-2400

DXS-32 Door Sensor
DUAL - 824
DXSR-1504
DXSR-1508
DVS-1200
DVS-2400

DXS-54 Motion Detector
DUAL - 824
DXSR-1504
DXSR-1508
DVS-1200
DVS-2400

DXS-62 Wristband/Pendant Panic
DUAL - 824
DXSR-1504
DXSR-1508
DVS-1200
DVS-2400

DXS-62A Wristband/Pendant Panic
PERS-2400A
DUAL - 824
AL-1 AlertLink
PERS-3600
DXSR-1504
DXSR-1508
DVS-1200
DVS-2400

DXS-63 Wristband/Pendant Panic
DUAL - 824
DXSR-1504
DXSR-1508
DVS-1200
DVS-2400

DXS-64 1-Button Pendant Panic
PERS-2400A
PERS-3600

DXS-72 Smoke Detector
DUAL - 824
DXSR-1504
DXSR-1508
DVS-1200
DVS-2400
DXR-701
DXR-702

DSX-73 Smoke Detector
PERS-2400A
DUAL - 824
PERS-3600
DXSR-1504
DXSR-1508
DVS-1200
DVS-2400
DXR-702

DXS-81 Bill Trap
DUAL - 824
DXSR-1504
DXSR-1508
DVS-1200
DVS-2400

DXS-91 Glassbreak
DUAL - 824
DXSR-1504
DXSR-1508
DVS-1200
DVS-2400

DXT-21 2Button Keyfob
DUAL - 824
DXSR-1504
DXSR-1508
DVS-1200
DVS-2400
DXR-701
DXR-702

DXT-23 3Button Keyfob

DUAL -824
DXSR-1504
DXSR-1508
DVS-1200
DVS-2400
DXR-701
DXR-702

DXT-25 5Button Keyfob

DXSR-1504
DXSR-1508
DXR-701
DXR-702

DXT-31 Door Sensor

DXSR-1504
DXSR-1508
DXR-701
DXR-702

DXT-41 1Button Keyfob

DUAL -824
DXSR-1504
DXSR-1508
DVS-1200
DVS-2400
DXR-701
DXR-702

DXT-42 2Button Keyfob

DUAL -824
DXSR-1504
DXSR-1508
DVS-1200
DVS-2400
DXR-701
DXR-702

DXT-54 Motion Detector

DXSR-1504
DXSR-1508
DXR-701
DXR-702

DXT-61A Pendant Panic

DUAL -824
DXSR-1504
DXSR-1508
DVS-1200
DVS-2400
DXR-701
DXR-702

DXT-72 Smoke Detector

DXSR-1504
DXSR-1508
DXR-701
DXR-702

DXT-81 Bill Trap

DXSR-1504
DXSR-1508
DXR-701
DXR-702

DXT-601 1-Button Pendant Panic
DXSR-1504
DXSR-1508
DXR-701
DXR-702

DXT-604 2-Button Pendant Panic
DXSR-1504
DXSR-1508
DXR-701
DXR-702