



**SILENT  
KNIGHT**  
FIRE SYSTEMS<sub>®</sub>

## Model 5204 Fire Control/Communicator Panel Built-in Touchpad Operating Instructions

These instructions must be framed and displayed next to the Model 5204 panel in accordance with NFPA 72 fire code for Local Protected Fire Alarm Systems.

| Function   | Enter (On Built-in Touchpad):           | On 5230, also enter: |
|--|---|----------------------|
| System test  | <b>0</b> <b>ENTER</b>                   | + Code 0 or 1        |
| Reset alarms (or smoke det.)   | <b>1</b> <b>ENTER</b> + Code 0 or 1     | Same                 |
| Clear alarm memory   | <b>2</b> <b>ENTER</b>                   | + Code 0 or 1        |
| Reset dialer   | <b>3</b> <b>ENTER</b> + Code 0          | Same                 |
| Start download   | <b>4</b> <b>ENTER</b> + Code 0          | Same                 |
| Alarm memory display   | <b>5</b> <b>ENTER</b>                   | + Code 0 or 1        |
| Display troubles   | <b>6</b> <b>ENTER</b>                   | + Code 0 or 1        |
| Silence troubles or alarms   | <b>SILENCE</b>                          | + Code 0 or 1        |
| Disable/Enable   | Zone #1-4 + <b>DISABLE</b>              | Same                 |
| Begin fire drill   | <b>2</b> <b>0</b> <b>ENTER</b> + Code 0 | + Code 0 or 1        |
| End fire drill   | <b>SILENCE</b>                          | + Code 0 or 1        |
| <i>The system sounds an alarm and reports a fire test when you exit fire drill mode.</i> |   |                      |

| Function  | Enter (On Built-in Touchpad or 5230):   |
|---|---|
| Walk test   | <b>2</b> <b>2</b> <b>ENTER</b> + Code 0 *   |
| Zone Troubleshooting mode                               | <b>2</b> <b>5</b> <b>ENTER</b> + Code 0 *   |
| Step Programming mode                                   | <b>2</b> <b>7</b> <b>ENTER</b> + Code 0 *   |
| Clear (start over if you make a mistake)                | <b>CLEAR</b>  |
| Set time  | <b>9</b> <b>ENTER</b> + 6-digit date  |
| For example, to set the time of Wed., 4:30 p.m., enter: | Use <i>w d h h m m</i> format for time, where:<br><i>w</i> = Day of week (0=Sun., 1=Mon., 2=Tue., 3=Wed., 4=Thu., 5=Fri., 6=Sat.)<br><i>d</i> = Time of day (0=AM, 1=PM)<br><i>hh</i> = Hour (enter leading 0 for 1-digit hrs.)<br><i>mm</i> = Minutes (enter leading 0 for 1-digit min.) |
|   | <b>3</b> <b>1</b> <b>0</b> <b>4</b> <b>3</b> <b>0</b>   |

\* To exit these modes with the 5230, press **STEP** **STEP** **CLEAR** **CLEAR**.

With the built-in touchpad, press **SILENCE** **SILENCE** **CLEAR** **CLEAR**.

For service call: