


Locating Sensor Buttons

In Adding a Sensor to your System, (Step 5) calls for “pressing” the correct “button” on the sensor that you are adding. This instruction sheet describes and illustrates the specific “button” and it’s location on the various types of sensors.

If you have any difficulties in adding a sensor, please call our toll-free, Technical Support Hotline at 866-494-0255


Activation “Buttons”



Door and Window: Remove top of the sensor and push button labeled “Press to Program”.




Key Chain Remote: Push both buttons at the same time.



Motion Sensor: Remove the back of the sensor to activate the button. If the sensor does not activate when you remove the back, push the spring (“button”) to activate it.



Carbon Monoxide Detector: Plug detector into a wall outlet. Push the button labeled “Test/Reset” on the front of the detector.



Glass Break Sensor: Remove front cover to activate the button. If the sensor does not activate when you remove the front cover, push the spring (“button”) to activate it.



Smoke Detector: Remove the back plate from the detector to automatically activate the “button”.



Panic Button - Pendant: Press the button.



Panic Button - Wrist: Press the button.