




CareTaker® WIRELESS WALL MOUNT TOUCHPAD


ITI Part #60-273

OVERVIEW

The CareTaker Wireless Wall Mount Touchpad has the identical functions as the Portable Hand-held Touchpad. The same transmitter circuit board is attached to the inside of the cover. The CareTaker Wall Mount Touchpad includes all of the keys of a Touch Tone® phone and has two additional   keys. Pushing both of these keys and holding them for one second activates the HELP signal. The HELP signal can also be activated by pressing the  key six times in rapid succession. The CareTaker Wall Mount Touchpad is suggested to be installed in a location accessible to all users of the system. As many as are required for the installation can be installed



INSTALLATION INSTRUCTIONS

1. Remove the set screw on the underside of the cover.
2. Level and mount the base of the Touchpad using appropriate fasteners.
3. Program the Touchpad by plugging it into the CPU and entering  **18**. "PROGRAM OK" is announced over the phone when the programming has been accepted
4. Attach the cover to the base and install the set screw.

NOTE: It is not possible to perform the  **C O D E 9** or any of the  commands with the Wireless Wall Mount Touchpad or the Hand Held Touchpad.