

Caretaker Keypad


A Touchpad (model 60-258) is available with a built-in voice message speaker and siren. In addition, four lights indicate the status of the system and the energy saver as well as the armed status and the existence of trouble conditions. The unit must be wired to the Central Processing Unit by a qualified installation technician. The Model 60-258 Keypad is required to be used in an Underwriters Laboratories, Inc. Listed Household Fire and Burglary Warning system.

- **TROUBLE BUTTON** - Push to get messages and silence trouble beeps.

SPEAKER

SYSTEM STATUS - ON when intrusion protection is in level 3.
FLASHING when intrusion protection is in level 2.
OFF when intrusion protection is OFF

SYSTEM OK - On when OK, OFF when service is required.



- **TOUCHPAD.**
Use like a Touch
Tone phone.

TROUBLE -
Flashes when a
message is waiting.

ENERGY SAVER -
ON when you turn on
Energy Saver feature.

"HELP" Buttons.
Push both at once and
hold to send a 'HELP
call.