



**WIRELESS**  
Security  
Automation  
Access Control

**INTERACTIVE TECHNOLOGIES, INC.**  
2266 SECOND STREET NORTH  
NORTH SAINT PAUL, MN 55109  
T: 651/777-5484  
F: 651/779-4890

*Old (cig pack)  
w/ panic  
lights button  
lights button not  
supported by Concord*

**To: ITI Technical Support**

**From: Jeff Carlson**

**Date: 11-09-98**

**Subject: Concord Paging Codes**

The following information should help you understand Concord's paging codes. The below codes are the sensor number or user number sent by Concord to a pager. See page 20 of the homeowner's manual for further explanation.

Regular User Codes	00-59
Not Used	60
Partition 1 Master Code	61
Partition 2 Master Code	62
Not Used	63-69
Duress Partition # 1	70
Duress Partition 2	71
Not Used	72-77
System Master Code	78
Installer Code	79
Dealer Number	80
AVM Number	81
Not Used	82-96
Quick Arm	97
Key Switch Arming Number	98
Key Fob Number	128
Reserved for Differentiating Fobs	129-204
Reserved for Fobs as Touchpads	205-213