

Big Red Panic Button Remote, Model KR15A

INSTALLATION AND OPERATING INSTRUCTIONS

The KR15A sends wireless Radio Frequency (RF) signals to an X-10 Transceiver (RR501 or TM751) or any X-10 security system base console, which receives the RF signals from the KR15A and passes them onto your house wiring. These signals are then received by X-10 Remote Sirens and Lamp, Appliance, or Wall Switch Modules to control lights (or appliances) around your home.

Install two AAA alkaline batteries inside the battery compartment. The KR15A defaults to Housecode A and Unit Code 1, so if that's what code you want it to control, you are finished setting up the KR15A.

Plug in an X-10 RF Transceiver (model RR501 or TM751, sold separately) or any X-10 security system base console (sold separately) and set it to Housecode A.

Plug a lamp into an X-10 Lamp Module (sold separately) and set it to Housecode A and Unit Code 1. Plug the module into any AC outlet.

Plug a Remote Siren, Model SH10A into any convenient AC outlet. Set it to A1 also.

Press the large red button on the KR15A. The lamp connected to any X-10 Module set to A1 will turn on. Hold the red button for a few seconds and the SH10A siren will start "dinging." Hold the button for still longer and the siren will sound a loud 95 decibel alarm. The siren will stop a few seconds after you release the button.

If you own an X-10 security system you can install the KR15A into the Console just like you would any other remote control, door/window sensor, or motion detector. Just place the Console in the INSTALL mode and press the red button on the KR15A for several seconds (until the Console chimes). Then place the Console in the RUN mode. Now when you press (and hold) the red button, first the Lamp Module will turn on, then the SH10A will ding, then the SH10A will alarm, then the security system's console will trip. The Console will then call a friend/neighbor, or call ORCA Monitoring Services, depending on which model of security system you own.

To change the House/Unit Code for the KR15A: Press and hold the Unit button (under the battery compartment lid) until the red light blinks twice, then release and press the button the desired number of times for the Unit Code you want (once for Unit Code 1, twice for Unit Code 2, etc.). The light blinks each time you press, and confirms your entry by blinking about 2 seconds after your last press. Use the same procedure to change the Housecode (pressing the House button instead). One press for Housecode A, two presses for B, etc. To confirm the code you've set: press the House or Unit code button - the light blinks back the appropriate number of times for the code that is set.

F.C.C. CAUTION - THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

This equipment generates and uses radio frequency energy, and if not installed and used properly, that is, in strict accordance with the manufacturers instructions, may cause interference to radio and television reception. It has been type tested and found to comply with the limits for remote control security devices in accordance with the specifications in Sub-Part B of Part 15 of *FCC Rules*, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by unplugging the equipment, try to correct the interference by one or more of the following measures.

- Reorient the antenna of the radio/TV experiencing the interference.
- Relocate the product with respect to the radio/TV.
- Move the product away from the radio/TV.
- Plug the product into an outlet on a different electrical circuit from the radio/TV experiencing the interference.

If necessary, consult your local dealer for additional suggestions.

NOTE: NO CHANGES OR MODIFICATIONS MAY BE MADE TO THE UNITS. ANY CHANGES MADE TO THE UNITS WILL VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

X-10 (USA) INC. LIMITED 1-YEAR WARRANTY

X-10(USA) Inc. warrants X-10 products to be free from defective material and workmanship for a period of one (1) year from the original date of purchase at retail. X-10 (USA) Inc. agrees to repair or replace, at it's sole discretion, a defective X-10 product if returned to X-10 (USA) Inc. within the warranty period and with proof of purchase.

If service is required under this warranty:

1. Return the defective unit postage prepaid to X-10 (USA) Inc. (see address on back).
2. Enclose a check for \$4.00 to cover postage and handling.
3. Enclose a dated proof of purchase.
4. X-10 is not responsible for shipping damage.
Units to be returned should be packed carefully.
5. For additional warranty information, contact X-10 (USA) Inc.

Your Name

Address

.....

Date Purchased 19..... Store where purchased

FROM

X-10 (USA) Inc.
91 Ruckman Rd., Box 420, Closter, NJ 07624-0420

First Name	Last Name	
<input type="text"/>	<input type="text"/>	
Street Address - No P.O. Box numbers (for U.P.S.)		
<input type="text"/>		
City	State	Zip
<input type="text"/>	<input type="text"/>	<input type="text"/>

CONTENTS - MERCHANDISE

RETURN POSTAGE GUARANTEED

POSTMASTER: THIS PARCEL MAY BE OPENED FOR POSTAL INSPECTION

X-10 (USA) Inc.
91 Ruckman Rd., Box 420,
Closter, NJ 07624-0420

Mini Timer MT522/MT10A

A Controller, Timer and Alarm Clock all in one! Programs up to 4 modules to go on and off at specific times, twice a day. Controls 8 modules instantly. Dims lights too.

Maxi Controller SC503

Lets you control up to 16 X-10 Modules at the touch of a button from anywhere in the house. Dims lights too!

Mini Controller MC460

Lets you control up to 8 X-10 Modules at the touch of a button from anywhere in the house. Dims lights too!

2-Way Home Control Interface CM11A

Set up from an IBM compatible PC to control up to 256 X-10 Modules. ActiveHome software & cable included.

Telephone Responder TR551

Lets you control up to 10 lights and appliances from any outside touch-tone phone.

Wireless Remote Control System RC5000

Lets you control 16 X-10 modules from inside or outside your home. Can also dim and brighten Lamp Modules and Wall Switch Modules. Works with the HR12A PalmPad Remote and X-10 RF Wall Switches (RW684, RW694, RW724).

Remote Siren SH10A

Responds to dim/bright commands to give a pleasant "ding-dong" and sounds a 95 decibel alarm when tripped by an ON command from any X-10 controller/security system.

Lamp Module LM465

Can be Dimmed and Brightened from any X-10 Controller. Responds to "All lights on". Rated for 300 W. Incandescent only. *2-Way version LM14A.*

Appliance Module - AM486/AM466

Two pin polarized (AM486) or 3 pin grounded (AM466). For controlling an air conditioner, TV, stereo, etc. anywhere in the home. Rated 15A for heaters, coffee pots etc.; 1/3 H.P. for motors; 400W for TVs; 500W for lamps. *2-Way versions available AM14A (2 pin), AM15A (3 pin).*

Wall Switch Module WS467

For controlling important indoor and outdoor security lights. Replaces your existing wall switch and installs like a regular dimmer. Dimmed/brightened from any X-10 Controller. Rated 500W incandescent only.

3 - Way Wall Switch Module WS4777

For controlling a light which is controlled by two switches. Same features as WS467.

Split Receptacle Module SR227

Replaces existing wall outlet. The top outlet functions like an Appliance Module, the bottom one is a regular outlet. Rated 15A. Controls ANYTHING which normally plugs into a regular AC outlet.

Universal Module UM506

Isolated contact relay and beeper. Can be set for momentary or continuous operation. Not compatible with DS7000 and DC8700 security systems.