

Lynx-Series **Programming AVM**

Step 1: Enter Program mode, Installer Code (4112) + 8 + 0 + 0. If this key sequence does not work or you do not know the installer code you can power down the system (AC & DC) then power back up and within 50 seconds press & hold the [*] + [#] keys simultaneously for about 5 seconds this should get you into program mode. If not then the panel may have been locked out of keypad programming.

Step 2: Press [*] 41 and enter the Primary Phone Number, if fewer than 20 Digits press [*]

Step 3: Press [*] 43 and enter the 4 digit Primary Account number

Step 4: Press [*] 48 and enter [7], [7] for contact ID reporting

Step 5: Press [*] 49 and enter [0] (default) because you cannot have dual/split/paging when doing AVM

Step 6: Press [*] 68 and enter a report code for the cancel report. NOTE: If this is not programmed the sirens will continue to sound through the AVM session.

Step 7: Press [*] 91 and enter [1] if using AVM and the Remote phone or [4] for AVM ONLY

Step 8: Press [*] 95 and enter the number of rings the panel will pick up on: 1-9; #10-#14 (#15 = Answering Machine defeat, call panel let it ring 1 time then hang up and call back)

Step 9: Program all Reporting codes for zones to be reported to central station

Step 10: Press [*] 99 to exit program mode.

Activation:

When the Lynx sends an alarm to central station an E606 (listen-in to follow) will also be sent, which causes the central station receiver to hold the line for one minute. When the panel receives a kiss off from the central station the AVM feature is activated in the Listen Mode (default) , which causes the sirens and keypad sounds to cease. The Panel will now be waiting for a command from the central station operator, if no command is heard within two minutes the call will be terminated. The central station operator begins the session, which lasts 5 minutes, by entering one of the following commands:

KEY FUNCTION

- 1** Talk Mode: Pressing the [1] key on the touch tone phone, enables one-way voice communication from the central station to the violated premises, and allows the operator to talk through the LYNX speaker. In this mode the ARMED (red) and READY (green) LEDs blink alternately.
- 2** VOX (Voice) Mode: Press the [2] key on the touch-tone phone, enables two-way voice communications between the central station and the violated premises. In this mode the ARMED (red) and READY (green) LEDs blink alternately.
- 3** Listen Mode: Pressing the [3] key on the touch-tone phone, enables one-way audio from the violated premises to the central station. The listen mode is the start up default mode of the voice feature and allows the operator to listen through the LYNX microphone.
- 7** Extends the session 5 minutes without changing its operating mode
- 9** Ends the session and disconnects the phone line. If operator hangs up without pressing 9, Lynx may hold the line for up to 5 minutes.