

PROGRAMMING INFORMATION
For Series XR40 COMMAND PROCESSOR Panels

Name _____	Account Number _____	Phone _____	Date _____
Address _____	City _____	State _____	Zip _____

COMMUNICATION

Communication Type: **NONE** DD 4-2 M2E CID
 Account Number -- -- -- (1 to 65,535)
 Transmission Delay -- -- (0 to 60 secs.)
 DTMF **NO** **YES**
 Defer Test Time **NO** YES
 Events Manager **SND** DLY KEEP
 Test Frequency -- -- (0 to 60 days)
 Test Time -- : -- AM PM

Receiver 1

Alarm **NO** **YES**
 Supv/Trouble **NO** **YES**
 O/C & User **NO** **YES**
 Test Report **NO** **YES**
 Backup **NO** YES

First Phone Number: -----

Second Phone Number: -----

Receiver 2

Pager Direct™ **NONE** NUM ALPHA
 Alarm **NO** YES
 Supv/Trouble **NO** YES
 O/C & User **NO** YES
 Test Report **NO** YES
 Backup **NO** YES

First Phone Number: -----

Second Phone Number: -----

Pager ID Number -----

REMOTE OPTIONS

Remote Key -----
 Manufacturer Authorization **NO** YES
 Armed Rings -- -- (0 to 15)
 Disarmed Rings -- -- (0 to 15)
 Alarm Receiver **NO** YES
 Service Receiver **NO** **YES**
 Disarm **NO** YES

SYSTEM REPORTS

Opening/Closing Reports **NO** **YES**
 Abort Reports **NO** YES
 Zone Restoral Reports **NO** **YES** DISARM
 Bypass Reports **NO** **YES**
 Schedule Change Reports **NO** YES
 Code Change Reports **NO** YES
 Ambush **NO** YES

SYSTEM OPTIONS

Mode **AREA** A/P H/A
 Closing Code **NO** YES
 Closing Check **NO** YES
 Entry Delay 1 -- -- (0 to 250 secs.)
 Entry Delay 2 -- -- (0 to 250 secs.)
 Exit Delay -- -- (0 to 250 secs.)
 Cross Zone Time -- -- (4 to 250 secs.)
 Power Fail Delay -- -- (0 to 9 hrs.)
 Reset Swinger Bypass **NO** **YES**
 Phone Access **NO** YES
 Zone Activity Hours -- (0 to 9 hrs.)
 Arm Activity Days -- (00 to 99 days)
 Time Change **NO** **YES**
 Hours from GMT -- -- (0 to 23 hrs.)
 Time Display **NO** **YES**

OUTPUT OPTIONS

Bell Cutoff Time -- -- (0 to 15 mins.)
 Automatic Bell Test **NO** YES
Bell Action . . .
 Fire Zones Steady **Pulse** Temporal None
 Burglary Zones **Steady** Pulse Temporal None
 Supervisory Zones Steady Pulse Temporal **None**
 Panic Zones Steady Pulse Temporal **None**
 Emergency Zones Steady Pulse Temporal **None**
 Auxiliary 1 Zones Steady Pulse Temporal **None**
 Auxiliary 2 Zones Steady Pulse Temporal **None**
Output Action . . .
 Cutoff Output 1 2 3 4
 Cutoff Time -- -- (0 to 15 mins.)
 Communication Fail Output -- (0 to 4)
 Fire Alarm Output -- (0 to 4)
 Fire Trouble Output -- (0 to 4)
 Ambush Output -- (0 to 4)
 Entry Output -- (0 to 4)
 Exit Output -- (0 to 4)
 Ready Output -- (0 to 4)
 Armed Output -- (0 to 4)
 Burglary Output -- (0 to 4)
 Ground Start Output -- (0 to 4)
 Cellular Backup Output -- (0 to 4)
 Late To Close Output -- (0 to 4)

AREA INFORMATION

Area Number -- (1 to 4)
 Area Name -----
 Auto Arming **NO** YES
 Bad Zones **BYP** FORC REF
 Auto Disarm **NO** YES

Area Number -- (1 to 4)
 Area Name -----
 Auto Arming **NO** YES
 Bad Zones **BYP** FORC REF
 Auto Disarm **NO** YES

Area Number -- (1 to 4)
 Area Name -----
 Auto Arming **NO** YES
 Bad Zones **BYP** FORC REF
 Auto Disarm **NO** YES

Area Number -- (1 to 4)
 Area Name -----
 Auto Arming **NO** YES
 Bad Zones **BYP** FORC REF
 Auto Disarm **NO** YES

NOTE: Factory default values are shown in bold type.

XR40 Programming Information

ZONE INFORMATION	Type	Area	Disarmed Open			Disarmed Short			Armed Open			Armed Short			Swinger	Prewarn	Entry Delay	Cross Zone	Priority	Style
			Message	Output	Action	Message	Output	Action	Message	Output	Action	Message	Output	Action						
Assign Area & Disarmed condition for NT, DY, EX, A1, A2, AR only	-- NT DY EX FI PN EM SV A1 A2 FV AR	INT BDRM PERIM or 1 to 4	A L T -	1 to 4	S P M F	A L T -	1 to 4	S P M F	A L T -	1 to 4	S P M F	A L T -	1 to 4	S P M F	N or Y	1 to 8	1 or 2	N or Y	N or Y	TGL ARM DIS STEP MNT
Zone Type Defaults	Abbr.																			
NIGHT	NT		-	O	-	-	O	-	A	O	-	A	O	-	Y				N	N
DAY	DY		T	O	-	T	O	-	A	O	-	A	O	-	Y				N	N
EXIT	EX		-	O	-	-	O	-	A	O	-	A	O	-	Y	1-8	1		N	N
FIRE	FI								T	O	-	A	O	-	N				N	N
PANIC	PN								T	O	-	A	O	-	N				N	N
EMERGENCY	EM								T	O	-	A	O	-	N				N	N
SUPERVISORY	SV								T	O	-	A	O	-	N				N	N
AUXILIARY 1	A1		T	O	-	A	O	-	T	O	-	A	O	-	N				N	N
AUXILIARY 2	A2		T	O	-	A	O	-	T	O	-	A	O	-	N				N	N
FIRE VERIFY	FV								T	O	-	A	O	-	N				N	N
ARMING	AR																			TGL
No.	Name																			
1																				
2																				
3																				
4																				
5																				
6																				
7																				
8																				
9																				
10																				
11																				
12																				
13																				
14																				
21																				
22																				
23																				
24																				
31																				
32																				
33																				
34																				
41																				
42																				
43																				
44																				
51																				
52																				
53																				
54																				
61																				
62																				
63																				
64																				
71																				
72																				
73																				
74																				
81																				
82																				
83																				
84																				

■ = Not available for this zone type

- = The default is blank for this function

Digital Monitoring Products

2841 E. Industrial Drive Springfield, MO 65802-6310 800-641-4282