

XT30/XT50 PROGRAMMING SHEET

Name _____ Account Number _____ Date _____

Address _____ City _____ State _____ Zip _____

COMMUNICATION

Account Number - - - - - (1 to 65,535)
 Transmission Delay - - (0, 15 to 45 sec., default =30)
 Communication Type: **DD** CID NET CELL NONE
 Backup Dialer **NO** YES
 Backup Cell **NO** YES
 Test Time - - : - - AM PM
 Net Test Days - - (0 to 60 days, default=1)
 Dialer Test Days - - (0 to 60 days, default=1)
 Cell Test Days - - (0 to 60 days, default=1)
 Check-in Minutes - - - - (0, or 15 to 240 min.)
 Failed Minutes - - - - (0, or 15 to 240 min.)
 Send Comm Trouble **NO** **YES**
 First GPRS APN - - - - -

Second GPRS APN - - - - -

Alarm Reports **NO** **YES**
 Supv/Trouble **NO** **YES**
 O/C & User **NO** **YES**
 First Phone #: - - - - -

Second Phone #: - - - - -

First IP Address - - - . - - - . - - - . - - -
 First IP Port - - - - -
 Second IP Address - - - . - - - . - - - . - - -
 Second IP Port - - - - -

NETWORK OPTIONS

DHCP **NO** **YES**
 Local IP Address - - - . - - - . - - - . - - -
 Gateway Address - - - . - - - . - - - . - - -
 Subnet Mask - - - . - - - . - - - . - - -
 DNS Server - - - . - - - . - - - . - - -
 Programming Port - - - - -

MESSAGING SETUP

Enable Messaging **NO** YES
 System Name - - - - -
 Destination 1 - - - - -
 Destination 2 - - - - -
 Destination 3 - - - - -
 Email Comm Type NET CELL
 Email O/C **NO** YES

SMS O/C **NO** YES
 SMTP Server - - - - -
 SMTP Server Port - - - - -
 SMTP User Name - - - - -
 SMTP Password - - - - -
 From Email Address - - - - -

REMOTE OPTIONS

Remote Key - - - - -
 Manufacturer Authorization **NO** YES
 Armed Rings - - (0 to 15, default = 8)
 Disarmed Rings - - (0 to 15, default = 8)
 Alarm Receiver **NO** YES
 Service Receiver **NO** **YES**
 Disarm **NO** YES

SYSTEM REPORTS

Opening/Closing Reports **NO** YES
 Abort Reports **NO** YES
 Zone Restoral Reports **NO** **YES** DISARM
 Bypass Reports **NO** **YES**
 Code Change Reports **NO** YES
 Ambush **NO** YES

SYSTEM OPTIONS

System AREA **A/P** H/A
 Closing Code **NO** YES
 Closing Check **NO** YES
 Entry Delay 1 - - - - (30 to 250 sec., default = 30)
 Entry Delay 2 - - - - (30 to 250 sec., default = 60)
 Exit Delay - - - - (45 to 250 sec., default = 60)
 Cross Zone Time - - - - (0, 4 to 250 sec.)
 Power Fail Delay - (0, **1** to 9 hrs.)
 Reset Swinger Bypass **NO** YES
 Telephone Access **NO** YES
 Zone Activity Hours - (0 to 9 hrs.)
 Arm Activity Days - (0 to 99 days)
 Time Change **NO** **YES**
 Hours from GMT - - (0 to 23 hrs., default = 6)
 Time Display **NO** **YES**
 House Code - - (0 to 50)
 Detect Wireless Jamming **NO** YES
 Wireless Audibles ANY **DAY** MIN
 Enable Keypad Panic Keys **NO** **YES**
 Occupied Premise **NO** **YES**

Note: Factory default values are shown in **bold** type.



BELL OPTIONS

Bell Cutoff Time _ _ (0 to 15 min., default = 5)
 Automatic Bell Test **NO** YES
 Bell Output _ _ **(0 to 4, 31-34, 41-44)**

Bell Action . . .

Fire Zones	Steady	Pulse	Temporal	None
Burglary Zones	Steady	Pulse	Temporal	None
Supervisory Zones	Steady	Pulse	Temporal	None
Panic Zones	Steady	Pulse	Temporal	None
Emergency Zones	Steady	Pulse	Temporal	None
Auxiliary 1 Zones	Steady	Pulse	Temporal	None
Auxiliary 2 Zones	Steady	Pulse	Temporal	None

OUTPUT OPTIONS

Cutoff Output	1	2	3	4
Cutoff Time	_ _	(0 to 15 min.)		
Comm Fail Output	_ _	(0 to 4, 31-34, 41-44)		
Fire Alarm Output	_ _	(0 to 4, 31-34, 41-44)		
Fire Trouble Output	_ _	(0 to 4, 31-34, 41-44)		
Ambush Output	_ _	(0 to 4, 31-34, 41-44)		
Entry Output	_ _	(0 to 4, 31-34, 41-44)		
Exit Output	_ _	(0 to 4, 31-34, 41-44)		
Ready Output	_ _	(0 to 4, 31-34, 41-44)		
Armed Output	_ _	(0 to 4, 31-34, 41-44)		
Burglary Output	_ _	(0 to 4, 31-34, 41-44)		
Late To Close Output	_ _	(0 to 4, 31-34, 41-44)		
Arm-Alarm Output	_ _	(0 to 4, 31-34, 41-44)		

AREA INFORMATION

Area Number _ **(1 to 4)**
 Area Name _
 Auto Arming **NO** YES
 Bad Zones **BYP** FORC REF
 Auto Disarm **NO** YES

Area Number _ **(1 to 4)**
 Area Name _
 Auto Arming **NO** YES
 Bad Zones **BYP** FORC REF
 Auto Disarm **NO** YES

Area Number _ **(1 to 4)**
 Area Name _
 Auto Arming **NO** YES
 Bad Zones **BYP** FORC REF
 Auto Disarm **NO** YES

Area Number _ **(1 to 4)**
 Area Name _
 Auto Arming **NO** YES
 Bad Zones **BYP** FORC REF
 Auto Disarm **NO** YES

Note: Factory default values are shown in **bold** type.

OUTPUT INFORMATION (WIRELESS)

Output No.	Output Name	Serial Number	Supervision Time (0, 3, 60, 240) Default = 240
31			
32			
33			
34			
41			
42			
43			
44			

Note: Assign Output Numbers 31 to 34 for slow response time wireless outputs (activates within 15 seconds) or 41 to 44 for fast response time wireless outputs (activates within 1 second).



800-641-4282

www.dmp.com

Made in the USA

INTRUSION • FIRE • ACCESS • NETWORKS

2500 North Partnership Boulevard

Springfield, Missouri 65803-8877

Zone Name	Serial Number	Key Fob	Type	Area	Wireless	DMP Wireless				Disarmed Open		Disarmed Short		Armed Open		Armed Short		Swinger	Prewarn	Entry Delay	Cross Zone	Priority	TGL ARM DIS STEP MINT Style
						1101 Contact	1101 External Contact N/O?	1114 Contact	Supervision Time	1142 LED Operation	Message	Output *	Action	Message	Output *	Action	Message						
Zone Type Defaults		N or Y	NT or DY	INT or BDRM or PERIM	N or Y	INT or EXT	N or Y	1 or 2 or 3 or 4	0 or 30 or 60 or 240	N or Y	- or 0	S or T or F	- or 0	S or T or F	- or 0	S or T or F	- or 0	S or T or F	1 or 2	N or Y	N or Y		
NIGHT		N	NT		N	INT	N	1	240	Y	-	S	-	S	-	S	-	S	1	N	N		
DAY		N	DY		N	INT	N	1	240	Y	T	S	0	S	0	S	0	S	1-5	N	N		
EXIT		N	EX		N	INT	N	1	240	Y	-	S	0	S	0	S	0	S	1-5	N	N		
FIRE		N	FI		N	INT	N	1	240	Y										N	N		
PANIC		N	PN		N	INT	N	1	240	Y										N	N		
EMERGENCY		N	EM		N	INT	N	1	240	Y										N	N		
SUPERVISORY		N	SV		N	INT	N	1	240	Y										N	N		
AUXILIARY 1		N	A1		N	INT	N	1	240	Y	T	S	0	S	0	S	0	S		N	N		
AUXILIARY 2		N	A2		N	INT	N	1	240	Y	T	S	0	S	0	S	0	S		N	N		
FIRE VERIFY		N	FV		N	INT	N	1	240	Y	T	S	0	S	0	S	0	S		N	N		
ARMING		N	AR		N	INT	N	1	240	Y										N	N		

* Outputs = 1 to 4, 31 to 34, or 41 to 44. = This function not available for this zone type.