

**PROGRAMMING INFORMATION**  
**For Series XR20 COMMAND PROCESSOR Panels**

Name \_\_\_\_\_ Account Number \_\_\_\_\_ Phone \_\_\_\_\_ Date \_\_\_\_\_  
 Address \_\_\_\_\_ City \_\_\_\_\_ State \_\_\_\_\_ Zip \_\_\_\_\_

**COMMUNICATION**

Communication Type NONE DD 4-2 M2E CID  
 Account Number \_ \_ \_ \_ (1 to 65,535)  
 Transmission Delay \_ \_ (0 to 60 in 10 sec. increments)  
 DTMF NO YES  
 Events Manager SND DLY KEEP  
 Test Frequency \_ \_ (0 to 60 days)  
 Test Time \_ \_ : \_ \_ AM PM

**Receiver 1**

Alarm NO YES  
 Supv/Trouble NO YES  
 O/C & User NO YES  
 Test Report NO YES  
 Backup NO YES  
 First Phone Number \_ \_ \_ \_ \_ \_ \_ \_ \_ \_  
 Second Phone Number \_ \_ \_ \_ \_ \_ \_ \_ \_ \_

**Receiver 2**

Pager NO NUM ALPHA  
 Alarm NO YES  
 Supv/Trouble NO YES  
 O/C & User NO YES  
 Test Report NO YES  
 Backup NO YES  
 First Phone Number \_ \_ \_ \_ \_ \_ \_ \_ \_ \_  
 Second Phone Number \_ \_ \_ \_ \_ \_ \_ \_ \_ \_  
 Pager ID Number \_ \_ \_ \_ \_ \_ \_ \_ \_ \_

**REMOTE OPTIONS**

Remote Key \_ \_ \_ \_ \_ \_ \_ \_ \_ \_  
 Manufacturer Authorization NO YES  
 Armed Rings \_ \_ (0 to 15)  
 Disarmed Rings \_ \_ (0 to 15)  
 Alarm Receiver NO YES  
 Service Receiver NO YES  
 Disarm NO YES

**SYSTEM REPORTS**

Opening/Closing Reports NO YES  
 Abort Reports NO YES  
 Zone Restoral Reports NO YES DISARM  
 Bypass Reports NO YES  
 Code Change Reports NO YES  
 Ambush NO YES

**SYSTEM OPTIONS**

Mode AREA A/P H/A  
 Closing Code NO YES  
 Closing Check NO YES  
 Entry Delay 1 \_ \_ \_ \_ (0 to 250 secs.)  
 Entry Delay 2 \_ \_ \_ \_ (0 to 250 secs.)  
 Exit Delay \_ \_ \_ \_ (0 to 250 secs.)  
 Cross Zone Time \_ \_ \_ \_ (0 to 250 secs.)  
 Power Fail Delay \_ \_ \_ \_ (0 to 9 hrs.)  
 Reset Swinger Bypass NO YES  
 Phone Access NO YES

**OUTPUT OPTIONS**

Bell Cutoff Time \_ \_ (0 to 15 mins.)  
 Automatic Bell Test NO YES  
 Bell Action . . . . .  
 Fire Zones Steady Pulse Temp None  
 Burglary Zones Steady Pulse Temp None  
 Supervisory Zones Steady Pulse Temp None  
 Panic Zones Steady Pulse Temp None  
 Emergency Zones Steady Pulse Temp None  
 Auxiliary 1 Zones Steady Pulse Temp None  
 Auxiliary 2 Zones Steady Pulse Temp None  
 Output Action . . . . .  
 Cutoff Outputs 1 2 3 4  
 Cutoff Time \_ \_ (0 to 15 mins.)  
 Communication Fail Output \_ (0 to 4)  
 Fire Alarm Output \_ (0 to 4)  
 Fire Trouble Output \_ (0 to 4)  
 Ambush Output \_ (0 to 4)  
 Entry Output \_ (0 to 4)  
 Exit Output \_ (0 to 4)  
 Ready Output \_ (0 to 4)  
 Armed Output \_ (0 to 4)  
 Burglary Output \_ (0 to 4)  
 Ground Start Output \_ (0 to 4)

**AREA INFORMATION**

Area Number \_ (1 to 4)  
 Area Name \_ \_ \_ \_ \_ \_ \_ \_ \_ \_  
 Auto Arming NO YES  
 Bad zones BYP FORC REF  
 Auto Disarm NO YES  
 Area Number \_ (1 to 4)  
 Area Name \_ \_ \_ \_ \_ \_ \_ \_ \_ \_  
 Auto Arming NO YES  
 Bad zones BYP FORC REF  
 Auto Disarm NO YES  
 Area Number \_ (1 to 4)  
 Area Name \_ \_ \_ \_ \_ \_ \_ \_ \_ \_  
 Auto Arming NO YES  
 Bad zones BYP FORC REF  
 Auto Disarm NO YES

# XR20 Programming Information

ZONE INFORMATION	Type	Area	Disarmed Open			Disarmed Short			Armed Open			Armed Short			Swinger	Entry Delay	Cross Zone	Priority	Style
			Message	Output	Action	Message	Output	Action	Message	Output	Action	Message	Output	Action					
Assign Area & Disarmed condition for NT, DY, EX, A1, A2, AR only	-- NT DY EX FI PN	INT BDRM PERIM	A	1	S	A	1	S	A	1	S	A	1	S	N	1	N	N	TGL
Assign Prewarn & Entry Delay for EX only	EM SV A1 A2 FV AR	or	L	to	P	L	to	P	L	to	P	L	to	P	or	or	or	or	ARM
Assign Style for AR only		1 to 4	T	4	M	T	4	M	T	4	M	T	4	M	Y	2	Y	Y	DIS
Zone Type Defaults	Abbr.		-		F	-		F	-		F	-		F					STEP
NIGHT	NT		-	O	-	-	O	-	A	O	-	A	O	-	Y		N	N	
DAY	DY		T	O	-	T	O	-	A	O	-	A	O	-	Y		N	N	
EXIT	EX		-	O	-	-	O	-	A	O	-	A	O	-	Y	1	N	N	
FIRE	FI								T	O	-	A	O	-	N		N	N	
PANIC	PN								T	O	-	A	O	-	N		N	N	
EMERGENCY	EM								T	O	-	A	O	-	N		N	N	
SUPERVISORY	SV								T	O	-	A	O	-	N		N	N	
AUXILIARY 1	A1		T	O	-	A	O	-	T	O	-	A	O	-	N		N	N	
AUXILIARY 2	A2		T	O	-	A	O	-	T	O	-	A	O	-	N		N	N	
FIRE VERIFY	FV								T	O	-	A	O	-	N			N	
ARMING	AR																		TGL
No. Name																			
1																			
2																			
3																			
4																			
5																			
6																			
7																			
8																			
9																			
10																			
11																			
12																			
13																			
14																			
21																			
22																			
23																			
24																			
31																			
32																			
33																			
34																			
41																			
42																			
43																			
44																			

■ = Not available for this zone type

— = The default is blank for this function