

Customer Information

Company	
Contact	
Department	
Extension	
Address	
City	
Province/State	
Postal/Zip Code	
Voice Telephone Number	
Email Address	
Panel Telephone Number:	3333
Additional Comments	

Function Key Options [000]

Key	Setting
1	03 - Stay Arm
2	04 - Away Arm
3	06 - Chime On/Off
4	14 - Command Output 2/Sensor Reset
5	16 - Quick Exit

Zone Labels (Zones 1-32) [*]-[01]...[32]

Zone	Label	Zone	Label
Zone 01	Zone 1	Zone 17	Zone 17
Zone 02	Zone 2	Zone 18	Zone 18
Zone 03	Zone 3	Zone 19	Zone 19
Zone 04	Zone 4	Zone 20	Zone 20
Zone 05	Zone 5	Zone 21	Zone 21
Zone 06	Zone 6	Zone 22	Zone 22
Zone 07	Zone 7	Zone 23	Zone 23
Zone 08	Zone 8	Zone 24	Zone 24
Zone 09	Zone 9	Zone 25	Zone 25
Zone 10	Zone 10	Zone 26	Zone 26
Zone 11	Zone 11	Zone 27	Zone 27
Zone 12	Zone 12	Zone 28	Zone 28
Zone 13	Zone 13	Zone 29	Zone 29
Zone 14	Zone 14	Zone 30	Zone 30
Zone 15	Zone 15	Zone 31	Zone 31
Zone 16	Zone 16	Zone 32	Zone 32

Fire Alarm Label [*]-[33]

Fire Alarm Label | Fire Zone

Partition Labels [*]-[34]...[35]

Partition 1 | System

Partition 2 | Partition 2

Partition 1 Utility Output Label [*]-[40]

Partition 1 Utility Output Label | Utility Output

Partition 2 Utility Output Label [*]-[41]

Partition 2 Utility Output Label | Utility Output

Partition 1 Sensor Reset Label [*]-[44]

Partition 1 Sensor Reset Label | Sensor Reset

Partition 2 Sensor Reset Label [*]-[45]

Partition 2 Sensor Reset Label | Sensor Reset

test, PC1555 3.2, G:\DLS\Folders\Accounts\Test.Dsc-LCD5500(Z)

Fail to Arm Event Message [*]-[51]

Fail to Arm Message	System Has	LCD Line 1
	Failed to Arm	LCD Line 2

Alarm When Armed Event Message [*]-[52]

Alarm when Armed Message	Alarm Occurred	LCD Line 1
	While Armed <>	LCD Line 2

First User Display Mask [*]-[60]

Setting	Option	Option Enabled	Option Disabled
Enabled	1	Hold [P] Key Prompt Enabled	Hold [P] Key Prompt Disabled
Enabled	2	Zone Bypassing Prompt Enabled	Zone Bypassing Prompt Disabled
Enabled	3	Troubles Prompt Enabled	Troubles Prompt Disabled
Enabled	4	Alarm Memory Prompt Enabled	Alarm Memory Prompt Disabled
Enabled	5	Door Chime Control Prompt Enabled	Door Chime Control Prompt Disabled
Enabled	6	Access Codes Prompt Enabled	Access Codes Prompt Disabled
Enabled	7	User Functions Prompt Enabled	User Functions Prompt Disabled
Enabled	8	Output Control Prompt Enabled	Output Control Prompt Disabled

Second User Display Mask [*]-[61]

Setting	Option	Option Enabled	Option Disabled
Disabled	1	Installer Programming Prompt Enabled	Installer Programming Prompt Disabled
Enabled	2	At-Home Arm Prompt Enabled	At-Home Arm Prompt Disabled
Enabled	3	Quick Arm Prompt Enabled	Quick Arm Prompt Disabled
Enabled	4	Interior Arm Prompt Enabled	Interior Arm Prompt Disabled
Disabled	5	Quick Exit Prompt Enabled	Quick Exit Prompt Disabled
Enabled	6	View Event Buffer Prompt Enabled	View Event Buffer Prompt Disabled
Disabled	7	For Future Use	
Disabled	8	Music Input Prompt Enabled	

Third User Display Mask [*]-[62]

Setting	Option	Option Enabled	Option Disabled
Enabled	1	System Test Prompt Enabled	System Test Prompt Disabled
Enabled	2	Time and Date Prompt Enabled	Time and Date Prompt Disabled
Enabled	3	Auto-Arm Control Prompt Enabled	Auto-Arm Control Prompt Disabled
Enabled	4	Auto-Arm Time Prompt Enabled	Auto-Arm Time Prompt Disabled
Enabled	5	Download Enable Prompt Enabled	Download Enable Prompt Disabled
Enabled	6	Bright Control Prompt Enabled	Bright Control Prompt Disabled
Enabled	7	Contrast Control Prompt Enabled	Contrast Control Prompt Disabled
Enabled	8	Buzzer Control Prompt Enabled	Buzzer Control Prompt Disabled

Downloaded LCD Message Duration [*]-[63]

003 Valid entries are 000-255, 000=Unlimited Message Display

Key Options [*]-[64]

Setting	Option	Option Enabled	Option Disabled
Enabled	1	[F] Key Enabled	[F] Key Disabled
Enabled	2	[A] Key Enabled	[A] Key Disabled
Enabled	3	[P] Key Enabled	[P] Key Disabled
Disabled	4	For Future Use	
Disabled	5	For Future Use	
Disabled	6	For Future Use	
Disabled	7	For Future Use	
Disabled	8	For Future Use	

Keypad Options [*]-[66]

Setting	Option	Option Enabled	Option Disabled
Enabled	1	Display Access Code when Programming	Display X's when Programming
Enabled	2	Local Clock Display Enabled	Local Clock Display Disabled
Disabled	3	For Future Use	
Disabled	4	For Future Use	
Disabled	5	For Future Use	
Disabled	6	For Future Use	
Disabled	7	For Future Use	
Disabled	8	For Future Use	