

PROGRAMMING RECORD SHEET

FOR MAGNUM ALERT — 800/800UL/800U/800S, CC18/8DD & CC18UL/8U

CONTROL CENTER FEATURES

FOLD

COMMUNICATOR FEATURES

ZONE ONE	ZONE TWO	ZONE THREE	ZONE FOUR	ZONE FIVE (PANIC)	ZONE SIX (AUX.)	LOW BATT.	
078	078	078	078	079	079	079	MANUAL SHUNTING
1	2	4	8	1	2		
080	080	080	080	081	081	081	DAY ZONE SUPERVISION
1	2	4	8	1	2		
082	082	082	082	083	083	083	PRIORITY ARMING
1	2	4	8	1	2	4	
084	084	084	084	085	085	085	AUTO-SHUNT ARMING
1	2	4	8	1	2		
086	086	086	086	087	087	087	24 HOUR PROTECTION
1	2	4	8	①	②	④	
088	088	088	088	089	089	089	AUTO-RESET
1	2	4	8	1	2		
090	090	090	090	091	091	091	EXIT/ENTRY DELAY
1	2	4	8	1	2		
094	094	094	094	095	095	095	50 MILLISECOND RESPONSE
1	2	4	8	1	2		
096	096	096	096	097	097	097	750 MILLISECOND RESPONSE
①	2	④	⑧	1	②	④	
106	106	106	106	107	107	107	TIMED ALARM OUTPUT
1	2	4	8	1	2		
108	108	108	108	109	109	109	PULSING ALARM OUTPUT
1	2	4	8	1	2		
110	110	110	110	111	111	111	RELAY CLOSURE ON ALARM
1	2	4	8	1	2		
112	112	112	112	113	113	113	MINI SOUNDER ON ALARM
1	2	4	8	1	2	4	
147	147	147	147	148	148	148	INPUT POLARITY
①	2	④	8	1	2		

STANDARD FEATURES

	ZONE ONE	ZONE TWO	ZONE THREE	ZONE FOUR	ZONE FIVE (PANIC)	ZONE SIX (AUX.)	LOW BATT.
ABORT DELAY BEFORE DIALING	092	092	092	092	093	093	093
	1	2	4	8	1	2	④
REPORT ON ALARM	098	098	098	098	099	099	099
	1	2	4	8	1	2	4
CONTROL CENTER RESTORAL REPORT	100	100	100	100	101	101	101
	1	2	4	8	1	2	4
ZONE RESTORAL REPORT	114	114	114	114	115	115	115
	1	2	4	8	1	2	4

CLOSING REPORT CODE	014	015
OPENING REPORT CODE	032	033

ADVANCED COMMUNICATOR FEATURES

099	CLOSING REPORT
8	
101	OPENING REPORT
8	
110	TOUCH TONE® DIALING
2	
116	4/2 FORMAT
4	
116	SUM CHECK
8	
117	BACK-UP REPORTING
1	
117	SPLIT REPORTING
2	
118	CONDITIONAL CLOSING REPORT
2	
118	OPENING REPORT AFTER ALARM
8	

CONDITIONAL CLOSING CODE	016	017
OPENING REPORT CODE (AFTER ALARM)	032	033

NOTE: 4/2 OR EXTENDED FORMAT

CUSTOMER:

ADDRESS:


DATE:

TIME SELECTOR CHART

TIME	1st BOX	2nd BOX
5	5	NONE
15	F	NONE
30	E	1
45	d	2
60	C	3

118 MAINTAINED KEY SWITCH
1

111 RELAY CLOSURE FOR KEY "ON"
8



PROGRAMMING RECORD SHEET COMMUNICATOR TRANSMISSION INFORMATION

FOR MAGNUM ALERT — 800/800UL/800U/800S, CCI8/8DD & CCI8UL/8U

	ZONE ONE	ZONE TWO	ZONE THREE	ZONE FOUR	ZONE FIVE (PANIC)	ZONE SIX (AUX.)	LOW BATT.
<input type="checkbox"/> STANDARD	000	002	004	006	008	010	012
<input type="checkbox"/> 4/2 OR EXTENDED FORMAT REPORTING	001	003	005	007	009	011	013

	ZONE ONE	ZONE TWO	ZONE THREE	ZONE FOUR	ZONE FIVE (PANIC)	ZONE SIX (AUX.)	LOW BATT.
<input type="checkbox"/> STANDARD	U18	U20	U22	U24	U26	U28	U30
<input type="checkbox"/> 4/2 OR EXTENDED FORMAT REPORTING	019	021	023	025	027	029	031

	3rd DIGIT	4th DIGIT	5th DIGIT	6th DIGIT
<input type="checkbox"/> SUBSCRIBER IDENTIFICATION #1	034	035	036	037
<input type="checkbox"/> SUBSCRIBER IDENTIFICATION #2 (for Back-up or Split Reporting only)	038	039	040	041

4th DIGIT
4/2 FORMAT ONLY
(see instructions)

	FOR 1st TELEPHONE #	FOR 2nd TELEPHONE #
<input type="checkbox"/> USE ONLY WHERE REQUIRED (see glossary)	042	060

	FOR 1st TELEPHONE #	FOR 2nd TELEPHONE #
<input type="checkbox"/> USE ONLY WHERE REQUIRED (see glossary)	043	061

	FOR 1st TELEPHONE #	FOR 2nd TELEPHONE #
<input type="checkbox"/> SEE GLOSSARY ENTER "E" FOR DIAL TONE DETECTION	044	062

	045	046	047	048	049	050	051	052	053	054	055	056	057
<input type="checkbox"/> 1st TELEPHONE NUMBER													
<input type="checkbox"/> 2nd TELEPHONE NUMBER (for Back-up or Split Reporting only)	063	064	065	066	067	068	069	070	071	072	073	074	075

CENTRAL STATION	RECEIVER
CHOOSE THE APPROPRIATE RECEIVER MASTER FROM:	
<input type="checkbox"/> CCI-7/8-1: Ademco Pulsing Hold	<input type="checkbox"/> CCI-7/8-4: Radionics "fast" format
<input type="checkbox"/> CCI-7/8-2: Ademco, Adcor, Vertex, Silent Knight "slow" format	<input type="checkbox"/> CCI-7/8-5: Silent Knight "fast" format
<input type="checkbox"/> CCI-7/8-3: SESCOA, DCI, Franklin, Vertex "fast" format	<input type="checkbox"/> CCI-7/8-6: Radionics, DCI, Franklin "slow" format