



Radionics™

**D2012
Program Record Sheet**

Account Information

Account Rx _____ - _____ Panel Type _____ Panel Phone # _____

Name _____

Address _____ City _____ State ____ Zip Code _____

Contact Phone # _____

Contact Person _____

Comments _____

Panel Location _____

Notes _____

1. SYSTEM CONFIGURATION

1 Account Number _____
2 Swinger Count 1 2 3 4
3 Keyswitch **Momentary**, Easikey
4 Custom Idle Text _____
5 Custom Idle Text 2 _____
6 Customer Service Text _____

2. PHONE

1 DTMF Dialing **Yes, No**
2 Phone 1 _____
3 Phone 2 _____
4 Phone Routing **Yes, No** _____
5 Fire Route **Local** _____
6 Non-Fire Route **Local** _____
7 Pt Trbl Route **Local** _____
8 Restoral Route **Local** _____
9 Closing Route **Local** _____
10 Opening Route **Local** _____
11 Cancel Route **Local** _____
12 Sys Trbl Route **Local** _____
13 Sys Res Route **Local** _____
14 Duress Route **Local** _____
15 Test Route **Local** _____

3. REPORTS

1 O/C Rpts-All On **Yes, No**
2 O/C Rpts-Part On **Yes, No**
3 Restricted O/C **Yes, No**
4 Delay Alarm Rpt **0** _____
5 Cancel Rpt **Yes, No**
6 Restoral Rpts **Yes, No, Delay**
7 AC Fail Buzz/Rpt _____
8 Point User Flag **Yes, No**

4. RECEIVER

	Modem,	Pulse
1 Rcvr Format		_____
2 Fire Group	0	_____
3 Non-Fire Group	0	_____
4 Pt Trbl Group	0	_____
5 Restoral Group	0	_____
6 Closing Group	0	_____
7 Opening Group	0	_____
8 Cancel Group	0	_____
9 Sys Trbl Group	0	_____
10 Sys Res Group	0	_____
11 Duress Group	0	_____
12 Test Group	0	_____

5. REMOTE PROGRAMMING

1 RAM Passcode **999999** _____
2 RAM Phone _____
3 Answer Armed **0** _____
4 Answer Disarmed **0** _____
5 Answer Machine **Yes, No**

6. OPEN/CLOSE

1 Entry Dly Time **30** _____
2 Exit Dly Time **60** _____
3 Extended Dly **120** _____
4 Exit Tone **Yes, No**
5 No Delay **Part On** _____
6 Excursion **Disabled**

7. A, B, C KEYS

1 A-Key Report **00** _____
2 A-Key Alarm Output **No Output**, Steady, Pulse
3 A-Key Ack Tone **Yes, No**
4 A-Key Text **A-KEY**, _____
5 B-Key Report **00** _____
6 B-Key Alarm Output **No Output**, Steady, Pulse
7 B-Key Ack Tone **Yes, No**
8 B-Key Text **B-KEY**, _____
9 C-Key Report **00** _____
10 C-Key Alarm Output **No Output**, Steady, Pulse
11 C-Key Ack Tone **Yes, No**
12 C-Key Text **C-KEY**, _____

8. BELL

1 Bell Timer **6** _____

2 Bell Test Yes, **No**

3 Single Ring Yes, **No**

4 Alarm on 2 Fail Yes, **No**

10. ADDRESS CONFIGURATION

1 Address 1 **Text Keypad,** _____

2 Address 2 **Not Used,** _____

3 Address 3 **Not Used,** _____

4 Address 4 **Not Used,** _____

5 Address 5 **Not Used,** _____

6 Address 6 **Not Used,** _____

7 Address 7 **Not Used,** _____

8 Address 8 **Not Used,** _____

9. TEST TIMER

1 Test Interval **No Report,** _____

2 Hours to Next **0** _____

3 Minutes to Next **0** _____

4 Defer Test Rpt Yes, **No**

11. POINT CODES & TEXT

Point Number 1 Code _____

Point Number 2 Code _____

Point Number 3 Code _____

Point Number 4 Code _____

Point Number 5 Code _____

Point Number 6 Code _____

12. TEXT

13. RELAYS*

- 1 Relay 1 Logic _____
- 2 Relay 2 Logic _____
- 3 Relay 1, Func 1 _____
- 4 Relay 1, Func 2 _____
- 5 Relay 2, Func 1 _____
- 6 Relay 2, Func 2 _____

RELAY PARAMETERS

Each relay parameter below is a separate group when keypad programming.

- 18 Relay 1, Function 1, Parameter - - - - -
- 19 Relay 1, Function 2, Parameter - - - - -
- 20 Relay 2, Function 1, Parameter - - - - -
- 21 Relay 2, Function 2, Parameter - - - - -

* Relay Function Selections:

- 0 - No Output
- 1 - Alarm 7- A, B, C Key Pulse 13 - Reset 19 - Entry and Exit Delay
- 2 - Alarm Memory 8 - A, B, C Key Momentary 14 - AC Failure 20 - Extended Delay
- 3 - Point Trouble 9 - Off with Passcode 15 - Battery Trouble 21 - Pulsed Output
- 4 - Follow Point 10 - Follow Alarm Output 16 - Communication Fail 22 - 2-second Output
- 5 - Watch Tone 11 - All On 17 - Communicating 23 - Not used
- 6 - A, B, C Key Steady 12 - Part On 18 - Ground Start 24 - Voice Request

14. USER TEST

- 1 Usr Tst, Bell Yes, **No**
- 2 Usr Tst, Battery Yes, **No**
- 3 Usr Tst, Comm Yes, **No**

15. PASSCODE

	#	Passcode #	Passcode Type
1 Instlr Code 654321 _____	1	123(456) _____	Owner _____
2 Passcode Length 3 _____	2	_____	_____
3 Code 8 = Duress Yes, No	3	_____	_____
4 Passcode Rquired Yes, No	4	_____	_____
5 Change Passcode _____	5	_____	_____
	6	_____	_____
	7	_____	_____
	8	_____	_____

16. PROGRAM LOCK

- 1 Return to Default (Keypad Programming Only)
- 2 Program Lock Yes, **No**
- 3 Disable System Yes, **No**



© 1997 Radionics, Inc., Salinas, CA, USA. All rights reserved
 ™ The Radionics logo is a registered trademark of Radionics, Inc., Salinas, CA, USA.

Radionics, Inc., 1800 Abbott Street
 P.O. Box 80012 Salinas, California 93912
 Customer Service: (800) 538-5807