

XR5FC/XR5SL PROGRAMMING SHEET

Name _____ Account Number _____ Date _____
 Address _____ City _____ State _____ Zip _____

COMMUNICATION

Communication Type NONE **DD** 4 - 2 CID
 2nd Phone Line NO **YES**
 Account Number _____ (1 to 65,535)
 DTMF NO **YES**

Receiver 1

Alarm NO **YES**
 Supv/Trouble NO **YES**
 Test Report NO **YES**
 Backup NO **YES**
 First Phone Number _____

Second Phone Number _____

Receiver 2

Pager NO YES
 Alarm NO YES
 Supv/Trouble NO YES
 Test Report NO YES
 Backup NO YES
 First Phone Number _____

Second Phone Number _____

Pager ID Number _____

REMOTE OPTIONS

Remote Key _____
 Manufacturer Authorization **NO** YES
 Armed Rings _____ (0 to 15, default = 8)
 Alarm Receiver **NO** YES
 Service Receiver NO **YES**

SYSTEM OPTIONS

Cross Zone Fault Time _____ (0 to 250 secs.)
 Zone Retard Delay _____ (0 to 250 secs.)
 Power Fail Delay _____ (6 to 12 hrs.)
 Reset Swinger Bypass NO **YES**

OUTPUT OPTIONS

Bell Cutoff Time _____ (0 to 15 mins.)
 Bell Action
 Fire Zones Stdy **Pulse** Temp CA **None**
 Supervisory Zones Stdy **Pulse** Temp CA **None**
 Auxiliary 1 Zones Stdy **Pulse** Temp CA **None**
 Output Action
 Cutoff Outputs 1 2 3 4
 Cutoff Time _____ (0 to 15 mins.)
 Communication Fail Output _____ (0 to 4)
 Fire Alarm Output _____ (0 to 4)
 Fire Trouble Output _____ (0 to 4)

NOTE: Default values are in bold type.

XR5FC/XR5SL Zone Programming

Zone Types	Type	Open			Short			Swinger	Retard	Cross Zone
		Message	Output	Action	Message	Output	Action			
Use this section of the programming sheet to record the program options you selected for the XR5 panel zones.		A	0	S	A	0	S			
		T	to	P	T	to	P	N	N	N
		L	4	M	L	4	M	or	or	or
		-		F	-		F	Y	Y	Y
Fire	FI	T	0	-	A	0	-	N	N	N
Supervisory	SV	T	0	-	A	0	-	N	N	N
Auxiliary 1	A1	T	0	-	A	0	-	N	N	N
Fire Verify	FV	T	0	-	A	0	-	N	N	
No.	Name									
1.										
2.										
3.										
4.										
5.										