

**PROGRAMMING INFORMATION**  
**For XRSuper6 COMMAND PROCESSOR™ Panel**

Name _____	Account Number _____	Phone _____	Date _____
Address _____	City _____	State _____	Zip _____

**COMMUNICATION**

Communication Type	<b>NONE</b>	DD	4 - 2	M2E	CID		
Account Number	- - - - - (1 to 65,535)						
Transmission Delay	- - (0 to 60 in 10 sec. increments)						
DTMF	<b>NO</b>	YES					
Defer Test	<b>NO</b>	YES					
Events Manager	<b>SND</b>	DLY	KEEP				
Test Frequency	- - (0 to 60 days)						
Test Time	- - : - AM PM						
<b>Receiver 1</b>							
Alarm	<b>NO</b>	YES					
Supv/Trouble	<b>NO</b>	YES					
O/C & User	<b>NO</b>	YES					
Test Report	<b>NO</b>	YES					
Backup	<b>NO</b>	YES					
First Phone Number	- - - - - - - - - -						
Second Phone Number	- - - - - - - - - -						
<b>Receiver 2</b>							
Pager	<b>NONE</b>	NUM					
Alarm	<b>NO</b>	YES					
Supv/Trouble	<b>NO</b>	YES					
O/C & User	<b>NO</b>	YES					
Test Report	<b>NO</b>	YES					
Backup	<b>NO</b>	YES					
First Phone Number	- - - - - - - - - -						
Second Phone Number	- - - - - - - - - -						
Pager ID Number	- - - - - - - - - -						

**OUTPUTOPTIONS**

Bell Cutoff Time	<b>- -</b> (0 to 15 mins.)				
Automatic Bell Test	<b>NO</b>	YES			
<b>Bell Action . . .</b>					
Fire Zones	Steady	<b>Pulse</b>	Temp	None	
Burglary Zones	<b>Steady</b>	Pulse	Temp	None	
Supervisory Zones	Steady	Pulse	Temp	None	
Panic Zones	Steady	Pulse	Temp	None	
Emergency Zones	Steady	Pulse	Temp	None	
Auxiliary 1 Zones	Steady	Pulse	Temp	None	
Auxiliary 2 Zones	Steady	Pulse	Temp	None	
<b>Output Action . . .</b>					
Cutoff Outputs	1 2 3 4				
Cutoff Time	<b>- -</b> (0 to 15 mins.)				
Communication Fail Output	<b>- -</b> (0 to 4)				
Fire Alarm Output	- (0 to 4)				
Fire Trouble Output	- (0 to 4)				
Ambush Output	- (0 to 4)				
Entry Output	- (0 to 4)				
Exit Output	- (0 to 4)				
Ready Output	- (0 to 4)				
Armed Output	- (0 to 4)				
Burglary Output	- (0 to 4)				
Ground Start Output	- (0 to 4)				
Cellular Backup Output	- (0 to 4)				

**Note:** Factory default values are shown in bold type.

**REMOTE OPTIONS**

Remote Key	<b>- - - - -</b>			
Manufacturer Authorization	<b>NO</b>	YES		
Armed Rings	- - (0 to 15)			
Disarmed Rings	- - (0 to 15)			
Alarm Receiver	<b>NO</b>	YES		
Service Receiver	<b>NO</b>	YES		
Disarm	<b>NO</b>	YES		

**SYSTEM REPORTS**

Opening/Closing Reports	<b>NO</b>	YES	LTD	ALM
Abort Reports	<b>NO</b>	YES		
Zone Restoral Reports	<b>NO</b>	YES	DISARM	
Bypass Reports	<b>NO</b>	YES		
Code Change Reports	<b>NO</b>	YES		
Ambush	<b>NO</b>	YES		

**SYSTEM OPTIONS**

Mode	<b>A/P</b>	H/A			
Closing Code	<b>NO</b>	YES			
Entry Delay 1	- - - (0 to 250 secs.)				
Entry Delay 2	- - - (0 to 250 secs.)				
Exit Delay	- - - (0 to 250 secs.)				
Cross Zone Time	- - - (0 to 250 secs.)				
Power Fail Delay	- (0 to 9 hrs.)				
Reset Swinger Bypass	<b>NO</b>	YES			
Telephone Access	<b>NO</b>	YES			
Zone Activity Hours	- (0 to 9 hrs.)				
Arm Activity Days	- (00 to 99 days)				
Time Change	<b>NO</b>	YES			
Hours from GMT	- - (0 to 23 hrs.)				
Time Display	<b>NO</b>	YES			

## XRSuper6 Programming Information

ZONE INFORMATION		Type	Area	Disarmed Open			Disarmed Short			Armed Open			Armed Short			Swinger	Entry Delay	Cross Zone	Priority	Style
		-- NT DY EX FI PN EM SV A1 A2 FV AR	INT BDRM PERIM	Message	Output	Action	N or Y 1 or 2	TGL ARM DIS STEP MNT												
Assign Area & Disarmed condition for NT, DY, EX, A1, A2, AR only				A L T -	1 to 4 -	S P M F	A L T -	1 to 4 F	S P M F	A L T -	1 to 4 -	S P M F	A L T -	1 to 4 -	N or Y 1 or 2	TGL ARM DIS STEP MNT				
Assign Entry Delay for EX only																				
Assign Style for AR only																				
Zone Type Defaults		Abbr.																		
NIGHT	NT			-	O	-	-	O	-	A	O	-	A	O	-	Y	N	N		
DAY	DY			T	O	-	T	O	-	A	O	-	A	O	-	Y	N	N		
EXIT	EX			-	O	-	-	O	-	A	O	-	A	O	-	Y 1	N	N		
FIRE	FI									T	O	-	A	O	-	N	N	N		
PANIC	PN									T	O	-	A	O	-	N	N	N		
EMERGENCY	EM									T	O	-	A	O	-	N	N	N		
SUPERVISORY	SV									T	O	-	A	O	-	N	N	N		
AUXILIARY 1	A1			T	O	-	A	O	-	T	O	-	A	O	-	N	N	N		
AUXILIARY 2	A2			T	O	-	A	O	-	T	O	-	A	O	-	N	N	N		
FIRE VERIFY	FV									T	O	-	A	O	-	N		N		
ARMING	AR																		TGL	
No.	Name																			
1		--	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
2		--	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
3		--	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
4		--	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
5		--	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
6		--	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
7		--	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
8		--	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
9		--	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
10		--	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
21		--	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
22		--	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
23		--	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
24		--	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
31		--	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
32		--	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
33		--	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
34		--	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
41		--	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
42		--	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
43		--	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
44		--	-----	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	

= Not available for this zone type

- = The default is blank for this function

## Digital Monitoring Products

2500 N. Partnership Boulevard Springfield, MO 65803 800-641-4282