

Customer Information

Company	
Contact	
Department	
Extension	
Address	
City	
Province/State	
Postal/Zip Code	
Voice Telephone Number	
Email Address	
Panel Telephone Number:	3333
Additional Comments	

Module Version

Module Version | Unknown Module Version

Language Selection

Select Language	English	ASCII Code
Special Character 0	é	0233
Special Character 1	è	0232
Special Character 2	à	0224
Special Character 3	ô	0244
Special Character 4	ê	0234
Special Character 5	ç	0231
Special Character 6	É	0201
Special Character 7	î	0238

Function Key Options [000]

Key	Setting
1	03 - Stay Arm
2	04 - Away Arm
3	06 - Chime On/Off
4	14 - Command Output 2/Sensor Reset
5	16 - Quick Exit

Zone Labels (Zones 1-32) [*]-[01]...[32]

Zone	Label	Zone	Label
Zone 01	Zone 1	Zone 17	Zone 17
Zone 02	Zone 2	Zone 18	Zone 18
Zone 03	Zone 3	Zone 19	Zone 19
Zone 04	Zone 4	Zone 20	Zone 20
Zone 05	Zone 5	Zone 21	Zone 21
Zone 06	Zone 6	Zone 22	Zone 22
Zone 07	Zone 7	Zone 23	Zone 23
Zone 08	Zone 8	Zone 24	Zone 24
Zone 09	Zone 9	Zone 25	Zone 25
Zone 10	Zone 10	Zone 26	Zone 26
Zone 11	Zone 11	Zone 27	Zone 27
Zone 12	Zone 12	Zone 28	Zone 28
Zone 13	Zone 13	Zone 29	Zone 29
Zone 14	Zone 14	Zone 30	Zone 30
Zone 15	Zone 15	Zone 31	Zone 31
Zone 16	Zone 16	Zone 32	Zone 32

Fire Alarm Label [*]-[33]

Fire Alarm Label | Fire Zone

Partition Labels [*]-[34]...[35]

Partition 1 | System

Partition Labels continued on Page 2...

Partition Labels continued from Page 1...

Partition 2 | Partition 2 |

Partition 1 Command Output #1 Label [*]-[40]

Partition 1 Command Output #1 Label | Command O/P 1 |

Partition 2 Command Output #1 Label [*]-[41]

Partition 2 Command Output #1 Label | Command O/P 1 |

Partition 1 Command Output #2 Label [*]-[44]

Partition 1 Command Output #2 Label | Command O/P 2 |

Partition 2 Command Output #2 Label [*]-[45]

Partition 2 Command Output #2 Label | Command O/P 2 |

Partition 1 Command Output #3 Label [*]-[46]

Partition 1 Command Output #3 Label | Command O/P 3 |

Partition 2 Command Output #3 Label [*]-[47]

Partition 2 Command Output #3 Label | Command O/P 3 |

Partition 1 Command Output #4 Label [*]-[48]

Partition 1 Command Output #4 Label | Command O/P 4 |

Partition 2 Command Output #4 Label [*]-[49]

Partition 2 Command Output #4 Label | Command O/P 4 |

Fail to Arm Event Message [*]-[51]

Fail to Arm Message | System Has | LCD Line 1
 | Failed to Arm | LCD Line 2

Alarm When Armed Event Message [*]-[52]

Alarm when Armed Message | Alarm Occurred | LCD Line 1
 | While Armed <> | LCD Line 2

First User Display Mask [*]-[60]

Setting	Option	Option Enabled	Option Disabled
<input type="text" value="Enabled"/>	1	Hold [P] Key Prompt Enabled	Hold [P] Key Prompt Disabled
<input type="text" value="Enabled"/>	2	Zone Bypassing Prompt Enabled	Zone Bypassing Prompt Disabled
<input type="text" value="Enabled"/>	3	Troubles Prompt Enabled	Troubles Prompt Disabled
<input type="text" value="Enabled"/>	4	Alarm Memory Prompt Enabled	Alarm Memory Prompt Disabled
<input type="text" value="Enabled"/>	5	Door Chime Control Prompt Enabled	Door Chime Control Prompt Disabled
<input type="text" value="Enabled"/>	6	Access Codes Prompt Enabled	Access Codes Prompt Disabled
<input type="text" value="Enabled"/>	7	User Functions Prompt Enabled	User Functions Prompt Disabled
<input type="text" value="Enabled"/>	8	Output Control Prompt Enabled	Output Control Prompt Disabled

Second User Display Mask [*]-[61]

Setting	Option	Option Enabled	Option Disabled
<input type="text" value="Disabled"/>	1	Installer Programming Prompt Enabled	Installer Programming Prompt Disabled
<input type="text" value="Enabled"/>	2	At-Home Arm Prompt Enabled	At-Home Arm Prompt Disabled
<input type="text" value="Enabled"/>	3	Quick Arm Prompt Enabled	Quick Arm Prompt Disabled
<input type="text" value="Enabled"/>	4	Interior Arm Prompt Enabled	Interior Arm Prompt Disabled
<input type="text" value="Disabled"/>	5	Quick Exit Prompt Enabled	Quick Exit Prompt Disabled
<input type="text" value="Enabled"/>	6	View Event Buffer Prompt Enabled	View Event Buffer Prompt Disabled
<input type="text" value="Disabled"/>	7	For Future Use	
<input type="text" value="Disabled"/>	8	Music Input Prompt Enabled	Music Input Prompt Disabled

Third User Display Mask [*]-[62]

Setting	Option	Option Enabled	Option Disabled
<input type="text" value="Enabled"/>	1	System Test Prompt Enabled	System Test Prompt Disabled
<input type="text" value="Enabled"/>	2	Time and Date Prompt Enabled	Time and Date Prompt Disabled
<input type="text" value="Enabled"/>	3	Auto-Arm Control Prompt Enabled	Auto-Arm Control Prompt Disabled
<input type="text" value="Enabled"/>	4	Auto-Arm Time Prompt Enabled	Auto-Arm Time Prompt Disabled
<input type="text" value="Enabled"/>	5	Download Enable Prompt Enabled	Download Enable Prompt Disabled

Third User Display Mask continued on Page 3...

Third User Display Mask continued from Page 2...

Enabled	6	Bright Control Prompt Enabled	Bright Control Prompt Disabled
Enabled	7	Contrast Control Prompt Enabled	Contrast Control Prompt Disabled
Enabled	8	Buzzer Control Prompt Enabled	Buzzer Control Prompt Disabled

Downloaded LCD Message Duration [*]-[63]

[003] Valid entries are 000-255, 000=Unlimited Message Display

Key Options [*]-[64]

Setting	Option	Option Enabled	Option Disabled
Enabled	1	[F] Key Enabled	[F] Key Disabled
Enabled	2	[A] Key Enabled	[A] Key Disabled
Enabled	3	[P] Key Enabled	[P] Key Disabled
Disabled	4	For Future Use	
Disabled	5	For Future Use	
Disabled	6	For Future Use	
Disabled	7	For Future Use	
Disabled	8	For Future Use	

Fourth User Display Mask [*]-[65]

Setting	Option	Option Enabled	Option Disabled
Enabled	1	User Callup Prompt Enabled	User Initiated Callup Prompt Disabled
Disabled	2	For Future Use	
Disabled	3	For Future Use	
Enabled	4	Command Output #1 Prompt Enabled	Command Output #1 Prompt Disabled
Enabled	5	Command Output #2 Prompt Enabled	Command Output #2 Prompt Disabled
Disabled	6	Command Output #3 Prompt Enabled	Command Output #3 Prompt Disabled
Disabled	7	Command Output #4 Prompt Enabled	Command Output #4 Prompt Disabled
Disabled	8	For Future Use	

Keypad Options [*]-[66]

Setting	Option	Option Enabled	Option Disabled
Enabled	1	Display Access Code when Programming	Display X's when Programming
Enabled	2	Local Clock Display Enabled	Local Clock Display Disabled
Disabled	3	Local Clock Display in 24hr	Local Clock Display in 12hr
Enabled	4	AutoScroll Alarm Enabled	AutoScroll Alarm Disabled
Disabled	5	Local Temperature Display Enabled	Local Temperature Display Disabled
Disabled	6	Bypass Options Prompt Enabled	Bypass Options Prompt Disabled
Disabled	7	For Future Use	
Disabled	8	For Future Use	

Fifth User Display Mask [*]-[67]

Setting	Option	Option Enabled	Option Disabled
Disabled	1	Thermostat CTRL Prompt Enabled	Thermostat CTRL Prompt Disabled
Disabled	2	Temperature Setting Prompt Enabled	Temperature Setting Prompt Disabled
Disabled	3	Occupancy Mode Prompt Enabled	Occupancy Mode Prompt Disabled
Disabled	4	Thermostat Mode Prompt Enabled	Thermostat Mode Prompt Disabled
Disabled	5	Fan Control Prompt Enabled	Fan Control Prompt Disabled
Disabled	6	For Keypad View Prompt Enabled	For Keypad View Prompt Disabled
Disabled	7	For Future Use	
Disabled	8	For Future Use	

Sixth User Display Mask [*]-[68]

Setting	Option	Option Enabled	Option Disabled
Disabled	1	Occupancy Mode Auxiliary Prompt Enabled	Occupancy Mode Auxiliary Prompt Disabled
Disabled	2	Occupancy Mode Day Prompt Enabled	Occupancy Mode Day Prompt Disabled
Disabled	3	Occupancy Mode Away Prompt Enabled	Occupancy Mode Away Prompt Disabled
Disabled	4	Occupancy Mode Night Prompt Enabled	Occupancy Mode Night Prompt Disabled
Disabled	5	For Future Use	
Disabled	6	For Future Use	
Disabled	7	For Future Use	
Disabled	8	For Future Use	