

FA100C PROGRAMMING FORM

FIELD	FUNCTION	PROGRAMMED VALUES
SYSTEM ARMING (*20-*23)		
*20	MASTER SECURITY CODE	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> Enter 4 digits, 0-9
*21	QUICK ARM ENABLE	† <input type="checkbox"/> 0 = no, 1 = yes
*22	KEYSWITCH ENABLE	† <input type="checkbox"/> 0 = no, 1 = yes
*23	FORCED BYPASS ENABLE	† <input type="checkbox"/> 0 = no, 1 = yes
ZONE RESPONSE PROGRAMMING (*29-*39)		
*30	ALARM BELL TIMEOUT	†† <input type="checkbox"/> 0 = none; 1 = 4 min; 2 = 8 min; 3 = 12 min
*31	ZONE 1 RESPONSE TYPE	<input type="checkbox"/>
*32	ZONE 2 RESPONSE TYPE	<input type="checkbox"/>
*33	ZONE 3 RESPONSE TYPE	<input type="checkbox"/>
*34	ZONE 4 RESPONSE TYPE	<input type="checkbox"/>
*35	ZONE 5 RESPONSE TYPE	<input type="checkbox"/>
*36	ZONE 6 RESPONSE TYPE	<input type="checkbox"/>
*37	ZONE 7 RESPONSE TYPE	<input type="checkbox"/> CONSOLE PANIC. Only zone types 0, 2, 6, 7, 8, 9 applicable.
*38	ENTRY DELAY	†† <input type="checkbox"/> 0 = 0 sec; 1 = 20 sec; 2 = 30 sec; 3 = 45 sec EXIT Delay = ENTRY Delay + 15 sec
*39	ZONE 3 RESPONSE TO OPEN	† <input type="checkbox"/> 0 = 400 ms nominal; 1 = 10 ms nominal
ZONE TYPES FOR PROGRAMMING FIELDS *31-37 0 (or undefined) = Zone Disabled 1 = ENTRY/EXIT, Burglary 2 = FIRE with timeout (Fields *35 and *37 only) 3 = PERIMETER, Burglary 4 = INTERIOR/FOLLOWER, Burglary 5 = TROUBLE BY DAY/ALARM BY NIGHT, Burglary 6 = 24 Hr (Silent) 7 = 24 Hr (Audible) 8 = 24 Hr (Auxiliary) 9 = FIRE without timeout (Fields *35 and *37 only)		
DIALER PROGRAMMING (*40-*47)		
*40	PABX ACCESS CODE	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> Enter 4 digits, 0-9. If fewer than 4 digits entered, exit by pressing * (and press 41, if entering next field). To clear entries from field, press *40*.
*41	PRIMARY PHONE No.	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> Enter up to 12 digits, 0-9. Do not fill unused spaces. If fewer than 12 digits entered, exit by pressing * (and press 42, if entering next field). To clear entries from field, press *41*.
*42	SECONDARY PHONE No.	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> Enter up to 12 digits, 0-9. Do not fill unused spaces. If fewer than 12 digits entered, exit by pressing * (and press 43, if entering next field). To clear entries from field, press *42*.
*43	SUBSCRIBER ACCOUNT No.	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> Enter 0-9; #+11 for B; #+12 for C; #+13 for D; #+14 for E; #+15 for F. If only 3 digits used, exit by pressing * (and press 44, if entering next field). To clear entries from field, press *43*.
	Examples:	For Acct No. 1234, enter: <input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/> 4 For Acct No. B234, enter: <input type="checkbox"/> #+11 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/> 4 For Acct No. 123, enter: <input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/> *
*44	REPORT FORMAT	<input type="checkbox"/> Enter * as the 4th digit of *43 if 3+1 dialer reporting is to be used. 0 = 3+1, 4+1 ADEMCO L/S STANDARD 6 or undefined = 4+2 ADEMCO EXPRESS 1 = 3+1, 4+1 RADIONICS STANDARD 8 = 3+1, 4+1 ADEMCO L/S EXPANDED 2 = 4+2 ADEMCO L/S STANDARD 9 = 3+1, 4+1 RADIONICS EXPANDED 3 = 4+2 RADIONICS STANDARD
*45	PHONE SYSTEM SELECT	†† <input type="checkbox"/> If Cent. Sta. IS NOT on a WATS line: 0 = Pulse Dial; 1 = Tone Dial If Cent. Sta. IS on a WATS line: 2 = Pulse Dial; 3 = Tone Dial
*46	FUTURE USE	† <input type="checkbox"/> Enter 0.
*47	15 SEC DIALER DELAY (BURG)	† <input type="checkbox"/> 0 = no, 1 = yes

† If a number other than 0 or 1 is entered, even numbers = same as 0; odd numbers = same as 1.
 †† If a number greater than 3 is entered, the control will subtract multiples of 4 to get to the allowable program range.

TO PROGRAM ALARM, SYSTEM STATUS, AND RESTORE REPORT CODES (*51-*74):

With a 3+1 or 4+1 Standard Format: Enter a code in the first box: 1-9, 0, B, C, D, E, or F. Enter [#+10] for 0, [#+11] for B, [#+12] for C, [#+13] for D, [#+14] for E, [#+15] for F.

A [0] (not [#+10]) in the first box will disable a report.

A [0] (not [#+10]) in the second box will result in automatic advance to the next field when programming.

With an Expanded or 4+2 Format: Enter codes in both boxes (1st and 2nd digits) for 1-9, 0, or B-F, as described above.

A [0] (not [#+10]) in the second box will eliminate the expanded message for that report.

A [0] (not [#+10]) in both boxes will disable the report.

Examples: For Code 3 (Single Digit), enter:

For Code 32 (Two Digits), enter:

For Code B2 (Hexadecimal) enter:

ALARM REPORT CODES (*51-*59)

- *51 ZONE 1 ALARM REPORT CODE
- *52 ZONE 2 ALARM REPORT CODE
- *53 ZONE 3 ALARM REPORT CODE
- *54 ZONE 4 ALARM REPORT CODE
- *55 ZONE 5 ALARM REPORT CODE
- *56 ZONE 6 ALARM REPORT CODE
- *57 ZONE 7 ALARM REPORT CODE
(Console Panic)
- *58 ZONE 8 ALARM REPORT CODE
(Duress)
- *59 ZONE 9 ALARM REPORT CODE
(Tamper)

SYS STATUS RPT CODES (*60-*66)

- *60 TROUBLE REPORT CODE
- *61 BYPASS REPORT CODE
- *62 AC LOSS REPORT CODE
- *63 LOW BAT REPORT CODE
- *64 TEST REPORT CODE
- *65 OPEN REPORT CODE †††
- *66 CLOSE REPORT CODE †††

††† 2nd digit is automatically sent as the user number if expanded or 4+2 reporting is selected.

RESTORE RPT CODES (*70-*74)

- *70 ALARM RESTORE RPT CODE
2nd digit is automatically sent as the 2nd digit of the zone alarm report code programmed in *51-*59, if expanded or 4+2 reporting is selected.
- *71 TROUBLE RESTORE RPT CODE
- *72 BYPASS RESTORE RPT CODE
- *73 AC RESTORE RPT CODE
- *74 LOW BAT RESTORE RPT CODE

DOWNLOAD INFO (*94-*97)

- *94 DOWNLOAD PHONE No.

Enter up to 12 digits, 0-9. Do not fill unused spaces. If fewer than 12 digits entered, exit field by pressing * (and press 95, if entering next field). To clear entries from field, press *94*.
- *96 INITIALIZES DOWNLOAD ID, SUBSCRIBER ACCOUNT No. FOR INITIAL DOWNLOAD
No entry required.
- *97 ZEROS ALL PROGRAM FIELDS
No entry required.

TO EXIT PROGRAM MODE (*98 or *99)

Press *98 or *99 if exiting programming, or next field number if continuing.

- *98 EXITS PROGRAMMING MODE and prevents re-entry by: Master Code + Code + 0.
- *99 EXITS PROGRAMMING MODE and allows re-entry by: Master Code + Code + 0.