

NOTE: The following open/close reporting codes are permanently assigned and cannot be changed.

USER CODE	4x2 CLOSING (ARMING) CODE	4x2 OPENING (DISARMING) CODE	ADEMCO CLOSING (ARMING) CODE	ADEMCO OPENING (DISARMING) CODE
MASTER	74	82	CLOSE U000	OPEN U000
RESTRICTED #1	75	83	CLOSE U001	OPEN U001
RESTRICTED #2	76	84	CLOSE U002	OPEN U002
RESTRICTED #3	77	85	CLOSE U003	OPEN U003
RESTRICTED #4	78	86	CLOSE U004	OPEN U004
RESTRICTED #5	79	87	CLOSE U005	OPEN U005
PAGE ALERT	80		CLOSE U006	
REMOTE ARM	81		R407 U007	
REMOTE DISARM		89		E407 U007

STEP #	PROGRAMMING FUNCTION & DETAILS	RANGE	DEFAULT	NEW #
210	SENSOR 1 ALARM REPORT CODE	0 - 99	11	
211	SENSOR 2 ALARM REPORT CODE	0 - 99	12	
212	SENSOR 3 ALARM REPORT CODE	0 - 99	13	
213	SENSOR 4 ALARM REPORT CODE	0 - 99	14	
214	SENSOR 5 ALARM REPORT CODE	0 - 99	15	
215	SENSOR 6 ALARM REPORT CODE	0 - 99	16	
216	SENSOR 7 ALARM REPORT CODE	0 - 99	17	
217	SENSOR 8 ALARM REPORT CODE	0 - 99	18	
218	SENSOR 9 ALARM REPORT CODE	0 - 99	19	
219	SENSOR 10 ALARM REPORT CODE	0 - 99	20	
220	SENSOR 11 ALARM REPORT CODE	0 - 99	21	
221	SENSOR 12 ALARM REPORT CODE	0 - 99	22	
222	SENSOR 13 ALARM REPORT CODE	0 - 99	23	
223	SENSOR 14 ALARM REPORT CODE	0 - 99	24	
224	SENSOR 15 ALARM REPORT CODE	0 - 99	25	
225	SENSOR 16 ALARM REPORT CODE	0 - 99	26	
226	SENSOR 17 ALARM REPORT CODE	0 - 99	27	
227	SENSOR 18 ALARM REPORT CODE	0 - 99	28	
228	SENSOR 19 ALARM REPORT CODE	0 - 99	29	
229	SENSOR 20 ALARM REPORT CODE	0 - 99	30	
230	SENSOR 21 ALARM REPORT CODE	0 - 99	31	
231	SENSOR 22 ALARM REPORT CODE	0 - 99	32	
232	SENSOR 23 ALARM REPORT CODE	0 - 99	33	
233	SENSOR 24 ALARM REPORT CODE	0 - 99	34	
234	SENSOR 1 TROUBLE REPORT CODE	0 - 99	41	
235	SENSOR 2 TROUBLE REPORT CODE	0 - 99	42	
236	SENSOR 3 TROUBLE REPORT CODE	0 - 99	43	
237	SENSOR 4 TROUBLE REPORT CODE	0 - 99	44	
238	SENSOR 5 TROUBLE REPORT CODE	0 - 99	45	
239	SENSOR 6 TROUBLE REPORT CODE	0 - 99	46	
240	SENSOR 7 TROUBLE REPORT CODE	0 - 99	47	
241	SENSOR 8 TROUBLE REPORT CODE	0 - 99	48	
242	SENSOR 9 TROUBLE REPORT CODE	0 - 99	49	
243	SENSOR 10 TROUBLE REPORT CODE	0 - 99	50	
244	SENSOR 11 TROUBLE REPORT CODE	0 - 99	51	
245	SENSOR 12 TROUBLE REPORT CODE	0 - 99	52	
246	SENSOR 13 TROUBLE REPORT CODE	0 - 99	53	
247	SENSOR 14 TROUBLE REPORT CODE	0 - 99	54	
248	SENSOR 15 TROUBLE REPORT CODE	0 - 99	55	
249	SENSOR 16 TROUBLE REPORT CODE	0 - 99	56	
250	SENSOR 17 TROUBLE REPORT CODE	0 - 99	57	
251	SENSOR 18 TROUBLE REPORT CODE	0 - 99	58	
252	SENSOR 19 TROUBLE REPORT CODE	0 - 99	59	
253	SENSOR 20 TROUBLE REPORT CODE	0 - 99	60	
254	SENSOR 21 TROUBLE REPORT CODE	0 - 99	61	
255	SENSOR 22 TROUBLE REPORT CODE	0 - 99	62	
256	SENSOR 23 TROUBLE REPORT CODE	0 - 99	63	
257	SENSOR 24 TROUBLE REPORT CODE	0 - 99	64	

USE THIS PROCEDURE TO CHANGE A SENSORS FUNCTION FROM ONE TYPE TO ANOTHER (PERIMETER TO INTERIOR, PANIC TO EMERGENCY, ETC.)

TO RESET THE SYSTEM TO THE FACTORY DEFAULTS
 START IN SETUP MODE
 ↓
 [M] STEP #999 FOR MASTER RESET
 ↓
 [TEST] PRESS TEST
 ↓
 [M] ENTER 999 TO OK THE MASTER RESET
 ↓
 [TEST] PRESS TEST, 1 BING SOUNDS, WAIT ABOUT 10 SECONDS
 ↓
 DONE

WARNING!
 THIS MASTER RESET PROCEDURE WILL ERASE ALL PROGRAMMED SENSORS AND RETURN ALL PROGRAMMING VALUES TO THE FACTORY DEFAULTS

TO CHANGE A SENSOR'S FUNCTION
 START IN SETUP MODE
 ↓
 [] SENSOR NUMBER FOR CHANGE
 ↓
 [M] SENSOR FUNCTION NUMBER
 ↓
 [M] 1 BING
 ↓
 DONE

	SENSOR FUNCTION	FCN #
SENSOR FUNCTION	AUTOMATION	1
	EMERGENCY	2
	PANIC	3
	FIRE	4
	PERIMETER	5
	EXIT/ENTRY	6
	INTERIOR	7
	CHIME	8
	2-BUTTON ARM/DISARM (LEFT); 2-BUTTON AUTOMATION (RIGHT)	9
	2-BUTTON ARM (LEFT); 2-BUTTON DISARM (RIGHT)	10
ENVIRONMENTAL	11	

	SENSOR SUPERVISORY FUNCTION	FCN #
SS FCN	NON-SUPERVISED	16
	SUPERVISED	17
	MANUAL RESTORING	18
	AUTO RESTORING	19

NOTE: The following Ademco reporting codes are permanently assigned and cannot be changed.

	EVENT	EVENT QUALIFIER	EVENT CODE	ZONE/USER #'S
ADEMCO CONTACT ID REPORTING CODES	SYSTEM FIRE	E	110	25
	SENSOR SMOKE	E	111	1 - 24
	DURESS	E	121	0
	BURGLARY	E	130	1 - 24
	SYSTEM EMERGENCY	E	120	26
	AUDIBLE PANIC	E	120	1 - 24
	SILENT PANIC	E	122	1 - 24
	SYSTEM LOW BATTERY	E = LOW	302	0
	SYSTEM LOW BATTERY RESTORAL	R = RESTORE	302	0
	SENSOR LOW BATTERY	E	384	1 - 24
	SUPERVISORY TROUBLE	E	381	1 - 24
	OPEN BY USER	E = OPEN	401	0 - 6
	REMOTE DISARM	E = OPEN	407	7
	CLOSE BY USER	R = CLOSE	401	0 - 6
	REMOTE OR QUICK ARM	R = CLOSE	407	7
	CANCEL BY USER	E	406	0
FORCE ARM	E	574	0	
2-WAY AUDIO	E	606	0	