

MF6000-SERIES PROGRAMMING RECORD SHEET

NOTE: IF THE DD6000 IS NOT INSTALLED, DO NOT PROGRAM ANY REPORTING FEATURES.

FEATURE	ALARM				TROUBLE				SYSTEM TROUBLE							
	ZONE								AC FAIL	WATER SUPPLY	SIGNAL TROUBLE	GND FAULT	TELCO TROUBLE	DEVICE DISABLE	LOW BATT	TEST TIMER
	1	2	3	4	1	2	3	4								
REPORT ON ALARM/TROUBLE	166	166	166	166	167	167	167	167	168	168	168	168	169	169	169	169
RESTORAL REPORT	170	170	170	170	171	171	171	171	172	172	172	172	173	173	173	173
WATERFLOW ZONE	178	178	178	178												
PRE-SIGNAL ALARM	180	180	180	180												
ALARM VERIFICATION	182	182	182	182												
INHIBIT SIGNAL-CIRCUIT ALARM	184	184	184	184												
INHIBIT TROUBLE RELAY					187	187	187	187	188	188	188	188	189	189	189	
INHIBIT AUXILIARY ALARM RELAY	190	190	190	190												



TOUCH-TONE ^(*) DIALING	194
TOUCH-TONE ^(*) /ROTARY BACKUP	194
(RESERVED)	194
(RESERVED)	194
POLARITY REVERSAL ALARM OPERATION	195
(RESERVED)	195
STATUS REPORTING	195
INHIBIT KEYPAD DIGIT BEEP	195
(RESERVED)	196
ENABLE R6000 OUTPUTS	196
INHIBIT KEYPAD ZONE/DEVICE BUTTONS	196
(RESERVED)	196
INHIBIT ZONE-TROUBLE RESOUND	197
INHIBIT SYSTEM-TROUBLE RESOUND	197
INHIBIT ZONE-ENABLE RESOUND	197
INHIBIT 24-HOUR TROUBLE REMINDER	197

TIME	1st BOX	2nd BOX
5	5	NONE
15	F	NONE
30	E	1
45	d	2
60	C	3

DON'T SHUT OFF SIGNAL CIRCUIT	215
SHUT OFF AUXILIARY ALARM RELAY	215
DON'T SHUT OFF TROUBLE RELAY	215

OFFSET (hr)	198	199
WATERFLOW RETARD TIME (sec)	200	201
VERIFICATION POWER-OFF TIME*	202	203
ADDL. SMOKE-DET. POWER-UP TIME**	204	205

DON'T SHUT OFF SIGNAL CIRCUIT	217
SHUT OFF AUXILIARY ALARM RELAY	217
DON'T SHUT OFF TROUBLE RELAY	217

PRE-SIGNAL ALARM DELAY	206	207
SIGNAL-CIRCUIT ALARM	208	209
TROUBLE RELAY	210	211
AUXILIARY ALARM RELAY	212	213

* In 1/4-sec (quarter-seconds). For Alarm Verification, program E,2 (46) = 11.5 sec.
 **In 1/4-sec (quarter-seconds). Leave blank for 2 seconds.

CUSTOMER:	
ADDRESS:	
TELEPHONE:	
DATE INSTALLED:	
NOTES:	

MFAG000-SERIES PROGRAMMING RECORD SHEET
Communicator Transmission Information

ALARM/TROUBLE CODES	GROUP 1								GROUP 2							
	ALARM				TROUBLE				SYSTEM TROUBLE							
	ZONE								AC	WATER	SIGNAL	GN0	TELCO	VOICE	LOW	TEST
	1	2	3	4	1	2	3	4	FAIL	SUPN	TROBLE	FAIL	TROBLE	DSAGL	BAT	TIMER
Single Digit	000	002	004	006	008	010	012	014	016	018	020	022	024	026	028	030
Extended or Two Digit	001	003	005	007	009	011	013	015	017	019	021	023	025	027	029	031
RESTORE CODES																
Single Digit	040	042	044	046	048	050	052	054	056	058	060	062	064	066	068	070
Extended or Two Digit	041	043	045	047	049	051	053	055	057	059	061	063	065	067	069	071

SUBSCRIBER I.D. NUMBERS	Alarm/Restoral ID ⁽¹⁾								Test-Timer ID ⁽²⁾				Status Code
	GROUP 1				GROUP 2				108	109	110	111	
Telephone 1	100	101	102	103	104	105	106	107	108	109	110	111	038
Telephone 2	132	133	134	135	136	137	138	139	140	141	142	143	(*) 039

	Format Rcvr Data	Dial-Tone Detection	Telephone Number															
Telephone 1	112 113	114	115	116	117	118	119	120	121	122	123	124	125	126	127	128	129	
			130	131														
Telephone 2	144 145	146	147	148	149	150	151	152	153	154	155	156	157	158	159	160	161	
			162	163														

ENTRY	RECEIVER FORMAT
Blank	ADEMCO, SILENT KNIGHT "SLOW"
1	SESCOA, VERTEX, DCI, FRANKLIN ⁽²⁾
2	RADIONICS "FAST" ⁽²⁾
3	SILENT KNIGHT "FAST"
4	RADIONICS, DCI, FRANKLIN "SLOW" ⁽²⁾
5	(RESERVED)
6	(RESERVED)
7	RADIONICS BFOK ⁽²⁾
8	FOR 2300Hz HANDSHAKE, ADD AN "8" TO THIS LOCATION

ENTRY	DATA FORMAT
Blank	EXTENDED OR SINGLE DIGIT
1	SINGLE DIGIT
2	TWO DIGIT (OR 4/2)
4	SUM CHECK

NOTES:

(1) GROUP-2 CODES MUST BE ENTERED, EVEN IF THEY ARE THE SAME AS GROUP-1 CODES.

(2) MUST BE PROGRAMMED FOR TEST TIMER OPERATION.

(3) THESE FORMATS TYPICALLY USE A 2300Hz HANDSHAKE; ADD AN "8" TO THIS ENTRY.

(4) TWO-DIGIT FORMAT ONLY.