GENESYS 824 ALPHA - INSTALLER PROGRAMMING SHEET

3440-0242 OPTEX INC. Torrance, California

					1	1	1		1	1	1		1	1	1		1	1		1		1	1	1			1
	ZONE			1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
MEMORY LOCATIC		ON	00	02	04	06	08	10	12	14	16	18	20	22	24	26	28	30	32	34	36	38	4 0	42	44	46	
			Default																								
00	Zone	Type - Loop Type *1	2 2																								
00A	Loop	Response	0 5																								
00B	00B Alarm Code		0 0																								
00C	00C Trouble Code		0 0																								
00D	00D Bypass Code		0 0																								
00E	0E Restore Code		0 0																								
00F	ZONE FEATURES																										
	1	TELEPHONE	YES																								
	2	AUDIBLE	YES																								
	3	PULSE BELL	NO																								
	4	PGM 1	NO																								
	5	PGM 2	NO																								
	6	WALK TEST	YES																								
	7	MONITOR	YES																								
	8	SILENT DAY	NO																								
000	ZONE FEATURES																										
00G	-						1	1		1	r	1			1			1	r	1	1				<u> </u>	<u>т </u>	1
	1	KEYPAD 1 AUDIBLE	YES																						<u> </u>	──	
	2	KEYPAD 2 AUDIBLE	YES																						<u> </u>	<u> </u>	
	3	KEYPAD 3 AUDIBLE	YES																						<u> </u>	<u> </u>	
	4	KEYPAD 4 AUDIBLE	YES																						<u> </u>	<u> </u>	
	5	DISPLAY ARMED	YES																						<u> </u>	<u> </u>	
	6	SHUNT ALLOWED	NO																						<u> </u>	<u> </u>	
	7	BYPASS ALLOWED	YES NO																						<u> </u>		
	8	RADIO OUTPUT	NO																						L	<u> </u>	
	*	-																									
		Zone Type 0 - ENTRY - EXIT 1	Loop type 0 - NORMALLY OPEN							ARMING MODE			ENTRY/EXIT		P	PERIMETER		INTERIOR #1		INTERIOR #2			INTERIOR #3				
		1 - ENTRY - EXIT 2 1 - NORMALLY CLOSED								ARIVING WODE			1 and 2			INSTANT					INTERIOR #2						
		2 - PERIMETER INS	ST 2 - NORMALLY OPEN - NORMALLY CLOSED							AWAY			Delayed Exit			Delayed Exit		Delayed Exit			Delayed Exit			Delayed			
4 - INTERIOR 25 - INTERIOR 3		3 - INTERIOR 1 4 - INTERIOR 2	 3 - N.O SUPERVISED W/EOL - reports trouble on break, alarm on short 							STAY			Delayed Ent Delayed Exit Delayed Ent			Instant Delayed Exit		Follower or Instant Delayed Exit			Follower or Instant Bypassed			Delayed			
		5 - INTERIOR 3	4 - N.C SUPERVISED W/EOL - reports													In	Instant			Follower or Instant							
	 6 - 24 HOUR trouble on short, alarm on open 7 - FIRE 24 HOUR 						INSTANT			Instant Always		/s In	Instant Always			Instant Always			Bypassed			Delayed					
		7 - FIRE 24 HOUR 8 - DAY CIRCUIT																									