



LINE PROGRAM

Ack Tones

PROMPT	DEFAULT	LINE 1	LINE 2	LINE 3	LINE 4	LINE 5	LINE 6	LINE 7	LINE 8
<i>Tone1</i>	2300 Hz								
<i>Tone2</i>	1400 Hz								
<i>Tone3</i>	Modem II								
<i>Tone4</i>	Modem II								
<i>Tone5</i>	MDMIIe/IIIA2								
<i>Tone6</i>	Dual Tone								
<i>Tone Duration</i>	12								

Phone Supervision

PROMPT	DEFAULT	LINE 1	LINE 2	LINE 3	LINE 4	LINE 5	LINE 6	LINE 7	LINE 8
<i>Line Sniff</i>	Yes								
<i>Pulse Errors</i>	Yes								
<i>AA Ring Count</i>	0								

Line Format

PROMPT	DEFAULT	LINE 1	LINE 2	LINE 3	LINE 4	LINE 5	LINE 6	LINE 7	LINE 8
<i>5-Digit</i>	3x1 Checksum								
<i>6-Digit</i>	4x2 Dbl Rnd								
<i>8-Digit</i>	4-1 Express								

Timing Adjustments

PROMPT	DEFAULT	LINE 1	LINE 2	LINE 3	LINE 4	LINE 5	LINE 6	LINE 7	LINE 8
<i>Ack Wait</i>	40								
<i>Rnd Wait</i>	60								
<i>Modem Time</i>	60								
<i>3x1 10 Cycle</i>	Yes								
<i>Pls + %</i>	75								
<i>Pls - %</i>	75								
<i>Digit Threshold</i>	14								

Listen-In

PROMPT	DEFAULT	LINE 1	LINE 2	LINE 3	LINE 4	LINE 5	LINE 6	LINE 7	LINE 8
<i>Duration</i>	0								
<i>Low Acct Digit</i>	B								
<i>High Acct Digit</i>	F								
<i>Refresh</i>	0								

MPU PROGRAM

PROMPT

DEFAULT

ENTRY

Global

PROMPT	DEFAULT	ENTRY
<i>Receiver Number</i>	01	
<i>Armed Status</i>	No	
<i>Auto Ack</i>	Yes	
<i>Buzz In Auto</i>	Yes	
<i>Buzz Alarm</i>	No	
<i>Busy Second Rpts</i>	Yes	
<i>Call Blocking</i>	Yes	
<i>Point/User Text</i>	Yes	
<i>Time Set Enable</i>	Yes	
<i>Time Set Report</i>	Yes	
<i>Power Supv Rpts</i>	Yes	

Line Card Groups

PROMPT	DEFAULT	ENTRY
<i>Line Card 1</i>	Blank	
<i>Line Card 3</i>	Blank	
<i>Line Card 3</i>	Blank	
<i>Line Card 4</i>	Blank	
<i>Line Card 5</i>	Blank	
<i>Line Card 6</i>	Blank	
<i>Line Card 7</i>	Blank	
<i>Line Card 8</i>	Blank	

Line Card Supervision

PROMPT	DEFAULT	ENTRY
<i>Line Card 1</i>	Yes	
<i>Line Card 1</i>	Yes	
<i>Line Card 2</i>	Yes	
<i>Line Card 3</i>	Yes	
<i>Line Card 4</i>	Yes	
<i>Line Card 5</i>	Yes	
<i>Line Card 6</i>	Yes	
<i>Line Card 7</i>	Yes	
<i>Line Card 8</i>	Yes	

PROMPT

DEFAULT

ENTRY

Internal Printer

PROMPT	DEFAULT	ENTRY
<i>Device</i>	Primary	
<i>Supervision</i>	Yes	

External Printer

PROMPT	DEFAULT	ENTRY
<i>Device</i>	Always Off	
<i>Supervision</i>	Yes	
<i>XON/XOFF</i>	Yes	
<i>CR/LF</i>	Yes	
<i>Parity</i>	No	
<i>Baud Rate</i>	1200	
<i>Data Bits</i>	Eight	

Automation Config

PROMPT	DEFAULT	ENTRY
<i>Output Format</i>	6500	
<i>Device</i>	Always Off	
<i>Supervision</i>	Yes	
<i>Group Reporting</i>	Yes	
<i>BFSK Fire Bit</i>	No	
<i>Modem Ille Fire</i>	Yes	
<i>SIA Fire Reset</i>	No	
<i>Comp Config</i>	7,P,2	
<i>Comp Parity</i>	Odd	
<i>Baud Rate</i>	1200	
<i>Handshake</i>	Ack	
<i>Ack Character</i>	06	
<i>Nack Character</i>	15	
<i>Trailer Char</i>	14	
<i>Automation Wait</i>	7	
<i>6500 Header Char</i>	Blank	
<i>Input Commands</i>	No	
<i>Link Test</i>	No	
<i>Packet Sep. (/)</i>	No	
<i>Sub Subscriber</i>	No	



Radionics™

Radionics, Inc., 1800 Abbott Street
P.O. Box 80012 Salinas, California 93912
Customer Service: (800) 538-5807

© 1997 Radionics, Inc., Salinas, CA, USA. All rights reserved
™The Radionics logo is a registered trademark of Radionics, Inc., Salinas, CA, USA.